



E Show Commands

- [show eemtest internal eem-state](#), on page 3
- [show email](#), on page 4
- [show encryption service stat](#), on page 5
- [show environment](#), on page 6
- [show eol status](#), on page 11
- [show errdisable detect](#), on page 12
- [show errdisable flap](#), on page 13
- [show evb](#), on page 14
- [show evb hosts](#), on page 15
- [show evb interface](#), on page 17
- [show evb internal event-history](#), on page 18
- [show evb internal mem-stats](#), on page 19
- [show evb internal state](#), on page 20
- [show evb vsi](#), on page 21
- [show event-history](#), on page 23
- [show event-history xbar](#), on page 24
- [show event manager environment](#), on page 25
- [show event manager event-types](#), on page 26
- [show event manager events action-log](#), on page 27
- [show event manager history events](#), on page 28
- [show event manager internal clients](#), on page 29
- [show event manager internal evmc debug counters](#), on page 30
- [show event manager internal evmc errors](#), on page 31
- [show event manager internal evmc mem-stats](#), on page 32
- [show event manager internal evmc msgs](#), on page 33
- [show event manager internal evmed errors](#), on page 34
- [show event manager internal evmed msgs](#), on page 35
- [show event manager internal evms debug counters](#), on page 36
- [show event manager internal evms errors](#), on page 37
- [show event manager internal evms mem-stats](#), on page 38
- [show event manager internal evms msgs](#), on page 39
- [show event manager internal mvsh mem-stats](#), on page 40
- [show event manager internal publisher sap](#), on page 41

- [show event manager policy-state](#), on page 42
- [show event manager policy internal](#), on page 43
- [show event manager script system](#), on page 44
- [show event manager system-policy](#), on page 45

show eemtest internal eem-state

show eemtest internal eem-state

Syntax Description

Syntax Description	
show	Show commands
eemtest	EEM test publisher commands
internal	EEM test publisher internal commands
eem-state	Show the EEM state in the test publisher

Command Mode

- /exec

show email

```
show email [ __readonly__ [ <ipv4> ] [ <ipv6> ] [ <host> ] [ <port> ] [ <reply> ] [ <from> ] [ <vrfname> ] ]
```

Syntax Description

Syntax Description		
show	Show running system information	
email	Pipe email configuration	
<i>__readonly__</i>	(Optional)	
<i>ipv4</i>	(Optional)	
<i>host</i>	(Optional)	
<i>port</i>	(Optional)	
<i>reply</i>	(Optional)	
<i>from</i>	(Optional)	
<i>vrfname</i>	(Optional)	

Command Mode

- /exec

show encryption service stat

```
show encryption service stat [ __readonly__ [ <encryptionService> <MasterKeyEncryption>
<Type6Encryption> ] ]
```

Syntax Description

Syntax Description		
show		Show running system information
encryption		Encryption service
service		Encryption service
stat		Encryptpin service status
__readonly__		(Optional)
<i>encryptionService</i>	(Optional)	Encryption service status
<i>MasterKeyEncryption</i>	(Optional)	Master key status
<i>Type6Encryption</i>	(Optional)	Is type 6 encryption used?

Command Mode

- /exec

show environment

```
show environment [ fan [ detail1 ] | power [ detail ] [ ampere ] [ input ] | temperature [ module <module> |
<s0> <santa-cruz-range> | psu ] ] [ __readonly__ { TABLE_clockinfo <clockname> <clkmodel> <clkhwver>
<clkstatus> <act_standby> } { fandetails <fan_filter_status> { TABLE_faninfo <fanname> <fanmodel>
<fanhwver> <fandir> <fanstatus> <failfanlet> } { TABLE_fan_zone_speed <zone> <speed> } {
TABLE_fantray <fanname> <fanname> <fanname> <fanperc> <fanrpm> } { TABLE_psufan <fanname>
<fan1rpm> <fan2rpm> } } { powersup <voltage_level> { TABLE_psinfo <psnum> <psmodel> <actual_out>
<actual_input> <tot_capa> <ps_status> } { TABLE_mod_pow_info <modnum> <mod_model> <actual_draw>
<allocated> <modstatus> } { power_summary <ps_redun_mode> <ps_oper_mode> <tot_pow_capacity>
<tot_gridA_capacity> <tot_gridB_capacity> <cumulative_power> <tot_pow_out_actual_draw>
<tot_pow_input_actual_draw> <tot_pow_alloc_budgeted> <available_pow> } { powersup_detail <reserve_sup>
<reserve_xbar> <reserve_fan> <reserve_supxbarfan> <pow_used_by_mods> } { TABLE_psinfo_n3k <psnum>
<psmodel> <input_type> <watts> <amps> <ps_status> } { TABLE_mod_pow_info_n3k <modnum>
<mod_model> <watts_requested> <amps_requested> <watts_allocated> <amps_allocated> <modstatus> } {
TABLE_psinputinfo_n3k <ps_slot> <ps_input_voltage> <ps_input_current> <ps_in_power>
<ps_output_voltage> <ps_output_current> <ps_state> } { power_summary_n3k <ps_redun_mode>
<ps_redun_op_mode> <tot_pow_capacity> <reserve_sup> <pow_used_by_mods> <available_pow> } } {
TABLE_tempinfo <tempmod> <sensor> <majthres> <minthres> <curtemp> <alarmstatus> } {
TABLE_psutempinfo <psumod> <inlet_temp> <outlet_temp> <heatsink_temp> } ]
```

Syntax Description

Syntax Description

show	Show running system information
environment	system environment information
fan	(Optional) Fan information
power	(Optional) Power capacity and power distribution information
detail	(Optional) Detail Fan-tray information when used with Fan. Detail Power capacity and power distribution information when used with Power
detail1	(Optional) Detail Fan-tray information when used with Fan
ampere	(Optional) Ampere Power capacity and power distribution information
input	(Optional) Power supply power input
temperature	(Optional) temperature sensor information
module	(Optional) enter a module number
<i>module</i>	(Optional) please enter the module number
<i>s0</i>	(Optional) xbar
<i>santa-cruz-range</i>	(Optional) please enter the xbar number
psu	(Optional) psu temperature
__readonly__	(Optional)

TABLE_clockinfo	(Optional) Environment Clock
<i>clockname</i>	(Optional) Clock Instance (A or B)
<i>clkmodel</i>	(Optional) Model number of clock
<i>clkhwver</i>	(Optional) Hardware version of the clock
<i>clkstatus</i>	(Optional) Present/Absent Status of the clock
<i>act_standby</i>	(Optional) Active/Standby Status of clock
fanetails	(Optional) Environment Fan
<i>fan_filter_status</i>	(Optional) Present/Absent Status of fan filter
TABLE_faninfo	(Optional) Fan Info
<i>fanname</i>	(Optional) Fan Instance
<i>fanmodel</i>	(Optional) Model number of fan
<i>fanhwver</i>	(Optional) Hardware version of the fan
<i>fandir</i>	(Optional) Air-flow direction of the fan-tray
<i>fanstatus</i>	(Optional) Present/Absent Status of the fan
TABLE_fan_zone_speed	(Optional) Fan Zone Speeds
<i>zone</i>	(Optional) Zone Number
<i>speed</i>	(Optional) Zone Speed
<i>failfanlet</i>	(Optional) failed fanlet number
TABLE_fantray	(Optional) Fan Tray Details table
<i>fanname</i>	(Optional) Fan Tray Instance
<i>fannum</i>	(Optional) Fan number in the tray
<i>fandir</i>	(Optional) Air-flow direction of the fan-tray
<i>fanperc</i>	(Optional) FAN Speed percentage
<i>fanrpm</i>	(Optional) FAN Speed RPM
TABLE_psufan	(Optional) PSU Fan Details table
<i>fanname</i>	(Optional) PSU Fan Instance
<i>fan1rpm</i>	(Optional) FAN1 Speed RPM
<i>fan2rpm</i>	(Optional) FAN2 Speed RPM
powersup	(Optional) Environment Power

<i>voltage_level</i>	(Optional) Voltage Level
TABLE_psinfo	(Optional) Power Supply Info
<i>psnum</i>	(Optional) Power Supply Number
<i>psmodel</i>	(Optional) Power Supply Model
<i>actual_out</i>	(Optional) Actual Output
<i>actual_input</i>	(Optional) Actual Input
<i>tot_capa</i>	(Optional) Total Capacity
<i>ps_status</i>	(Optional) Power Supply Status
TABLE_mod_pow_info	(Optional) Module Power Info
<i>modnum</i>	(Optional) Module number
<i>mod_model</i>	(Optional) Model ProductID number
<i>actual_draw</i>	(Optional) Actual Draw
<i>allocated</i>	(Optional) Power allocated
<i>modstatus</i>	(Optional) Module Status
power_summary	(Optional) Power Usage Summary
<i>ps_redun_mode</i>	(Optional) Mode: Redundant or Non-redundant
<i>ps_oper_mode</i>	(Optional) Operational Mode
<i>tot_pow_capacity</i>	(Optional) Total Power Capacity
<i>tot_gridA_capacity</i>	(Optional) Total Grid-A Capacity
<i>tot_gridB_capacity</i>	(Optional) Total Grid-B Capacity
<i>cumulative_power</i>	(Optional) Total Power of all Inputs
<i>tot_pow_out_actual_draw</i>	(Optional) Total Power Output, Actuals
<i>tot_pow_input_actual_draw</i>	(Optional) Total Power Input, Actuals
<i>tot_pow_alloc_budgeted</i>	(Optional) Total Power Allocated/budgeted
<i>available_pow</i>	(Optional) Remaining Power Available
powersup_detail	(Optional) PowerSupply Details
<i>reserve_sup</i>	(Optional) Power reserved for Supervisors
<i>reserve_xbar</i>	(Optional) Power reserved for Xbars
<i>reserve_fan</i>	(Optional) Power reserved for Fans

<i>reserve_supxbarfan</i>	(Optional) Total Power reserved for Sups,Xbars,Fans
<i>pow_used_by_mods</i>	(Optional) Power currently used by Modules
TABLE_tempinfo	(Optional) Environment Temperature
<i>tempmod</i>	(Optional) Module
<i>sensor</i>	(Optional) Sensor name
<i>majthres</i>	(Optional) Major Threshold
<i>minthres</i>	(Optional) Minor Threshold
<i>curtemp</i>	(Optional) Current temperature
<i>alarmstatus</i>	(Optional) Alarm Status
TABLE_psutempinfo	(Optional) PSU temperature info table
<i>psumod</i>	(Optional) PSU Module
<i>inlet_temp</i>	(Optional) Inlet Temperature
<i>outlet_temp</i>	(Optional) Outlet Temperature
<i>heatsink_temp</i>	(Optional) Heatsink Temperature
TABLE_psinfo_n3k	(Optional) Power Supply Info
<i>psnum</i>	(Optional) Power Supply Number
<i>psmodel</i>	(Optional) Power Supply Model
<i>input_type</i>	(Optional) Power Supply Input Type
<i>watts</i>	(Optional) Power in Watts
<i>amps</i>	(Optional) Power in Amps
<i>ps_status</i>	(Optional) Power Supply Status
TABLE_mod_pow_info_n3k	(Optional) Module Power Info
<i>modnum</i>	(Optional) Module number
<i>mod_model</i>	(Optional) Model ProductID number
<i>watts_requested</i>	(Optional) Power requested in Watts
<i>amps_requested</i>	(Optional) Power requested in Amps
<i>watts_allocated</i>	(Optional) Power allocated in Watts
<i>amps_allocated</i>	(Optional) Power allocated in Amps
<i>modstatus</i>	(Optional) Module Status

<i>TABLE_psinputinfo_n3k</i>	(Optional) Power Supply power input
<i>ps_slot</i>	(Optional) Power Supply Number
<i>ps_input_voltage</i>	(Optional) Power Supply input volatage
<i>ps_input_current</i>	(Optional) Power Supply input current
<i>ps_in_power</i>	(Optional) Power Supply input power
<i>ps_output_voltage</i>	(Optional) Power Supply output volatage
<i>ps_output_current</i>	(Optional) Power Supply output current
<i>ps_state</i>	(Optional) Power Supply status
<i>power_summary_n3k</i>	(Optional) Power Usage Summary
<i>ps_redun_mode</i>	(Optional) Mode: Redundant or Non-redundant
<i>ps_redun_op_mode</i>	(Optional) Operational mode: Redundant or Non-redundant
<i>tot_pow_capacity</i>	(Optional) Total Power Capacity
<i>reserve_sup</i>	(Optional) Power reserved for Supervisors
<i>pow_used_by_mods</i>	(Optional) Power currently used by Modules
<i>available_pow</i>	(Optional) Total Power Available

Command Mode

- /exec

show eol status

show eol status

Syntax Description

Syntax Description	show Show running system information
---------------------------	--------------------------------------

eol last

status

Command Mode

- /exec

show errdisable detect

```
show errdisable { detect | recovery } [ __readonly__ TABLE_errdisable <cause> <state> [ <time_interval> ] ]
```

Syntax Description

Syntax Description		
show	Show running system information	
errdisable	Error disable	
detect	Show errdisable detect	
recovery	Show errdisable recovery	
__readonly__	(Optional) Read Only	
TABLE_errdisable	(Optional) show errdisable	
cause	(Optional) errdisable cause	
state	(Optional) Interface state	
time_interval	(Optional) err recovery time interval	

Command Mode

- /exec

show errdisable flap

show errdisable flap

Syntax Description

Syntax	Description
show	Show running system information
errdisable	Error disable
flap	linkstate flapping

Command Mode

- /exec

show evb

```
show evb [ __readonly__ <evb_role> <evb_vdp_mac> [ <evb_cisco_mac> ] [ <evb_user_mac> ] <evb_rwd>
<evb_rka> <evb_cnt_rcv_vdpdu> <evb_cnt_drop_vdpdu> <evb_cnt_rcv_tlv> <evb_cnt_rcv_mgr_tlv>
<evb_cnt_rcv_assoc_tlv> <evb_cnt_rcv_cmd> ]
```

Syntax Description

Syntax Description	show	Show running system information
	evb	EVB (Edge Virtual Bridge)
	__readonly__	(Optional)
	evb_role	(Optional) EVB role
	evb_vdp_mac	(Optional) VDP Mac address
	evb_cisco_mac	(Optional) Cisco Mac address
	evb_user_mac	(Optional) User mac address
	evb_rwd	(Optional) Resource wait init exponent
	evb_rka	(Optional) Keep-alive init exponent
	evb_cnt_rcv_vdpdu	(Optional) No. received vdpdu
	evb_cnt_drop_vdpdu	(Optional) No. dropped vdpdu
	evb_cnt_rcv_tlv	(Optional) No. received tlv
	evb_cnt_rcv_mgr_tlv	(Optional) No. received mgr tlv
	evb_cnt_rcv_assoc_tlv	(Optional) No. received assoc tlv
	evb_cnt_rcv_cmd	(Optional) No. received commands

Command Mode

- /exec

show evb hosts

```
show evb hosts [ { summary | detail | internal-info } ] [ { [ mac <mac-addr> | interface <intf-name> | vlan
<vlan-id> | vni <vni-id> | ip <ip-addr> | ipv6 <ipv6-addr> | name <host-name> ] + } ] [ __readonly__
<evb_cnt_host> <evb_cnt_assoc_vsi> [ { TABLE_evb_host <host_row_id> <host_name> [ <host_uuid> ] [
{ TABLE_evb_vsi <vsi_row_id> <mgr_id> <vsi_id> [ <vsi_host_name> ] <interface> [ <vpc> ] [ <s_channel>
] [ <station_mac> ] [ <m_state> ] [ <e_state> ] [ <reason> ] [ <timer> ] [ <profile_id> ] [ {
TABLE_evb_vsi_filter <filter_row_id> [ <filter_group> ] [ <filter_vid> ] [ <filter_bd> ] [ <filter_mac> ] [
<filter_ip> ] } } ] } ] }
```

Syntax Description

Syntax Description	
show	Show running system information
evb	EVB (Edge Virtual Bridge)
hosts	Host information
summary	(Optional) Display summary information
detail	(Optional) Display detailed information
internal-info	(Optional) Display detailed and internal information
mac	(Optional) Display hosts by MAC address
<i>mac-addr</i>	(Optional) MAC Address
interface	(Optional) Display hosts by interface
<i>intf-name</i>	(Optional) Interface name
vlan	(Optional) Display hosts by VLAN
<i>vlan-id</i>	(Optional) VLAN ID
vni	(Optional) Display hosts by Virtual Network Identifier
<i>vni-id</i>	(Optional) VNI
ip	(Optional) Display hosts by IP address
ipv6	(Optional) Display hosts by IPv6 address
<i>ip-addr</i>	(Optional) IP address
name	(Optional) Display hosts by host name
<i>host-name</i>	(Optional) Host name substring
<i>__readonly__</i>	(Optional)
<i>evb_cnt_host</i>	(Optional) No. host entries

<i>evb_cnt_assoc_vsi</i>	(Optional) No. associated VSI entires
TABLE_evb_host	(Optional) EVB host table
<i>host_row_id</i>	(Optional) Host row id
<i>host_name</i>	(Optional) Host name
<i>host_uuid</i>	(Optional) Host uuid
TABLE_evb_vsi	(Optional) EVB vsi table
<i>vsi_row_id</i>	(Optional) VSI row id
<i>mgr_id</i>	(Optional) Manager id
<i>vsi_id</i>	(Optional) VSI id
<i>vsi_host_name</i>	(Optional) Host name
<i>interface</i>	(Optional) Interface
<i>vpc</i>	(Optional) VPC
<i>s_channel</i>	(Optional) S-Channel
<i>station_mac</i>	(Optional) Station mac address
<i>profile_id</i>	(Optional) Profile id
<i>m_state</i>	(Optional) Machine state
<i>e_state</i>	(Optional) Entry state
<i>reason</i>	(Optional) State reaon
<i>timer</i>	(Optional) Countdown timer
TABLE_evb_vsi_filter	(Optional) EVB filter table
<i>filter_row_id</i>	(Optional) Filter row id
<i>filter_group</i>	(Optional) Group id
<i>filter_vid</i>	(Optional) Vlan id
<i>filter_bd</i>	(Optional) Bridge-domain id
<i>filter_mac</i>	(Optional) Mac address
<i>filter_ip</i>	(Optional) IP address

Command Mode

- /exec

show evb interface

```
show evb interface [ <intf-name> ]
```

Syntax Description

Syntax Description	show	Show running system information
	evb	EVB (Edge Virtual Bridge)
	interface	Display interface information
	<i>intf-name</i>	(Optional) Interface name

Command Mode

- /exec

show evb internal event-history

show evb internal event-history { <evt-hist-subsystem> | msgs }

Syntax Description

Syntax Description		
show		Show running system information
evb		EVB (Edge Virtual Bridge)
internal		Show EVB internal information
event-history		Show EVB event history buffers
msgs		EVB various message logs
<i>evt-hist-subsystem</i>		EVB event history buffers

Command Mode

- /exec

show evb internal mem-stats

show evb internal mem-stats [all] [detail]

Syntax Description

Syntax Description	
show	Show running system information
evb	EVB (Edge Virtual Bridge)
internal	Internal information
mem-stats	Dynamic memory stats
all	(Optional) Display private and shared memory statistics
detail	(Optional) Detailed information

Command Mode

- /exec

show evb internal state

show evb internal state

Syntax Description

Syntax Description	
show	Show running system information
evb	EVB (Edge Virtual Bridge)
internal	Internal information
state	Internal state maintained by EVB

Command Mode

- /exec

show evb vsi

```
show evb vsi [ { summary | detail | internal-info } ] [ { [ mac <mac-addr> | interface <intf-name> | vlan
<vlan-id> | vni <vni-id> | ip <ip-addr> | ipv6 <ipv6-addr> ] + } ] [ __readonly__ <evb_cnt_vsi>
<evb_cnt_assoc_vsi> [ { TABLE_evb_vsi <vsi_row_id> <mgr_id> <vsi_id> [ <vsi_host_name> ] <interface>
[ <vpc> ] [ <s_channel> ] [ <station_mac> ] [ <m_state> ] [ <e_state> ] [ <reason> ] [ <timer> ] [ <profile_id>
] [ { TABLE_evb_vsi_filter <filter_row_id> [ <filter_group> ] [ <filter_vid> ] [ <filter_bd> ] [ <filter_mac>
] [ <filter_ip> ] } } ] ] ]
```

Syntax Description

Syntax Description

show	Show running system information
evb	EVB (Edge Virtual Bridge)
vsi	Virtual Station Interface (VSI) information
summary	(Optional) Display summary information
detail	(Optional) Display detailed information
internal-info	(Optional) Display detailed and internal information
mac	(Optional) Display VSI by MAC address
<i>mac-addr</i>	(Optional) MAC Address
interface	(Optional) Display VSI by interface
<i>intf-name</i>	(Optional) Interface name
vlan	(Optional) Display VSI by VLAN
<i>vlan-id</i>	(Optional) VLAN ID
vni	(Optional) Display VSI by Virtual Network Identifier
<i>vni-id</i>	(Optional) VNI
ip	(Optional) Display VSI by IP address
ipv6	(Optional) Display VSI by IPv6 address
<i>ip-addr</i>	(Optional) IP address
<i>__readonly__</i>	(Optional)
<i>evb_cnt_vsi</i>	(Optional) No. VSI entries
<i>evb_cnt_assoc_vsi</i>	(Optional) No. associated VSI entries
TABLE_evb_vsi	(Optional) EVB vsi table
<i>vsi_row_id</i>	(Optional) VSI row id

<i>mgr_id</i>	(Optional) Manager id
<i>vsi_id</i>	(Optional) VSI id
<i>vsi_host_name</i>	(Optional) Host name
<i>interface</i>	(Optional) Interface
<i>vpc</i>	(Optional) VPC
<i>s_channel</i>	(Optional) S-Channel
<i>station_mac</i>	(Optional) Station mac address
<i>profile_id</i>	(Optional) Profile id
<i>m_state</i>	(Optional) Machine state
<i>e_state</i>	(Optional) Entry state
<i>reason</i>	(Optional) State reaon
<i>timer</i>	(Optional) Countdown timer
TABLE_evb_vsi_filter	(Optional) EVB filter table
<i>filter_row_id</i>	(Optional) Filter row id
<i>filter_group</i>	(Optional) Group id
<i>filter_vid</i>	(Optional) Vlan id
<i>filter_bd</i>	(Optional) Bridge-domain id
<i>filter_mac</i>	(Optional) Mac address
<i>filter_ip</i>	(Optional) IP address

Command Mode

- /exec

show event-history

show event-history

Syntax Description

Syntax Description	
show	Show running system information
event-history	show switch wide event history configuration

Command Mode

- /exec

show event-history xbar

show event-history xbar

Syntax Description

Syntax Description

show	Show running system information
event-history	show switch wide event history configuration
xbar	Show all event-history debugging flags of xbar

Command Mode

- /exec

show event manager environment

```
show event manager environment { all | <varname> } [ __readonly__ <environment-details> ]
```

Syntax Description

Syntax Description		
show		Show running system information
event		Event Manager commands
manager		Event Manager commands
environment		Show information about environment variables
all		Show information about all the configured environment variables
<i>varname</i>		The environment variable name on which information is required
__readonly__		(Optional)
<i>environment-details</i>		(Optional)

Command Mode

- /exec

show event manager event-types

```
show event manager event-types [ all | <event-type-name> ] [ module <module-id> ] [ __readonly__ {
<event-types> } ]
```

Syntax Description

Syntax Description		
show		Show running system information
event		Event Manager commands
manager		Event Manager commands
event-types		Show information about registered event types
all		(Optional) Show information about advanced event types as well
<i>event-type-name</i>		(Optional) Show information about the specified event type
module		(Optional) Show information about event types on other modules
<i>module-id</i>		(Optional)
__readonly__		(Optional)
<i>event-types</i>		(Optional)

Command Mode

- /exec

show event manager events action-log

show event manager events action-log [policy <policy-name> | event-type <event-type-name>]

Syntax Description

Syntax Description		
show		Show running system information
event		Event Manager commands
manager		Event Manager commands
events		Show information about the history of past events
action-log		Show policy action logs
policy		(Optional) Name of policy
<i>policy-name</i>		(Optional) Enter policy name
event-type		(Optional) Name of event
<i>event-type-name</i>		(Optional) Enter event type

Command Mode

- /exec

show event manager history events

```
show event manager history events [ detail ] [ maximum <n-events> ] [ severity <sev> ] [ __readonly__ {
<history-events> } ]
```

Syntax Description

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
history	Show information about the history of past activity
events	Show information about the history of past events
detail	(Optional) Show information about the event parameters as well
maximum	(Optional) Specify an upper limit on the number of events to be shown
<i>n-events</i>	(Optional) Specify the maximum number of events to be shown
severity	(Optional) Show only those events whose severity is \geq specified severity
<i>sev</i>	(Optional) Enter the severity threshold
<i>__readonly__</i>	(Optional)
<i>history-events</i>	(Optional)

Command Mode

- /exec

show event manager internal clients

show event manager internal clients [all] [module <module-id>]

Syntax Description

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
internal	Internal event manager commands
clients	Show information about clients registered with EEM system
all	(Optional) Show information about advanced clients as well
module	(Optional) Show information about services on other modules
<i>module-id</i>	(Optional)

Command Mode

- /exec

show event manager internal evmc debug counters

show event manager internal evmc debug counters

Syntax Description

Syntax Description	
show	Show running system information
event	Event Manager commands
manager	Event Manager commands
internal	Commands for internal use
evmc	Event Manager Client commands
debug	Show debug information
counters	Show information about the debug counters

Command Mode

- /exec

show event manager internal evmc errors

show event manager internal evmc errors

Syntax Description

Syntax Description		
show	Show running system information	
event	Event Manager commands	
manager	Event Manager commands	
internal	Commands for internal use	
evmc	Event Manager Client commands	
errors	Show error logs	

Command Mode

- /exec

show event manager internal evmc mem-stats

show event manager internal evmc mem-stats [detail]

Syntax Description

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
internal	Commands for internal use
evmc	Event Manager Client commands
mem-stats	Show information about memory allocation statistics
detail	(Optional) Show detailed information about memory allocation statistics

Command Mode

- /exec

show event manager internal evmc msgs

show event manager internal evmc msgs

Syntax Description

Syntax Description		
show	Show running system information	
event	Event Manager commands	
manager	Event Manager commands	
internal	Commands for internal use	
evmc	Event Manager Client commands	
msgs	Show message logs	

Command Mode

- /exec

show event manager internal evmed errors

show event manager internal evmed errors

Syntax Description

Syntax Description	
show	Show running system information
event	Event Manager commands
manager	Event Manager commands
internal	Internal event manager commands
evmed	Generic event publisher
errors	Show error logs

Command Mode

- /exec

show event manager internal evmed msgs

show event manager internal evmed msgs

Syntax Description

Syntax Description	
show	Show running system information
event	Event Manager commands
manager	Event Manager commands
internal	Internal event manager event publisher commands
evmed	Generic event publiser
msgs	Show message logs

Command Mode

- /exec

show event manager internal evms debug counters

show event manager internal evms debug counters

Syntax Description

Syntax Description	
show	Show running system information
event	Event Manager commands
manager	Event Manager commands
internal	Internal event manager commands
evms	Event Manager Server commands
debug	Show debug information
counters	Show information about the debug counters

Command Mode

- /exec

show event manager internal evms errors

show event manager internal evms errors

Syntax Description

Syntax Description		
show	Show running system information	
event	Event Manager commands	
manager	Event Manager commands	
internal	Internal event manager commands	
evms	Event Manager Server commands	
errors	Show error logs	

Command Mode

- /exec

show event manager internal evms mem-stats

show event manager internal evms mem-stats [detail]

Syntax Description

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
internal	Internal event manager commands
evms	Event Manager Server commands
mem-stats	Show information about memory allocation statistics
detail	(Optional) Show detailed information about memory allocation statistics

Command Mode

- /exec

show event manager internal evms msgs

show event manager internal evms msgs

Syntax Description

Syntax Description		
show	Show running system information	
event	Event Manager commands	
manager	Event Manager commands	
internal	Internal event manager commands	
evms	Event Manager Server commands	
msgs	Show message logs	

Command Mode

- /exec

show event manager internal mvsh mem-stats

show event manager internal mvsh mem-stats [detail]

Syntax Description

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
internal	Commands for internal use
mvsh	MVSH commands
mem-stats	Show information about memory allocation statistics
detail	(Optional) Show detailed information about memory allocation statistics

Command Mode

- /exec

show event manager internal publisher sap

show event manager internal publisher sap <sapnum> [module <module-id>]

Syntax Description

Syntax Description	
show	Show running system information
event	Event Manager commands
manager	Event Manager commands
internal	Internal event manager commands
publisher	Show information about the EEM state in a publisher
sap	Enter the SAP of the publisher
<i>sapnum</i>	The SAP of the publisher
module	(Optional) Show information about a publisher on other module
<i>module-id</i>	(Optional)

Command Mode

- /exec

show event manager policy-state

```
show event manager policy-state <name> [ module <module-id> ] [ __readonly__ { <policy-state> } ]
```

Syntax Description

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
policy-state	Show information about the state of a policy
<i>name</i>	Name of the policy
module	(Optional) Get the information from a module
<i>module-id</i>	(Optional)
<i>__readonly__</i>	(Optional)
<i>policy-state</i>	(Optional)

Command Mode

- /exec

show event manager policy internal

show event manager policy internal [<policy-name> | inactive]

Syntax Description

Syntax Description		
show		Show running system information
event		Event Manager commands
manager		Event Manager commands
policy		Show information about applets or script policies
internal		Show detailed information about the configured/registered policies
inactive		(Optional) List the policies that are not active in the system
<i>policy-name</i>		(Optional) Show detailed information about the specified policy

Command Mode

- /exec

show event manager script system

```
show event manager script system { all | <script-name> } [ __readonly__ <script_system_details> ]
```

Syntax Description

Syntax Description		
show		Show running system information
event		Event Manager commands
manager		Event Manager commands
script		Show information about a script policy
system		Show information about a system script policy
all		Show all the available system script policies
<i>script-name</i>		Name of the system script policy
<i>__readonly__</i>		(Optional)
<i>script_system_details</i>		(Optional)

Command Mode

- /exec

show event manager system-policy

```
show event manager system-policy [ all | <policy-name> ] [ __readonly__ { <sys-pol-details> } ]
```

Syntax Description

Syntax Description		
show	Show running system information	
event	Event Manager commands	
manager	Event Manager commands	
system-policy	Show information about default system policies	
all	(Optional) Show all policies (including advanced and non-overridable ones)	
<i>policy-name</i>	(Optional) Show detailed information about the specified policy	
<i>__readonly__</i>	(Optional)	
<i>sys-pol-details</i>	(Optional)	

Command Mode

- /exec

show event manager system-policy