



Converting from Cisco NX-OS to ACI Boot Mode and from ACI Boot Mode Back to Cisco NX-OS

This chapter describes how to convert a Cisco Nexus 9000 Series switch from Cisco NX-OS to Cisco Application Centric Infrastructure (ACI) boot mode. It contains the following sections:

- [Converting to ACI Boot Mode, on page 1](#)
- [Converting a Replacement Standby Supervisor to ACI Boot Mode, on page 3](#)
- [Converting Back to Cisco NX-OS, on page 4](#)

Converting to ACI Boot Mode

You can convert any Cisco Nexus 9000 Series switch from Cisco NX-OS to ACI boot mode.



Note You cannot convert a Cisco Nexus 3164Q or 31128PQ switch to ACI boot mode.



Note Use this procedure to convert a Cisco Nexus 9000 Series switch running Cisco NX-OS Release 7.0(3)I1(2) or later to ACI boot mode.

Before you begin

Verify whether your switch hardware is supported in ACI boot mode by checking the "Supported Hardware" section of the [Release Notes for Cisco Nexus 9000 Series ACI-Mode Switches](#). For example, line cards are not compatible between Cisco NX-OS and ACI boot mode.

Remove or turn off any unsupported modules (using the **poweroff module** *module* command). Otherwise, the software uses a recovery/retry mechanism before powering down the unsupported modules, which can cause delays in the conversion process.

For dual-supervisor systems, use the **show module** command to make sure that the standby supervisor module is in the ha-standby state.

Verify that the Application Policy Infrastructure Controller (APIC) is running Release 1.0(2j) or a later release.

Make sure that the ACI image is 11.0(2x) or a later release.

Use the **show install all impact epld** *epld-image-name* command to verify that the switch does not require any EPLD image upgrades. If any upgrades are required, follow the instructions in the [Cisco Nexus 9000 Series FPGA/EPLD Upgrade Release Notes](#).

Step 1 Verify that the switch is running Cisco NX-OS Release 7.0(3)I1(2) or a later release.

Example:

```
switch(config)# show version
Software
BIOS: version 07.34
NXOS: version 7.0(3)I2(1)
BIOS compile time: 08/11/2015
NXOS image file name is: bootflash:///nxos.7.0.3.I1.2.bin
NXOS compile time: 08/13/2015 10:50:20 [08/13/2015 2:25]
```

Cisco NX-OS filenames begin with "nxos" [beginning with Cisco NX-OS Release 7.0(3)I2(1)] or "n9000" while ACI filenames begin with "aci-n9000."

Step 2 Follow these steps to copy the ACI image from the APIC:

- a) Set the IP address on the mgmt0 interface of the switch to allow connectivity between this interface and the APIC.
- b) Enable SCP services on the switch.

Example:

```
switch(config)# feature scp-server
```

- c) From the APIC CLI, use SCP to copy the firmware image from the APIC to the active supervisor module on the switch.

Example:

```
admin@apic1:aci> scp -r /firmware/fwrepos/fwrepo/switch-image-name
admin@switch-ip-address:switch-image-name
```

- d) For dual-supervisor systems, copy the ACI image to the standby supervisor module.

Example:

```
switch(config)# copy bootflash:aci-image bootflash://sup-standby/
```

Step 3 Follow these steps to boot to the ACI image:

- a) Configure the switch to not boot from Cisco NX-OS.

Example:

```
switch(config)# no boot nxos
```

- b) Save the configuration.

Example:

```
switch(config)# copy running-config startup-config
```

Note You must run the **copy running-config startup-config** command prior to booting the ACI image. Do not run it after you enter the **boot aci** command.

- c) Boot the active and standby supervisor modules with the ACI image.

Example:

```
switch(config)# boot aci bootflash:aci-image-name
```

Caution Do not enter the **copy running-config startup-config** command after the **boot aci** command. If you do, the switch will go to the loader> prompt.

- d) Verify the integrity of the file by displaying the MD5 checksum.

Example:

```
switch(config)# show file bootflash:aci-image-name md5sum
```

- e) Reload the switch.

Example:

```
switch(config)# reload
```

- f) Log in to the switch as an administrator.

Example:

```
Login: admin
```

Step 4 Verify whether you must install certificates for your device.

Example:

```
admin@apic1:aci> openssl asn1parse -in /securedata/ssl/server.crt
```

Look for PRINTABLESTRING in the command output. If "Cisco Manufacturing CA" is listed, the correct certificates are installed. If something else is listed, contact TAC to generate and install the correct certificates for your device.

Note You might need to install certificates for Cisco Nexus 9000 Series switches that were shipped prior to May 2014.

To run this command, contact TAC.

What to do next

See the ACI and APIC documentation to configure and operate your switch in ACI mode: <http://www.cisco.com/c/en/us/support/cloud-systems-management/application-policy-infrastructure-controller-apic/tsd-products-support-series-home.html>.

Converting a Replacement Standby Supervisor to ACI Boot Mode

If you ever need to replace the standby supervisor module in a dual-supervisor system, you will need to copy and boot the ACI image for use with the replacement standby supervisor.

Before you begin

Copy the ACI image to a USB drive.

Step 1 Reload the switch.

Example:

```
switch# reload
```

Step 2 Enter a break sequence (Ctrl-C or Ctrl-]) during the initial boot sequence to access the loader> prompt.

Example:

```
Ctrl-C  
loader>
```

Step 3 Plug the USB drive containing the ACI image into the standby supervisor USB slot.

Step 4 Boot the ACI image.

Example:

```
loader> boot usb#:aci-image-name
```

Note If you have two USB drives, enter the **dir** command to see which drive contains the ACI image. Then specify either **usb1** or **usb2** in the **boot** command.

Step 5 Log in to the switch as an administrator.

```
Login: admin
```

Step 6 Copy the ACI image from the USB drive to the switch.

Example:

```
switch# copy usb#:aci-image-name bootflash:aci-image-name
```

Converting Back to Cisco NX-OS

You can convert a Cisco Nexus 9000 Series switch from ACI boot mode back to Cisco NX-OS.

Step 1 Reload the switch.

Example:

```
switch# reload
```

Step 2 Enter a break sequence (Ctrl-C or Ctrl-]) during the initial boot sequence to access the loader> prompt.

Example:

```
Ctrl-C  
loader>
```

Step 3 Configure the boot process to stop at the switch(boot)# prompt.

Example:

```
loader> cmdline recoverymode=1
```

Step 4 Boot the active supervisor module with the Cisco NX-OS image.

Example:

```
loader> boot nxos.7.0.3.I7.6.bin
```

Note If the Cisco NX-OS image mentioned in the bootvariable is not present in the bootflash, the system falls back to the loader prompt during the boot sequence. To recover the switch from the loader prompt, boot the system through a different image present in the bootflash, perform a **tftpboot**, or boot through a USB device.

Note For some Cisco NX-OS releases and Cisco Nexus 9000 Series switches, the following error message appears:

```
!!Fatal error!!  
Can't reserve space for RPM repo  
Please free up bootflash space and reboot
```

If you see this error message, start over from Step 1. After Step 3, enter the **cmdline init_system** command and then go to Step 4. The switch boots into the normal Cisco NX-OS prompt and skips the switch(boot)# prompt.

Step 5 Restores the switch's file system partitioning to the default settings. The bootflash filesystem is reset to Cisco NX-OS partitioning, and the Cisco NX-OS image is deleted.

Example:

```
switch(boot)# init system
```

Step 6 Completes the upload of the nx-os image file.

Example:

```
switch(boot)# load-nxos
```

Note For some Cisco Nexus 9000 Series switches, the device does not load with the normal Cisco NX-OS prompt (switch#) and instead comes up as "bash-4.2#". In this case, you must power cycle the device, jump to loader, and boot the NX-OS image using either TFTP or an USB method.

- For TFTP method - First assign a IP address and gateway to the device using the **set ip ip address subnet mask** and the **set gw gateway address** commands. This is required as the **init system** command in the above step erases all available configurations on the device

Example

```
loader> set ip 1.1.1.2 255.255.255.0
loader>set gw 1.1.1.1
```

Then use the **tftp** command to load the image.

```
loader> boot tftp://<tftp server ip>/<nxos-image-name>
```

- For USB method - Mount the USB on the switch and execute the **dir** command on the loader to see the contents of the bootflash folder and the USB device.

Example

```
loader > dir
usb1::
lost+found
/nxos.7.0.3.I7.5.bin
```

Then boot the NX-OS image using the following command:.

```
loader> boot usb1:/nxos-image
Example: boot usb1:/nxos.7.0.3.I7.5.bin
```

Once you boot the NX-OS image, the device will load as an NX-OS switch and you can continue with the remaining steps.

Step 7 Re-copy the Cisco NX-OS image into bootflash: and set the appropriate boot variables to ensure that the system boots the Cisco NX-OS image on the next reload.

Example:

TFTP example:

```
switch# copy tftp://tftp-server-ip/nxos-image-name bootflash:
switch# configure terminal
switch(config)# boot nxos bootflash:nxos-image-name
switch(config)# copy running-config startup-config
switch(config)# end
```

USB example:

```
switch# copy usb1:nxos-image-name bootflash:
switch# configure terminal
switch(config)# boot nxos bootflash:nxos-image-name
switch(config)# copy running-config startup-config
switch(config)# end
```

Step 8 Wait for the system controllers to come up, which could take approximately 15 to 20 minutes.

File system differences between ACI and Cisco NX-OS require a one-time reformatting change during the ACI to Cisco NX-OS conversion. Subsequent reloads with the Cisco NX-OS image will be faster.

Step 9 Verify that the active supervisor module and the system controllers are in the active state.

Example:

```
switch# show module
Mod  Ports  Module-Type          Model          Status
---  -
27   0      Supervisor Module   N9K-SUP-A     active
28   0      Supervisor Module   N9K-SUP-A     ha-standby
29   0      System Controller   N9K-SC-A      active
30   0      System Controller   N9K-SC-A      active
```

Step 10 For dual-supervisor systems, follow Steps 3 through 6 on the standby supervisor.

Step 11 Log in to the switch and verify that it is running Cisco NX-OS software.

```
Software
BIOS: version 07.34
NXOS: version 7.0(3)I2(1)
BIOS compile time: 08/11/2015
NXOS image file name is: bootflash:///nxos.7.0.3.I1.2.bin
NXOS compile time: 08/13/2015 10:50:20 [08/13/2015 2:25]
```

Using SCP on the ACI Shell to Load NX-OS Image into Bootflash

Use this task if you have a switch in ACI mode and must convert it to NX-OS mode, but are unable to perform a TFTP boot and the USB option is not available. The following steps describe how to boot the switch on ACI mode, configure the management port, and copy the software image to the bootflash partition.

The leaf switch boots into ACI mode in fabric discovery state.

Step 1 Log in with the username "admin" and no password. The command prompt appears:

```
#
```

Step 2 **configure terminal**

Example:

```
# configure terminal
(config)#
```

Step 3 **interface mgmt 0**

Example:

```
(config)# interface mgmt 0
(config-if)#
```

Step 4 **ip address *ipv4-address* { [*/length*] [*subnet-mask*] }**

Example:

```
(config-if)# ip address 10.1.1.20/24
(config-if)#
```

Step 5 **no shutdown**

Example:

```
(config-if)# no shutdown
(config-if)#
```

Step 6 **exit****Example:**

```
(config-if)# exit
(config)#
```

Step 7 **vrf context management****Example:**

```
(config)# vrf context management
(config-vrf)#
```

Step 8 **ip route *ipv4-address* { [/length] | [subnet-mask] } default-gw-*ipv4-address* { [/length] | [subnet-mask] }****Example:**

```
(config-vrf)# ip route 0.0.0.0/0 10.1.1.30/24
(config-vrf)#
```

Step 9 **end****Example:**

```
(config-vrf)# end
#
```

Step 10 **cd /bootflash****Example:**

```
# cd /bootflash
#
```

Step 11 **scp *username* @ *scp-server-ip-address* : *nxos-image*****Example:**

```
# scp user1@10.1.1.25:n9000-dk9.7.0.3.I1.1.bin
#
```

Step 12 Reload the switch, break into the loader prompt, and follow the steps to load the NX-OS image as shown in the previous Converting Back to Cisco NX-OS the procedure. The newly copied software image appears in the bootflash.

Example

```
# configure terminal
(config)# interface mgmt 0
(config-if)# ip address 10.1.1.20/24
(config-if)# no shutdown
(config-if)# exit
(config)# vrf context management
(config-vrf)# ip route 0.0.0.0/0 10.1.1.30/24
(config-vrf)#end
# cd /bootflash
# scp user1@10.1.1.25:n9000-dk9.7.0.3.I1.1.bin
```