



CHAPTER 4

Configuring Marking

This chapter describes how to configure the marking features on the Cisco NX-OS device that you can use to define the class of traffic to which the packet belongs.

This chapter includes the following sections:

- [Information About Marking, page 4-1](#)
- [Licensing Requirements for Marking, page 4-2](#)
- [Prerequisites for Marking, page 4-2](#)
- [Guidelines and Limitations, page 4-2](#)
- [Configuring Marking, page 4-3](#)
- [Verifying the Marking Configuration, page 4-15](#)
- [Configuration Examples for Marking, page 4-15](#)
- [Feature History for Marking, page 4-15](#)

Information About Marking

Marking is a method that you use to modify the QoS fields of the incoming and outgoing packets. The QoS fields that you can mark are CoS in Layer 2, and IP precedence and Differentiated Service Code Point (DSCP) in Layer 3. The QoS group and discard class are two labels local to the system that you can assign intermediate marking values. You can use these two labels to determine the final values marked in a packet.

You can use marking commands in traffic classes that are referenced in a policy map. The marking features that you can configure are listed in [Table 4-1](#).

Table 4-1 Configurable Marking Features

Marking Feature	Description
DSCP	Layer 3 DSCP. Note If you manipulate this dscp value, you cannot manipulate discard class values, and vice-versa.
IP precedence	Layer 3 IP precedence. Note IP precedence uses only the lower 3 bits of the type of service (ToS) field. The device overwrites the first 3 bits of the ToS field to 0.

Send document comments to nexus7k-docfeedback@cisco.com.

Table 4-1 Configurable Marking Features (continued)

Marking Feature	Description
CoS	Layer 2 class of service (CoS).
QoS group	Locally significant QoS values that can be manipulated and matched within the system. The range is from 0 to 126.
Discard class	Locally significant values that can be matched and manipulated within the system. The range is from 0 to 63. Note If you manipulate this discard class value, you cannot manipulate dscp values, and vice-versa.
Ingress and egress ports	Status of the marking applies to incoming or outgoing packets.
Using table maps	Method to use table maps for marking.

Unless noted as a restriction, you can apply marking features to both incoming and outgoing packets.

Licensing Requirements for Marking

The following table shows the licensing requirements for this feature:

Product	License Requirement
Cisco NX-OS	The QoS feature does not require a license. Any feature not included in a license package is bundled with the Cisco NX-OS system images and is provided at no extra charge to you. For a complete explanation of the Cisco NX-OS licensing scheme, see the <i>Cisco NX-OS Licensing Guide</i> .

However, using virtual device contexts (VDCs) requires an Advanced Services license.

Prerequisites for Marking

Marking has the following prerequisites:

- You must be familiar with [Chapter 3, “Using Modular QoS CLI.”](#)
- You are logged on to the switch.
- You are in the correct VDC. A VDC is a logical representation of a set of system resources. You can use the **switchto vdc** command with a VDC number.

Guidelines and Limitations

Marking has the following configuration guidelines and limitations:

- The **set cos** command can only be used in ingress policies when no other set commands are used for the same packet for egress.
- You can use only the **set qos-group** command in ingress policies.
- You can use only the **set discard-class** command in ingress policies.

Send document comments to nexus7k-docfeedback@cisco.com.

- When PIM is enabled on the switch virtual interface (SVI), you cannot mark the layer-2 switched multicast traffic on that VLAN.

Configuring Marking

You can combine one or more of the marking features in a policy map to control the setting of QoS values. You can then apply policies to either incoming or outgoing packets on an interface.

This section includes the following topics:

- [Configuring DSCP Marking, page 4-3](#)
- [Configuring IP Precedence Marking, page 4-5](#)
- [Configuring CoS Marking, page 4-7](#)
- [Configuring QoS Group Marking, page 4-7](#)
- [Configuring Discard Class Marking, page 4-8](#)
- [Configuring Ingress and Egress Marking, page 4-10](#)
- [Configuring DSCP Port Marking, page 4-10](#)
- [Configuring Table Maps for Use in Marking, page 4-12](#)
- [Configuring Marking Using Table Maps, page 4-13](#)



Note

Do not press **Enter** after you use the **set** command and before you add the rest of the command. If you press **Enter** directly after entering the **set** keyword, you will be unable to continue to configure with the QoS configuration.

Configuring DSCP Marking



Note

If you configure this value, you cannot configure the discard-class value (see the “[Configuring Discard Class Marking](#)” section on page 4-8).

You can set the DSCP value in the six most significant bits of the DiffServ field of the IP header to a specified value. You can enter numeric values from 0 to 60, in addition to the standard DSCP values shown in [Table 4-2](#).

Table 4-2 **Standard DSCP Values**

Value	List of DSCP Values
af11	AF11 dscp (001010)—decimal value 10
af12	AF12 dscp (001100)—decimal value 12
af13	AF13 dscp (001110)—decimal value 14
af21	AF21 dscp (010010)—decimal value 18
af22	AF22 dscp (010100)—decimal value 20
af23	AF23 dscp (010110)—decimal value 22

Send document comments to nexus7k-docfeedback@cisco.com.

Table 4-2 **Standard DSCP Values (continued)**

Value	List of DSCP Values
af31	AF31 dscp (011010)—decimal value 26
af32	AF40 dscp (011100)—decimal value 28
af33	AF33 dscp (011110)—decimal value 30
af41	AF41 dscp (100010)—decimal value 34
af42	AF42 dscp (100100)—decimal value 36
af43	AF43 dscp (100110)—decimal value 38
cs1	CS1 (precedence 1) dscp (001000)—decimal value 8
cs2	CS2 (precedence 2) dscp (010000)—decimal value 16
cs3	CS3 (precedence 3) dscp (011000)—decimal value 24
cs4	CS4 (precedence 4) dscp (100000)—decimal value 32
cs5	CS5 (precedence 5) dscp (101000)—decimal value 40
cs6	CS6 (precedence 6) dscp (110000)—decimal value 48
cs7	CS7 (precedence 7) dscp (111000)—decimal value 56
default	Default dscp (000000)—decimal value 0
ef	EF dscp (101110)—decimal value 46

For more information about DSCP, see RFC 2475.

SUMMARY STEPS

1. **configure terminal**
2. **policy-map [type qos] [match-first] {qos-policy-map-name | qos-dynamic}**
3. **class [type qos] {class-map-name | qos-dynamic | class-default} [insert-before before-class-map-name]**
4. **set dscp dscp-value**

Send document comments to nexus7k-docfeedback@cisco.com.

DETAILED STEPS

	Command	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters configuration mode.
Step 2	policy-map [type qos] [match-first] [<i>qos-policy-map-name</i>] qos-dynamic Example: switch(config)# policy-map policy1 switch(config-pmap-qos)#	Creates or accesses the policy map named <i>qos-policy-map-name</i> , and then enters policy-map mode. The policy-map name can contain alphabetic, hyphen, or underscore characters, is case sensitive, and can be up to 40 characters.
Step 3	class [type qos] [<i>class-map-name</i>] qos-dynamic class-default } [insert-before <i>before-class-map-name</i>] Example: switch(config-pmap)# class class1 switch(config-pmap-c-qos)#	Creates a reference to <i>class-map-name</i> , and enters policy-map class configuration mode. The class is added to the end of the policy map unless insert-before is used to specify the class to insert before. Use the class-default keyword to select all traffic that is not currently matched by classes in the policy map.
Step 4	set dscp <i>dscp-value</i> Example: switch(config-pmap-c-qos)# set dscp af31 switch(config-pmap-c-qos)#	Sets the DSCP value to <i>dscp-value</i> . Standard values are shown in Table 4-2 .

This example shows how to display the policy-map configuration as shown below:

```
switch# show policy-map policy1
```

Configuring IP Precedence Marking

You can set the value of the IP precedence field in bits 0–2 of the IPv4 type of service (ToS) field of the IP header.



Note

The device rewrites the last 3 bits of the ToS field to 0 for packets that match this class.

[Table 4-3](#) shows the precedence values.

Table 4-3 **Precedence Values**

Value	List of Precedence Values
<0-7>	IP precedence value
critical	Critical precedence (5)
flash	Flash precedence (3)
flash-override	Flash override precedence (4)

Send document comments to nexus7k-docfeedback@cisco.com.

Table 4-3 **Precedence Values (continued)**

Value	List of Precedence Values
immediate	Immediate precedence (2)
internet	Internetnetwork control precedence (6)
network	Network control precedence (7)
priority	Priority precedence (1)
routine	Routine precedence (0)

SUMMARY STEPS

1. **configure terminal**
2. **policy-map** [**type qos**] [**match-first**] {*qos-policy-map-name* | **qos-dynamic**}
3. **class** [**type qos**] {*class-map-name* | **qos-dynamic** | **class-default**} [**insert-before** *before-class-map-name*]
4. **set precedence** *precedence-value*

DETAILED STEPS

	Command	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters configuration mode.
Step 2	policy-map [type qos] [match-first] [<i>qos-policy-map-name</i> qos-dynamic] Example: switch(config)# policy-map policy1 switch(config-pmap-qos)#	Creates or accesses the policy map named <i>qos-policy-map-name</i> , and then enters policy-map mode. The policy-map name can contain alphabetic, hyphen, or underscore characters, is case sensitive, and can be up to 40 characters.
Step 3	class [type qos] { <i>class-map-name</i> qos-dynamic class-default } [insert-before <i>before-class-map-name</i>] Example: switch(config-pmap-qos)# class class1 switch(config-pmap-c-qos)#	Creates a reference to <i>class-map-name</i> and enters policy-map class configuration mode. The class is added to the end of the policy map unless insert-before is used to specify the class to insert before. Use the class-default keyword to select all traffic that is not currently matched by classes in the policy map.
Step 4	set precedence <i>precedence-value</i> Example: switch(config-pmap-c-qos)# set precedence 3 switch(config-pmap-c-qos)#	Sets the IP precedence value to <i>precedence-value</i> . The value can range from 0 to 7. You can enter one of the values shown in Table 4-3 .

This example shows how to display the policy-map configuration:

```
switch# show policy-map policy1
```

Send document comments to nexus7k-docfeedback@cisco.com.

Configuring CoS Marking

You can set the value of the CoS field in the high-order three bits of the VLAN ID Tag field in the IEEE 802.1Q header.

SUMMARY STEPS

1. **configure terminal**
2. **policy-map [type qos] [match-first] {qos-policy-map-name | qos-dynamic}**
3. **class [type qos] {class-map-name | qos-dynamic | class-default} [insert-before before-class-map-name]**
4. **set cos cos-value**

DETAILED STEPS

	Command	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters configuration mode.
Step 2	policy-map [type qos] [match-first] [qos-policy-map-name qos-dynamic] Example: switch(config)# policy-map policy1 switch(config-pmap-qos)#	Creates or accesses the policy map named <i>qos-policy-map-name</i> , and then enters policy-map mode. The policy-map name can contain alphabetic, hyphen, or underscore characters, is case sensitive, and can be up to 40 characters.
Step 3	class [type qos] {class-map-name qos-dynamic class-default} [insert-before before-class-map-name] Example: switch(config-pmap-qos)# class class1 switch(config-pmap-c-qos)#	Creates a reference to <i>class-map-name</i> , and enters policy-map class configuration mode. The class is added to the end of the policy map unless insert-before is used to specify the class to insert before. Use the class-default keyword to select all traffic that is not currently matched by classes in the policy map.
Step 4	set cos cos-value Example: switch(config-pmap-c-qos)# set cos 3 switch(config-pmap-c-qos)#	Sets the CoS value to <i>cos-value</i> . The value can range from 0 to 7.

This example shows how to display the policy-map configuration:

```
switch# show policy-map policy1
```

Configuring QoS Group Marking

You can set the value of the internal label QoS group, which is only locally significant. You can reference this value in subsequent policy actions or classify traffic that is referenced in egress policies by using the **match qos-group** class-map command.

Send document comments to nexus7k-docfeedback@cisco.com.

**Note**

You can set QoS group only in ingress policies.

SUMMARY STEPS

1. **configure terminal**
2. **policy-map** [**type qos**] [**match-first**] {*qos-policy-map-name* | **qos-dynamic**}
3. **class** [**type qos**] {*class-map-name* | **qos-dynamic** | **class-default**} [**insert-before** *before-class-map-name*]
4. **set qos-group** *qos-group-value*

DETAILED STEPS

	Command	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters configuration mode.
Step 2	policy-map [type qos] [match-first] { <i>qos-policy-map-name</i> qos-dynamic } Example: switch(config)# policy-map policy1 switch(config-pmap-qos)#	Creates or accesses the policy map named <i>qos-policy-map-name</i> , and then enters policy-map mode. The policy-map name can contain alphabetic, hyphen, or underscore characters, is case sensitive, and can be up to 40 characters.
Step 3	class [type qos] { <i>class-map-name</i> qos-dynamic class-default } [insert-before <i>before-class-map-name</i>] Example: switch(config-pmap-qos)# class class1 switch(config-pmap-c-qos)#	Creates a reference to <i>class-map-name</i> , and enters policy-map class configuration mode. The class is added to the end of the policy map unless insert-before is used to specify the class to insert before. Use the class-default keyword to select all traffic that is not currently matched by classes in the policy map.
Step 4	set qos-group <i>qos-group-value</i> Example: switch(config-pmap-c-qos)# set qos-group 100 switch(config-pmap-c-qos)#	Sets the QoS group value to <i>qos-group-value</i> . The value can range from 0 to 126.

This example shows how to display the policy-map configuration:

```
switch# show policy-map policy1
```

Configuring Discard Class Marking

**Note**

If you configure this value, you cannot configure the DSCP value. See the [“Configuring DSCP Marking”](#) section on page 4-3.

Send document comments to nexus7k-docfeedback@cisco.com.

You can set the value of the internal label discard class, which is locally significant only. You can reference this value in subsequent policy actions or classify traffic that is referenced in egress policies by using the **match discard-class** class-map command.



Note

You can set the discard class only in ingress policies.

SUMMARY STEPS

1. **configure terminal**
2. **policy-map** [**type qos**] [**match-first**] {*qos-policy-map-name* | **qos-dynamic**}
3. **class** [**type qos**] {*class-map-name* | **qos-dynamic** | **class-default**} [**insert-before** *before-class-map-name*]
4. **set discard-class** *discard-class-value*

DETAILED STEPS

	Command	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters configuration mode.
Step 2	policy-map [type qos] [match-first] { <i>qos-policy-map-name</i> qos-dynamic } Example: switch(config)# policy-map policy1 switch(config-pmap-qos)#	Creates or accesses the policy map named <i>qos-policy-map-name</i> , and then enters policy-map mode. The policy-map name can contain alphabetic, hyphen, or underscore characters, is case sensitive, and can be up to 40 characters.
Step 3	class [type qos] { <i>class-map-name</i> qos-dynamic class-default } [insert-before <i>before-class-map-name</i>] Example: switch(config-pmap-qos)# class class1 switch(config-pmap-c-qos)#	Creates a reference to <i>class-map-name</i> , and enters policy-map class configuration mode. The class is added to the end of the policy map unless insert-before is used to specify the class to insert before. Use the class-default keyword to select all traffic that is not currently matched by classes in the policy map.
Step 4	set discard-class <i>discard-class-value</i> Example: switch(config-pmap-c-qos)# set discard-class 40 switch(config-pmap-c-qos)#	Sets the discard class value to <i>discard-class-value</i> . The value can range from 0 to 63. Note For information on using table maps with marking, see the “Configuring Marking Using Table Maps” section on page 4-13.

Send document comments to nexus7k-docfeedback@cisco.com.

This example shows how to display the policy-map configuration:

```
switch# show policy-map policy1
```

Configuring Ingress and Egress Marking

You can apply the marking instructions in a QoS policy map to ingress or egress packets by attaching that QoS policy map to an interface. To select ingress or egress, you specify either the **input** or **output** keyword in the **service-policy** command. For detailed instructions, see the “[Attaching and Detaching a QoS Policy Action from an Interface](#)” section on page 3-17.

Configuring DSCP Port Marking

You can set the DSCP value for each class of traffic defined in a specified ingress policy map.

The default behavior of the device is to preserve the DSCP value, or to trust DSCP. To make the port untrusted, change the DSCP value. Unless you configure a QoS policy and attach that policy to specified interfaces, the DSCP value is preserved.



Note

- You can attach only one policy type qos map to each interface in each direction.
- The DSCP value is trust on the Layer 3 port of a Cisco NX-OS device.
- If the default policy-map policy is used, DSCP maps to a relevant CoS value and the queuing works correctly.
- If a customer policy is used, you must manually set the DSCP value to map to a CoS value so that the traffic is queued to the correct queue.

SUMMARY STEPS

1. **configure terminal**
2. **policy-map [type qos] [match-first] {qos-policy-map-name | qos-dynamic}**
3. **class [type qos] {class-map-name | qos-dynamic | class-default} [insert-before before-class-map-name]**
4. **set dscp-value**
5. **exit**
6. **class [type qos] {class-map-name | qos-dynamic | class-default} [insert-before before-class-map-name]**
7. **set dscp-value**
8. **exit**
9. **class [type qos] {class-map-name | qos-dynamic | class-default} [insert-before before-class-map-name]**
10. **set dscp-value**
11. **exit**
12. **interface ethernet {slot/port}**

Send document comments to nexus7k-docfeedback@cisco.com.

13. service-policy [type qos] {input | output} {policy-map-name | qos-dynamic} [no-stats]

DETAILED STEPS

	Command	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters configuration mode.
Step 2	policy-map [type qos] [match-first] [qos-policy-map-name qos-dynamic] Example: switch(config)# policy-map policy1 switch(config-pmap-qos)#	Creates or accesses the policy map named <i>qos-policy-map-name</i> and then enters policy-map mode. The policy-map name can contain alphabetic, hyphen, or underscore characters, is case sensitive, and can be up to 40 characters.
Step 3	class [type qos] {class-map-name qos-dynamic class-default} [insert-before before-class-map-name] Example: switch(config-pmap)# class class1 switch(config-pmap-c-qos)#	Creates a reference to <i>class-map-name</i> and enters policy-map class configuration mode. The class is added to the end of the policy map unless insert-before is used to specify the class to insert before. Use the class-default keyword to select all traffic that is not currently matched by classes in the policy map.
Step 4	set dscp-value Example: switch(config-pmap-c-qos)# set dscp af31 switch(config-pmap-c-qos)#	Sets the DSCP value to <i>dscp-value</i> . Valid values are shown in Table 4-2 .
Step 5	exit Example: switch(config-pmap-c-qos)# exit switch(config-pmap-qos)#	Returns to policy-map configuration mode.
Step 6	class [type qos] {class-map-name qos-dynamic class-default} [insert-before before-class-map-name] Example: switch(config-pmap-qos)# class class2 switch(config-pmap-c-qos)#	Creates a reference to <i>class-map-name</i> , and enters policy-map class configuration mode. The class is added to the end of the policy map unless insert-before is used to specify the class to insert before. Use the class-default keyword to select all traffic that is not currently matched by classes in the policy map.
Step 7	set dscp-value Example: switch(config-pmap-c-qos)# set dscp af13 switch(config-pmap-c-qos)#	Sets the DSCP value to <i>dscp-value</i> . Valid values are shown in Table 4-2 .
Step 8	exit Example: switch(config-pmap-c-qos)# exit switch(config-pmap-qos)#	Returns to policy-map configuration mode.

Send document comments to nexus7k-docfeedback@cisco.com.

	Command	Purpose
Step 9	class [type qos] { <i>class-map-name</i> qos-dynamic class-default } [insert-before <i>before-class-map-name</i>] Example: switch(config-pmap-qos)# class class-default switch(config-pmap-c-qos)#	Creates a reference to <i>class-map-name</i> , and enters policy-map class configuration mode. The class is added to the end of the policy map unless insert-before is used to specify the class to insert before. Use the class-default keyword to select all traffic that is not currently matched by classes in the policy map.
Step 10	set dscp-value Example: switch(config-pmap-c-qos)# set dscp af22 switch(config-pmap-c-qos)#	Sets the DSCP value to <i>dscp-value</i> . Valid values are shown in Table 4-2 .
Step 11	exit Example: switch(config-pmap-c-qos)# exit switch(config-pmap-qos)#	Returns to policy-map configuration mode.
Step 12	interface ethernet { <i>slot/port</i> } Example: switch(config)# interface ethernet 1/1 switch(config-if)#	Enters interface mode to configure the Ethernet interface.
Step 13	service-policy [type qos] { input output } { <i>policy-map-name</i> qos-dynamic } [no-stats] Example: switch(config-if)# service-policy input policy1 switch(config-if)#	Adds <i>policy-map-name</i> to the input packets of the interface. You can attach only one input policy and one output policy to an interface.

This example shows how to display the policy-map configuration:

```
switch# show policy-map policy1
```

Configuring Table Maps for Use in Marking

You can use the system-defined table maps to define the mapping of values from one variable to another from a source QoS field to a destination QoS field. For the list of system-defined table maps, see [Chapter 3, “Using Modular QoS CLI.”](#) The source and destination fields are determined by the context of the table map in the **set** and **police** commands. For information about table maps, see the “[Configuring Marking Using Table Maps](#)” section on page 4-13.



Note

The system-defined table maps are not configurable. To display the current values, enter the **show table map** command.

Use the **default** command to define the destination value of unmapped source values. By default, unmapped values are copied to the destination value, so that the destination value is the same as the source value. The *ignore* variable for the **default** command is no longer supported.

Send document comments to nexus7k-docfeedback@cisco.com.

**Note**

You can use only one of the system-defined, table maps in this procedure. For information on the system-defined table maps, see [Chapter 3, “Using Modular QoS CLI.”](#)

Configuring Marking Using Table Maps

You can use the system-defined table maps to perform marking in the **set** and **police** policy map class commands.

**Note**

For the list of system-defined table maps, see [Chapter 3, “Using Modular QoS CLI.”](#)

A source field and destination field are specified in the command that maps to the source and destination values supplied in the referenced table map. The QoS fields that can be used in these commands are listed in [Table 4-4](#).

Table 4-4 **QoS Table Map Fields**

QoS Table Map Field	Description
CoS	Class of service field in the 802.1Q header.
DSCP	Differentiated Services Code Point in the IP header.
IP precedence	Bits 0–2 of the IPv4 ToS field.
Discard class	Locally significant values that can be matched and manipulated within the system. The range is from 0 to 63.

By using the system-defined table maps, you cannot change unlike values, but you can only change one value to another when it is the same variable. You can use the markdown system-defined table maps for the **exceed** or **violate** action of the **police** command by using the same syntax as the **set** command.

**Note**

The internal label QoS group is not supported through table maps.

**Note**

Marking down in the **police** command requires the use of a table map.

For information on the **police** command, see [Chapter 6, “Configuring Policing.”](#)

Send document comments to nexus7k-docfeedback@cisco.com.

SUMMARY STEPS

1. **configure terminal**
2. **policy-map** [**type qos**] [**match-first**] {*qos-policy-map-name* | **qos-dynamic**}
3. **class** [**type qos**] {*class-map-name* | **qos-dynamic** | **class-default**} [**insert-before** *before-class-map-name*]
4. **set** {**cos** | **dscp** | **discard-class** | **precedence** | **discard-class**} {**cos** | **dscp** | **discard-class** | **precedence** | **discard-class**} *table-map-name*
5. **exit**

DETAILED STEPS

	Command	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters configuration mode.
Step 2	policy-map [type qos] [match-first] { <i>qos-policy-map-name</i> qos-dynamic } Example: switch(config)# policy-map policy1 switch(config-pmap-qos)#	Creates or accesses the policy map named <i>qos-policy-map-name</i> , and then enters policy-map mode. The policy-map name can contain alphabetic, hyphen, or underscore characters, is case sensitive, and can be up to 40 characters.
Step 3	class [type qos] { <i>class-map-name</i> qos-dynamic class-default } [insert-before <i>before-class-map-name</i>] Example: switch(config-pmap-qos)# class class1 switch(config-pmap-c-qos)#	Creates a reference to <i>class-map-name</i> and enters policy-map class configuration mode. The class is added to the end of the policy map unless insert-before is used to specify the class to insert before. Use the class-default keyword to select all traffic that is not currently matched by classes in the policy map.
Step 4	set { cos dscp discard-class precedence discard-class } { cos dscp discard-class precedence discard-class } <i>table-map-name</i> Example: switch(config-pmap-c-qos)# set cos dscp cos-dscp-map switch(config-pmap-c-qos)#	Sets the first packet field to the value of the second packet field based on the mapping values specified in the referenced <i>table-map-name</i> . Note The <i>table-map-name</i> must be the name of one of the system-defined table maps, which are not configurable, listed in Chapter 3, “Using Modular QoS CLI.” You cannot use the name of a user-defined table in this procedure. The example shows that CoS is replaced by DSCP based on the system-defined cos-dscp-map.
Step 5	exit Example: switch(config-pmap-c)# exit switch(config-pmap-qos)#	Returns to policy-map configuration mode.

This example shows how to display the policy1 policy-map configuration:

```
switch# show policy-map policy
```

Send document comments to nexus7k-docfeedback@cisco.com.

Verifying the Marking Configuration

To display the marking configuration information, perform one of the following tasks:

Command	Purpose
<code>show table-map</code>	Displays all table maps.
<code>show policy-map</code>	Displays all policy maps.

Configuration Examples for Marking

The following example shows how to configure marking:

```
configure terminal
policy-map type qos untrust_dcsp
  class class-default
    set dscp 0
policy-map type queuing untrust_1Gport_policy
  class type queuing 2q4t-in-q-default
    set cos 0
policy-map type queuing untrust_10Gport_policy
  class type queuing 8q2t-in-q-default
    set cos 0
```

Feature History for Marking

Table 4-5 lists the release history for this feature.

Table 4-5 *Feature History for Marking*

Feature Name	Releases	Feature Information
<code>set cos</code> command	5.0(3)	Support for <code>set cos</code> command in ingress policies.

Send document comments to nexus7k-docfeedback@cisco.com.