



Autonomous Fabric IDs

- [Information About Autonomous Fabric IDs, on page 1](#)
- [Guidelines and Limitations, on page 2](#)
- [Default Settings, on page 2](#)
- [Configuring AFIDs, on page 2](#)
- [Verifying IVR Configuration, on page 3](#)
- [Feature History, on page 4](#)

Information About Autonomous Fabric IDs

You can configure AFIDs individually for VSANs, or you can set the default AFIDs for all VSANs on a switch. If you configure an individual AFID for a subset of the VSANs on a switch that has a default AFID, that subset uses the configured AFID while all other VSANs on that switch use the default AFID.

You can only use an AFID configuration when the VSAN topology is in IVR auto topology mode. In IVR manual topology mode, the AFIDs are specified in the VSAN topology configuration itself and a separate AFID configuration is not needed.



Note Two VSANs with the same VSAN number but different AFIDs are counted as two VSANs out of the total 128 VSANs allowed in the fabric.

When devices attached to multiple switches belong to one VSAN, they cannot communicate with each other by configuring the regular zone set because the AFIDs are different. You can consider that the different AFIDs are different fabrics; therefore, the three switches represent three separate fabrics.

If we specify the IVR VSAN topology as shown below, IVR will set up the connection between the devices across the switches even though they have the same VSAN.

```
switch# show ivr vsan-topology
AFID  SWITCH WNN                Active  Cfg.   VSANS
-----
  1   20:00:00:0d:ec:27:6b:c0  yes    yes    1
  2   20:00:00:0d:ec:27:6c:00  yes    yes    1
  3   20:00:00:0d:ec:27:6c:40  yes    yes    1
```

Total: 3 entries in active and configured IVR VSAN-Topology

•

Guidelines and Limitations

IVR has the following guidelines and limitations:

- All border switches in the fabric must be Cisco SAN switches. Other switches in the fabric can be non-Cisco switches.

Default Settings

Parameters	Default
IVR feature	Disabled
IVR NAT	Disabled
IVR distribution	Disabled
IVR Autotopology	Disabled
IVR VSANs	Not added to virtual domains
QoS for IVR Zones	Low

Configuring AFIDs

Configuring Default AFIDs

SUMMARY STEPS

1. `autonomous-fabric-id database`
2. `switch-wwn wwndefault-autonomous-fabric-id afid`

DETAILED STEPS

	Command or Action	Purpose
Step 1	autonomous-fabric-id database Example: <pre>switch(config)# autonomous-fabric-id database switch(config-afid-db)#</pre>	Enters AFID database configuration mode.
Step 2	switch-wwn <i>wwn</i>default-autonomous-fabric-id <i>afid</i> Example: <pre>switch(config-afid-db)# switch-wwn 20:00:00:0c:91:90:3e:80 default-autonomous-fabric-id 5</pre>	Configures the default AFID for all VSANs not explicitly associated with an AFID. The valid range for the default AFID is 1 to 64.

Configuring an Individual AFID

SUMMARY STEPS

1. `autonomous-fabric-id database`
2. `switch-wwn wwn autonomous-fabric-id afid vsan-ranges range`

DETAILED STEPS

	Command or Action	Purpose
Step 1	autonomous-fabric-id database Example: <pre>switch(config)# autonomous-fabric-id database switch(config-afid-db)#</pre>	Enters AFID configuration mode.
Step 2	switch-wwn <i>wwn</i> autonomous-fabric-id <i>afid</i> vsan-ranges <i>range</i> Example: <pre>switch(config-afid-db)# switch-wwn 20:00:00:0c:91:90:3e:80 autonomous-fabric-id 10 vsan-ranges 1,2,5-8</pre>	Configures an AFID and VSAN range for a switch. The valid range for AFIDs is 1 to 64.

Verifying IVR Configuration

To display the IVR configuration, perform one of the following tasks:

Command	Purpose
<code>show ivr</code>	Displays the status for the IVR configuration.
<code>show ivr diagnostics</code>	Displays information about IVR diagnostics.
<code>show ivr merge status</code>	Displays information the last IVR merge event.
<code>show ivr pending</code>	Displays information about the IVR pending database.
<code>show ivr pending-diff</code>	Displays the differences between the pending database and the config database.
<code>show ivr vsan-topology [active configured]</code>	Displays the IVR VSAN topology.
<code>show ivr session status</code>	Displays information about IVR CFS session.

Command	Purpose
show ivr virtual-domains	Displays information about IVR virtual domains for all local VSANs.
show ivr zone	Displays information about IVR zones.
show ivr zoneset	Displays information about IVR zone sets.
show ivr service-group active	Displays information about the active service group.
show ivr service-group configured	Displays information about the configured service group.
show autonomous-fabric-id database	Displays information about the AFIDs.
show ivr virtual-fcdomain-add-status	Displays the status of the IVR virtual domain configuration.

Related Topics

[Information about IVR Zones and Zonesets](#)

[Configuring IVR Zones](#)

[Configuring IVR Zone Sets](#)

Feature History

Table 1: Feature History IVR

Feature Name	Releases	Feature Information
IVR	5.2(1)	This feature was introduced.