

# **Configuring OSPF**

- How to Configure OSPF, on page 1
- Information About OSPF, on page 12

# **How to Configure OSPF**

## **Default IS-IS Configuration**

Table 1: Default IS-IS Configuration

Feature	Default Setting
Ignore link-state PDU (LSP) errors	Enabled.
IS-IS type	Conventional IS-IS—The router acts as both a Level 1 (station) and a Level 2 (area) router.  Multiarea IS-IS—The first instance of the IS-IS routing process is a Level 1-2 router. Remaining
	instances are Level 1 routers.
Default-information originate	Disabled.
Log IS-IS adjacency state changes.	Disabled.
LSP generation throttling timers	Maximum interval between two consecutive occurrences—5000 milliseconds.
	Initial LSP generation delay—50 milliseconds.
	Hold time between the first and second LSP generation—200 milliseconds.
LSP maximum lifetime (without a refresh)	1200 seconds (20 minutes) before the LSP packet is deleted.
LSP refresh interval	Every 900 seconds (15 minutes).
Maximum LSP packet size	1497 bytes.

Feature	Default Setting
NSF Awareness	Enabled. Allows Layer 3 devicess to continue forwarding packets from a neighboring Nonstop Forwarding-capable router during hardware or software changes.
Partial route computation (PRC) throttling timers	Maximum PRC wait interval—5000 milliseconds.
	Initial PRC calculation delay after a topology change—50 milliseconds.
	Hold time between the first and second PRC calculation—200 milliseconds.
Partition avoidance	Disabled.
Password	No area or domain password is defined, and authentication is disabled.
Set-overload-bit	Disabled. When enabled, if no arguments are entered, the overload bit is set immediately and remains set until you enter the <b>no set-overload-bit</b> command.
Shortest path first (SPF) throttling timers	Maximum interval between consecutive SFPs—5000 milliseconds.
	Initial SFP calculation after a topology change—200 milliseconds.
	Hold time between the first and second SFP calculation—50 milliseconds.
Summary-address	Disabled.

## **Configuring Basic OSPF Parameters**

To enable OSPF, create an OSPF routing process, specify the range of IP addresses to associate with the routing process, and assign area IDs to be associated with that range.

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	router ospf process-id  Example:	Enables OSPF routing, and enter router configuration mode. The process ID is an internally used identification parameter that is locally assigned and can be any positive integer. Each OSPF routing process has a unique value.

	Command or Action	Purpose
	Device(config)# router ospf 15	Note OSPF for Routed Access supports only one OSPFv2 and one OSPFv3 instance with a maximum number of 1000 dynamically learned routes.
Step 3	network address wildcard-mask area area-id	Define an interface on which OSPF runs and the area ID
	Example:	for that interface. You can use the wildcard-mask to use a single command to define one or more multiple interfaces
Device(config) # network 10.1.1.1 255.240.0.	Device(config) # network 10.1.1.1 255.240.0.0 area 20	to be associated with a specific OSPF area. The area ID can be a decimal value or an IP address.
Step 4	end	Returns to privileged EXEC mode.
	Example:	
	Device(config)# end	
Step 5	show ip protocols	Verifies your entries.
	Example:	
	Device# show ip protocols	
Step 6	copy running-config startup-config	(Optional) Saves your entries in the configuration file.
	Example:	
	Device# copy running-config startup-config	

## **Configuring OSPF Interfaces**

You can use the **ip ospf** interface configuration commands to modify interface-specific OSPF parameters. You are not required to modify any of these parameters, but some interface parameters (hello interval, dead interval, and authentication key) must be consistent across all routers in an attached network. If you modify these parameters, be sure all routers in the network have compatible values.



Note

The **ip ospf** interface configuration commands are all optional.

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	

	Command or Action	Purpose
	Device# configure terminal	
Step 2	interface interface-id  Example:	Enters interface configuration mode, and specifies the Layer 3 interface to configure.
	Device(config)# interface gigabitethernet 1/0/1	
Step 3	ip ospf cost Example:	(Optional) Explicitly specifies the cost of sending a packet on the interface.
	Device(config-if)# ip ospf 8	
Step 4	ip ospf retransmit-interval seconds  Example:	(Optional) Specifies the number of seconds between link state advertisement transmissions. The range is 1 to 65535 seconds. The default is 5 seconds.
Step 5	<pre>Device(config-if) # ip ospf transmit-interval 10  ip ospf transmit-delay seconds</pre>	(Optional) Sets the estimated number of seconds to wait
oreh a	Example:	before sending a link state update packet. The range is 1 to 65535 seconds. The default is 1 second.
	Device(config-if)# ip ospf transmit-delay 2	
Step 6	<pre>ip ospf priority number Example:</pre>	(Optional) Sets priority to help find the OSPF designated router for a network. The range is from 0 to 255. The default is 1.
	Device(config-if)# ip ospf priority 5	
Step 7	<pre>ip ospf hello-interval seconds Example: Device(config-if)# ip ospf hello-interval 12</pre>	(Optional) Sets the number of seconds between hello packets sent on an OSPF interface. The value must be the same for all nodes on a network. The range is 1 to 65535 seconds. The default is 10 seconds.
Step 8	<pre>ip ospf dead-interval seconds Example:  Device(config-if) # ip ospf dead-interval 8</pre>	(Optional) Sets the number of seconds after the last device hello packet was seen before its neighbors declare the OSPF router to be down. The value must be the same for all nodes on a network. The range is 1 to 65535 seconds. The default is 4 times the hello interval.
Step 9	<pre>ip ospf authentication-key key Example:  Device(config-if) # ip ospf authentication-key password</pre>	(Optional) Assign a password to be used by neighboring OSPF routers. The password can be any string of keyboard-entered characters up to 8 bytes in length. All neighboring routers on the same network must have the same password to exchange OSPF information.
Step 10	ip ospf message digest-key keyid md5 key  Example:	(Optional) Enables MDS authentication. • keyid—An identifier from 1 to 255.

Command or Action	Purpose
Device(config-if)# ip ospf message digest-key 16 md5 your1pass	• <i>key</i> —An alphanumeric password of up to 16 bytes.
ip ospf database-filter all out  Example:	(Optional) Block flooding of OSPF LSA packets to the interface. By default, OSPF floods new LSAs over all interfaces in the same area, except the interface on which
Device(config-if)# ip ospf database-filter all out	the LSA arrives.
end	Returns to privileged EXEC mode.
Example:	
Device(config)# end	
show ip ospf interface [interface-name]	Displays OSPF-related interface information.
Example:	
Device# show ip ospf interface	
show ip ospf neighbor detail	Displays NSF awareness status of neighbor switch. The output matches one of these examples:
Example.	• Options is 0x52
Device# show ip ospf neighbor detail	LLS Options is 0x1 (LR)
	When both of these lines appear, the neighbor switch is NSF aware.
	• <i>Options is 0x42</i> —This means the neighbor switch is not NSF aware.
copy running-config startup-config	(Optional) Saves your entries in the configuration file.
Example:	
Device# copy running-config startup-config	
	Device(config-if)# ip ospf message digest-key 16 md5 yourlpass  ip ospf database-filter all out  Example:  Device(config-if)# ip ospf database-filter all out  end  Example:  Device(config)# end  show ip ospf interface [interface-name]  Example:  Device# show ip ospf interface  show ip ospf neighbor detail  Example:  Device# show ip ospf neighbor detail  copy running-config startup-config  Example:

# **Configuring OSPF Area Parameters**

#### Before you begin



Note

The OSPF area router configuration commands are all optional.

Command or Action	Purpose
configure terminal	Enters global configuration mode.
<pre>Device# configure terminal</pre>	
router ospf process-id  Example:	Enables OSPF routing, and enter router configuration mode.
Device (config) # router ospf 109  area area-id authentication  Example:	(Optional) Allow password-based protection against unauthorized access to the identified area. The identifier can be either a decimal value or an IP address.
area area-id authentication message-digest  Example:	(Optional) Enables MD5 authentication on the area.
message-digest  area area-id stub [no-summary]  Example:	(Optional) Define an area as a stub area. The <b>no-summary</b> keyword prevents an ABR from sending summary link advertisements into the stub area.
Device (config-router) # area 1 stub  area area-id nssa [no-redistribution] [default-information-originate] [no-summary]  Example:	(Optional) Defines an area as a not-so-stubby-area. Every router within the same area must agree that the area is NSSA. Select one of these keywords:
<pre>Device(config-router)# area 1 nssa default-information-originate</pre>	<ul> <li>no-redistribution—Select when the router is an NSSA ABR and you want the redistribute command to import routes into normal areas, but not into the NSSA.</li> <li>default-information-originate—Select on an ABR</li> </ul>
	<ul> <li>to allow importing type 7 LSAs into the NSSA.</li> <li>no-redistribution—Select to not send summary LSAs into the NSSA.</li> </ul>
area area-id range address mask  Example:	(Optional) Specifies an address range for which a single route is advertised. Use this command only with area border routers.
	Example:  Device# configure terminal  router ospf process-id Example:  Device (config)# router ospf 109  area area-id authentication Example:  Device (config-router)# area 1 authentication  area area-id authentication message-digest Example:  Device (config-router)# area 1 authentication message-digest  area area-id stub [no-summary] Example:  Device (config-router)# area 1 stub  area area-id nssa [no-redistribution] [default-information-originate] [no-summary] Example:  Device (config-router)# area 1 nssa default-information-originate

	Command or Action	Purpose
Step 8	end	Returns to privileged EXEC mode.
	Example:	
	Device(config)# end	
Step 9	show ip ospf [process-id]	Displays information about the OSPF routing process in
Example:	general or for a specific process ID to verify configuration.	
	Device# show ip ospf	
Step 10	show ip ospf [process-id [area-id]] database	Displays lists of information related to the OSPF database
	Example:	for a specific router.
	Device# show ip osfp database	
Step 11	copy running-config startup-config	(Optional) Saves your entries in the configuration file.
	Example:	
	Device# copy running-config startup-config	

# **Configuring Other OSPF Parameters**

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	router ospf process-id	Enables OSPF routing, and enter router configuration
	Example:	mode.
	Device(config)# router ospf 10	
Step 3	summary-address address mask	(Optional) Specifies an address and IP subnet mask for
	Example:	redistributed routes so that only one summary route is advertised.
	Device(config) # summary-address 10.1.1.1 255.255.255.0	
Step 4	area area-id virtual-link router-id [hello-interval seconds] [retransmit-interval seconds] [trans]	(Optional) Establishes a virtual link and set its parameters.

	Command or Action	Purpose
	[[authentication-key key]   message-digest-key keyid md5 key]]	
	Example:	
	Device(config) # area 2 virtual-link 192.168.255.1 hello-interval 5	
Step 5	default-information originate [always] [metric metric-value] [metric-type type-value] [route-map map-name]	(Optional) Forces the ASBR to generate a default route into the OSPF routing domain. Parameters are all optional.
	Example:	
	Device(config)# default-information originate metric 100 metric-type 1	
Step 6	ip ospf name-lookup	(Optional) Configures DNS name lookup. The default is
	Example:	disabled.
	Device(config)# ip ospf name-lookup	
Step 7	ip auto-cost reference-bandwidth ref-bw	(Optional) Specifies an address range for which a single
	Example:	route will be advertised. Use this command only with area border routers.
	Device(config)# ip auto-cost reference-bandwidth 5	
Step 8	distance ospf {[inter-area dist1] [inter-area dist2]	(Optional) Changes the OSPF distance values. The default
	[external dist3]} Example:	distance for each type of route is 110. The range is 1 to 255.
	Device(config)# distance ospf inter-area 150	
Step 9	passive-interface type number	(Optional) Suppresses the sending of hello packets through the specified interface.
	Example:	and opposition internation
	Device(config) # passive-interface gigabitethernet 1/0/6	
Step 10	timers throttle spf spf-delay spf-holdtime spf-wait	(Optional) Configures route calculation timers.
	<pre>Example: Device(config) # timers throttle spf 200 100 100</pre>	• <i>spf-delay</i> —Delay between receiving a change to SPF calculation. The range is from 1 to 600000 in miliseconds.
		• <i>spf-holdtime</i> —Delay between first and second SPF calculation. The range is from 1 to 600000 in milliseconds.

	Command or Action	Purpose
		• <i>spf-wait</i> —Maximum wait time in milliseconds for SPF calculations. The range is from 1 to 600000 in milliseconds.
Step 11	ospf log-adj-changes	(Optional) Sends syslog message when a neighbor state
	Example:	changes.
	Device(config)# ospf log-adj-changes	
Step 12	end	Returns to privileged EXEC mode.
	Example:	
	Device(config)# end	
Step 13	show ip ospf [process-id [area-id]] database	Displays lists of information related to the OSPF database
	Example:	for a specific router.
	Device# show ip ospf database	
Step 14	copy running-config startup-config	(Optional) Saves your entries in the configuration file.
	Example:	
	Device# copy running-config startup-config	

# **Changing LSA Group Pacing**

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	router ospf process-id	Enables OSPF routing, and enter router configuration mode.
	Example:	
	Device(config)# router ospf 25	
Step 3	timers lsa-group-pacing seconds	Changes the group pacing of LSAs.
	Example:	
	Device(config-router)# timers lsa-group-pacing 15	

	Command or Action	Purpose
Step 4	end	Returns to privileged EXEC mode.
	Example:	
	Device(config)# end	
Step 5	show running-config	Verifies your entries.
	Example:	
	Device# show running-config	
Step 6	copy running-config startup-config	(Optional) Saves your entries in the configuration file.
	Example:	
	Device# copy running-config startup-config	

# **Configuring a Loopback Interface**

Command or Action	Purpose
configure terminal	Enters global configuration mode.
Example:	
Device# configure terminal	
interface loopback 0	Creates a loopback interface, and enter interface
Example:	configuration mode.
Device(config)# interface loopback 0	
ip address address mask	Assign an IP address to this interface.
Example:	
Device(config-if)# ip address 10.1.1.5 255.255.240.0	
end	Returns to privileged EXEC mode.
Example:	
Device(config)# end	
	configure terminal  Example:  Device# configure terminal  interface loopback 0  Example:  Device(config)# interface loopback 0  ip address address mask  Example:  Device(config-if)# ip address 10.1.1.5 255.255.240.0  end  Example:

	Command or Action	Purpose
Step 5	show ip interface	Verifies your entries.
	Example:	
	Device# show ip interface	
Step 6	copy running-config startup-config	(Optional) Saves your entries in the configuration file.
	Example:	
	Device# copy running-config startup-config	

## **Configuration Examples for OSPF**

### **Example: Configuring Basic OSPF Parameters**

This example shows how to configure an OSPF routing process and assign it a process number of 109:

```
Device(config) # router ospf 109
Device(config-router) # network 131.108.0.0 255.255.255.0 area 24
```

## **Monitoring OSPF**

You can display specific statistics such as the contents of IP routing tables, caches, and databases.

#### **Table 2: Show IP OSPF Statistics Commands**

show ip ospf [process-id]	Displays general information about OSPF routing
	processes.

show ip ospf [process-id] database [router] [link-state-id]	Displays lists of information related to the OSPF database.
show ip ospf [process-id] database [router] [self-originate]	
show ip ospf [process-id] database [router] [adv-router [ip-address]]	
show ip ospf [process-id] database [network] [link-state-id]	
show ip ospf [process-id] database [summary] [link-state-id]	
show ip ospf [process-id] database [asbr-summary] [link-state-id]	
show ip ospf [process-id] database [external] [link-state-id]	
show ip ospf [process-id area-id] database [database-summary]	
show ip ospf border-routes	Displays the internal OSPF routing ABR and ASBR table entries.
show ip ospf interface [interface-name]	Displays OSPF-related interface information.
show ip ospf neighbor [interface-name] [neighbor-id] detail	Displays OSPF interface neighbor information.
show ip ospf virtual-links	Displays OSPF-related virtual links information.

### **Feature Information for OSPF**

Table 3: Feature Information for OSPF

Feature Name	Release	Feature Information
OSPF (Open Shortest Path First)	Cisco IOS XE 3.3SE	This feature was introduced

## **Information About OSPF**

OSPF is an Interior Gateway Protocol (IGP) designed expressly for IP networks, supporting IP subnetting and tagging of externally derived routing information. OSPF also allows packet authentication and uses IP multicast when sending and receiving packets. The Cisco implementation supports RFC 1253, OSPF management information base (MIB).

The Cisco implementation conforms to the OSPF Version 2 specifications with these key features:

• Definition of stub areas is supported.

- Routes learned through any IP routing protocol can be redistributed into another IP routing protocol. At the intradomain level, this means that OSPF can import routes learned through EIGRP and RIP. OSPF routes can also be exported into RIP.
- Plain text and MD5 authentication among neighboring routers within an area is supported.
- Configurable routing interface parameters include interface output cost, retransmission interval, interface transmit delay, router priority, router dead and hello intervals, and authentication key.
- Virtual links are supported.
- Not-so-stubby-areas (NSSAs) per RFC 1587are supported.

OSPF typically requires coordination among many internal routers, area border routers (ABRs) connected to multiple areas, and autonomous system boundary routers (ASBRs). The minimum configuration would use all default parameter values, no authentication, and interfaces assigned to areas. If you customize your environment, you must ensure coordinated configuration of all routers.



Note

It is not recommended to use OSPF aggressive timers. An OSPF hello timer of less than five seconds is considered aggressive. OSPF and other routing protocols are handled at normal priority and sub second scheduling under high CPU usage conditions in not guaranteed.

BFD control packets are handled with high priority by a separate queue and bfd packets are processed in a high priority thread. BFD is preferred over OSPF for faster convergence.

## **OSPF Nonstop Forwarding**

The Device or switch stack supports two levels of nonstop forwarding (NSF):

- OSPF NSF Awareness, on page 13
- OSPF NSF Capability, on page 13

#### **OSPF NSF Awareness**

The IP-services feature set supports OSPF NSF Awareness for IPv4. When the neighboring router is NSF-capable, the Layer 3 Device continues to forward packets from the neighboring router during the interval between the primary Route Processor (RP) in a router crashing and the backup RP taking over, or while the primary RP is manually reloaded for a non-disruptive software upgrade.

This feature cannot be disabled.

### **OSPF NSF Capability**

The IP services feature set supports the OSPFv2 NSF IETF format in addition to the OSPFv2 NSF Cisco format that is supported in earlier releases. For information about this feature, see: NSF—OSPF (RFC 3623 OSPF Graceful Restart).

The IP-services feature set also supports OSPF NSF-capable routing for IPv4 for better convergence and lower traffic loss following a stack's active switch change. When an active switch changeover occurs in an OSPF NSF-capable stack, the new active switch must do two things to resynchronize its link-state database with its OSPF neighbors:

- Release the available OSPF neighbors on the network without resetting the neighbor relationship.
- Reacquire the contents of the link-state database for the network.

After an active switch changeover, the new active switch sends an OSPF NSF signal to neighboring NSF-aware devices. A device recognizes this signal to mean that it should not reset the neighbor relationship with the stack. As the NSF-capable active switch receives signals from other routes on the network, it begins to rebuild its neighbor list.

When the neighbor relationships are reestablished, the NSF-capable active switch resynchronizes its database with its NSF-aware neighbors, and routing information is exchanged between the OSPF neighbors. The new active switch uses this routing information to remove stale routes, to update the routing information database (RIB), and to update the forwarding information base (FIB) with the new information. The OSPF protocols then fully converge.



Note

OSPF NSF requires that all neighbor networking devices be NSF-aware. If an NSF-capable router discovers non-NSF aware neighbors on a network segment, it disables NSF capabilities for that segment. Other network segments where all devices are NSF-aware or NSF-capable continue to provide NSF capabilities.

Use the **nsf** OSPF routing configuration command to enable OSPF NSF routing. Use the **show ip ospf** privileged EXEC command to verify that it is enabled.

For more information, see *Cisco Nonstop Forwarding*: http://www.cisco.com/en/US/docs/ios/ha/configuration/guide/ha-nonstp\_fwdg.html

## **OSPF Area Parameters**

You can optionally configure several OSPF area parameters. These parameters include authentication for password-based protection against unauthorized access to an area, stub areas, and not-so-stubby-areas (NSSAs). Stub areas are areas into which information on external routes is not sent. Instead, the area border router (ABR) generates a default external route into the stub area for destinations outside the autonomous system (AS). An NSSA does not flood all LSAs from the core into the area, but can import AS external routes within the area by redistribution.

Route summarization is the consolidation of advertised addresses into a single summary route to be advertised by other areas. If network numbers are contiguous, you can use the **area range** router configuration command to configure the ABR to advertise a summary route that covers all networks in the range.

### **Other OSPF Parameters**

You can optionally configure other OSPF parameters in router configuration mode.

- Route summarization: When redistributing routes from other protocols. Each route is advertised
  individually in an external LSA. To help decrease the size of the OSPF link state database, you can use
  the summary-address router configuration command to advertise a single router for all the redistributed
  routes included in a specified network address and mask.
- Virtual links: In OSPF, all areas must be connected to a backbone area. You can establish a virtual link
  in case of a backbone-continuity break by configuring two Area Border Routers as endpoints of a virtual
  link. Configuration information includes the identity of the other virtual endpoint (the other ABR) and

the nonbackbone link that the two routers have in common (the transit area). Virtual links cannot be configured through a stub area.

- Default route: When you specifically configure redistribution of routes into an OSPF routing domain, the route automatically becomes an autonomous system boundary router (ASBR). You can force the ASBR to generate a default route into the OSPF routing domain.
- Domain Name Server (DNS) names for use in all OSPF **show** privileged EXEC command displays makes it easier to identify a router than displaying it by router ID or neighbor ID.
- Default Metrics: OSPF calculates the OSPF metric for an interface according to the bandwidth of the interface. The metric is calculated as *ref-bw* divided by bandwidth, where *ref* is 10 by default, and bandwidth (*bw*) is specified by the **bandwidth** interface configuration command. For multiple links with high bandwidth, you can specify a larger number to differentiate the cost on those links.
- Administrative distance is a rating of the trustworthiness of a routing information source, an integer between 0 and 255, with a higher value meaning a lower trust rating. An administrative distance of 255 means the routing information source cannot be trusted at all and should be ignored. OSPF uses three different administrative distances: routes within an area (interarea), routes to another area (interarea), and routes from another routing domain learned through redistribution (external). You can change any of the distance values.
- Passive interfaces: Because interfaces between two devices on an Ethernet represent only one network segment, to prevent OSPF from sending hello packets for the sending interface, you must configure the sending device to be a passive interface. Both devices can identify each other through the hello packet for the receiving interface.
- Route calculation timers: You can configure the delay time between when OSPF receives a topology
  change and when it starts the shortest path first (SPF) calculation and the hold time between two SPF
  calculations.
- Log neighbor changes: You can configure the router to send a syslog message when an OSPF neighbor state changes, providing a high-level view of changes in the router.

## **LSA Group Pacing**

The OSPF LSA group pacing feature allows the router to group OSPF LSAs and pace the refreshing, check-summing, and aging functions for more efficient router use. This feature is enabled by default with a 4-minute default pacing interval, and you will not usually need to modify this parameter. The optimum group pacing interval is inversely proportional to the number of LSAs the router is refreshing, check-summing, and aging. For example, if you have approximately 10,000 LSAs in the database, decreasing the pacing interval would benefit you. If you have a very small database (40 to 100 LSAs), increasing the pacing interval to 10 to 20 minutes might benefit you slightly.

### **Loopback Interfaces**

OSPF uses the highest IP address configured on the interfaces as its router ID. If this interface is down or removed, the OSPF process must recalculate a new router ID and resend all its routing information out its interfaces. If a loopback interface is configured with an IP address, OSPF uses this IP address as its router ID, even if other interfaces have higher IP addresses. Because loopback interfaces never fail, this provides greater stability. OSPF automatically prefers a loopback interface over other interfaces, and it chooses the highest IP address among all loopback interfaces.

Loopback Interfaces