



Configuring RIP

- [Information About RIP, on page 1](#)
- [How to Configure Routing Information Protocol, on page 2](#)
- [Configuration Examples for Routing Information Protocol, on page 11](#)
- [Feature History for Routing Information Protocol, on page 12](#)

Information About RIP

The Routing Information Protocol (RIP) is an interior gateway protocol (IGP) created for use in small, homogeneous networks. It is a distance-vector routing protocol that uses broadcast User Datagram Protocol (UDP) data packets to exchange routing information. The protocol is documented in RFC 1058. You can find detailed information about RIP in *IP Routing Fundamentals*, published by Cisco Press.

Using RIP, the switch sends routing information updates (advertisements) every 30 seconds. If a router does not receive an update from another router for 180 seconds or more, it marks the routes served by that router as unusable. If there is still no update after 240 seconds, the router removes all routing table entries for the non-updating router.

RIP uses hop counts to rate the value of different routes. The hop count is the number of routers that can be traversed in a route. A directly connected network has a hop count of zero; a network with a hop count of 16 is unreachable. This small range (0 to 15) makes RIP unsuitable for large networks.

If the router has a default network path, RIP advertises a route that links the router to the pseudonetwork 0.0.0.0. The 0.0.0.0 network does not exist; it is treated by RIP as a network to implement the default routing feature. The switch advertises the default network if a default was learned by RIP or if the router has a gateway of last resort and RIP is configured with a default metric. RIP sends updates to the interfaces in specified networks. If an interface's network is not specified, it is not advertised in any RIP update.

RIP for IPv6

Routing Information Protocol (RIP) for IPv6 is a distance-vector protocol that uses hop count as a routing metric. It includes support for IPv6 addresses and prefixes and the all-RIP-routers multicast group address FF02::9 as the destination address for RIP update messages.

For configuring RIP for IPv6, see the *Configuring RIP for IPv6* section.

For more information about RIP for IPv6, see the “Implementing RIP for IPv6” chapter in the *Cisco IOS IPv6 Configuration Library* on Cisco.com.

Summary Addresses and Split Horizon

Routers connected to broadcast-type IP networks and using distance-vector routing protocols normally use the split-horizon mechanism to reduce the possibility of routing loops. Split horizon blocks information about routes from being advertised by a router on any interface from which that information originated. This feature usually optimizes communication among multiple routers, especially when links are broken.

How to Configure Routing Information Protocol

The following sections provide configurational information about RIP.

Default RIP Configuration

Table 1: Default RIP Configuration

| Feature | Default Setting |
|---------------------------------|--|
| Auto summary | Enabled. |
| Default-information originate | Disabled. |
| Default metric | Built-in; automatic metric translations. |
| IP RIP authentication key-chain | No authentication. Authentication mode: clear text. |
| IP RIP triggered | Disabled |
| IP split horizon | Varies with media. |
| Neighbor | None defined. |
| Network | None specified. |
| Offset list | Disabled. |
| Output delay | 0 milliseconds. |
| Timers basic | <ul style="list-style-type: none"> • Update: 30 seconds. • Invalid: 180 seconds. • Hold-down: 180 seconds. • Flush: 240 seconds. |
| Validate-update-source | Enabled. |
| Version | Receives RIP Version 1 and 2 packets; sends Version 1 packets. |

Configuring Basic RIP Parameters

To configure RIP, you enable RIP routing for a network and optionally configure other parameters. On the switch, RIP configuration commands are ignored until you configure the network number.

Procedure

| | Command or Action | Purpose |
|---------------|---|---|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password, if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters global configuration mode. |
| Step 3 | ip routing Example: Device(config)# ip routing | Enables IP routing. (Required only if IP routing is disabled.) |
| Step 4 | router rip Example: Device(config)# router rip | Enables a RIP routing process, and enter router configuration mode. |
| Step 5 | network <i>network number</i> Example: Device(config-router)# network 12.0.0.0 | Associates a network with a RIP routing process. You can specify multiple network commands. RIP routing updates are sent and received through interfaces only on these networks. <p>Note You must configure a network number for the RIP commands to take effect.</p> |
| Step 6 | neighbor <i>ip-address</i> Example: Device(config-router)# neighbor 10.2.5.1 | (Optional) Defines a neighboring router with which to exchange routing information. This step allows routing updates from RIP (normally a broadcast protocol) to reach nonbroadcast networks. |
| Step 7 | offset-list [<i>access-list number</i> <i>name</i>] {in out} <i>offset</i> [<i>type number</i>] Example: | (Optional) Applies an offset list to routing metrics to increase incoming and outgoing metrics to routes learned through RIP. You |

| | Command or Action | Purpose |
|----------------|--|--|
| | Device (config-router) # offset-list 103 in 10 | can limit the offset list with an access list or an interface. |
| Step 8 | timers basic <i>update invalid holddown flush</i> Example: Device (config-router) # timers basic 45 360 400 300 | (Optional) Adjusts routing protocol timers. Valid ranges for all timers are 0 to 4294967295 seconds. <ul style="list-style-type: none"> • <i>update</i>—The time between sending routing updates. The default is 30 seconds. • <i>invalid</i>—The timer after which a route is declared invalid. The default is 180 seconds. • <i>holddown</i>—The time before a route is removed from the routing table. The default is 180 seconds. • <i>flush</i>—The amount of time for which routing updates are postponed. The default is 240 seconds. |
| Step 9 | version {1 2} Example: Device (config-router) # version 2 | (Optional) Configures the switch to receive and send only RIP Version 1 or RIP Version 2 packets. By default, the switch receives Version 1 and 2 but sends only Version 1. You can also use the interface commands ip rip {send receive} version 1 2 1 2 to control what versions are used for sending and receiving on interfaces. |
| Step 10 | no auto summary Example: Device (config-router) # no auto summary | (Optional) Disables automatic summarization. By default, the switch summarizes subprefixes when crossing classful network boundaries. Disable summarization (RIP Version 2 only) to advertise subnet and host routing information to classful network boundaries. |
| Step 11 | output-delay <i>delay</i> Example: Device (config-router) # output-delay 8 | (Optional) Adds interpacket delay for RIP updates sent. By default, packets in a multiple-packet RIP update have no delay added between packets. If you are sending packets to a lower-speed device, you can add an interpacket delay in the range of 8 to 50 milliseconds. |
| Step 12 | end Example: Device (config-router) # end | Returns to privileged EXEC mode. |

| | Command or Action | Purpose |
|----------------|---|--|
| Step 13 | show ip protocols Example: Device# <code>show ip protocols</code> | Verifies your entries. |
| Step 14 | copy running-config startup-config Example: Device# <code>copy running-config startup-config</code> | (Optional) Saves your entries in the configuration file. |

Configuring RIP Authentication

RIP Version 1 does not support authentication. If you are sending and receiving RIP Version 2 packets, you can enable RIP authentication on an interface. The key chain specifies the set of keys that can be used on the interface. If a key chain is not configured, no authentication is performed, not even the default.

The switch supports two modes of authentication on interfaces for which RIP authentication is enabled: plain text and MD5. The default is plain text.

Procedure

| | Command or Action | Purpose |
|---------------|---|--|
| Step 1 | enable Example: Device> <code>enable</code> | Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# <code>configure terminal</code> | Enters global configuration mode. |
| Step 3 | interface <i>interface-id</i> Example: Device(config)# <code>interface gigabitethernet 1/0/1</code> | Enters interface configuration mode, and specifies the interface to configure. |
| Step 4 | ip rip authentication key-chain <i>name-of-chain</i> Example: Device(config-if)# <code>ip rip authentication key-chain trees</code> | Enables RIP authentication. |

| | Command or Action | Purpose |
|---------------|---|---|
| Step 5 | ip rip authentication mode {text md5} Example: <pre>Device(config-if)# ip rip authentication mode md5</pre> | Configures the interface to use plain text authentication (the default) or MD5 digest authentication. |
| Step 6 | end Example: <pre>Device(config)# end</pre> | Returns to privileged EXEC mode. |
| Step 7 | show running-config Example: <pre>Device# show running-config</pre> | Verifies your entries. |
| Step 8 | copy running-config startup-config Example: <pre>Device# copy running-config startup-config</pre> | (Optional) Saves your entries in the configuration file. |

Configuring RIP for IPv6

For more information about configuring RIP routing for IPv6, see the “Implementing RIP for IPv6” chapter in the *Cisco IOS IPv6 Configuration Library* on Cisco.com,

To configure RIP routing for IPv6, perform this procedure:

Before you begin

Before configuring the switch to run IPv6 RIP, you must enable routing by using the **ip routing** command in global configuration mode, enable the forwarding of IPv6 packets by using the **ipv6 unicast-routing** command in global configuration mode, and enable IPv6 on any Layer 3 interfaces on which IPv6 RIP is to be enabled.

Procedure

| | Command or Action | Purpose |
|---------------|--|---|
| Step 1 | enable Example: <pre>Device> enable</pre> | Enables privileged EXEC mode. Enter your password if prompted. |
| Step 2 | configure terminal Example: | Enters global configuration mode. |

| | Command or Action | Purpose |
|----------------|--|---|
| | Device# <code>configure terminal</code> | |
| Step 3 | ipv6 router rip <i>name</i> Example: Device(config)# <code>ipv6 router rip cisco</code> | Configures an IPv6 RIP routing process, and enters router configuration mode for the process. |
| Step 4 | maximum-paths <i>number-paths</i> Example: Device(config-router)# <code>maximum-paths 6</code> | (Optional) Define the maximum number of equal-cost routes that IPv6 RIP can support. The range is from 1 to 32, and the default is 16 routes. |
| Step 5 | exit Example: Device(config-router)# <code>exit</code> | Returns to global configuration mode. |
| Step 6 | interface <i>interface-id</i> Example: Device(config)# <code>interface gigabitethernet 1/0/1</code> | Enters interface configuration mode, and specifies the Layer 3 interface to configure. |
| Step 7 | ipv6 rip <i>name</i> enable Example: Device(config-if)# <code>ipv6 rip cisco enable</code> | Enables the specified IPv6 RIP routing process on the interface. |
| Step 8 | ipv6 rip <i>name</i> default-information {only originate} Example: Device(config-if)# <code>ipv6 rip cisco default-information only</code> | (Optional) Originates the IPv6 default route (::/0) into the RIP routing process updates sent from the specified interface. Note To avoid routing loops after the IPv6 default route (::/0) is originated from any interface, the routing process ignores all default routes received on any interface. <ul style="list-style-type: none"> • only—Select to originate the default route, but suppress all other routes in the updates sent on this interface. • originate—Select to originate the default route in addition to all other routes in the updates sent on this interface. |
| Step 9 | end Example: Device(config)# <code>end</code> | Returns to privileged EXEC mode. |
| Step 10 | Use one of the following: | <ul style="list-style-type: none"> • Displays information about current IPv6 RIP processes. |

| | Command or Action | Purpose |
|----------------|---|--|
| | <ul style="list-style-type: none"> • <code>show ipv6 rip [name] [interface interface-id] [database] [next-hops]</code> • <code>show ipv6 rip</code> <p>Example:</p> <pre>Device# show ipv6 rip cisco interface gigabitethernet 2/0/1</pre> <p>or</p> <pre>Device# show ipv6 rip</pre> | <ul style="list-style-type: none"> • Displays the current contents of the IPv6 routing table. |
| Step 11 | <p>copy running-config startup-config</p> <p>Example:</p> <pre>Device# copy running-config startup-config</pre> | (Optional) Saves your entries in the configuration file. |

Configuring Summary Addresses and Split Horizon



Note In general, disabling split horizon is not recommended unless you are certain that your application requires it to properly advertise routes.

If you want to configure an interface running RIP to advertise a summarized local IP address pool on a network access server for dial-up clients, use the **ip summary-address rip** interface configuration command.



Note If split horizon is enabled, neither autosummary nor interface IP summary addresses are advertised.

Procedure

| | Command or Action | Purpose |
|---------------|---|---|
| Step 1 | <p>enable</p> <p>Example:</p> <pre>Device> enable</pre> | <p>Enables privileged EXEC mode.</p> <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | <p>configure terminal</p> <p>Example:</p> <pre>Device# configure terminal</pre> | Enters global configuration mode. |
| Step 3 | <p>interface interface-id</p> <p>Example:</p> | Enters interface configuration mode, and specifies the Layer 3 interface to configure. |

| | Command or Action | Purpose |
|---------------|---|--|
| | Device(config)# interface gigabitethernet 1/0/1 | |
| Step 4 | ip address <i>ip-address subnet-mask</i> Example: Device(config-if)# ip address 10.1.1.10 255.255.255.0 | Configures the IP address and IP subnet. |
| Step 5 | ip summary-address rip ip address <i>ip-network mask</i> Example: Device(config-if)# ip summary-address rip ip address 10.1.1.30 255.255.255.0 | Configures the IP address to be summarized and the IP network mask. |
| Step 6 | no ip split horizon Example: Device(config-if)# no ip split horizon | Disables split horizon on the interface. |
| Step 7 | end Example: Device(config)# end | Returns to privileged EXEC mode. |
| Step 8 | show ip interface <i>interface-id</i> Example: Device# show ip interface gigabitethernet 1/0/1 | Verifies your entries. |
| Step 9 | copy running-config startup-config Example: Device# copy running-config startup-config | (Optional) Saves your entries in the configuration file. |

Configuring Split Horizon

Routers connected to broadcast-type IP networks and using distance-vector routing protocols normally use the split-horizon mechanism to reduce the possibility of routing loops. Split horizon blocks information about routes from being advertised by a router on any interface from which that information originated. This feature can optimize communication among multiple routers, especially when links are broken.



Note In general, we do not recommend disabling split horizon unless you are certain that your application requires it to properly advertise routes.

Procedure

| | Command or Action | Purpose |
|---------------|---|--|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters global configuration mode. |
| Step 3 | interface <i>interface-id</i> Example: Device (config)# interface gigabitethernet 1/0/1 | Enters interface configuration mode, and specifies the interface to configure. |
| Step 4 | ip address <i>ip-address subnet-mask</i> Example: Device (config-if)# ip address 10.1.1.10 255.255.255.0 | Configures the IP address and IP subnet. |
| Step 5 | no ip split-horizon Example: Device (config-if)# no ip split-horizon | Disables split horizon on the interface. |
| Step 6 | end Example: Device (config)# end | Returns to privileged EXEC mode. |
| Step 7 | show ip interface <i>interface-id</i> Example: Device# show ip interface gigabitethernet 1/0/1 | Verifies your entries. |

| | Command or Action | Purpose |
|---------------|---|--|
| Step 8 | copy running-config startup-config Example: <pre>Device# copy running-config startup-config</pre> | (Optional) Saves your entries in the configuration file. |

Configuration Examples for Routing Information Protocol

The following sections provide configuration examples for RIP.

Configuration Example for Summary Addresses and Split Horizon

In this example, the major net is 10.0.0.0. The summary address 10.2.0.0 overrides the autosummary address of 10.0.0.0 so that 10.2.0.0 is advertised out interface Gigabit Ethernet port 2, and 10.0.0.0 is not advertised. In the example, if the interface is still in Layer 2 mode (the default), you must enter a **no switchport** interface configuration command before entering the **ip address** interface configuration command.



Note If split horizon is enabled, neither autosummary nor interface summary addresses (those configured with the **ip summary-address rip** router configuration command) are advertised.

```
Device(config)# router rip
Device(config-router)# interface gigabitethernet1/0/2
Device(config-if)# ip address 10.1.5.1 255.255.255.0
Device(config-if)# ip summary-address rip 10.2.0.0 255.255.0.0
Device(config-if)# no ip split-horizon
Device(config-if)# exit
Device(config)# router rip
Device(config-router)# network 10.0.0.0
Device(config-router)# neighbor 2.2.2.2 peer-group mygroup
Device(config-router)# end
```

Example: Configuring RIP for IPv6

This example shows how to enable the RIP routing process *cisco* with a maximum of eight equal-cost routes and to enable it on an interface:

```
Device> enable
Device# configure terminal
Device(config)# ipv6 router rip cisco
Device(config-router)# maximum-paths 8
Device(config)# exit
Device(config)# interface gigabitethernet2/0/11
Device(config-if)# ipv6 rip cisco enable
```

Feature History for Routing Information Protocol

This table provides release and related information for the features explained in this module.

These features are available in all the releases subsequent to the one they were introduced in, unless noted otherwise.

| Release | Feature | Feature Information |
|--------------------------------|------------------------------|---|
| Cisco IOS XE Gibraltar 16.11.1 | Routing Information Protocol | The Routing Information Protocol is an interior gateway protocol (IGP) created for use in small and homogeneous networks. |

Use the Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>.