



## Post-Installation Tasks

---

- [Changing the Default Password, on page 1](#)
- [Updating the License, on page 1](#)

### Changing the Default Password

#### Procedure

---

- Step 1** From the menu choose **Administration > Users**.
- Step 2** Click the **Login Users** tab.
- Step 3** Choose **admin** from the list of Login Users.
- Step 4** Click **Change Password**.
- Step 5** In the **Change Password** dialog box, enter the new password and confirm it.
- Step 6** Click **Save**.
- 

### Updating the License

You must perform the following procedure to update the license before you start using Cisco IMC Supervisor. For the list of valid licenses, see [About Licenses](#). You must generate a license key, claim and register the Product Access Key. After installing Cisco IMC Supervisor, the license is validated and you can start using Cisco IMC Supervisor.

#### Before you begin

If you received a zipped license file by email, extract and save the **.lic** file to your local machine.

#### Procedure

---

- Step 1** Choose **Administration > License**.
- Step 2** On the **License** page, choose **License Keys**.

**Step 3** On the **License Keys** page, click **Update License**.

**Step 4** On the **Update License** screen, do one of the following:

- To upload a **.lic** file, click **Browse**, navigate to and select the **.lic** file, then click **Upload**.
- For a license key, check the **Enter License Text** check box then copy and paste the license key only into the **License Text** field. The license key is typically at the top of the file, after Key ->.

You can also copy and paste the full text of a license file into the **License Text** field.

**Step 5** Click **Submit**.

The license file is processed, and a message appears confirming the successful update.

---