



# Commands

---

This chapter includes the following sections:

- [activate \(firmware\), page 5](#)
- [cancel, page 6](#)
- [clear \(log\), page 7](#)
- [clear \(sel\), page 8](#)
- [commit, page 9](#)
- [connect, page 10](#)
- [discard, page 11](#)
- [exit, page 12](#)
- [factory-default \(cimc\), page 13](#)
- [generate-csr \(certificate\), page 14](#)
- [ping \(network\), page 15](#)
- [power \(chassis\), page 16](#)
- [reapply \(bios\), page 18](#)
- [reboot \(chassis\), page 19](#)
- [recover \(bios\), page 20](#)
- [scope bios, page 21](#)
- [scope certificate, page 22](#)
- [scope chassis, page 23](#)
- [scope cimc, page 24](#)
- [scope fault, page 25](#)
- [scope firmware \(bios\), page 26](#)
- [scope http, page 27](#)
- [scope ipblocking \(network\), page 28](#)

- [scope ipmi, page 29](#)
- [scope kvm, page 30](#)
- [scope ldap, page 31](#)
- [scope log \(cimc\), page 32](#)
- [scope network \(cimc\), page 33](#)
- [scope pef \(fault\), page 34](#)
- [scope sel, page 36](#)
- [scope sensor, page 37](#)
- [scope sol, page 38](#)
- [scope ssh, page 39](#)
- [scope tech-support \(cimc\), page 40](#)
- [scope trap-destination \(fault\), page 41](#)
- [scope user, page 42](#)
- [scope user-session, page 43](#)
- [scope vmedia, page 44](#)
- [set action \(pef\), page 45](#)
- [set addr \(trap-destination\), page 47](#)
- [set boot-order \(bios\), page 48](#)
- [set \(chassis\), page 50](#)
- [set description \(chassis\), page 51](#)
- [set enabled \(trap-destination\), page 52](#)
- [set \(fault\), page 53](#)
- [set \(http\), page 54](#)
- [set \(ipblocking\), page 56](#)
- [set \(ipmi\), page 57](#)
- [set \(kvm\), page 58](#)
- [set \(ldap\), page 60](#)
- [set locator-led \(chassis\), page 62](#)
- [set \(network\), page 63](#)
- [set \(sol\), page 66](#)
- [set \(ssh\), page 68](#)
- [set \(user\), page 69](#)
- [set \(vmedia\), page 71](#)

- [set cli output](#), page 72
- [set path \(tech-support\)](#), page 73
- [set send-alert \(pef\)](#), page 74
- [set tftp-ip \(tech-support\)](#), page 75
- [show actual-boot-order \(bios\)](#), page 76
- [show bios](#), page 77
- [show certificate](#), page 78
- [show chassis](#), page 80
- [show cimc](#), page 81
- [show configuration pending](#), page 82
- [show cpu \(chassis\)](#), page 83
- [show dimm \(chassis\)](#), page 85
- [show entries \(log\)](#), page 87
- [show entries \(sel\)](#), page 89
- [show fan \(sensor\)](#), page 91
- [show fault](#), page 93
- [show firmware \(cimc\)](#), page 94
- [show hdd \(chassis\)](#), page 95
- [show http](#), page 96
- [show ipblocking \(network\)](#), page 97
- [show ipmi](#), page 98
- [show kvm](#), page 99
- [show ldap](#), page 100
- [show led \(chassis\)](#), page 101
- [show network \(cimc\)](#), page 102
- [show pef \(fault\)](#), page 103
- [show psu \(chassis\)](#), page 104
- [show psu \(sensor\)](#), page 105
- [show psu-redundancy \(sensor\)](#), page 106
- [show sol](#), page 107
- [show ssh](#), page 108
- [show tech-support \(cimc\)](#), page 109
- [show temperature \(sensor\)](#), page 110

- [show trap-destination \(fault\)](#), page 111
- [show user](#), page 112
- [show user-session](#), page 113
- [show version](#), page 114
- [show vmedia](#), page 115
- [start](#), page 116
- [terminate \(user-session\)](#), page 117
- [top](#), page 118
- [update \(firmware\)](#), page 119
- [upload \(certificate\)](#), page 120

# activate (firmware)

To activate CIMC firmware, use the **activate** command.

## activate

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Firmware (/cimc/firmware)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to activate CIMC firmware:

```
server# scope cimc
server /cimc # scope firmware
server /cimc/firmware # activate
server /cimc/firmware #
```

### Related Commands

Command	Description
show cimc	
show version	

# cancel

To stop the technical support process, use the **cancel** command.

## cancel

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Technical support (/cimc/tech-support)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to stop the technical support process:

```
server# scope cimc
server /cimc # scope tech-support
server /cimc/tech-support # cancel
This operation will cancel your current Tech Support upload.
Continue?[y|N]y
server /cimc/tech-support #
```

### Related Commands

Command	Description
start	

# clear (log)

To clear the CIMC log, use the **clear** command in log mode.

## clear

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Log (/cimc/log)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to clear the CIMC log:

```
server# scope cimc
server /cimc # scope log
server /cimc/log # clear
server /cimc/log #
```

### Related Commands

Command	Description
show sel	
show sensor	

# clear (sel)

To clear the system event log, use the **clear** command in sel mode.

## clear

This command has no arguments or keywords.

### Command Default

None

### Command Modes

System event log (/sel)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to clear the system event log:

```
server# scope sel
server /sel # clear
server /sel #
```

### Related Commands

Command	Description
show sel	
show sensor	



# commit

To save configuration changes, use the **commit** command.

## commit

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Any command mode

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to save a configuration change:

```
server /http # set enabled yes
server /http* # commit
server http #
```

### Related Commands

Command	Description
discard	

# connect

To connect to either the server CLI or the server shell, use the **connect** command.

**connect** {**host** | **shell**}

## Syntax Description

<b>host</b>	Specifies the CLI on the server.
<b>shell</b>	Specifies the GNU bash shell on the server.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Usage Guidelines

Use the **exit** command to exit the GNU bash shell.

## Examples

This example shows how to connect to the server shell:

```
server# connect shell
bash-3.2
```

# discard

To discard all configurations, use the **discard** command.

## **discard**

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Any command mode

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to discard all configurations:

```
server# discard
server#
```

### Related Commands

Command	Description
discard	

# exit

To leave any mode, use the **exit** command.

## exit

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Any command mode

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to exit bios mode:

```
server /bios # exit
server#
```

### Related Commands

Command	Description
scope	
enter	

# factory-default (cimc)

To set the server to factory default, use the **factory-default** command.

## factory-default

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Cisco Integrated Management Controller (/cimc)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to set the server to factory default:

```
server# scope cimc
server /cimc # factory-default
This operation will reset the BMC configuration to factory default.
All your configuration will be lost.
Continue?[y|n] y
```

# generate-csr (certificate)

To generate a Certificate Request Signing (CSR), use the **generate-csr** command.

## generate csr

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Certificate (/certificate)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to generate a CSR :

```
server# scope certificate
server /certificate # generate-csr
```

```
Common Name (CN): abcCertificate
Organization Name (O): abcCo
Organization Unit (OU): 01
Locality (L): west
StateName (S): CA
Country Code (CC): US
Email: abcCo@abcCo.com
Continue to generate CSR?[y|N] y
```

```
-----BEGIN CERTIFICATE REQUEST-----
MIIB0TCCAToCAQAwbDELMAkGA1UEBhMCVVMxCzAJBgNVBAGTAkNBMQ0wCwYDVQQH
EwRoZXJlMQwwCgYDVQQKEwN0aW0xCzAJBgNVBAsTAjAxMQwwCgYDVQQDEwNib2Ix
GDAWBgkqhkiG9w0BCQEWCW1lQG1lLmNvbTCBnzANBgkqhkiG9w0BAQEFAAOBjQAw
gYkCgYEAw49pYuDxdOfHtXwBT7k5kX1set/I3e8TtkuO/EQ5HVD9HrPIy4Kpb3Oj
33CkqjysVWBpPSGzWAlEL6cZYs5p6JxR74+tgW5BYpNKRLNFawpsTZvCXhe/n/O2
WYsxlFnWlm6BgQnPKCBCp9R1ESmq9Np24r2c3PEStZEjeIVWbaUCAwEAAaAlMCMG
CSqGSib3DQIEJBzEWExRBIGNoYWxsZW5nZSBwYXNzd29yZDANBgkqhkiG9w0BAQUF
AAOBgQBosXif9feLXHBK19kqeVZ8uqRgoM1cM03aBTImjIO1RgwhRLuMrG2l+thA
CT+fbYOYXJ4bHsn25XQjcSdG0uxsti3C2SnK83nKdulpEzBzj545rvH20QK+RtHN
YUBEKvABCeQoIUu+ErMtGvryaQw7WQiQjWf+RTf8IXDGShtIQwQ==
-----END CERTIFICATE REQUEST-----
```

```
server /certificate #
```

### Related Commands

Command	Description
show certificate	
show ssh	

## ping (network)

To ping, use the **ping** command in network mode.

**ping** *address*

Syntax Description	<i>address</i>	The IP address or the hostname.
Command Default	None	
Command Modes	Network (/cimc/network)	
Command History	Release	Modification
	1.0(1)	This command was introduced.

### Examples

This example shows how to ping:

```
server# scope cimc
server /cimc # scope network
server /cimc/network # ping 209.165.200.225

Press CTRL+C to stop.
PING 209.165.200.225 (209.165.200.225): 56 data bytes
64 bytes from 209.165.200.225: seq=0 ttl=122 time=2.000 ms
64 bytes from 209.165.200.225: seq=1 ttl=122 time=2.000 ms
64 bytes from 209.165.200.225: seq=2 ttl=122 time=2.000 ms
64 bytes from 209.165.200.225: seq=3 ttl=122 time=3.000 ms
64 bytes from 209.165.200.225: seq=4 ttl=122 time=2.000 ms

--- 209.165.200.225 ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 2.000/2.200/3.000 ms

server /cimc/network #
```

# power (chassis)

To manage server power, use the **power** command.

**power** {cycle | hard-reset | off | on | shutdown}

## Syntax Description

<b>cycle</b>	Power cycles the server.
<b>hard-reset</b>	Hard resets the server.
<b>off</b>	Powers off the server.
<b>on</b>	Powers on the server.
<b>shutdown</b>	Shuts down the server.

## Command Default

None

## Command Modes

Chassis (/chassis)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to power off the server :

```
server# scope chassis
server /chassis # power off
```

```
This operation will change the server's power state.
Continue?[y|n] y
```

```
server /chassis #
```

## Usage Guidelines

- Cycle—Power off, then power on.
- Hard reset—Power off, then power on. Equivalent to pressing the front panel reset button, or performing an IPMI reset.
- Shutdown—Graceful shut down of the OS, then power off.



**Related Commands**

Command	Description
show chassis	
show psu	

# reapply (bios)

To reapply the boot order, use the **reapply** command in bios mode.

This command has no arguments or keywords.

## Command Default

None

## Command Modes

BIOS (/bios)

## Command History

Release	Modification
1.0(1x)	This command was introduced.

## Examples

This example shows how to reapply the boot order:

```
server# scope bios
server /bios # re-apply
Boot order has been successfully re-applied
server /bios #
```

## Related Commands

Command	Description
set boot-order (bios)	
show actual-boot-order	

# reboot (chassis)

To reboot the server, use the **reboot** command.

## reboot

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Cisco Integrated Management Controller (/cimc)

### Command History

Release	Modification
1.0(1)	This command was introduced.
1.0(1X)	This command was deprecated.

### Examples

This example shows how to reboot the server:

```
server# scope cimc  
server /cimc # reboot
```

```
This operation will reboot the BMC.  
Continue?[y|n] y
```

### Related Commands

Command	Description
power	

# recover (bios)

To recover corrupted BIOS, use the **recover** command in firmware mode.

## recover

This command has no arguments or keywords.

### Command Default

None

### Command Modes

BIOS (/bios)

### Command History

Release	Modification
1.0(1X)	This command was introduced.

### Usage Guidelines

Before executing the **recover** command, perform the following tasks:

- Ensure that the BIOS recovery ISO image is available for your use
- Launch the KVM Console
- Power off server
- Map the BIOS recovery ISO image using vMedia

Executing the **recover** command automatically powers the server on. After the recovery is finished, power cycle or reset the server.

### Examples

This example shows how to recover corrupted BIOS:

```
server# scope bios
server /bios # recover
```

This operation will automatically power on the server to perform BIOS FW recovery.  
Continue?[y|N]**y**

```
server /bios #
```



#### Note

You can use the CLI or the KVM console to monitor the progress of the recovery.

### Related Commands

Command	Description
show bios	
show version	

# scope bios

To enter bios mode, use the **scope bios** command.

## scope bios

This command has no arguments or keywords.

### Command Default

None

### Command Modes

BIOS (/bios)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use bios mode to set the server boot order:

- CDROM—CD-ROM boot
- EFI—Extensible Firmware Interface boot
- FDD—Floppy disk drive boot
- HDD—Hard disk drive boot
- PXE—Preboot Execution Environment boot

### Examples

This example shows how to enter BIOS mode:

```
server# scope bios
server /bios #
```

### Related Commands

Command	Description
show bios	
show firmware	

# scope certificate

To enter certificate mode, use the **scope certificate** command.

## scope certificate

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Certificate (/certificate)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use certificate mode to perform the following tasks:

- Generate a certificate signing request
- Upload a signed certificate

### Examples

This example shows how to enter certificate mode:

```
server# scope certificate
server /certificate #
```

### Related Commands

Command	Description
generate-csr	
show certificate	

# scope chassis

To enter chassis mode, use the **scope chassis** command.

## scope chassis

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Chassis (/chassis)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use chassis mode to set the following chassis properties:

- Server description
- Server locator LED state

### Examples

This example shows how to enter chassis mode:

```
server# scope chassis
server /chassis #
```

### Related Commands

Command	Description
show chassis	
show led	

# scope cimc

To enter cimc mode, use the **scope cimc** command.

## scope cimc

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Cisco Integrated Management Controller (/cimc)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use cimc mode to perform the following actions:

- Reset the CIMC to factory defaults
- Reboot the CIMC

### Examples

This example shows how to enter cimc mode :

```
server# scope cimc
server /cimc #
```

### Related Commands

Command	Description
show cimc	
show log (cimc)	



# scope fault

To enter fault mode, use the **scope fault** command.

## scope fault

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Fault (/fault)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use fault mode to set the following SNMP properties:

- Community string
- Platform event

### Examples

This example shows how to enter fault mode :

```
server# scope fault  
server /fault #
```

### Related Commands

Command	Description
show fault	
show pef	

# scope firmware (bios)

To enter firmware mode, use the **scope firmware** command in bios mode.

## scope firmware

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Firmware (/bios/firmware)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use firmware mode to perform the following tasks:

- Activate and upload firmware
- Display firmware information

### Examples

This example shows how to enter BIOS mode:

```
server# scope bios
server /bios # scope firmware
server /bios/firmware #
```

### Related Commands

Command	Description
show bios	
show firmware	

# scope http

To enter http mode, use the **scope http** command.

## scope http

This command has no arguments or keywords.

### Command Default

None

### Command Modes

HTTP (/http)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use http mode to set the following HTTP properties:

- Enabling or disabling HTTP
- Specifying port numbers and the HTTP connection timeout

### Examples

This example shows how to enter http mode :

```
server# scope http  
server /http #
```

### Related Commands

Command	Description
show http	
show http-port	

# scope ipblocking (network)

To enter ipblocking mode, use the **scope ipblocking** command in network mode.

## scope ipblocking

This command has no arguments or keywords.

### Command Default

None

### Command Modes

IP blocking (/cimc/network/ipblocking)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use ipblocking mode to perform the following tasks:

- Enable or disable IP blocking
- Set failure count, failure window, and penalty time

### Examples

This example shows how to enter ipblocking mode :

```
server# scope cimc
server /cimc # scope network
server /cimc/network # scope ipblocking
server /cimc/network/ipblocking #
```

### Related Commands

Command	Description
show ipblocking	
set penalty-time	

# scope ipmi

To enter ipmi mode, use the **scope ipmi** command.

## scope ipmi

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Intelligent Platform Management Interface (/ipmi)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use ipmi mode to perform the following tasks:

- Enable or disable IPMI
- Create an encryption key
- Set the security privilege level

### Examples

This example shows how to enter ipmi mode :

```
server# scope ipmi
server /ipmi #
```

### Related Commands

Command	Description
show ipmi	
set encryption-key	

# scope kvm

To enter kvm mode, use the **scope kvm** command.

## scope kvm

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Keyboard, video and mouse (/kvm)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use kvm mode to set the following KVM properties:

- Encryption
- KVM port number
- Local video
- Maximum sessions

### Examples

This example shows how to enter kvm mode :

```
server# scope kvm  
server /kvm #
```

### Related Commands

Command	Description
set max-sessions	
show kvm	

# scope ldap

To enter ldap mode, use the **scope ldap** command.

## scope ldap

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Lightweight Directory Access Protocol (/ldap)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use ldap mode to perform the following LDAP properties:

- Enable or disable LDAP
- Set attribute and Base DN (Base Distinguished Name)
- Enable encryption
- Create LDAP server IP address and connection timeout

### Examples

This example shows how to enter ldap mode :

```
server# scope ldap  
server /ldap #
```

### Related Commands

Command	Description
set server-ip	
show ldap	

# scope log (cimc)

To enter log mode, use the **scope log** command in cimc mode.

## scope log

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Log (/cimc/log)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use log mode to perform the following tasks:

- Clear the CIMC trace log
- Display CIMC trace log entries

### Examples

This example shows how to enter log mode :

```
server# scope cimc
server /cimc # scope log
server /cimc/log #
```

### Related Commands

Command	Description
show entries	
show log	



# scope network (cimc)

To enter network mode, use the **scope network** command in cimc mode.

## scope network

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Network (/cimc/network)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use network mode to perform the following tasks:

- Enable DHCP and DNS
- Create a host name
- Set the NIC mode and redundancy
- Create an IPv4 IP address, gateway, and netmask
- Enable the VLAN membership feature

### Examples

This example shows how to enter network mode :

```
server# scope cimc
server /cimc # scope network
server /cimc/network #
```

### Related Commands

Command	Description
set dhcp-enabled	
show network	

## scope pef (fault)

To enter pef mode, use the **scope pef** command in fault mode.

**scope pef** *pef-index*

### Syntax Description

<i>pef-index</i>	The index of a specific performance event filter. The range of valid values is 1 to 12. See Usage Guideline for a complete list of performance event filter indexes.
------------------	--

### Command Default

None

### Command Modes

Performance event filter (/fault/pef)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

Following is a list of the performance event filter indexes:

- 1—Temperature Critical Assert Filter
- 2—Temperature Warning Assert Filter
- 3—Voltage Critical Assert Filter
- 4—Current Assert Filter
- 5—Fan Critical Assert Filter
- 6—Processor Assert Filter
- 7—Power Supply Critical Assert Filter
- 8—Power Supply Warning Assert Filter
- 9—Power Supply Redundancy Lost Filter
- 10—Discrete Power Supply Assert Filter
- 11—Memory Assert Filter
- 12—Drive Slot Assert Filter

### Examples

This example shows how to enter pef mode:

```
server# scope fault
server /fault # scope pef 3
server /fault/pef #
```

**Related Commands**

Command	Description
show pef	

# scope sel

To enter sel mode, use the **scope sel** command.

## scope sel

This command has no arguments or keywords.

### Command Default

None

### Command Modes

System event log (/sel)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use sel mode to perform the following tasks:

- Clear the system event log
- Show configuration and system event log entries

### Examples

This example shows how to enter sel mode :

```
server# scope sel
server /sel #
```

### Related Commands

Command	Description
show entries	
show sel	

# scope sensor

To enter sensor mode, use the **scope sensor** command.

## scope sensor

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Sensor (/sensor)

### Command History

Release	Modification
1.0(1X)	This command was introduced.

### Usage Guidelines

You use sensor mode to display fan, psu, psu-redundancy, temperature, and voltage sensors information.

### Examples

This example shows how to enter sensor mode :

```
server# scope sensor
server /sensor #
```

### Related Commands

Command	Description
show fan	
show voltage	

# scope sol

To enter sol mode, use the **scope sol** command.

## scope sol

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Serial over LAN (/sol)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use sol mode to perform the following tasks:

- Enable or disable SoL
- Set the baud rate

### Examples

This example shows how to enter sol mode :

```
server# scope sol  
server /sol #
```

### Related Commands

Command	Description
set baud-rate	
show sol	

# scope ssh

To enter ssh mode, use the **scope ssh** command.

## scope ssh

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Secure Shell (/ssh)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use ssh mode to perform the following tasks:

- Enable or disable SSH
- Set the SSH port number and connection timeout interval

### Examples

This example shows how to enter ssh mode :

```
server# scope ssh
server /ssh #
```

### Related Commands

Command	Description
set timeout (/ssh)	
show ssh	

# scope tech-support (cimc)

To enter tech-support mode, use the **scope tech-support** command in cimc mode.

## scope tech-support

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Technical support (/cimc/tech-support)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use tech-support mode to set up the TFTP path and server address.

### Examples

This example shows how to enter tech-support mode :

```
server# scope cimc
server /cimc # scope tech-support
server /cimc/tech-support #
```

### Related Commands

Command	Description
show tech-support	
start	



## scope trap-destination (fault)

To enter trap-destination mode, use the **scope trap-destination** command in fault mode.

**scope trap-destination** *trap-destination-index*

<b>Syntax Description</b>	<i>trap-destination-index</i>	The index of a specific trap destination. The range of valid values is 1 to 4. See Usage Guideline for a complete list of trap destination indexes.				
<b>Command Default</b>	None					
<b>Command Modes</b>	Trap destination (/fault/trap-destination)					
<b>Command History</b>	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>1.0(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	1.0(1)	This command was introduced.	
Release	Modification					
1.0(1)	This command was introduced.					
<b>Usage Guidelines</b>	A trap destination index corresponds to a specific trap destination IP address. There are up to four possible trap destination indexes. You pair an index with an IP address using the <b>set addr</b> command in trap-destination mode.					
<b>Examples</b>	This example shows how to enter trap-destination mode:  server# <b>scope fault</b> server /fault # <b>scope trap-destination 4</b> server /fault/trap-destination #					
<b>Related Commands</b>	<table><tr><th>Command</th><th>Description</th></tr><tr><td>show trap-destination</td><td></td></tr></table>	Command	Description	show trap-destination		
Command	Description					
show trap-destination						

# scope user

To enter user mode, use the **scope user** command.

**scope user** {1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15}

## Syntax Description

<b>1</b> through <b>15</b>	Specifies users 1 through 15.
----------------------------------	-------------------------------

## Command Default

None

## Command Modes

User (/user)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Usage Guidelines

You use user mode to perform the following tasks:

- Enable user services
- Create user names, roles, and passwords

## Examples

This example shows how to enter user mode :

```
server# scope user
server /user #
```

## Related Commands

Command	Description
set user-name	
show user	

# scope user-session

To enter user-session mode, use the **scope user-session** command.

## scope user-session

This command has no arguments or keywords.

### Command Default

None

### Command Modes

User session (/user-session)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use user-session mode to display details about user sessions.

### Examples

This example shows how to enter user-session mode :

```
server# scope user-session
server /user-session #
```

### Related Commands

Command	Description
show user	
show user-session	

# scope vmedia

To enter vmedia mode, use the **scope vmedia** command.

## scope vmedia

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Virtual media (/vmedia)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You use vmedia mode to perform the following tasks:

- Enable virtual media services
- Enable encryption

### Examples

This example shows how to enter vmedia mode :

```
server# scope vmedia
server /vmedia #
```

### Related Commands

Command	Description
set	
show vmedia	

## set action (pef)

To set up an action for a performance event filter, use the **set action** command in pef mode.

```
set action {none | power-off | reboot | power-cycle}
```

### Syntax Description

<b>none</b>	Specifies no action.
<b>power-off</b>	Specifies that the server power off.
<b>reboot</b>	Specifies that the server reboots.
<b>power-cycle</b>	Specifies that the server power cycle.

### Command Default

None

### Command Modes

Performance event filters (/fault/pef)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

Following is a list of the performance event filter indexes:

- 1—Temperature Critical Assert Filter
- 2—Temperature Warning Assert Filter
- 3—Voltage Critical Assert Filter
- 4—Current Assert Filter
- 5—Fan Critical Assert Filter
- 6—Processor Assert Filter
- 7—Power Supply Critical Assert Filter
- 8—Power Supply Warning Assert Filter
- 9—Power Supply Redundancy Lost Filter
- 10—Discrete Power Supply Assert Filter
- 11—Memory Assert Filter
- 12—Drive Slot Assert Filter

## Examples

This example shows how to set up an action for performance event filter 3:

```
server# scope fault
server /fault # scope pef 3
server /fault/pef # set action power-cycle
server /fault/pef* # commit
server /fault/pef #
```

## Related Commands

Command	Description
show pef	

## set addr (trap-destination)

To assign an IP address to a trap destination index, use the **set addr** command in trap-destination mode.

**set addr** *ip-address*

### Syntax Description

<i>ip-address</i>	The IP address of the trap destination. The format is x.x.x.x.
-------------------	--

### Command Default

None

### Command Modes

Trap destination (/fault/trap-destination)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to assign an IP address to a trap destination index:

```
server# scope fault
server /fault # scope trap-destination 3
server /fault/trap-destination # set addr 209.165.200.225
server /fault/trap-destination* # commit
server /fault/trap-destination #
```

### Related Commands

Command	Description
show trap-destination	

# set boot-order (bios)

To set the boot order for the server, use the **set boot-order** command in bios mode.

**set boot-order** *boot-order*

## Syntax Description

<b>boot-order</b>	Sets the server boot order.
<i>boot-order</i>	The server boot order. Use the following boot order arguments, arranging them in the order that you want: <ul style="list-style-type: none"> <li>• hdd</li> <li>• pxe</li> <li>• fdd</li> <li>• efi</li> <li>• cdrom</li> </ul>

## Command Default

None

## Command Modes

BIOS (/bios)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Usage Guidelines

Type the boot order arguments using quotes and commas as delimiters. Following is an example:

"EFI","HDD","FDD","CDROM","PXE"

The arguments are not case sensitive.

## Examples

This example shows how to set up the boot order for the server:

```
server# scope bios
server /bios # set boot-order "EFI","HDD","FDD","CDROM","PXE"
server /bios* # commit
server /bios #
```

## Related Commands

Command	Description
show bios	



Command	Description
show actual-boot-order	

## set (chassis)

To describe the chassis, use the **set** command in chassis mode. You can also toggle the chassis locator LED.

**set** {**description** *chassis-description* | **locator-led** {**on** | **off**}}

### Syntax Description

<b>description</b>	Specifies the description of the chassis.
<i>chassis-description</i>	The description of the chassis. The range of valid values is 1 to 64.
<b>locator-led</b>	Specifies whether the chassis locator LED.
<b>on</b>	Turns the server locator LED on.
<b>off</b>	Turns the server locator LED off.

### Command Default

None

### Command Modes

Chassis (/chassis)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

When you turn on the locator LED, it flashes. This allows you to easily locate the chassis.

### Examples

This example shows how to turn on the locator LED:

```
server# scope chassis
server /chassis # set locator-led on
server /chassis* # commit
server /chassis #
```

### Related Commands

Command	Description
show chassis	
show led	

# set description (chassis)

To set up a description for the chassis, use the **set description** command in chassis mode.

**set description** *chassis-description*

Syntax Description	<i>chassis-description</i>	The description of the chassis. The range of valid values is 1 to 64.
--------------------	----------------------------	---

Command Default	None
-----------------	------

Command Modes	Chassis (/chassis)
---------------	--------------------

Command History	Release	Modification
	1.0(1)	This command was introduced.

Examples	<p>This example shows how to :</p> <pre>server# scope chassis server /chassis # set description testServer server /chassis* # commit server /chassis #</pre>
----------	--

Related Commands	Command	Description
	show chassis	

## set enabled (trap-destination)

To enable or disable trap destinations on the server, use the **set enabled** command in trap-destination mode.

**set enabled** {no | yes}

### Syntax Description

<b>no</b>	Specifies that trap destination services are disabled.
<b>yes</b>	Specifies that trap destination services are enabled.

### Command Default

None

### Command Modes

Trap destination (/fault/trap-destination)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to enable trap destination services:

```
server# scope fault
server /fault # scope trap-destination 2
server /fault/trap-destination # set enabled yes
server /fault/trap-destination* # commit
server /fault/trap-destination #
```

### Related Commands

Command	Description
show trap-destination	

## set (fault)

To create an SNMP community, use the **set** command in fault mode. You can also enable platform events.

**set** {**community-str** *community-name* | **platform-event-enabled** {**no** | **yes**}}

### Syntax Description

<b>community-str</b>	Specifies the SNMP community string (name).
<i>community-name</i>	The name of the SNMP community. The range of valid values is 1 to 18.
<b>platform-event-enabled</b>	Specifies whether platform event alerts are enabled or disabled.
<b>no</b>	Sets platform event alerts to disabled.
<b>yes</b>	Sets platform event alerts to enabled.

### Command Default

None

### Command Modes

Fault (/fault)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to create an SNMP community string:

```
server# scope fault
server /fault # set community-str cs100
server /fault* # commit
server /fault #
```

### Related Commands

Command	Description
show fault	
show pef	

## set (http)

To set up Hyper Text Transfer Protocol (HTTP) services on the server, use the **set** command in http mode.

**set** {**enabled** {**no** | **yes**} | **http-port** *port-number* | **https-port** *port-number* | **timeout** *time*}

### Syntax Description

<b>enabled</b>	Specifies whether HTTP services are enabled or disabled.
<b>no</b>	Specifies that HTTP is not enabled.
<b>yes</b>	Specifies that HTTP is enabled.
<b>http-port</b>	Sets the HTTP server port number.
<i>port-number</i>	The HTTP port number of the server. The range of valid values is 1 to 65536. <b>Note</b> You also use this argument with the <b>https-port</b> keyword.
<b>https-port</b>	Sets the HTTPS server port number.
<b>timeout</b>	Sets the HTTP connection timeout time.
<i>time</i>	The connection timeout time, in seconds. The range of valid values is 60 to 10800.

### Command Default

None

### Command Modes

HTTP (/http)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to set the HTTP port number:

```
server# scope http
server /http # set http-port 80
server /http* # commit
server /http #
```

### Related Commands

Command	Description
show http-port	

Command	Description
show https-port	

## set (ipblocking)

To set up IP blocking on the server, use the **set** command in ipblocking mode.

**set** {**enabled** {**no** | **yes**} | **fail-count** *fail-number* | **fail-window** *fail-window* | **penalty-time** *penalty-time*}

### Syntax Description

<b>enabled</b>	Specifies whether IP blocking services are enabled or disabled.
<b>no</b>	Specifies that IP blocking is not enabled.
<b>yes</b>	Specifies that IP blocking is enabled.
<b>fail-count</b>	Sets the failure count.
<i>fail-number</i>	The failure number. The range of valid values is 3 to 10.
<b>fail-window</b>	Sets the failure window.
<i>fail-window</i>	The failure window. The range of valid values is 60 to 120.
<b>penalty-time</b>	Sets the blocking time.
<i>penalty-time</i>	The blocking time, in seconds. The range of valid values is 60 to 10800.

### Command Default

None

### Command Modes

IP blocking (/cimc/chassis/ipblocking)

### Command History

Release	Modification
1.0(1X)	This command was introduced.

### Examples

This example shows how to enable IP blocking:

```
server# scope cimc
server /cimc # scope network
server /cimc/network # scope ipblocking
server /cimc/network/ipblocking # set enabled yes
server /cimc/network/ipblocking* # commit
server /cimc/network/ipblocking #
```

### Related Commands

Command	Description
show ipblocking	



## set (ipmi)

To set up IPMI services on the server, use the **set** command in ipmi mode.

**set** {**enabled** {**no** | **yes**} | **encryption-key** *encryption-key* | **privilege-level** {**admin** | **read-only** | **user**}}

### Syntax Description

<b>enabled</b>	Specifies whether IPMI is enabled or disabled.
<b>no</b>	Specifies that IPMI is not enabled.
<b>yes</b>	Specifies that IPMI is enabled.
<b>encryption-key</b>	Specifies the IPMI encryption key.
<i>encryption-key</i>	The IPMI encryption key. The valid value is 40 hex numbers.
<b>privilege-level</b>	Specifies the IPMI privilege level.
<b>admin</b>	Sets the IPMI privilege level to admin.
<b>read-only</b>	Sets the IPMI privilege level to read-only.
<b>user</b>	Sets the IPMI privilege level to user.

### Command Default

None

### Command Modes

Intelligent Platform Management Interface (/ipmi)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to set the IPMI encryption key:

```
server# scope ipmi
server /ipmi # set encryption-key a9 62 b5 0a 68 6e e3 02 72 ce af f1 39 f8 1e 05 f5 19 d5
e1 7f f4 71 b9 9a 41 be e3 f5 06 4e cc 0f 63 67 2e a2 9c 74 d0
server /ipmi* # commit
server /ipmi #
```

### Related Commands

Command	Description
show ipmi	

## set (kvm)

To enable KVM on the server, use the **set** command in kvm mode.

**set** {**enabled** {**no** | **yes**} | **encrypted** {**no** | **yes**} | **kvm-port** *port-number* | **local-video** {**no** | **yes**} | **max-sessions** *number-of-sessions*}

### Syntax Description

<b>enabled</b>	Specifies whether KVM is enabled or disabled.
<b>no</b>	Specifies disable. Following are the uses of the <b>no</b> keyword: <ul style="list-style-type: none"> <li>• Specifies that KVM is disabled when used with the <b>enabled</b> keyword.</li> <li>• Specifies that encryption is disabled when used with the <b>encrypted</b> keyword.</li> <li>• Specifies that local video is disabled when used with the <b>local-video</b> command.</li> </ul>
<b>yes</b>	Specifies enable. Following are the uses of the <b>yes</b> keyword: <ul style="list-style-type: none"> <li>• Specifies that KVM is enabled when used with the <b>enabled</b> command.</li> <li>• Specifies that encryption is enabled when used with the <b>encrypted</b> command.</li> <li>• Specifies that local video is enabled when used with the <b>local-video</b> command.</li> </ul>
<b>encrypted</b>	Specifies whether KVM is encrypted or not encrypted.
<b>kvm-port</b>	Specifies the KVM port.
<i>port number</i>	The KVM port number. The range of valid values is 1 to 65535.
<b>local-video</b>	Specifies local video.
<b>max-sessions</b>	Specifies the maximum number of KVM sessions.
<i>number-of-sessions</i>	The maximum number of concurrent KVM sessions. The range of valid values is 1 to 4.

### Command Default

None

### Command Modes

Keyboard Video Mouse (/kvm)

### Command History

Release	Modification
1.0(1)	This command was introduced.

**Usage Guidelines**

Use the **local-video** command to display the KVM session on any monitor attached to the server.

**Examples**

This example shows how to enable KVM:

```
server# scope kvm
server /kvm # set kvm enabled
server /kvm* # commit
server /kvm #
```

**Related Commands**

Command	Description
show kvm	

## set (ldap)

To set up an LDAP (Lightweight Directory Access Protocol) directory on the server, use the **set** command in ldap mode.

**set** {**attribute** *attribute-name* | **base-dn** *base-dn-name* | **enabled** {**no** | **yes**} | **encrypted** {**no** | **yes**} | **server-ip** *ip-address* | **timeout** *time*}

### Syntax Description

<b>attribute</b>	Specifies the LDAP attribute.
<i>attribute-name</i>	The name of the attribute. The range of valid values is 1 to 64.
<b>base-dn</b>	Specifies the LDAP Base DN.
<i>base-dn-name</i>	The Base DN name. The range of valid values is 1 to 63.
<b>enabled</b>	Specifies whether LDAP is enabled or disabled.
<b>no</b>	Specifies disable. Following are the uses of the <b>no</b> keyword: <ul style="list-style-type: none"> <li>• Specifies that LDAP is not enabled for the <b>enabled</b> keyword.</li> <li>• Specifies that encryption is not enabled for the <b>encrypted</b> keyword.</li> </ul>
<b>yes</b>	Specifies enable. Following are the uses of the <b>yes</b> command: <ul style="list-style-type: none"> <li>• Specifies that LDAP is enabled for the <b>enabled</b> command.</li> <li>• Specifies that encryption is enabled for the <b>encrypted</b> command.</li> </ul>
<b>encrypted</b>	Specifies whether the Active Directory is encrypted or not encrypted.
<b>server-ip</b>	Specifies the Active Directory server IP address.
<i>ip-address</i>	The Active Directory server IP address. The format is X.X.X.X.
<b>timeout</b>	Specifies the Active Directory server connection timeout.
<i>time</i>	The wait time before a connection timeout, in seconds. The range of valid values is 0 to 1800.

### Command Default

None

### Command Modes

Lightweight Directory Access Protocol (/ldap)

**Command History**

Release	Modification
1.0(1)	This command was introduced.

**Usage Guidelines**

You must be logged in as admin to set LDAP properties.

**attribute**—Specify an LDAP attribute that contains the role and locale information for the user. This property is always a name-value pair. The system queries the user record for the value that matches this attribute name. You can use the existing LDAP attribute that is mapped to CIMC user roles and locales. You can also create a custom attribute, such as the CiscoAVPair attribute, which has the following attribute ID:

1.3.6.1.4.1.9.287247.1

If you do not specify this property, user access is restricted to read-only.

**enabled**—When LDAP is enabled, all user authentication and role authorization is performed by Active Directory. CIMC ignores the local user database. If CIMC cannot establish a connection to Active Directory, it reverts to using the local user database.

**Examples**

This example shows how to set the Active Directory server timeout property:

```
server# scope ldap
server /ldap # set timeout 100
server /ldap* # commit
server /ldap #
```

**Related Commands**

Command	Description
show ldap	

## set locator-led (chassis)

To turn the server locator LED on or off, use the **set locator-led** command in chassis mode.

**set locator-led {off | on}**

### Syntax Description

<b>off</b>	Turns the loactor LED off.
<b>on</b>	Turns the loactor LED on.

### Command Default

None

### Command Modes

Chassis (/chassis)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to turn on the locator LED:

```
server# scope chassis
server /chassis # set locator-led on
server /chassis* # commit
server /chassis #
```

### Related Commands

Command	Description
show chassis	
show led	

## set (network)

To set up server network services on the server, use the **set** command in network mode.

**set** {**alternate-dns-server** *ip-address* | **dhcp-enabled** {**no** | **yes**} | **dns-use-dhcp** | **hostname** *host-name* | **mode** {**dedicated** | **shared-lom** | **shipping**} | **preferred-dns-server** | **redundancy** {**none** | **active-standby**} | **v4-addr** *ip-address* | **v4-gateway** *ip-address* | **v4-netmask** *netmask* | **vlan-enabled** {**no** | **yes**} | **vlan-id** *vlan-id* | **vlan-priority** *priority-number*}

### Syntax Description

<b>alternate-dns-server</b>	Specifies an alternate DNS server.
<i>ip-address</i>	The DNS server IP address. You also use this argument with the <b>preferred-dns-server</b> , <b>v4-addr</b> , and <b>v4-gateway</b> keywords. The format is X.X.X.X.
<b>dhcp-enabled</b>	Specifies whether DHCP is enabled or disabled on the server.
<b>no</b>	Specifies disable. Following are the uses of the <b>no</b> keyword: <ul style="list-style-type: none"> <li>Specifies that DHCP is not enabled when used with the <b>dhcp-enabled</b> keyword.</li> <li>Specifies that VLAN membership is not enabled when used with the <b>vlan-enabled</b> keyword.</li> </ul>
<b>yes</b>	Specifies enable. Following are the uses of the <b>yes</b> keyword: <ul style="list-style-type: none"> <li>Specifies that DHCP is enabled when used with the <b>dhcp-enabled</b> command.</li> <li>Specifies that encryption is enabled when used with the <b>vlan-enabled</b> command.</li> </ul>
<b>dns-use-dhcp</b>	Specifies that DNS addresses are retrieved via DHCP.
<b>hostname</b>	Specifies the server name.
<i>host-name</i>	The name of the server. The range of valid values is 1 to 63.
<b>mode</b>	Specifies the server NIC mode.
<b>dedicated</b>	Sets the server network mode to dedicated.
<b>shared-lom</b>	Sets the server network mode to shared LOM.
<b>shipping</b>	Sets the server network mode to shipping.
<b>preferred-dns-server</b>	Specifies the preferred DNS server.

<b>redundancy</b>	Specifies whether redundancy is enabled or disabled on the server.
<b>none</b>	Sets server redundancy to none.
<b>active-standby</b>	Sets server redundancy to active standby failover.
<b>v4-addr</b>	Sets the server IPv4 IP address.
<b>v4-gateway</b>	Sets the server IPv4 gateway.
<b>v4-netmask</b>	Sets the server IPv4 netmask.
<i>net-mask</i>	The IPv4 netmask. The format is X.X.X.X.
<b>vlan-enabled</b>	Specifies whether server to VLAN membership is enabled or disabled.
<b>vlan-id</b>	Sets the VLAN ID.
<i>vlan-id</i>	The identification number of the VLAN.
<b>vlan-priority</b>	Sets the VLAN priority.
<i>priority-number</i>	The priority number of the VLAN.

**Command Default** None

**Command Modes** Network (/cimc/network)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.0(1)	This command was introduced.
	1.0(1x)	The <b>shipping</b> keyword was introduced.

### Usage Guidelines

You must log in as a user with admin privileges to configure network properties.

**mode** — The CIMC network settings determine which ports can reach the CIMC. The following network mode options are available, depending on your platform:

- Dedicated—A connection to the CIMC is available through the management Ethernet port or ports.
- Shared LOM—A connection to the CIMC is available only through the LAN On Motherboard (LOM) Ethernet host ports.
- Shipping—A connection to the CIMC is available through the management Ethernet port or ports using a limited factory default configuration.



**Note**

In shared LOM mode, all host ports must belong to the same subnet.

**active-standby**—Active/standby failover lets you use a standby security appliance to take over the functionality of a failed unit. When the active unit fails, it changes to the standby state, while the standby unit changes to the active state. The appliance that becomes active assumes the IP addresses and MAC addresses of the failed unit and begins to pass traffic.

**vlan-enabled**—When you use the VLAN commands, you are committing your server to a membership in a particular VLAN. Following are the advantages of becoming a member of a VLAN:

- Provides traffic isolation, which leads to enhanced security.
- Reduces broadcast and multicast traffic, which leads to improved network performance.

**Examples**

This example shows how to enable DHCP:

```
server# scope cimc
server /cimc # scope network
server /cimc/network # set dhcp-enabled yes
server /cimc/network* # commit
server /cimc/network #
```

**Related Commands**

Command	Description
show dhcp	
show network	

## set (sol)

To set up SoL (Serial over LAN) on the server, use the **set** command in sol mode.

**set {baud-rate {9600 | 19200 | 38400 | 57600 | 115200} | enabled {no | yes}}**

### Syntax Description

<b>baud-rate</b>	Specifies the SoL baud rate.
<b>9600</b>	Sets baud rate to 9600 .
<b>19200</b>	Sets baud rate to 19200.
<b>38400</b>	Sets baud rate to 38400.
<b>57600</b>	Sets baud rate to 57600.
<b>115200</b>	Sets baud rate to 115200.
<b>enabled</b>	Specifies whether SoL is enabled or disabled.
<b>no</b>	Sets SoL to disabled.
<b>yes</b>	Sets SoL to enabled.

### Command Default

None

### Command Modes

Serial over LAN (/sol)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You must log in as a user with admin privileges to configure serial over LAN.

Serial over LAN (SoL) is a mechanism that enables the input and output of the serial port of a managed system to be redirected via an SSH session over IP. SoL provides a means of reaching the host console via CIMC.

For redirection to SoL, the server console must have the following configuration:

- Console redirection to serial port A
- No flow control
- Baud rate the same as configured for SoL
- VT-100 terminal type

- Legacy OS redirection disabled

The SoL session will display line-oriented information such as boot messages, and character-oriented screen menus such as BIOS setup menus. If the server boots an operating system or application with a bitmap-oriented display, such as Windows, the SoL session will no longer display. If the server boots a command-line-oriented operating system (OS), such as Linux, you may need to perform additional configuration of the OS in order to properly display in an SoL session.

In the SoL session, your keystrokes are transmitted to the console except for the function key F2. To send an F2 to the console, press the Escape key, then press 2.

## Examples

This example shows how to set the baud rate:

```
server# scope sol
server /sol # set baud-rate 115200
server /sol* # commit
server /sol #
```

## Related Commands

Command	Description
show sol	

## set (ssh)

To set up SSH (Secure Shell) services on the server, use the **set** command in ssh mode.

**set** {**enabled** {**no** | **yes**} | **ssh-port** *port-number* | **timeout** *time*}

### Syntax Description

<b>enabled</b>	Specifies whether SSH is enabled or disabled.
<b>no</b>	Sets SSH to disabled.
<b>yes</b>	Sets SSH to enabled.
<b>ssh-port</b>	Specifies the SSH port.
<i>port-number</i>	The SSH port number. The range of valid values is 1 to 65535.
<b>timeout</b>	Specifies the SSH connection timeout.
<i>time</i>	The wait time before a connection timeout, in seconds. The range of valid values is 60 to 10800.

### Command Default

None

### Command Modes

Secure Shell (/ssh)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You must log in as a user with admin privileges to configure SSH.

### Examples

This example shows how to set the SSH port number:

```
server# scope ssh
server /ssh # set ssh-port 22
server /ssh* # commit
server /ssh #
```

### Related Commands

Command	Description
show ssh	

## set (user)

To set up on the server, use the **set** command in user mode.

**set** {**enabled** {**no** | **yes**} | **name** *user-name* | **password** *password* | **role** {**admin** | **read-only** | **user**}}

### Syntax Description

<b>enabled</b>	Specifies whether user accounts are enabled or disabled.
<b>no</b>	Specifies that user accounts are not enabled.
<b>yes</b>	Specifies that user accounts are enabled.
<b>name</b>	Sets the name of the user.
<i>user-name</i>	The name of the user. The range of valid values is 1 to 70.
<b>password</b>	Sets up the password.
<i>password</i>	The password. The range of valid values is 1 to 80.
<b>role</b>	Sets up the users role.
<b>admin</b>	Sets the user role to admin.
<b>read-only</b>	Sets the user role to read-only.
<b>user</b>	Sets the user role to user.

### Command Default

None

### Command Modes

User (/user)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You must log in as a user with admin privileges to configure local users.

A user of the CLI will be one of three roles:

- **admin**—Configuration and control
- **user**—No configuration
- **read-only**—No configuration or control

To recover from a lost admin password, see the Cisco UCS C-Series server installation and service guide for your platform.

### Examples

This example shows how to enable user accounts:

```
server# scope user
server /user # set enabled yes
server /user* # commit
server /user #
```

### Related Commands

Command	Description
show user	
show user-session	

## set (vmedia)

To set up VMedia (virtual media) services on the server, use the **set** command in vmedia mode.

**set** {**enabled** {**no** | **yes**} | **encrypted** {**no** | **yes**}}

### Syntax Description

<b>enabled</b>	Specifies whether VMedia services are enabled or disabled.
<b>no</b>	Specifies disable. Following are the uses of the <b>no</b> keyword: <ul style="list-style-type: none"> <li>• Specifies that VMedia is disabled when used with the <b>enabled</b> keyword.</li> <li>• Specifies that encryption is disabled when used with the <b>encrypted</b> keyword.</li> </ul>
<b>yes</b>	Specifies that VMedia is enabled. Specifies enable. Following are the uses of the <b>yes</b> keyword: <ul style="list-style-type: none"> <li>• Specifies that VMedia is enabled when used with the <b>enabled</b> command.</li> <li>• Specifies that encryption is enabled when used with the <b>encrypted</b> command.</li> </ul>
<b>encrypted</b>	Sets up encryption for VMedia.

### Command Default

None

### Command Modes

Virtual media (/vmedia)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Usage Guidelines

You must log in as a user with admin privileges to configure virtual media.

### Examples

This example shows how to enable VMedia:

```
server# scope vmedia
server /vmedia # set enabled yes
server /vmedia* # commit
server /vmedia #
```

### Related Commands

Command	Description
show vmedia	

# set cli output

To change the CLI output, use the **set cli output** command.

**set cli output** {default | yaml}

## Syntax Description

<b>cli output</b>	Specifies server CLI output.
<b>default</b>	Sets CLI output to default.
<b>yaml</b>	Sets CLI output to YAML (Yet Another Markup Language).

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to change the CLI output to YAML:

```
server# set cli output yaml
CLI output format set to yaml
server#
```



## set path (tech-support)

To set the TFTP path, use the **set path** command in tech-support mode.

**set path** *tftp-path*

Syntax Description	<i>tftp-path</i>	The TFTP path.
--------------------	------------------	----------------

Command Default	None
-----------------	------

Command Modes	Technical support (/cimc/tech-support)
---------------	--

Command History	Release	Modification
	1.0(1)	This command was introduced.

Usage Guidelines	<p>Specifies the path to the support data file should be stored.</p> <p>Perform this task along with <b>set tftp-ip</b> when requested by the Cisco Technical Assistance Center (TAC). This utility creates a summary report containing configuration information, logs and diagnostic data that will help TAC in troubleshooting and resolving technical issues.</p>
------------------	---

Examples	<p>This example shows how to set the TFTP path:</p>
----------	---

```
server# scope cimc
server /cimc # scope tech-support
server /cimc/tech-support # set path /test/test.bin
server /cimc/tech-support* # commit
server /cimc/tech-support #
```

Related Commands	Command	Description
	set tftp-ip	
	show tech-support	

## set send-alert (pef)

To enable performance event filter alerts on the server, use the **set send-alert** command in pef mode.

**set send-alert** {no | yes}

### Syntax Description

<b>no</b>	Specifies that performance event filter alerts are not enabled.
<b>yes</b>	Specifies that performance event filter alerts are enabled.

### Command Default

None

### Command Modes

Performance event filters (/fault/pef)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to enable performance event filter alerts on the server:

```
server# scope fault
server /fault # scope pef
server /fault/pef # set send-alert yes
server /fault/pef* # commit
server /fault/pef #
```

### Related Commands

Command	Description
show pef	

## set tftp-ip (tech-support)

To set the TFTP server IP address, use the **set tftp-ip** command in tech-support mode.

**set tftp-ip** *ip-address*

Syntax Description	<i>ip-address</i>	The IP address of the TFTP server. The format is X.X.X.X.
--------------------	-------------------	---

Command Default	None
-----------------	------

Command Modes	Technical support (/cimc/tech-support)
---------------	--

Command History	Release	Modification
	1.0(1)	This command was introduced.

Usage Guidelines	<p>Specifies the IP address of the TFTP server on which the support data file should be stored.</p> <p>Perform this task along with <b>set path</b> when requested by the Cisco Technical Assistance Center (TAC). This utility creates a summary report containing configuration information, logs and diagnostic data that will help TAC in troubleshooting and resolving technical issues.</p>
------------------	---

Examples	<p>This example shows how to set the TFTP server IP address:</p>
----------	--

```
server# scope cimc
server /cimc # scope tech-support
server /cimc/tech-support # set tftp-ip 209.165.200.225
server /cimc/tech-support* # commit
server /cimc/tech-support #
```

Related Commands	Command	Description
	set tftp-path	
	show tech-support	

# show actual-boot-order (bios)

To display the actual boot order, use the **show actual-boot-order** command in bios mode.

**show actual-boot-order [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information about the actual boot order in list format.
---------------	--

## Command Default

None

## Command Modes

BIOS (/bios)

## Command History

Release	Modification
1.0(1x)	This command was introduced.

## Examples

This example shows how to display the actual boot order:

```
server# scope bios
server /bios # show actual-boot-order
```

Boot Order	Type	Boot Device
1	CD/DVD	CD-ROM
2	CD/DVD	Cisco Virtual CD/DVD 1.18
3	Network Device (PXE)	Cisco NIC 23:0.0
4	Network Device (PXE)	MBA v5.0.5 Slot 0100
5	Network Device (PXE)	MBA v5.0.5 Slot 0101
6	Network Device (PXE)	MBA v5.0.5 Slot 0200
7	Network Device (PXE)	MBA v5.0.5 Slot 0201
8	Network Device (PXE)	Cisco NIC 22:0.0
9	Internal EFI Shell	Internal EFI Shell
10	FDD	Cisco Virtual HDD 1.18
11	FDD	Cisco Virtual Floppy 1.18

```
server /bios #
```

## Related Commands

Command	Description
set boot-order	

# show bios

To display information about the BIOS, use the **show bios** command.

**show bios [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information about the bios, in list format.
---------------	--

## Command Default

None

## Command Modes

Root (server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Usage Guidelines

**show bios** displays the server boot order. **show bios detail** and **show detail** in bios mode displays the server boot order and firmware update/recovery information.

When you use the **detail** keyword, the boot order of the following available boot devices displays:

- CDRom—Bootable CD-ROM
- FDD—Floppy disk drive
- HDD—Hard disk drive
- PXE—PXE boot
- EFI—Extensible Firmware Interface

## Examples

This example shows how to display the server boot order:

```
server# show bios
Boot Order
-----
CDROM, FDD, HDD, PXE, EFI
server#
```

## Related Commands

Command	Description
set boot-order	
recover	

# show certificate

To display informaion about the server certificate, use the **show certificate** command.

**show certificate [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays the whole certificate.
---------------	--

## Command Default

None

## Command Modes

Root (server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Usage Guidelines

**show certificate** displays the serial number of the certificate, and the dates the certificate is valid for. **show certificate detail** in root mode and **show detail** in certificate mode displays the whole certificate.

## Examples

This example shows how to display the serial number of the certificate, and the dates the certificate is valid for:

```
server# show certificate
```

```
Serial Number   Valid From           Valid To
-----
001             Apr 13 13:49:00 2009 GMT Apr 11 13:49:00 2019 GMT
```

```
server#
```

This example shows how to display the whole certificate:

```
server# show certificate detail
```

```
Certificate Information:
  Serial Number: 00
  Subject Country Code (CC): US
  Subject State (S): California
  Subject Locality (L): San Jose
  Subject Organization (O): ABC Inc.
  Subject Organizational Unit (OU):
  Subject Common Name (CN): abcinc.com
  Issuer Country Code (CC): US
  Issuer State (S): California
  Issuer Locality (L): San Jose
  Issuer Organization (O): Cisco Systems Inc.
  Issuer Organizational Unit (OU):
  Issuer Common Name (CN): cisco.com
  Valid From: Sep  8 22:53:59 2009 GMT
  Valid To: Sep  6 22:53:59 2019 GMT
```

```
server#
```

**Related Commands**

Command	Description
generate-csr	
upload	

# show chassis

To display information about the chassis, use the **show chassis** command.

**show chassis [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information about the chassis, in list format.
---------------	---

## Command Default

None

## Command Modes

Root (server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Usage Guidelines

**show chassis** displays information about the chassis in table format. **show chassis detail** and **show detail** in chassis mode displays serial number, product name, PID, UUID, and description. Additionally, it displays chassis power state and the state of the locator LED.

## Examples

This example shows how to display information about the chassis in table format:

```
server# show chassis

Power Serial Number Product Name  UUID
-----
on     QTF-0934-00    R100-1120402  208F4277020FBADBADBEA80000DEAD00

server#
```

## Related Commands

Command	Description
set locator-led	



# show cimc

To display information about CIMC, use the **show cimc** command.

**show cimc [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information about CIMC, in list format.
---------------	--

## Command Default

None

## Command Modes

Root (server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Usage Guidelines

**show cimc** displays information about CIMC in table format. **show cimc detail** and **show detail** in cimc mode displays firmware version and boot loader version.

## Examples

This example shows how to display information about CIMC in table format:

```
server# show cimc
Firmware Version      Current Time
-----
1.0(0.86)             Fri Oct  2 12:19:17 2009
server#
```

## Related Commands

Command	Description
show firmware	
show log (cimc)	

# show configuration pending

To display uncommitted configuration commands, use the **show configuration pending** command.

## show configuration pending

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Any command mode

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example displays uncommitted configuration commands:

```
server /cimc/network *# show configuration pending

Modify /cimc/network
  hostname SanJoseServer3
  dhcp-enabled yes
  v4-addr 10.20.30.111
  dns-use-dhcp yes

server /cimc/network *#
```

### Related Commands

Command	Description
commit	
discard	

# show cpu (chassis)

To display information about the CPU, use the **show cpu** command in the chassis mode.

**show cpu [detail]**

<b>Syntax Description</b>	<b>detail</b> (Optional) Displays detailed information about the CPU, in list format.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Chassis (/chassis)				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>1.0(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	1.0(1)	This command was introduced.
Release	Modification				
1.0(1)	This command was introduced.				

**Usage Guidelines** **show cpu** displays a list of CPUs. **show cpu detail** displays information for each CPU .

Following are commands you use to manage your view of the list of CPUs:

- Enter key—Next line
- Space bar—Next page
- q key—Quit
- r key—Show the rest

## Examples

This example shows how to display detailed information about the CPUs:

```
server# scope chassis
server /chassis # show cpu detail

Name CPU1:
  Manufacturer: Intel(R) Corporation
  Family: Xeon
  Thread Count : 8
  Cores : 4
  Serial No.: Not Specified
  Version: Intel(R) Xeon(R) CPU L5520 @ 2.27GHz
  Speed (Mhz) : 2266
  Max. Speed (Mhz) : 4000
  Signature: "Signature: Type 0, Family 6, Model 26, Stepping 5
  Status: Enabled
Name CPU2:
  Manufacturer: Intel(R) Corporation
  Family: Xeon
  Thread Count : 8
  Cores : 4
  Serial No.: Not Specified
  Version: Intel(R) Xeon(R) CPU L5520 @ 2.27GHz
```

**show cpu (chassis)**

```
Speed (Mhz) : 2266
Max. Speed (Mhz) : 4000
Signature: "Signature: Type 0, Family 6, Model 26, Stepping 5
Status: Enabled
```

```
server /chassis #
```

**Related Commands**

Command	Description
show dimm	
show psu	

# show dimm (chassis)

To display information about the DIMMs (dual inline memory modules) in the chassis, use the **show dimm** command in chassis mode.

**show dimm [detail]**

Syntax Description	<b>detail</b> (Optional) Displays detailed information about the DIMMs, in list format.
--------------------	---

Command Default	None
-----------------	------

Command Modes	Chassis (/chassis)
---------------	--------------------

Command History	Release	Modification
	1.0(1)	This command was introduced.

**Usage Guidelines** **show dimm** displays a list of DIMMs. **show dimm detail** displays capacity, speed, and type for each DIMM.

Following are commands you use to manage your view of the list of DIMMs:

- Enter key—Next line
- Space bar—Next page
- q key—Quit
- r key—Show the rest

## Examples

This example shows how to display detailed information about the DIMMs:

```
server# scope chassis
server /chassis # show dimm detail
```

```
Name DIMM_A1:
  Capacity (MB): 2048
  Speed (MHz): 1067
  Type: Other
Name DIMM_A2:
  Capacity (MB): 0
  Speed (MHz): 1067
  Type: Other
Name DIMM_B1:
  Capacity (MB): 0
  Speed (MHz): 1067
  Type: Other
Name DIMM_B2:
  Capacity (MB): 0
  Speed (MHz): 1067
```

**show dimm (chassis)**

```
      Type: Other
Name DIMM_C1:
      Capacity (MB): 0
      Speed (MHz): 1067
      Type: Other
Name DIMM_C2:
      Capacity (MB): 0
      Speed (MHz): 1067
--More--
```

**Related Commands**

Command	Description
show cpu	

# show entries (log)

To display the CIMC event log, use the **show entries** command in log mode.

**show entries [detail]**

<b>Syntax Description</b>	<b>detail</b> (Optional) Displays the CIMC event log in detail.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Log (/cimc/log)				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>1.0(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	1.0(1)	This command was introduced.
Release	Modification				
1.0(1)	This command was introduced.				

**Usage Guidelines** **show entries** displays trace log entries in continuous string format. **show entries detail** displays time, source, and description for each trace log entry, in list format.

Following are commands you use to manipulate your view of the log:

- Enter key—Next line
- Space bar—Next page
- q key—Quit
- r key—Show the rest

## Examples

This example shows how to display the detailed event log:

```
server# scope cimc
server /cimc # scope log
server /cimc/log # show entries detail

Trace Log:
  Time: 1970 Jan 2 17:04:57
  Source: BMC:dropbear:-
  Description: " pam_session_manager(sshd:session): session (37) opened for user admin
from 10.21.115.69 by (uid=0) "
  Order: 0
Trace Log:
  Time: 1970 Jan 2 17:04:57
  Source: BMC:dropbear:-
  Description: " pam_auth_status(sshd:session): Login Successfull for user=admin,
host=10.21.115.69 "
  Order: 1
Trace Log:
  Time: 1970 Jan 2 17:04:57
  Source: BMC:dropbear:-
  Description: " pam_pass_if(sshd:session): unknown option: privilege=privIsLoginUser "
```

**show entries (log)**

```
Order: 2
Trace Log:
Time: 1970 Jan 2 17:04:57
Source: BMC:dropbear:-
Description: " pam_ldap_manager(sshd:auth): Start -----> "
Order: 3
--More--
```

**Related Commands**

Command	Description
show entries (sel)	



# show entries (sel)

To display the system event log, use the **show entries** command in sel mode.

**show entries** [**detail**]

## Syntax Description

<b>detail</b>	(Optional) Displays the system event log in detail.
---------------	---

## Command Default

None

## Command Modes

SEL (/sel )

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Usage Guidelines

**show entries** displays system event log entries in continuous strings. **show entries detail** displays time, source, and description for each system event log entry, in list format.

Following are commands you use to manipulate your view of the log:

- Enter key—Next line
- Space bar—Next page
- q key—Quit
- r key—Show the rest

## Examples

This example shows how to display the system event log:

```
server# scope sel
server /sel # show entries
```

Time	Severity	Description
[System Boot]	Informational	" LED_PSU_STATUS: Platform sensor, OFF event was asserted"
[System Boot]	Informational	" LED_HLTH_STATUS: Platform sensor, GREEN was asserted"
[System Boot]	Normal	" PSU_REDUNDANCY: PS Redundancy sensor, Fully Redundant was asserted"
[System Boot]	Normal	" PSU2 PSU2_STATUS: Power Supply sensor for PSU2, Power Supply input lost (AC/DC) was deasserted"
[System Boot]	Informational	" LED_PSU_STATUS: Platform sensor, ON event was asserted"
[System Boot]	Informational	" LED_HLTH_STATUS: Platform sensor, AMBER was asserted"
[System Boot]	Critical	" PSU_REDUNDANCY: PS Redundancy sensor, Redundancy Lost was asserted"
[System Boot]	Critical	" PSU2 PSU2_STATUS: Power Supply sensor for PSU2, Power Supply input lost (AC/DC) was asserted"
[System Boot]	Normal	" HDD_01_STATUS: Drive Slot sensor, Drive Presence was

**show entries (sel)**

```

asserted"
[System Boot]          Critical      " HDD_01_STATUS: Drive Slot sensor, Drive Presence was
deasserted"
[System Boot]          Informational " DDR3_P2_D1_INFO: Memory sensor, OFF event was asserted"

[System Boot]          Critical      " DDR3_P1_C2_PRS: Presence sensor, Device Removed / Device
Absent was asserted"
[System Boot]          Critical      " DDR3_P1_C1_PRS: Presence sensor, Device Removed / Device
Absent was asserted"
[System Boot]          Critical      " DDR3_P1_B2_PRS: Presence sensor, Device Removed / Device
Absent was asserted"
[System Boot]          Critical      " DDR3_P1_B1_PRS: Presence sensor, Device Removed / Device
Absent was asserted"
[System Boot]          Critical      " DDR3_P1_A2_PRS: Presence sensor, Device Removed / Device
Absent was asserted"
[System Boot]          Normal       " DDR3_P1_A1_PRS: Presence sensor, Device Inserted /
Device Present was asserted"
[System Boot]          Critical      " DDR3_P2_F2_PRS: Presence sensor, Device Removed / Device
Absent was asserted"
[System Boot]          Critical      " DDR3_P2_F1_PRS: Presence sensor, Device Removed / Device
Absent was asserted"
--More--

```

**Related Commands**

Command	Description
show entries (log)	

# show fan (sensor)

To display information about the fan sensors, use the **show fan** command in sensor mode.

**show fan [detail]**

## Syntax Description

**detail** (Optional) Displays .

## Command Default

None

## Command Modes

Sensor (/sensor)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to display information about the fan sensors:

```
Server# scope sensor
Server /sensor # show fan
```

Name	Sensor Status	Reading	Units	Min. Warning	Max. Warning
Min. Failure	Max. Failure				
PSU1_FAN_1	Normal	6592	RPM	N/A	N/A
N/A	N/A				
PSU2_FAN_1	Normal	2560	RPM	N/A	N/A
N/A	N/A				
W793_FAN1_TACH1	Normal	5300	RPM	N/A	N/A
800	N/A				
W793_FAN1_TACH2	Normal	5400	RPM	N/A	N/A
800	N/A				
W793_FAN2_TACH1	Normal	5500	RPM	N/A	N/A
800	N/A				
W793_FAN2_TACH2	Normal	5400	RPM	N/A	N/A
800	N/A				
W793_FAN3_TACH1	Normal	5300	RPM	N/A	N/A
800	N/A				
W793_FAN3_TACH2	Normal	5500	RPM	N/A	N/A
800	N/A				
W793_FAN4_TACH1	Normal	5300	RPM	N/A	N/A
800	N/A				
W793_FAN4_TACH2	Normal	5500	RPM	N/A	N/A
800	N/A				

--More--

```
Server /sensor # show fan detail
Name PSU1_FAN_1:
  Sensor Status: Normal
  Reading: 7872
  Units: RPM
  Min. Warning: N/A
  Max. Warning: N/A
  Min. Failure: N/A
```

**show fan (sensor)**

```

        Max. Failure: N/A
Name PSU2_FAN_1:
  Sensor Status: Normal
  Reading: 2496
  Units: RPM
  Min. Warning: N/A
  Max. Warning: N/A
  Min. Failure: N/A
  Max. Failure: N/A
Name W793_FAN1_TACH1:
  Sensor Status: Normal
  Reading: 5300
  Units: RPM
  Min. Warning: N/A
  Max. Warning: N/A
  Min. Failure: 800
  Max. Failure: N/A
Name W793_FAN1_TACH2:
  Sensor Status: Normal
  Reading: 5400
  Units: RPM
  Min. Warning: N/A
  Max. Warning: N/A
  Min. Failure: 800
  Max. Failure: N/A
Name W793_FAN2_TACH1:
  Sensor Status: Normal
  Reading: 5500
  Units: RPM
  Min. Warning: N/A
  Max. Warning: N/A
  Min. Failure: 800
  Max. Failure: N/A
Name W793_FAN2_TACH2:
  Sensor Status: Normal
--More--

```

**Related Commands**

Command	Description
show cpu	

# show fault

To display information about SNMP services on the server, use the **show fault** command.

**show fault [detail]**

Syntax Description	<table><tr><td>detail</td><td>(Optional) Displays detailed information about SNMP services, in list format.</td></tr></table>		detail	(Optional) Displays detailed information about SNMP services, in list format.				
detail	(Optional) Displays detailed information about SNMP services, in list format.							
Command Default	None							
Command Modes	Root (server#)							
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>1.0(1)</td><td>This command was introduced.</td></tr></table>		Release	Modification	1.0(1)	This command was introduced.		
Release	Modification							
1.0(1)	This command was introduced.							
Usage Guidelines	<b>show fault</b> displays information about SNMP services in table format. <b>show fault</b> , <b>show fault detail</b> , and <b>show detail</b> in fault mode display information about community strings and platform enabled events.							
Examples	<p>This example shows how to display SNMP services information in table format:</p> <pre>server# show fault  SNMP Community String Platform Event Enabled ----- 33West                  yes 34West                  no  server#</pre>							
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>show pef</td><td></td></tr><tr><td>show trap-destination</td><td></td></tr></table>		Command	Description	show pef		show trap-destination	
Command	Description							
show pef								
show trap-destination								

# show firmware (cimc)

To display information about the firmware on the server, use the **show firmware** command in cimc mode.

**show firmware** [**detail**]

Syntax Description	detail	(Optional) Displays detailed information about firmware, in list format.
--------------------	--------	--

Command Default	None
-----------------	------

Command Modes	CIMC (/cimc)
---------------	--------------

Command History	Release	Modification
	1.0(1)	This command was introduced.

Usage Guidelines	<b>show firmware</b> displays information about firmware in table format. <b>show firmware detail</b> and <b>show detail</b> in firmware mode display information about updates, firmware version, and boot loader version.
------------------	---

Examples	This example shows how to display information about updates, firmware version, and boot loader version:
----------	---

```
server# scope cimc
server /cimc # show firmware detail

Firmware Image Information:
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 1.0(0.86)
  FW Image 1 Version: 1.0(0.86)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 1.0(0.74)
  FW Image 2 State: BACKUP INACTIVATED

server /cimc #
```

Related Commands	Command	Description
	show cimc	
	show version	

# show hdd (chassis)

To display information about installed hard disk drives (HDD) in the chassis, use the **show hdd** command in chassis mode.

**show hdd [detail]**

<b>Syntax Description</b>	<b>detail</b> (Optional) Displays detailed information about the HDDs in list form.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Chassis (/chassis #)				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>1.0(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	1.0(1)	This command was introduced.
Release	Modification				
1.0(1)	This command was introduced.				

## Examples

This example shows how to display information about hard disk drives in the chassis:

```
Server# scope chassis
Server /chassis # show hdd
Name                               Status
-----
HDD_01_STATUS                     present
HDD_02_STATUS                     present
HDD_03_STATUS                     present
HDD_04_STATUS                     present

Server /chassis # show hdd detail
Name HDD_01_STATUS:
      Status : present
Name HDD_02_STATUS:
      Status : present
Name HDD_03_STATUS:
      Status : present
Name HDD_04_STATUS:
      Status : present

Server /chassis #
```

<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td>show psu</td><td></td></tr> </table>	Command	Description	show psu	
Command	Description				
show psu					

# show http

To display information about HTTP services on the server, use the **show http** command.

**show http [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information about HTTP services, in list format.
---------------	---

## Command Default

None

## Command Modes

Root (server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Usage Guidelines

**show http** displays HTTP information in table format. **show http detail** and **show detail** in http mode display information about HTTP ports, session timeout, and session activity.

## Examples

This example shows how to display information about HTTP services in table format:

```
server# show http

HTTP Port  HTTPS Port  Timeout  Active Sessions  Enabled
-----
80          443           1800      0                  yes

server#
```

## Related Commands

Command	Description
set http-port	
set https-port	



# show ipblocking (network)

To display information about the network IP blocking configuration, use the **show ipblocking** command in network mode.

**show ipblocking [detail]**

Syntax Description	<b>detail</b> (Optional) Displays detailed information about the IP blocking configuration in list format.
--------------------	--

Command Default	None
-----------------	------

Command Modes	IP blocking (/cimc/network)
---------------	-----------------------------

Command History	Release	Modification
	1.0(1)	This command was introduced.

## Examples

This example shows how to display information about the IP blocking configuration:

```
server# scope cimc
Server /cimc # scope network
server /cimc/network # show ipblocking detail
```

```
IP Blocking Setting:
  Enabled: no
  Fail Count: 5
  Fail Window: 60
  Blocking Time: 300
```

```
server /cimc/network #
```

Related Commands	Command	Description
	show network	

# show ipmi

To display information about the configuration and status of IPMI (Intelligent Platform Management Interface) on the server, use the **show ipmi** command.

**show ipmi [detail]**

Syntax Description	detail	(Optional) Displays detailed information about the configuration and status of IPMI on the server in list format.
--------------------	--------	---

Command Default	None
-----------------	------

Command Modes	Root (server#)
---------------	----------------

Command History	Release	Modification
	1.0(1)	This command was introduced.

## Examples

This example shows how to display information about the configuration and status of IPMI:

```
server# show ipmi detail

IPMI over LAN Settings:
  Enabled: yes
  Encryption Key: abcdef01234567890abcdef01234567890abcdef
  Privilege Level Limit: admin

server#
```

Related Commands	Command	Description
	set enabled (ipmi)	
	set encryption-key (ipmi)	

# show kvm

To display information about the KVM, use the **show kvm** command.

**show kvm [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information about the KVM in list format.
---------------	--

## Command Default

None

## Command Modes

Root (server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to display information about the KVM:

```
server# show kvm
```

Encryption Enabled	Local Video	Active Sessions	Enabled KVM Port
no	no	0	yes 2068

```
server#
```

## Related Commands

Command	Description
set kvm-port	
set max-sessions (kvm)	

# show ldap

To display information about the configuration and status of the Active Directory, use the **show ldap** command.

**show ldap [detail]**

Syntax Description	detail	(Optional) Displays detailed information about the configuration and status of the Active Directory in list format.
--------------------	--------	---

Command Default	None
-----------------	------

Command Modes	Root (server#)
---------------	----------------

Command History	Release	Modification
	1.0(1)	This command was introduced.

**Examples** This example shows how to display information about the configuration and status of the Active Directory:

```
server# show ldap detail

LDAP Settings:
  Server IP: 10.20.30.136
  BaseDN: example.com
  Encrypted: no
  Timeout: 60
  Enabled: no
  Attribute: CiscoAvPair

server#
```

Related Commands	Command	Description
	set server-ip (ldap)	
	set base-dn (ldap)	

## show led (chassis)

To display information about the server LEDs, use the **show led** command in the chassis command mode.

**show led** [**detail**]

<b>Syntax Description</b>	<b>detail</b> (Optional) Displays detailed information about the server LEDs in list format.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Chassis (/chassis)				
<b>Command History</b>	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>1.0(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	1.0(1)	This command was introduced.
Release	Modification				
1.0(1)	This command was introduced.				

### Examples

This example shows how to display information about the server LEDs:

```
server# scope chassis
server /chassis # show led
```

LED Name	LED State	LED Color
DDR3_P2_D1_INFO	OFF	AMBER
DDR3_P1_A1_INFO	OFF	RED
LED_HLTH_STATUS	ON	GREEN
LED_FPID	OFF	BLUE
LED_PSU_STATUS	OFF	AMBER
LED_DIMM_STATUS	ON	GREEN
LED_CPU_STATUS	ON	GREEN

<b>Related Commands</b>	<table><tr><th>Command</th><th>Description</th></tr><tr><td>set locator-led</td><td></td></tr></table>	Command	Description	set locator-led	
Command	Description				
set locator-led					

# show network (cimc)

To display information about the server network configuration, use the **show network** command in cimc mode.

**show network [detail]**

Syntax Description	detail	(Optional) Displays detailed information about the server network configuration in list format.
--------------------	--------	---

Command Default	None
-----------------	------

Command Modes	CIMC (/cimc)
---------------	--------------

Command History	Release	Modification
	1.0(1)	This command was introduced.

## Examples

This example shows how to display information about the server network configuration:

```
server# scope cimc
server /cimc # show network

DHCP Enabled VLAN Enabled
-----
no           no

server#
```

Related Commands	Command	Description
	set dhcp-enabled	
	show ipblocking	

## show pef (fault)

To display information about the configuration and status of PEFs (Platform Event Filters), use the **show pef** command in fault mode.

**show pef** [*pef-name*][**detail**]

### Syntax Description

<i>pef-number</i>	Displays information about the specified PEF. If the <i>pef-number</i> variable is omitted, the command displays information about all PEFs.
<b>detail</b>	(Optional) Displays detailed information in list form.

### Command Default

None

### Command Modes

Fault (/fault)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to display information about the configuration and status of all PEFs:

```
Server# scope fault
Server /fault # show pef
```

Platform	Event	Filter	Action	Send Alert
1	Temperature	Critical Assert Filter	none	no
2	Temperature	Warning Assert Filter	none	no
3	Voltage	Critical Assert Filter	none	no
4	Voltage	Warning Assert Filter	none	no
5	Current	Assert Filter	none	no
6	Fan	Critical Assert Filter	none	no
7	Fan	Warning Assert Filter	none	no
8	Processor	Assert Filter	none	no
9	Power Supply	Critical Assert Filter	none	no
10	Power Supply	Warning Assert Filter	none	no
11	Power Supply	Redundancy Lost Filter	none	no
12	Discrete Power Supply	Assert Filter	none	no
13	Memory	Assert Filter	none	no
14	Drive Slot	Assert Filter	none	no

```
server /fault #
```

### Related Commands

Command	Description
set platform-event-enabled	

## show psu (chassis)

To display information about the PSUs (power supply units), use the **show psu** command in chassis mode.

**show psu [detail]**

### Syntax Description

<b>detail</b>	(Optional) Displays detailed information about the PSUs in list format.
---------------	---

### Command Default

None

### Command Modes

Chassis (/chassis)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to display information about the chassis PSUs:

```
server# scope chassis
server /chassis # show psu detail
```

```
Name PSU1:
  In. Power (Watts): 103
  Out. Power (Watts): 0
  Firmware :
  Status : Present
```

```
server /chassis #
```

### Related Commands

Command	Description
show voltage	



# show psu (sensor)

To display information about the status of the PSU (power supply unit) sensors, use the **show psu** command in sensor mode.

**show psu [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information about the PSU sensors in list format.
---------------	--

## Command Default

None

## Command Modes

Sensor (/sensor)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to display information about the status of the PSU sensors:

```
server# scope sensor
server /sensor # show psu
```

Name Min. Failure	Sensor Status Max. Failure	Reading	Units	Min. Warning	Max. Warning
PSU1_POUT N/A	Normal 680	68	Watts	N/A	652
PSU1_PIN N/A	Normal 680	76	Watts	N/A	652
PSU1_STATUS	Normal	present			
PSU2_STATUS	Critical	absent			

```
server /sensor #
```

## Related Commands

Command	Description
show voltage	

# show psu-redundancy (sensor)

To display information about the status of PSU (power supply unit) redundancy, use the **show psu-redundancy** command in sensor mode.

**show psu-redundancy [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information about the status of PSU redundancy in list format.
---------------	---

## Command Default

None

## Command Modes

Sensor (/sensor)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to display information about the status of PSU redundancy:

```
server# scope sensor
server /sensor # show psu-redundancy detail
```

```
Name PSU_REDUNDANCY:
  Reading: full
  Sensor Status: Normal
```

```
server /sensor #
```

## Related Commands

Command	Description
show psu	

# show sol

To display information about the SoL (Serial over LAN) configuration, use the **show sol** command.

**show sol [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information about the SoL (serial over LAN) configuration in list format.
---------------	--

## Command Default

None

## Command Modes

Root (/server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to display information about the SoL configuration:

```
server# show sol detail
```

```
Serial Over LAN:
  Enabled: no
  Baud Rate(bps): 115200
```

```
server#
```

## Related Commands

Command	Description
set baud-rate	

# show ssh

To display information about the SSH (Secure Shell) configuration on the server, use the **show ssh** command.

**show ssh [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information about the SSH configuration in list format.
---------------	--

## Command Default

None

## Command Modes

Root (server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to display information about the SSH configuration:

```
server# show ssh detail
```

```
SSH Settings:
  SSH Port: 22
  Timeout: 10800
  Max Sessions: 4
  Active Sessions: 1
  Enabled: yes
```

```
server#
```

## Related Commands

Command	Description
set enabled (ssh)	
set ssh-port (ssh)	

# show tech-support (cimc)

To display information about the configuration of the tech-support utility, use the **show tech-support** command in cimc mode.

**show tech-support [detail]**

Syntax Description	<b>detail</b> (Optional) Displays detailed information about the configuration of the tech-support utility in list format.
--------------------	--

Command Default	None
-----------------	------

Command Modes	CIMC (/cimc)
---------------	--------------

Command History	Release	Modification
	1.0(1)	This command was introduced.

## Examples

This example shows how to display information about the configuration of the tech-support utility:

```
server# scope cimc
server /cimc # show tech-support detail
```

```
Tech Support:
  TFTP Server Address: 10.20.30.211
  TFTP Path: /user/tech-support
  Progress(%): 100
  Status: COMPLETED
```

```
server /cimc #
```

Related Commands	Command	Description
	set path (tech-support)	
	set tftp-ip (tech-support)	

# show temperature (sensor)

To display information about the status of the temperature sensors, use the **show temperature** command in sensor mode.

**show temperature** [**detail**]

<b>Syntax Description</b>	<b>detail</b> (Optional) Displays detailed information about the status of the temperature sensors in list format.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Sensor (/sensor)				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>1.0(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	1.0(1)	This command was introduced.
Release	Modification				
1.0(1)	This command was introduced.				

## Examples

This example shows how to display information about the status of the temperature sensors:

```
server# scope sensor
server /sensor # show temperature
```

Name	Sensor Status	Reading	Units	Min. Warning	Max. Warning
Min. Failure Max. Failure					
IOH_TEMP_SENS	Normal	42.0	C	N/A	80.0
N/A 85.0					
P2_TEMP_SENS	Normal	43.0	C	N/A	80.0
N/A 81.0					
P1_TEMP_SENS	Normal	45.0	C	N/A	80.0
N/A 81.0					
DDR3_P2_D1_TMP	Normal	28.0	C	N/A	90.0
N/A 95.0					
DDR3_P1_A1_TMP	Normal	30.0	C	N/A	90.0
N/A 95.0					
PSU1_TEMP_1	Normal	40.0	C	N/A	60.0
N/A 65.0					
PSU2_TEMP_1	Normal	40.0	C	N/A	60.0
N/A 65.0					
FP_AMBIENT_TEMP	Normal	22.0	C	N/A	40.0
N/A 45.0					

```
server /sensor #
```

## show trap-destination (fault)

To display information about SNMP trap destinations, use the **show trap-destination** command in fault mode.

**show trap-destination** [*trap-destination-number*] [**detail**]

### Syntax Description

<i>trap-destination-number</i>	Displays information about only the specified SNMP trap destination. If the <i>trap-destination-number</i> variable is omitted, displays information about all SNMP trap destinations.
<b>detail</b>	(Optional) Displays detailed information about SNMP trap destinations in list format.

### Command Default

None

### Command Modes

Fault (/fault)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to display information about the SNMP trap destinations:

```
server# scope fault
server /fault # show trap-destination

Trap Destination IP Address      Enabled
-----
1                209.165.200.225    yes
2                0.0.0.0              no
3                0.0.0.0              no
4                0.0.0.0              no

server /fault #
```

### Related Commands

Command	Description
set addr (trap-destination)	

# show user

To display information about user profiles on the server, use the **show user** command.

**show user** [*user-number*] [**detail**]

## Syntax Description

<i>user-number</i>	(Optional) Displays only the specified user profile. If the <i>user-number</i> variable is omitted, displays all user profiles.
<b>detail</b>	(Optional) Displays detailed information in list form.

## Command Default

None

## Command Modes

Root (server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to display information about all user profiles:

```
server# show user
```

User	Name	Role	Enabled
1	admin	admin	yes
2	jsmith	admin	yes
3	(n/a)	(n/a)	no
4	(n/a)	(n/a)	no
5	bjones	readonly	yes
6	(n/a)	(n/a)	no
7	(n/a)	(n/a)	no
8	(n/a)	(n/a)	no
9	(n/a)	(n/a)	no
10	(n/a)	(n/a)	no
11	(n/a)	(n/a)	no
12	(n/a)	(n/a)	no
13	(n/a)	(n/a)	no
14	(n/a)	(n/a)	no
15	(n/a)	(n/a)	no

```
server#
```

## Related Commands

Command	Description
set enabled (user)	
set name (user)	



# show user-session

To display information about current user sessions, use the **show user-session** command.

**show user-session** [*session-number*] [**detail**]

## Syntax Description

<i>session-number</i>	Displays information about a specific session.
<b>detail</b>	(Optional) Displays detailed information about current user sessions in list format.

## Command Default

None

## Command Modes

Root (server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to display user session information for all current user sessions:

```
server# show user-session
```

ID	Name	IP Address	Type	Killable
4	admin	10.20.30.123	CLI	yes
2	admin	10.20.30.185	vKVM	yes
5	read-only	10.20.30.187	CLI	no

```
server#
```

This example shows how to display user session information about a specific user session:

```
server# show user-session 2
```

ID	Name	IP Address	Type	Killable
2	admin	10.20.30.185	vKVM	yes

```
server#
```

## Related Commands

Command	Description
show user	

# show version

To display the version number of the running firmware, use the **show version** command.

**show version [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays the version number of the running firmware in list format.
---------------	--

## Command Default

None

## Command Modes

Root (server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to display the version of the running firmware:

```
server# show version

Firmware Version
-----
1.0 (0.82)

server#
```

## Related Commands

Command	Description
activate (firmware)	

# show vmedia

To display information about the status and configuration of virtual media, use the **show vmedia** command.

**show vmedia [detail]**

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information about the status and configuration of virtual media in list format.
---------------	--

## Command Default

None

## Command Modes

Root (server#)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to display information about the status and configuration of virtual media:

```
server# show vmedia
Encryption Enabled Active Sessions
-----
no                        0
server#
```

## Related Commands

Command	Description
set encryption (vmedia)	

# start

To start the technical support process, use the **start** command.

## start

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Technical support (/cimc/tech-support)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to start the technical support process:

```
server# scope cimc
server /cimc # scope tech-support
server /cimc/tech-support # start
Tech Support upload started.
server /cimc/tech-support #
```

### Related Commands

Command	Description
cancel	

# terminate (user-session)

To terminate a CLI session, use the **terminate** command in user-session mode.

## terminate

This command has no arguments or keywords.

### Command Default

None

### Command Modes

User session (/user-session)

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to terminate a CLI session:

```
server# scope user-session  
server /user-session # terminate
```

### Related Commands

Command	Description
show user-session	

# top

To return to root mode from any other mode, use the **top** command.

## top

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Any command mode

### Command History

Release	Modification
1.0(1)	This command was introduced.

### Examples

This example shows how to enter root mode from log mode:

```
server /cimc/log # top
server#
```

### Related Commands

Command	Description
exit	

# update (firmware)

To update server firmware, use the **update** command.

**update** *ip-address file-path*

## Syntax Description

<i>ip-address</i>	The IP address of the TFTP server. The format is X.X.X.X.
<i>file-path</i>	The path to the update file on the TFTP server.

## Command Default

None

## Command Modes

Firmware (/cimc/firmware)

## Command History

Release	Modification
1.0(1)	This command was introduced.

## Examples

This example shows how to update server firmware:

```
server# scope cimc
server /cimc # scope firmware
server /cimc/firmware # update 209.165.200.225 //test/cimc66-78.bin
<CR> Press Enter key
Firmware update has started.
Please check the status using "show detail"
server /cimc/firmware #
```

## Related Commands

Command	Description
show cimc	
show version	

# upload (certificate)

To upload a certificate, use the **upload** command in certificate mode.

This command has no arguments or keywords.

## Command Default

None

## Command Modes

Certificate (/certificate)

## Command History

Release	Modification
1.0(1x)	This command was introduced.

## Examples

This example shows how to upload a certificate:

```
server# scope certificate
server /certificate # upload
Please paste your certificate here, when finished, press CTRL+D.

MIIB0TCCAToCAQAwbDELMAkGA1UEBhMCVVMxCzAJBgNVBAGTAkNBMQ0wCwYDVQQH
EwRoZXJlMQwwCgYDVQQKEwN0aW0xCzAJBgNVBAsTAjAxMQwwCgYDVQQDEwNib2Ix
GDAWBgkqhkiG9w0BCQEWCW1lQG1lLmNvbTCBnzANBgkqhkiG9w0BAQEFAAOBjQAw
gYkCgYEAw49pYuDXd0fHtXwBT7k5kX1set/I3e8TtkuO/EQ5HVd9HrPIy4Kpb3Oj
33CkqjysVWBpPSGzWA1EL6cZYs5p6JxR74+tgW5BYpNKRLNFawpsTZvCXhe/n/O2
WYsxlFnWlm6BgQnPKCBCp9R1ESmq9Np24r2c3PEStZEjeIVWbaUCAwEAAaAlMCMG
CSqGSIB3DQEBJBzEWEeXRBIGNoYWxsZW5nZSBwYXNzd29yZDANBgkqhkiG9w0BAQUF
AAOBgQBosXif9feLXHBK19kqeVZ8uqRgoMlcM03aBTImjIO1RgwhRLuMrG2l+thA
CT+fbYOYXJ4bHsn25XQjcsdG0uxsti3C2SnK83nKdulpEzBzj545rvH20QK+RtHN
YUBEKvABCeQoIUu+ErMtGvryaQw7WQiQjWf+RTf8IXDGShIQwQ==

server /certificate #
```

## Related Commands

Command	Description
generate-csr (certificate)	
show certificate	