



Managing the Toolbar

- [Managing Server Power, on page 1](#)
- [Pinging a Hostname or IP Address from the Web UI, on page 2](#)
- [Launching vKVM, on page 2](#)
- [Rebooting CIMC, on page 3](#)

Managing Server Power

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

Step 1 In the **Toolbar** menu, click the **Host Power** link.

Step 2 Select from the following drop-down options:

Name	Description
Power On	Powers on the server.
Power Off	Powers off the server, even if tasks are running on that server. Note If any firmware or BIOS updates are in progress, do not power off or reset the server until those tasks are complete.
Power Cycle	Powers off and powers on the server.
Hard Reset	Reboots the server.
Shut Down	Shuts down the server if the operating system supports that feature.

Pinging a Hostname or IP Address from the Web UI

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

Step 1 In the **Toolbar** menu, click the **Ping** icon.

Step 2 In the **Ping Details** dialog box, update the following fields:

Name	Description
* Hostname/IPAddress field	Hostname or IP address you want to reach out to.
* Number of Retries field	The maximum number of retries allowed to ping the IP address. The default value is 3. The valid range is from 1 to 10.
* Timeout field	The maximum response time for a pinging activity. The default value is 10 seconds. The valid range is from 1 to 20 seconds.
Ping Status field	Displays results of the pinging activity.
Details button	Displays details of the pinging activity.
Ping button	Pings the IP address.
Cancel button	Closes the dialog box without pinging.

Launching vKVM

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

Step 1 To launch the console from **CIMC Home** page, click the **Launch vKVM** link in the toolbar.

Step 2 Alternatively, in the **Navigation** pane, click the **Compute** menu.

Step 3 In the **Compute** menu work pane, click the **RemoteManagement** tab.

Step 4 In the **Remote Management** pane, click the **Virtual KVM** tab.

Step 5 In the **Virtual KVM** tab, click the **Launchv KVM** link.

Step 6 Click the URL link displayed in the pop-up window (HTML based KVM console only) to load the client application.

Note You must click the link every time you launch the KVM console.

Step 7

Rebooting CIMC

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

Step 1 In the **Toolbar** menu, click the **CIMC Reboot** link.

Step 2 In the dialog box, click **OK** to proceed with the reboot, or click **Cancel** to cancel.

If you reboot, CIMC will be unavailable for the duration of the reboot. You must login again after the reboot is complete.
