



Preface

This preface includes the following sections:

- [Audience, page i](#)
- [Organization, page i](#)
- [Conventions, page ii](#)
- [Related Documentation, page iii](#)
- [Documentation Feedback , page iii](#)
- [Obtaining Documentation and Submitting a Service Request , page iii](#)

Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in one or more of the following:

- Server administration
- Storage administration
- Network administration
- Network security

Organization

This document includes the following chapters:

| Title | Description |
|--|---|
| Overview of Cisco Unified Computing System | Describes the Cisco Unified Computing System (Cisco UCS). |

| Title | Description |
|-----------------------------------|--|
| Overview of Cisco UCS Manager | Describes the management service for the components in a Cisco UCS instance. |
| Overview of Cisco UCS Manager CLI | Describes the command line interface (CLI) of the Cisco UCS Manager. |
| Commands | Describes the CLI commands. |

Conventions

This document uses the following conventions:

| Convention | Indication |
|---------------------------|---|
| bold font | Commands, keywords, GUI elements, and user-entered text appear in bold font . |
| <i>italic font</i> | Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> . |
| [] | Elements in square brackets are optional. |
| {x y z} | Required alternative keywords are grouped in braces and separated by vertical bars. |
| [x y z] | Optional alternative keywords are grouped in brackets and separated by vertical bars. |
| string | A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks. |
| <code>courier font</code> | Terminal sessions and information the system displays appear in <code>courier font</code> . |
| <> | Nonprinting characters such as passwords are in angle brackets. |
| [] | Default responses to system prompts are in square brackets. |
| !, # | An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line. |



Note

Means *reader take note*.

**Tip**

Means *the following information will help you solve a problem.*

**Caution**

Means *reader be careful.* In this situation, you might perform an action that could result in equipment damage or loss of data.

**Timesaver**

Means *the described action saves time.* You can save time by performing the action described in the paragraph.

**Warning**

Means *reader be warned.* In this situation, you might perform an action that could result in bodily injury.

Related Documentation

Documentation for Cisco UCS C-Series Rack-Mount Servers is available at the following URL:

<http://www.cisco.com>

The following documents pertain to the C-Series Rack-Mount Servers:

- *UCS Rack Servers Documentation Roadmap*
- *Cisco UCS C-Series Rack-Mount Servers Configuration Guide*
- *Cisco UCS C-Series Rack-Mount Servers CLI Configuration Guide*
- *Cisco UCS C-Series Rack-Mount Servers Command Reference*
- *Cisco UCS C200 M1 Server Installation and Service Guide*
- *Release Notes for Cisco UCS C-Series Rack-Mount Servers*
- *Regulatory Compliance and Safety Information for Cisco UCS*

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to ucs-docfeedback@cisco.com. We appreciate your feedback.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly What's New in Cisco Product Documentation, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.