

Managing the Capability Catalog in Cisco UCS Central

This chapter includes the following sections:

- Capability Catalog, page 1
- Configuring a Capability Catalog Upgrade, page 2
- Viewing a Capability Catalog in a Domain Group, page 3

Capability Catalog

The Capability Catalog is a set of tunable parameters, strings, and rules. Cisco UCS uses the catalog to update the display and configurability of components such as newly qualified DIMMs and disk drives for servers.

The catalog is divided by hardware components, such as the chassis, CPU, local disk, and I/O module. You can use the catalog to view the list of providers available for that component. There is one provider per hardware component. Each provider is identified by the vendor, model (PID), and revision. For each provider, you can also view details of the equipment manufacturer and the form factor.

For information about which hardware components are dependent upon a particular catalog release, see the component support tables in the Service Notes for the B- Series servers. For information about which components are introduced in a specific release, see the Cisco UCS Release Notes.

Contents of the Capability Catalog

The contents of the Capability Catalog include the following:

Implementation-Specific Tunable Parameters

- · Power and thermal constraints
- Slot ranges and numbering
- · Adapter capacities

Hardware-Specific Rules

- Firmware compatibility for components such as the BIOS, CIMC, RAID controller, and adapters
- Diagnostics
- Hardware-specific reboot

User Display Strings

- Part numbers, such as the CPN, PID/VID
- Component descriptions
- · Physical layout/dimensions
- OEM information

Updates to the Capability Catalog

The Cisco UCS Infrastructure Software Bundle includes capability catalog updates. Unless otherwise instructed by Cisco Technical Assistance Center, you only need to activate the capability catalog update after you've downloaded, updated, and activated a Cisco UCS Infrastructure Software Bundle.

As soon as you activate a capability catalog update, Cisco UCS immediately updates to the new baseline catalog. You do not have to perform any further tasks. Updates to the capability catalog do not require you to reboot or reinstall any component in a Cisco UCS domain.

Each Cisco UCS Infrastructure Software Bundle contains a baseline catalog. In rare circumstances, Cisco releases an update to the capability catalog between Cisco UCS releases and makes it available on the same site where you download firmware images.

For information about capability catalog releases supported by specific Cisco UCS releases, see the *Release Notes for Cisco UCS Software* accessible through the *Cisco UCS B-Series Servers Documentation Roadmap* available at the following URL: http://www.cisco.com/go/unifiedcomputing/b-series-doc.

Configuring a Capability Catalog Upgrade

Procedure

	Command or Action	Purpose
Step 1	UCSC# connect policy-mgr	Enters policy manager mode.
Step 2	UCSC(policy-mgr) # scope domain-group domain-group	Enters domain group root mode and (optionally) enters a sub-domain group under the domain group root. To enter the domain group root mode, type / as the <i>domain-group</i> .

	Command or Action	Purpose
Step 3	UCSC(policy-mgr)/domain-group# scope fw-catalog-pack	Enters the capability catalog packages mode.
Step 4	UCSC(policy-mgr) /domain-group/fw-catalog-pack # set catalogversion < catalogversion>	Specifies the capability catalog version for this update.
Step 5	UCSC(policy-mgr) /domain-group/fw-catalog-pack* # commit-buffer	Commits the transaction to the system.

The following example shows how to configure a capability catalog update for a domain group from Cisco UCS Central:

UCSC# connect policy-mgr UCSC(policy-mgr) /domain-group # fw-catalog-pack UCSC(policy-mgr) /domain-group/fw-catalog-pack # set catalogversion 3.0(0.163)A UCSC(policy-mgr) /domain-group* # commit-buffer UCSC(policy-mgr) /domain-group*

Viewing a Capability Catalog in a Domain Group

	Command or Action	Purpose
Step 1	UCSC# connect policy-mgr	Enters policy manager mode.
Step 2	UCSC(policy-mgr) # scope domain-group domain-group	Enters domain group root mode and (optionally) enters a sub-domain group under the domain group root. To enter the domain group root mode, type / as the <i>domain-group</i> .
Step 3	UCSC(policy-mgr)/domain-group# scope fw-catalog-pack <i>default</i>	Enters the capability catalog packages mode.
Step 4	UCSC(policy-mgr) /domain-group/fw-catalog-pack # show detail	Specifies the capability catalog version for this update.

Procedure

I

The following example shows how to view the capability catalog in a domain group from Cisco UCS Central CLI:

```
UCSC# connect policy-mgr
UCSC(policy-mgr) /domain-group # fw-catalog-pack default
UCSC(policy-mgr) /domain-group/fw-catalog-pack # show detail
Catalog Pack:
Name: root/default
Mode: Staged
Catalog Version: 3.0(0.163)T
```

1

Description: default
UCSC(policy-mgr) /domain-group* #