



Cisco UCS Manager Add-in Settings and Troubleshooting

This chapter includes the following section:

- [Using the Cisco UCS Manager Add-in Settings Option, page 1](#)
- [Troubleshooting and Common Errors, page 2](#)

Using the Cisco UCS Manager Add-in Settings Option

The settings option is available as the last top level node in the context tree. The following procedure includes steps to set the parameters:

Procedure

- Step 1** On the toolbar, click **Cisco UCS Manager**.
- Step 2** In the navigation pane, click **Add-in Settings**.
The Settings dialog box appears.
- Step 3** In the **Refresh Timer Interval (>=1)** field, enter the refresh time interval you want to set.
The time interval range is 1 to 1440 minutes. The default is 5 minutes. This time interval controls how often the information on the selected view in the add-in is refreshed.
- Step 4** Select an option for which you want to save the log files from the **Logging Mode** drop-down list.
The default value is **INFO**.
- Step 5** In the **Log File Size (1-100)** field, enter a number to set the size of the error log.
The default value is 10 MB. This is the size of the log file. If the log exceeds the set file size, a new file is created with a suffix that starts with one and increments by one for the subsequent files.
- Step 6** **Log File Path** indicates the path where the log files are saved.
The log file parameters are set and the log will be saved at a location indicated in the Log File Path.
- Step 7** (Optional) Click **Reset To Defaults** if you want to reset the values to defaults, and click **Apply** to commit these changes.

Note **Reset To Defaults** option is clickable when you modified the **Refresh Timer Interval (>=1)**, **Logging Mode**, or **Log File Size (1-100)** values.

Step 8 In the **Proxy Settings** area, follow these steps:

- To use the system proxy settings, click **Use System Proxy Settings** radio button and click **Apply**.
- To specify proxy settings applicable to all registered UCS Domains within the add-in, click **Use Add-in Proxy Settings** radio button and enter the following details:

Field	Description
Address	IP address or host name of the proxy server.
Username	Username of the proxy server.
Password	Password of the proxy server.
Port	Port number of the proxy server.

Step 9 Click **Apply**.

Troubleshooting and Common Errors

Troubleshooting

The log file parameters are set using the settings option available with the add-in and the log file is saved at a location indicated in the Log File Path. For any issues in the add-in, contact Cisco Technical Assistance Center (TAC) with the archived log files.

Common Errors and Resolutions

If you encounter any issues while installing the add-in indicating missing dll files, you can resolve these issues by ensuring you have read and write permissions for the `..\Program Files\Microsoft System Center 2012\Virtual Machine Manager\bin\AddInPipeline` folder (folder that runs the VMM Console) on your machine.