



Cisco UCS Central Storage Management Guide, Release 1.4

First Published: December 17, 2015

Last Modified: December 24, 2015

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2015 Cisco Systems, Inc. All rights reserved.



CONTENTS

Preface

Preface vii

Audience vii

Conventions vii

Related Cisco UCS Documentation ix

Documentation Feedback ix

CHAPTER 1

Overview 1

Overview 1

Cisco UCS Central User Documentation Reference 1

CHAPTER 2

Ports and Port Channels 3

Server and Uplink Ports 3

Unified Ports 4

Unified Storage Ports 4

Unified Uplink Ports 5

Port Modes 5

Effect of Port Mode Changes on Data Traffic 5

Port Roles 6

Guidelines for Configuring Unified Ports 7

Cautions and Guidelines for Configuring Unified Uplink Ports and Unified Storage Ports 7

Configuring Unified Ports 8

Configuring Ports 9

Configuring an Appliance Port 9

Configuring an FCoE Storage Port 11

Configuring an FCoE Uplink Port 11

Configuring a Server Port 12

Configuring an Uplink Port 12

- Configuring an FC Storage Port 13
- Configuring an FC Uplink Port 14
- Scalability and Breakout Ports 14
- Managing Configured Ports 15
- Creating a Port Channel 15
 - Creating an Ethernet Port Channel 16
 - Creating an FC Port Channel 16
 - Creating an FCoE Port Channel 17
 - Creating an Appliance Port Channel 17
- Fibre Channel Switching Mode 18
 - Configuring Fibre Channel Switching Mode 18
- Pin Groups 19
 - Creating a Pin Group 20
- Viewing Port Configuration Status 21

CHAPTER 3**Global VSAN 23**

- Global VSANs 23
 - Creating or Editing a VSAN 23

CHAPTER 4**vHBA Management 25**

- vHBA Overview 25
 - Creating or Editing a vHBA Template 25
 - Host Interface Placement Policy 26
 - Creating or Editing a Host Interface Placement Policy 26
 - vHBA to vCon Assignment ? To Be Added 26
 - Default vHBA Behavior Policy - To Be Added 26

CHAPTER 5**Storage Pools 27**

- WWN Pools 27
 - Creating and Editing a WWN Pool 28
 - Deleting a Pool 29

CHAPTER 6**Storage Policies 31**

- Fibre Channel Adapter Policy 31
 - Creating or Editing a Fibre Channel Adapter Policy 32

SAN Connectivity Policy	33
Creating or Editing a SAN Connectivity Policy	33
Storage Connection Policy	33
Creating or Editing a Storage Connection Policy	33
Fibre Channel Zoning	34
Configuring Zoning	35
Direct-Attached Storage	35
Configuring Direct-Attached Storage	35

CHAPTER 7**Storage Profiles 37**

Storage Profiles	37
Virtual Drives	37
Virtual Drive Naming	39
RAID Levels	39
Supported LUN Modifications	40
Unsupported LUN Modifications	40
LUN Dereferencing	41
Creating or Editing a Storage Profile	41
Disk Groups and Disk Group Configuration Policies	42
Creating or Editing a Disk Group Configuration Policy	42



Preface

- [Audience, page vii](#)
- [Conventions, page vii](#)
- [Related Cisco UCS Documentation, page ix](#)
- [Documentation Feedback, page ix](#)

Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in one or more of the following:

- Server administration
- Storage administration
- Network administration
- Network security

Conventions

Text Type	Indication
GUI elements	GUI elements such as tab titles, area names, and field labels appear in this font . Main titles such as window, dialog box, and wizard titles appear in this font .
Document titles	Document titles appear in <i>this font</i> .
TUI elements	In a Text-based User Interface, text the system displays appears in <code>this font</code> .
System output	Terminal sessions and information that the system displays appear in <code>this font</code> .

Text Type	Indication
CLI commands	CLI command keywords appear in this font . Variables in a CLI command appear in <i>this font</i> .
[]	Elements in square brackets are optional.
{x y z}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

**Note**

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the document.

**Tip**

Means *the following information will help you solve a problem*. The tips information might not be troubleshooting or even an action, but could be useful information, similar to a Timesaver.

**Caution**

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.

**Timesaver**

Means *the described action saves time*. You can save time by performing the action described in the paragraph.

**Warning****IMPORTANT SAFETY INSTRUCTIONS**

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

Related Cisco UCS Documentation

Documentation Roadmaps

For a complete list of all B-Series documentation, see the *Cisco UCS B-Series Servers Documentation Roadmap* available at the following URL: <http://www.cisco.com/go/unifiedcomputing/b-series-doc>.

For a complete list of all C-Series documentation, see the *Cisco UCS C-Series Servers Documentation Roadmap* available at the following URL: <http://www.cisco.com/go/unifiedcomputing/c-series-doc>.

For information on supported firmware versions and supported UCS Manager versions for the rack servers that are integrated with the UCS Manager for management, refer to [Release Bundle Contents for Cisco UCS Software](#).

Other Documentation Resources

Follow [Cisco UCS Docs on Twitter](#) to receive document update notifications.

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to ucs-docfeedback@cisco.com. We appreciate your feedback.



Overview

- [Overview, page 1](#)
- [Cisco UCS Central User Documentation Reference, page 1](#)

Overview

This guide contains conceptual and procedural information on the following components that are intrinsic to Cisco UCS Central storage management:

- Ports and port channels
- SAN and VSAN
- vHBA
- Storage Pools
- Storage Policies
- Storage Profiles

Cisco UCS Central User Documentation Reference

Beginning with Release 1.4, the Cisco UCS Central user guide has been divided into several use case-based documents. You can use the appropriate guide to understand and configure Cisco UCS Central.

Guide	Description
Cisco UCS Central Getting Started Guide	Provides a brief introduction to the Cisco UCS infrastructure, Cisco UCS Manager, and Cisco UCS Central. Includes an overview of the HTML5 UI, how to register Cisco UCS domains in Cisco UCS Central, and how to activate licenses.

Guide	Description
Cisco UCS Central Administration Guide	Provides information on administrative tasks, such as user management, communication, firmware management, backup management, and Smart Call Home.
Cisco UCS Central Authentication Guide	Provides information on authentication tasks, such as passwords, users and roles, RBAC, TACACS+, RADIUS, LDAP, and SNMP.
Cisco UCS Central Server Management Guide	Provides information on server management, such as equipment policies, physical inventory, service profiles and templates, server pools, server boot, and server policies.
Cisco UCS Central Storage Management Guide	Provides information on storage management, such as ports and port channels, VSAN and vHBA management, storage pools, storage policies, storage profiles, disk groups, and disk group configuration.
Cisco UCS Central Network Management Guide	Provides information on network management, such as ports and port channels, VLAN and vNIC management, network pools, and network policies.



CHAPTER 2

Ports and Port Channels

- [Server and Uplink Ports, page 3](#)
- [Unified Ports, page 4](#)
- [Port Modes, page 5](#)
- [Port Roles, page 6](#)
- [Guidelines for Configuring Unified Ports, page 7](#)
- [Configuring Unified Ports, page 8](#)
- [Configuring Ports, page 9](#)
- [Scalability and Breakout Ports, page 14](#)
- [Managing Configured Ports, page 15](#)
- [Creating a Port Channel, page 15](#)
- [Fibre Channel Switching Mode, page 18](#)
- [Pin Groups, page 19](#)
- [Viewing Port Configuration Status, page 21](#)

Server and Uplink Ports

Each fabric interconnect can include the following port types:

Server Ports

Server ports handle data traffic between the fabric interconnect and the adapter cards on the servers.

You can only configure server ports on the fixed port module. Expansion modules do not include server ports.

Uplink Ethernet Ports

Uplink Ethernet ports handle Ethernet traffic between the fabric interconnect and the next layer of the network. All network-bound Ethernet traffic is pinned to one of these ports.

By default, Ethernet ports are unconfigured. However, you can configure them to function in the following ways:

- Uplink
- FCoE
- Appliance

You can configure uplink Ethernet ports on either the fixed module or an expansion module.

Uplink Fibre Channel Ports

Uplink Fibre Channel ports handle FCoE traffic between the fabric interconnect and the next layer of the storage area network. All network-bound FCoE traffic is pinned to one of these ports.

By default, Fibre Channel ports are uplink. However, you can configure them to function as Fibre Channel storage ports. This is useful in cases where Cisco UCS requires a connection to a Direct-Attached Storage (DAS) device.

You can only configure uplink Fibre Channel ports on an expansion module. The fixed module does not include uplink Fibre Channel ports.

Unified Ports

All ports on the Cisco UCS 6200 Series Fabric Interconnect and above are unified, and can be configured to carry either Ethernet or Fibre Channel traffic. These ports are not reserved. A Cisco UCS domain cannot use these ports until you configure them.

**Note**

When you configure a port on a fabric interconnect, the administrative state is automatically set to enabled. If the port is connected to another device, this may cause traffic disruption. You can disable the port after configuring it.

Unified Storage Ports

Unified storage is configuring the same physical port as an Ethernet storage interface and FCoE storage interface. You can configure any appliance port or FCoE storage port as a unified storage port on either a fixed module or an expansion module. To configure a unified storage port, the fabric interconnect must be in Fibre Channel switching mode.

In a unified storage port, you can enable/disable individual FCoE storage or appliance interfaces.

- In a unified storage port, if you do not specify a non default VLAN for the appliance port the fcoe-storage-native-vlan will be assigned as the native VLAN on the unified storage port. If the appliance port has a non default native VLAN specified as native VLAN, this will be assigned as the native VLAN for unified storage port.

- When you enable or disable the appliance interface, the corresponding physical port is enabled/disabled. So when you disable the appliance interface in a unified storage, even if the FCoE storage is enabled, it goes down with the physical port.
- When you enable or disable FCoE storage interface, the corresponding VFC is enabled or disabled. So when the FCoE storage interface is disabled in a unified storage port, the appliance interface will continue to function normally.

Unified Uplink Ports

When you configure an Ethernet uplink and an FCoE uplink on the same physical Ethernet port, it is called the unified uplink port. You can individually enable or disable either FCoE or Ethernet interfaces independently.

- Enabling or disabling the FCoE uplink results in corresponding VFC being enabled or disabled.
- Enabling or disabling an Ethernet uplink results in corresponding physical port being enabled or disabled.

If you disable an Ethernet uplink, it disables the underlying physical port in an unified uplink. So, even if the FCoE uplink is enabled, the FCoE uplink also goes down. But if you disable an FCoE uplink, only the VFC goes down. If the Ethernet uplink is enabled, it can still function properly in the unified uplink port.

Port Modes

The port mode determines whether a unified port on the fabric interconnect is configured to carry Ethernet or Fibre Channel traffic. The fabric interconnect does not automatically discover the port mode. You configure the port mode in Cisco UCS Central.

Changing the port mode deletes the existing port configuration and replaces it by a new logical port. Any objects associated with that port configuration, such as VLANs and VSANS, are removed. There is no restriction on the number of times you can change the port mode for a unified port.

Effect of Port Mode Changes on Data Traffic

Port mode changes can cause an interruption to the data traffic for the Cisco UCS domain. The length of the interruption and the traffic that is affected depend upon the configuration of the Cisco UCS domain and the module on which you made the port mode changes.

**Tip**

To minimize the traffic disruption during system changes, form a Fibre Channel uplink port-channel across the fixed and expansion modules.

Impact of Port Mode Changes on an Expansion Module

After you make port mode changes on an expansion module, the module reboots. All traffic through ports on the expansion module is interrupted for approximately one minute while the module reboots.

Impact of Port Mode Changes on the Fixed Module in a Cluster Configuration

A cluster configuration has two fabric interconnects. After you make port changes to the fixed module, the fabric interconnect reboots. The impact on the data traffic depends upon whether or not you have configured the server vNICs to failover to the other fabric interconnect when one fails.

If you change the port modes on the expansion module of one fabric interconnect and then wait for that to reboot before changing the port modes on the second fabric interconnect, the following occurs:

- With server vNIC failover, traffic fails over to the other fabric interconnect and no interruption occurs.
- Without server vNIC failover, all data traffic through the fabric interconnect on which you changed the port modes is interrupted for approximately eight minutes while the fabric interconnect reboots.

If you change the port modes on the fixed modules of both fabric interconnects simultaneously, all data traffic through the fabric interconnects are interrupted for approximately eight minutes while the fabric interconnects reboot.

Impact of Port Mode Changes on the Fixed Module in a Standalone Configuration

A standalone configuration has only one fabric interconnect. After you make port changes to the fixed module, the fabric interconnect reboots. All data traffic through the fabric interconnect is interrupted for approximately eight minutes while the fabric interconnect reboots.

Port Roles

The port role defines the type of traffic carried over a unified port connection.

All of the port roles listed are configurable on both the fixed and expansion module, including server ports, which are configurable on the 6200 and later series fabric interconnect expansion modules.

By default, unified ports changed to Ethernet port mode are set to the uplink Ethernet port role. Unified ports changed to Fibre Channel (FC) port mode are set to the FC uplink port role. You cannot unconfigure FC ports.

Changing the port role does not require a reboot.

When you set the port mode to Ethernet, you can configure the following port roles:

- Server ports
- Ethernet uplink ports
- FCoE storage ports
- FCoE uplink ports
- Appliance ports

When you set the port mode to FC, you can configure the following port roles:

- FC uplink ports
- FC storage ports

Guidelines for Configuring Unified Ports

Consider the following guidelines and restrictions when configuring unified ports:

Hardware and Software Requirements

Unified ports are not supported on 6100 series fabric interconnects.

Port Mode Placement

Because the Cisco UCS Central GUI interface uses a slider to configure the port mode for unified ports on a fixed or expansion module, it automatically enforces the following restrictions which limits how port modes can be assigned to unified ports. When using the Cisco UCS Central CLI interface, these restrictions are enforced when you commit the transaction to the system configuration. If the port mode configuration violates any of the following restrictions, the Cisco UCS Central CLI displays an error:

- Ethernet ports must be grouped together in a block. For each module (fixed or expansion), the Ethernet port block must start with the first port and end with an even numbered port.
- Fibre Channel ports must be grouped together in a block. For each module (fixed or expansion), the first port in the Fibre Channel port block must follow the last Ethernet port and extend to include the rest of the ports in the module. For configurations that include only Fibre Channel ports, the Fibre Channel block must start with the first port on the fixed or expansion module.
- Alternating Ethernet and Fibre Channel ports is not supported on a single module.

Example of a valid configuration— Might include unified ports 1–16 on the fixed module configured in Ethernet port mode and ports 17–32 in Fibre Channel port mode. On the expansion module you could configure ports 1–4 in Ethernet port mode and then configure ports 5–16 in Fibre Channel mode. The rule about alternating Ethernet and Fibre Channel port types is not violated because this port arrangement complies with the rules on each individual module.

Example of an invalid configuration— Might include a block of Fibre Channel ports starting with port 16. Because each block of ports has to start with an odd-numbered port, you would have to start the block with port 17.



Note

The total number of uplink Ethernet ports and uplink Ethernet port channel members that can be configured on each fabric interconnect is limited to 31. This limitation includes uplink Ethernet ports and uplink Ethernet port channel members configured on the expansion module.

Cautions and Guidelines for Configuring Unified Uplink Ports and Unified Storage Ports

The following are cautions and guidelines to follow while working with unified uplink ports and unified storage ports:

- You must configure a non default native VLAN on FCoE and unified uplink ports. This VLAN is not used for any traffic. Cisco UCS Central will reuse an existing `fcoe-storage-native-vlan` for this purpose. This `fcoe-storage-native-vlan` will be used as a native VLAN on FCoE and unified uplinks.

- In an unified uplink port, if you do not specify a non default VLAN for the Ethernet uplink port the fcoe-storage-native-vlan will be assigned as the native VLAN on the unified uplink port. If the Ethernet port has a non default native VLAN specified as native VLAN, this will be assigned as the native VLAN for unified uplink port.
- When you create or delete a member port under an Ethernet port channel, Cisco UCS Central automatically creates or deletes the member port under FCoE port channel. The same happens when you create or delete a member port in FCoE port channel.
- When you configure an Ethernet port as a standalone port, such as server port, Ethernet uplink, FCoE uplink or FCoE storage and make it as a member port for an Ethernet or FCOE port channel, Cisco UCS Central automatically makes this port as a member of both Ethernet and FCoE port channels.
- When you remove the membership for a member port from being a member of server uplink, Ethernet uplink, FCoE uplink or FCoE storage, Cisco UCS Central deletes the corresponding members ports from Ethernet port channel and FCoE port channel and creates a new standalone port.
- For unified uplink ports and unified storage ports, when you create two interfaces, only one license is checked out. As long as either interface is enabled, the license remains checked out. The license will be released only if both the interfaces are disabled for a unified uplink port or a unified storage port.
- Cisco UCS 6100 series fabric interconnect switch can only support 1VF or 1VF-PO facing same downstream NPV switch.

Configuring Unified Ports

Step 1 In the Search bar, click the Search icon and select **Fabric Interconnects**.

Step 2 Click the **Operations** icon and select **Unified Port Configuration**.

Step 3 Use your mouse to drag the slider along the bar until the displays shows the port mode configuration that you want to use.

The ports are displayed as follows:

- Ethernet ports are displayed in green.
- FC ports are displayed in purple.
- Disabled ports are displayed in faded green or purple.

Note Depending on the server, the Ethernet and FC port slider may be reversed.

Step 4 Click **Configure**.

Note Configuring unified ports reboots the FI, and can cause an interruption to the data traffic for the Cisco UCS domain.

Configuring Ports



Note Ethernet uplink ports configured for Cisco UCS Manager releases prior to 3.1 were supported in Cisco UCS Central release 1.3, but are not supported in Cisco UCS Central release 1.4. Any additional configuration of those ports must be done in Cisco UCS Manager.

Step 1 In the Search bar, click the Search icon and select **Fabric Interconnects**.

Step 2 On the Fabric Interconnect page, click the **Ports** tab.

Step 3 Select the port that you want to configure.

Step 4 Click the Operations icon on the far right and select **Configure Port**.
The **Configure Port** page for the selected port displays.

Step 5 Select the **Role** for the port.
For Ethernet ports, this can be one of the following:

- **Appliance**—See [Configuring an Appliance Port](#), on page 9.
- **FCoE Storage**—See [Configuring an FCoE Storage Port](#), on page 11.
- **FCoE Uplink**—See [Configuring an FCoE Uplink Port](#), on page 11.
- **Server**—See [Configuring a Server Port](#), on page 12.
- **Uplink**—See [Configuring an Uplink Port](#), on page 12.

For FC ports, this can be one of the following:

- **FC Storage**—See [Configuring an FC Storage Port](#), on page 13.
- **FC Uplink**—See [Configuring an FC Uplink Port](#), on page 14.

Step 6 Complete the fields as required for your selection.

Step 7 Click **Save**.

Configuring an Appliance Port

Appliance ports are used to connect fabric interconnects to directly attached NFS storage.



Note If you are changing the configuration from an FCoE storage port to an appliance port, admin users have the option to make the port appliance only or unified storage.

-
- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
- Step 2** On the Fabric Interconnect page, click the **Ports** tab.
- Step 3** Select the port that you want to configure.
- Step 4** Click the Operations icon on the far right and select **Configure Port**.
The **Configure Port** page for the selected port displays.
- Step 5** In the **Role** drop-down, select **Appliance**.
- Step 6** On the **Basic** tab, do the following:
- Enter the **Interface User Label**.
 - Select the port speed.
 - Select the quality of service setting associated with this interface. This can be one of the following:
 - **Platinum**—Use this priority for vNIC traffic only.
 - **Gold**—Use this priority for vNIC traffic only.
 - **Silver**—Use this priority for vNIC traffic only.
 - **Bronze**—Use this priority for vNIC traffic only.
 - **Best Effort**—Do not use this priority. It is reserved for the Basic Ethernet traffic lane.
 - **Fibre Channel**—Use this priority for vHBA traffic only.
- Step 7** On the **Policies** tab, select the flow control policy, pin group, and network control policy.
- Step 8** On the **VLANs** tab, choose whether the port will be a **Trunk** or **Access** port, and select the VLANs that you want to assign to the ports.
- Trunk ports can have multiple VLANS and allow the VLANS to transport between switches over the trunk link.
 - Access ports have one VLAN and is connected to an end point. If the VLAN is a primary VLAN, secondary VLANs are required.
- The VLANs that you select are displayed in the **VLANs from System** column. VLANs that were created in Cisco UCS Manager are displayed in the **VLANs Configured on Domain** column.
- Step 9** On the **Ethernet Target Endpoint** tab, click **Enabled** to enter the **Name** and **MAC Address** for the endpoint.
The Ethernet target endpoint is disabled by default.
- Step 10** Click **Save**.
-

Configuring an FCoE Storage Port

Fibre Channel over Ethernet (FCoE) Storage ports allow storage consolidation from two separate links to a single storage that carries both Fibre Channel (FC) and Ethernet traffic.



Note If you are changing the configuration from an appliance port to an FCoE storage port, admin users have the option to make the port FCoE storage only or unified storage.

Before You Begin

The Fibre Channel switching mode must be set to Switching for these ports to be valid. The storage ports cannot function in end-host mode.

-
- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
 - Step 2** On the Fabric Interconnect page, click the **Ports** tab.
 - Step 3** Select the port that you want to configure.
 - Step 4** Click the Operations icon on the far right and select **Configure Port**.
The **Configure Port** page for the selected port displays.
 - Step 5** In the **Role** drop-down, select **FCoE Storage**.
 - Step 6** On the **Basic** tab, enter the **Interface User Label**.
 - Step 7** On the **VSAN** tab, select the VSANs that you want to assign to the ports.
The VSANs that you select are displayed in the **VSAN** column. VSANs that were created in Cisco UCS Manager are displayed in the **VSAN on Domain** column.
 - Step 8** Click **Save**.
-

Configuring an FCoE Uplink Port

FCoE Uplink ports are physical Ethernet interfaces between the fabric interconnects and the upstream Ethernet switch, used for carrying FCoE traffic. With this support, the same physical Ethernet port can carry both Ethernet traffic and Fibre Channel traffic.

**Note**

If you are changing the configuration from an uplink port to an FCoE uplink port, admin users have the option to make the port FCoE uplink only or unified uplink.

-
- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
 - Step 2** On the Fabric Interconnect page, click the **Ports** tab.
 - Step 3** Select the port that you want to configure.
 - Step 4** Click the Operations icon on the far right and select **Configure Port**.
The **Configure Port** page for the selected port displays.
 - Step 5** In the **Role** drop-down, select **FCoE Uplink**.
 - Step 6** On the **Basic** tab, enter the **Interface User Label**.
 - Step 7** On the **Policies** tab, select the link profile policy that you want to assign to the port.
 - Step 8** Click **Save**.
-

Configuring a Server Port

Server Ports handle data traffic between the Fabric Interconnect and the adapter cards on the servers. Server ports are only configurable on the 6200 series and 6300 series fabric interconnect expansion modules.

-
- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
 - Step 2** On the Fabric Interconnect page, click the **Ports** tab.
 - Step 3** Select the port that you want to configure.
 - Step 4** Click the Operations icon on the far right and select **Configure Port**.
The **Configure Port** page for the selected port displays.
 - Step 5** In the **Role** drop-down, select **Server**.
 - Step 6** On the **Basic** tab, enter the **Interface User Label**.
 - Step 7** Click **Save**.
-

Configuring an Uplink Port

Ethernet Uplink Ports connect to external LAN Switches. Network bound Ethernet traffic is pinned to one of these ports.



Note If you are changing the configuration from an FCoE uplink port to an uplink port, admin users have the option to make the port uplink only or unified uplink.

-
- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
- Step 2** On the Fabric Interconnect page, click the **Ports** tab.
- Step 3** Select the port that you want to configure.
- Step 4** Click the Operations icon on the far right and select **Configure Port**.
The **Configure Port** page for the selected port displays.
- Step 5** In the **Role** drop-down, select **Uplink**.
- Step 6** On the **Basic** tab, do the following:
- Enter the **Interface User Label**.
 - Select the port speed.
- Step 7** On the **VLANs** tab, select the VLANs that you want to assign to the ports.
The VLANs that you select are displayed in the **VLANs from System** column. VLANs that were created in Cisco UCS Manager are displayed in the **VLANs Configured on Domain** column.
- Step 8** On the **Policies** tab, select the flow control policy and link profile.
- Step 9** Click **Save**.
-

Configuring an FC Storage Port

FC Storage ports allow you to directly attach an FC storage device to a port on the FI.

Before You Begin

The Fibre Channel switching mode must be set to Switching for these ports to be valid. The storage ports cannot function in end-host mode.

-
- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
- Step 2** On the Fabric Interconnect page, click the **Ports** tab.
- Step 3** Select the port that you want to configure.
- Step 4** Click the Operations icon on the far right and select **Configure Port**.
The **Configure Port** page for the selected port displays.
- Step 5** In the **Role** drop-down, select **FC Storage**.
- Step 6** On the **Basic** tab, enter the **Interface User Label** and select a fill pattern.
- Step 7** On the **VSAN** tab, select the VSANs that you want to assign to the ports.
The VSANs that you select are displayed in the **VSAN** column. VSANs that were created in Cisco UCS Manager are displayed in the **VSAN on Domain** column.

Step 8 Click **Save**.

Configuring an FC Uplink Port

FC uplink ports allow you to connect to external SAN switches.

Step 1 In the Search bar, click the Search icon and select **Fabric Interconnects**.

Step 2 On the Fabric Interconnect page, click the **Ports** tab.

Step 3 Select the port that you want to configure.

Step 4 Click the Operations icon on the far right and select **Configure Port**.
The **Configure Port** page for the selected port displays.

Step 5 In the **Role** drop-down, select **FC Uplink**.

Step 6 On the **Basic** tab, enter the **Interface User Label** and select a fill pattern.

Step 7 On the **VSAN** tab, select the VSANs that you want to assign to the ports.
The VSANs that you select are displayed in the **VSAN from System** column. VSANs that were created in Cisco UCS Manager are displayed in the **VSAN Configured on Domain** column.

Step 8 Click **Save**.

Scalability and Breakout Ports

The Cisco UCS 6300 Series Fabric Interconnect contain scalability ports that can be broken out into groups of 4 10-Gigabit Ethernet ports.

- The Cisco UCS 6324 Fabric Interconnect contains one scalability port that can be used as a licensed server port for supported Cisco UCS rack servers, an appliance port, or a FCoE port.
- The Cisco UCS 6332 and Cisco UCS 6332-16 UP fabric interconnects contain multiple 40-Gigabit Ethernet ports that can be broken out into 10-Gigabit Ethernet ports.

Managing Configured Ports

- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
- Step 2** On the Fabric Interconnect page, click the **Ports** tab.
- Step 3** Select the configured port that you want to change.
- Step 4** Click the Operations icon on the far right.
- Step 5** Select one of the following:
- **Configuration Status**—Displays the status of the port.
 - **Configure Port**—Enables you to change the configuration of the port.
 - **Unconfigure Port**—Deletes the port configuration information. If you unconfigure a port, all traffic using the port will stop.
 - **Enable Port**—Sets the administrative state of the port to Enabled. Only visible when the port is Disabled.
 - **Disable Port**—Sets the administrative state of the port to Disabled. Only visible when the port is Enabled.
 - **Unconfigure Breakout Port**—Combines the four 10GbE ports into a single 40GbE port.
 - **Configure as Breakout Port**—Turns the port into a scalability port that can be broken out into four 10GbE ports.
- Step 6** Complete the fields as required.
-

Creating a Port Channel

- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
- Step 2** Click the **Operations** icon and select **Create Port Channel**.
- Step 3** In **Basic**, select the type of port channel that you want to create. This can be one of the following:
- **Ethernet**—See [Creating an Ethernet Port Channel](#), on page 16.
 - **FC**—See [Creating an FC Port Channel](#), on page 16.
 - **FCoE**—See [Creating an FCoE Port Channel](#), on page 17.
 - **Appliance**—See [Creating an Appliance Port Channel](#), on page 17.
- Step 4** Complete the fields as required for your selection.
- Step 5** Click **Save**.
-

Creating an Ethernet Port Channel

- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
- Step 2** Click the **Operations** icon and select **Create Port Channel**.
- Step 3** In **Basic**, select **Ethernet** and complete the following:
- Enter the **Port ID, Name**, and optional **Description**.
 - Select the admin speed and whether to enable auto negotiation.
- Step 4** Click **Policies** and select the flow control and LACP policy that you want to assign to the ports.
- Step 5** Click **VLANs** and select the VLANs that you want to assign to the ports. The VLANs that you select are displayed in the **VLANs from System** column. VLANs that were created in Cisco UCS Manager are displayed in the **VLANs Configured on Domain** column.
- Step 6** Click **Ports** and click the Plus icon to add ports to the port channel.
- Step 7** Click **Save**.
-

Creating an FC Port Channel

- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
- Step 2** Click the **Operations** icon and select **Create Port Channel**.
- Step 3** In **Basic**, select **FC** and complete the following:
- Enter the **Port ID, Name**, and optional **Description**.
 - Select the admin speed and whether to enable auto negotiation.
- Step 4** Click **VSANs** and select the VSANs that you want to assign to the ports. The VSANs that you select are displayed in the **VSAN** column. VSANs that were created in Cisco UCS Manager are displayed in the **VSAN on Domain** column.
- Step 5** Click **Ports** and click the Plus icon to add ports to the port channel.
- Step 6** Click **Save**.
-

Creating an FCoE Port Channel

- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
- Step 2** Click the **Operations** icon and select **Create Port Channel**.
- Step 3** In **Basic**, select **FCoE**.
- Step 4** Enter the **Port Channel ID**, **Name**, and optional **Description**.
- Step 5** Click **Policies** and LACP policy that you want to assign to the ports.
- Step 6** Click **Ports** and click the Plus icon to add ports to the port channel.
- Step 7** Click **Save**.
-

Creating an Appliance Port Channel

- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
- Step 2** Click the **Operations** icon and select **Create Port Channel**.
- Step 3** In **Basic**, select and complete the following:
- Enter the **Port ID**, **Name**, and optional **Description**.
 - Select the admin speed and whether to use **Static** mode or dynamic **LACP**.
 - Select the quality of service setting associated with this interface. This can be one of the following:
 - **Platinum**—Use this priority for vNIC traffic only.
 - **Gold**—Use this priority for vNIC traffic only.
 - **Silver**—Use this priority for vNIC traffic only.
 - **Bronze**—Use this priority for vNIC traffic only.
 - **Best Effort**—Do not use this priority. It is reserved for the Basic Ethernet traffic lane.
 - **Fibre Channel**—Use this priority for vHBA traffic only.
- Step 4** Click **Policies** and select the flow control policy, LACP policy, network control policy, and the pin group that you want to assign to the ports.
- Step 5** Click **VLANs** and select the VLANs that you want to assign to the ports. The VLANs that you select are displayed in the **VLANs from System** column. VLANs that were created in Cisco UCS Manager are displayed in the **VLANs Configured on Domain** column.
- Step 6** Click **Ethernet Target Endpoint** and click **Enabled** to enter the **Name** and **MAC Address** for the endpoint. The Ethernet target endpoint is disabled by default.

Step 7 Click **Ports** and click the Plus icon to add ports to the port channel.

Step 8 Click **Save**.

Fibre Channel Switching Mode

The Fibre Channel switching mode determines how the fabric interconnect behaves as a switching device between the servers and storage devices. The fabric interconnect operates in either of the following Fibre Channel switching modes:

End-Host Mode

End-host mode allows the fabric interconnect to act as an end host to the connected fibre channel networks, representing all servers (hosts) connected to it through virtual host bus adapters (vHBAs). This behavior is achieved by pinning (either dynamically pinned or hard pinned) vHBAs to Fibre Channel uplink ports, which makes the Fibre Channel ports appear as server ports (N-ports) to the rest of the fabric. When in end-host mode, the fabric interconnect avoids loops by denying uplink ports from receiving traffic from one another.

End-host mode is synonymous with N Port Virtualization (NPV) mode. This mode is the default Fibre Channel Switching mode.

**Note**

When you enable end-host mode, if a vHBA is hard pinned to an uplink Fibre Channel port and this uplink port goes down, the system cannot repin the vHBA, and the vHBA remains down.

Switch Mode

Switch mode is the traditional Fibre Channel switching mode. Switch mode allows the fabric interconnect to connect directly to a storage device. Enabling Fibre Channel switch mode is useful in Pod models where there is no SAN (for example, a single Cisco UCS domain that is connected directly to storage), or where a SAN exists (with an upstream MDS).

Switch mode is not the default Fibre Channel switching mode.

**Note**

In Fibre Channel switch mode, SAN pin groups are irrelevant. Any existing SAN pin groups are ignored.

Configuring Fibre Channel Switching Mode

You can configure your fabric interconnect to use either FC End-Host Mode or FC Switch Mode. By default, the FI is set to end-host mode.

**Note**

When you change the Fibre Channel switching mode, Cisco UCS Central logs you out and restarts the fabric interconnect. For a cluster configuration, Cisco UCS Central restarts both fabric interconnects sequentially. The second fabric interconnect can take several minutes to complete the change in Fibre Channel switching mode and become system ready.

-
- Step 1** Select **Fabric Interconnects** from the Search icon. The **All Fabric Interconnects** page displays.
- Step 2** From the **All Fabric Interconnects** page, click on the fabric interconnect that you want to configure.
- Step 3** On the detailed view for the FI, click the **Operations** icon and select the FC switching mode. If you are using end-host mode, **Set FC Switching Mode** is shown. If you are using FC switching mode, **Set FC End-Host Mode** is shown.
- Step 4** Click **Yes** on the warning page to change the configuration and restart the FI.
-

Pin Groups

LAN Pin Groups

Cisco UCS uses LAN pin groups to pin Ethernet traffic from a vNIC on a server to an uplink Ethernet port or port channel on the fabric interconnect. You can use this pinning to manage the distribution of traffic from the servers.

To configure pinning for a server, you must include the LAN pin group in a vNIC policy. The vNIC policy is then included in the service profile assigned to that server. All traffic from the vNIC travels through the I/O module to the specified uplink Ethernet port.

**Note**

If you do not assign a pin group to a server interface through a vNIC policy, Cisco UCS Central chooses an uplink Ethernet port or port channel for traffic from that server interface dynamically. This choice is not permanent. A different uplink Ethernet port or port channel may be used for traffic from that server interface after an interface flap or a server reboot.

If an uplink is part of a LAN pin group, the uplink is not necessarily reserved for only that LAN pin group. Other vNIC's policies that do not specify a LAN pin group can use the uplink as a dynamic uplink.

SAN Pin Groups

Cisco UCS uses SAN pin groups to pin Fibre Channel traffic from a vHBA on a server to an uplink Fibre Channel port on the fabric interconnect. You can use this pinning to manage the distribution of traffic from the servers.



Note In Fibre Channel switch mode, SAN pin groups are irrelevant. Any existing SAN pin groups will be ignored.

To configure pinning for a server, you must include the SAN pin group in a vHBA policy. The vHBA policy is then included in the service profile assigned to that server. All traffic from the vHBA will travel through the I/O module to the specified uplink Fibre Channel port.

You can assign the same pin group to multiple vHBA policies. As a result, you do not need to manually pin the traffic for each vHBA.



Important Changing the target interface for an existing SAN pin group disrupts traffic for all vHBAs which use that pin group. The fabric interconnect performs a log in and log out for the Fibre Channel protocols to re-pin the traffic.

Creating a Pin Group

You can create a pin group for either LAN or SAN.

-
- Step 1** In the Search bar, click the Search icon and select **Domains**.
 - Step 2** Click the domain where you want to create a pin group.
 - Step 3** On the domain page, click the **Operations** icon and select **Create Pin Group**. This launches the **Create Pin Group** dialog box.
 - Step 4** In **Basic**, choose whether you want to create a LAN pin group or a SAN pin group.
 - Step 5** Enter the **Name** and optional **Description**.
 - Step 6** In **Fabric A Target**, choose whether you want to manually select a port, or select an existing port channel.
 - Step 7** If you selected **Manual**, select the port.
For LAN pin groups, only ethernet uplink ports are shown. For SAN pin groups, only FC and FCoE uplink ports are shown.
 - Step 8** If you selected **Port Channel**, select an existing port channel.
For LAN pin groups, only ethernet port channels are shown. For SAN pin groups, only FC and FCoE port channels are shown.
 - Step 9** In **Fabric B Target**, select a port or a port channel.
 - Step 10** Click **Create**.
-

Viewing Port Configuration Status

- Step 1** In the Search bar, click the Search icon and select **Fabric Interconnects**.
 - Step 2** Click the Fabric Interconnect that you want to view.
 - Step 3** On the Fabric Interconnect page, click the **Ports** tab.
 - Step 4** Select the port for which you want to view the configuration status.
 - Step 5** Click the Operations icon on the far right and select **Configuration Status**.
The **Configuration Status** page for the selected port displays.
 - Step 6** Click **Close** to close the window.
-



Global VSAN

- [Global VSANs, page 23](#)

Global VSANs

Cisco UCS Central enables you to define global VSAN in the SAN cloud or the Storage cloud. The global VSANs created in Cisco UCS Central are specific to the fabric interconnect where you create them. You can assign a VSAN to either Fabric A or Fabric B, or to both Fabric A and B. Global VSANs are not common VSANs in Cisco UCS Central.

Resolution of global VSANs takes place in Cisco UCS Central prior to deployment of global service profiles that reference them to Cisco UCS Manager. If a global service profile references a global VSAN, and that VSAN does not exist, deployment of the global service profile to Cisco UCS Manager will fail due to insufficient resources. All global VSANs created in Cisco UCS Central must be resolved before deploying that global service profile.

Global VSANs are available and can be used in Cisco UCS Manager, even if no global service profile with reference to a global VSAN is deployed in that UCS domain. A global VSAN is not deleted when a global service profile that references it is deleted.

Global VSANs that are referenced by a global service profile available to a Cisco UCS Manager instance remain available unless they are specifically deleted for use from the domain group. Global VSANs can be localized in Cisco UCS Manager, in which case they act as local VSANs. Unless a global VSAN is localized, it cannot be deleted from Cisco UCS Manager.

Creating or Editing a VSAN

You can create a VSAN with IDs from 1 to 4093, except for those in the following reserved ranges:

- If you plan to use FC switch mode in a Cisco UCS domain, do not configure VSANs with an ID in the range from 3040 to 4078.
- If you plan to use FC end-host mode in a Cisco UCS domain, do not configure VSANs with an ID in the range from 3840 to 4079.

**Important**

FCoE VLANs in the SAN cloud and vLANs in the LAN cloud must have different IDs. Using the same ID for an FCoE vLAN in a VSAN and for a vLAN results in a critical fault and traffic disruption for all vNICs and uplink ports using that VLAN. Ethernet traffic is dropped on any VLAN which has an ID that overlaps with an FCoE vLAN ID.

You can create a VSAN at the domain group root or in a specific domain. You can also assign the VSAN to either fabric A or fabric B, or to both fabric A and B. When you assign the VSAN to both fabrics, both of them must have different VSAN ID and FCoE vLAN ID.

After creating a VSAN, if necessary, you can edit **Fabric Zoning**, **Fabric** assignment, **VSAN ID** and the **FCoE vLAN ID**.

Step 1 In the Task bar, type **Create VSAN** and press Enter.
This launches the **Create vSAN** dialog box.

Step 2 Select the type of VSAN that you want to create.
This can be one of the following:

- **SAN**—Connects your fabric interconnect to external switches.
- **Storage**—Directly connects your storage to the fabric interconnect.

Step 3 Click **Domain Group Location** and select the location in which you want to create this VSAN.

Step 4 Enter a **Name**.
VSAN name is case sensitive.

Important Do not use the name **default** when you create a VSAN in Cisco UCS Central. If you want to create a global default VSAN, you may use **globalDefault** for the name.

Step 5 (Optional) Select the **Enabled** radio button in the **FC Zoning Settings** panel to enable Fibre Channel zoning.
Fibre Channel zoning can be one of the following:

- **disabled**—The upstream switch configures and controls the Fibre Channel zoning, or Fibre Channel zoning is not implemented on this VSAN.
- **enabled**—Cisco UCS Manager will configure and control Fibre Channel zoning when the VSAN is deployed.

Note Fibre Channel zoning is disabled by default.

Step 6 Select the Fabric where you want to assign this VSAN.
If you assign the VSAN to both fabrics, enter the VSAN ID and FCoE VLAN ID for both fabrics. If not, assign the IDs for the selected VSAN.

Step 7 Click **Create**.



vHBA Management

- [vHBA Overview, page 25](#)

vHBA Overview

Creating or Editing a vHBA Template

To edit a specific vHBA template, type vHBA Template in the search bar to find the vHBA template you want to edit.



Note

Global vHBAs can be used in local service profiles created in Cisco UCS Manager.

-
- Step 1** In the Task bar, type **Create vHBA Template** and press Enter. This launches the **Create vHBA Template** dialog box.
 - Step 2** In **Basic**, select the **Organization** where you want to create the vHBA template.
 - a) Enter a **Name** and **Description**.
 - b) Select the options for **Type**, **Fabric ID**, and enter **Max Data Field Size(Bytes)**.
 - Step 3** Click **WWN Address Pool** and select the WWN addresses. If you do not assign a WWN address pool, the system assigns the default.
 - Step 4** Click **vSANs** and add the vSANs you want to use for this vHBA template.
 - Step 5** Click **Policies** . If the policies are not assigned, click on each of the policies and pin group. On the right, click the drop-down to display related policies and pin group and select the one you want for this vHBA template.
 - Step 6** Click **Create**.
-

Host Interface Placement Policy

The host interface placement policy enables you to determine the user-specified virtual network interface connection (vCon) placement for vNICs and vHBAs.

To create a host interface placement policy, see [Creating or Editing a Host Interface Placement Policy](#), on page 26. Details for existing policies are displayed on the **Host Interface Placement Policy** page.

Creating or Editing a Host Interface Placement Policy

- Step 1** In the Task bar, type **Create Host Interface Placement Policy** and press Enter. This launches the **Create Host Interface Placement Policy** dialog box.
- Step 2** Click **Organization** and select the location in which you want to create the policy.
- Step 3** Enter a **Name** and optional **Description**.
The policy name is case sensitive.
- Step 4** Select the **Virtual Slot Mapping Scheme**.
This can be one of the following:
- **Linear Ordered**—The virtual slots are assigned in order.
 - **Round Robin**—The virtual slots are assigned sequentially.
- Step 5** Select the **Virtual Slot Selection Preference** for each virtual slot.
This can be one of the following:
- **all**—All configured vNICs and vHBAs can be assigned. This is the default.
 - **assigned-only**—vNICs and vHBAs must be explicitly assigned.
 - **exclude-dynamic**—Dynamic vNICs and vHBAs cannot be assigned.
 - **exclude-unassigned**—Unassigned vNICs and vHBAs cannot be assigned.
 - **exclude-usnic**—usNIC vNICs cannot be assigned.
- Step 6** Click **Create**.
-

vHBA to vCon Assignment ? To Be Added

Default vHBA Behavior Policy - To Be Added



Storage Pools

This chapter includes the following sections:

- [WWN Pools, page 27](#)

WWN Pools

A WWN pool is a collection of WWNs for use by the Fibre Channel vHBAs in a Cisco UCS domain. WWN pools created in Cisco UCS Central can be shared between Cisco UCS domains. You create separate pools for the following:

- WW node names assigned to the server
- WW port names assigned to the vHBA
- Both WW node names and WW port names



Important

A WWN pool can include only WWNNs or WWPNS in the ranges from 20:00:00:00:00:00:00:00 to 20:FF:FF:FF:FF:FF:FF:FF:FF or from 50:00:00:00:00:00:00:00 to 5F:FF:FF:FF:FF:FF:FF:FF:FF. All other WWN ranges are reserved. To ensure the uniqueness of the Cisco UCS WWNNs and WWPNS in the SAN fabric, we recommend that you use the following WWN prefix for all blocks in a pool:
20:00:00:25:B5:XX:XX:XX

If you use WWN pools in service profiles, you do not have to manually configure the WWNs that will be used by the server associated with the service profile. In a system that implements multi-tenancy, you can use a WWN pool to control the WWNs used by each organization.

You assign WWNs to pools in blocks.

WWNN Pools

A WWNN pool is a WWN pool that contains only WW node names. If you include a pool of WWNNs in a service profile, the associated server is assigned a WWNN from that pool.

WWPN Pools

A WWPN pool is a WWN pool that contains only WW port names. If you include a pool of WWPNs in a service profile, the port on each vHBA of the associated server is assigned a WWPN from that pool.

WWxN Pools

A WWxN pool is a WWN pool that contains both WW node names and WW port names. You can specify how many ports per node are created with WWxN pools. The pool size for WWxN pools must be a multiple of ports-per-node + 1. For example, if there are 7 ports per node, the pool size must be a multiple of 8. If there are 63 ports per node, the pool size must be a multiple of 64.

Creating and Editing a WWN Pool

After creating a WWN pool you can edit by selecting the **Edit** icon on the overall summary page of the selected WWN pool. To select a WWN pool, go to **All Pools** page and select the WWN pool that you want to edit. The page redirects you to the overall summary page of the selected WWN pool.

Step 1 In the Task bar, type **Create WWN Pool** and press **Enter**.
This launches the **Create WWN Pool** dialog box.

Step 2 In **Basic**, complete the following:

- Click **Organization** and select the location in which you want to create the pool.
- Enter name and description of the WWN pool.
- In the **World Wide Name (WWN) Used For** area, select one of the following:
 - **Port (WWPN)**—The pool is used for both WWNNs and WWPNs.
 - **Node (WWNN)**—The pool is used for WWNNs.
 - **Both (WWxN)**—The pool is used for WWNNs.

Step 3 In **WWN Blocks**, complete the following:

- Click the **Create** icon.
- In the **WWN Block Start** column, enter the first WWN initiator in the block.
- In the **Size** column, enter the total number of WWN initiators in the pool.
- Click the **Apply** icon.
Additional fields related to WWN pools are displayed.
- Click the **WWNs** tab, you can view a graphical representation of the number of WWN addresses in the pool, the number of assigned WWN addresses, and the duplicate MAC addresses and WWN summary.
- In **Access Control**, select the ID range access control policy to apply to this block. If you do not have a policy, you can create one by typing **Create ID Range Access Control Policy** in the task bar.

Step 4 Click **Create**.

Note You must wait a minimum of 5 seconds before you create another pool.

What to Do Next

- Include the WWPN pool in a vHBA template.
- Include the WWNN pool in a service profile or service profile template.
- Include the WWxN pool in a service profile or service profile template.

Deleting a Pool

If you delete a pool, Cisco UCS Central does not reallocate any addresses from that pool that have been assigned to vNICs or vHBAs in Cisco UCS Manager. All assigned addresses from a deleted pool remain with the vNIC or vHBA to which they are assigned until one of the following occurs:

- The associated service profiles are deleted.
- The vNIC or vHBA to which the address is assigned is deleted.
- The vNIC or vHBA is assigned to a different pool.

Step 1 In the navigation bar, click the Search icon and select **Pools**.
This launches the **All Pools** dialog box.

Step 2 In the **Pool Name** column, locate the pool that you want to delete.
You can search for the pool in one of the following ways:

- Browse through the list of pools.
- Click the **Search** icon and enter the pool name.
- Select a pool type from the **Filters** column.

Step 3 Double-click the pool.
This launches the overall summary page of the selected pool.

Step 4 Click the **Delete** icon.
If Cisco UCS Central displays a confirmation dialog box, click **Delete**.



Storage Policies

This chapter includes the following sections:

- [Fibre Channel Adapter Policy, page 31](#)
- [SAN Connectivity Policy, page 33](#)
- [Storage Connection Policy, page 33](#)
- [Fibre Channel Zoning, page 34](#)
- [Direct-Attached Storage, page 35](#)

Fibre Channel Adapter Policy

Fibre channel adapter policies govern the host-side behavior of the adapter, including how the adapter handles traffic. For example, you can use these policies to change default settings for the following:

- Queues
- Interrupt handling
- Performance enhancement
- RSS hash
- Failover in an cluster configuration with two fabric interconnects

**Note**

For Fibre Channel adapter policies, the values displayed by Cisco UCS Central may not match those displayed by applications such as QLogic SANsurfer. For example, the following values may result in possible mismatch between SANsurfer and Cisco UCS Central:

- **Max LUNs Per Target**—SANsurfer has a maximum of 256 LUNs and does not display more than that number. Cisco UCS Central supports a higher maximum number of LUNs.
 - **Link Down Timeout**—In SANsurfer, you configure the timeout threshold for link down in seconds. In Cisco UCS Central, you configure this value in milliseconds. Therefore, a value of 5500 ms in Cisco UCS Central displays as 5 s in SANsurfer.
 - **Max Data Field Size**—SANsurfer has allowed values of 512, 1024, and 2048. Cisco UCS Central allows you to set values of any size. Therefore, a value of 900 in Cisco UCS Central displays as 512 in SANsurfer.
-

Operating System Specific Adapter Policies

By default, Cisco UCS provides a set of Fibre channel adapter policies. These policies include the recommended settings for each supported server operating system. Operating systems are sensitive to the settings in these policies. Storage vendors typically require non-default adapter settings. You can find the details of these required settings on the support list provided by those vendors.

**Note**

We recommend that you use the values in these policies for the applicable operating system. Do not modify any of the values in the default policies unless directed to do so by Cisco Technical Support.

Creating or Editing a Fibre Channel Adapter Policy

-
- Step 1** In the Task bar, type **Create Fibre Channel Adapter Policy** and press Enter. This launches the **Create Fibre Channel Adapter Policy** dialog box.
- Step 2** In **Basic**, click **Organization** and select the location in which you want to create this policy.
- Step 3** Enter a **Name** and optional **Description**. The policy name is case sensitive.
- Step 4** In **Resources**, complete the fields as necessary.
- Step 5** In **Settings**, complete the fields as necessary.
- Step 6** Click **Create**.
-

SAN Connectivity Policy

SAN connectivity policies determine the connections and the network communication resources between the server and the SAN on the network. These policies use pools to assign WWNs, and WWPNS to servers and to identify the vHBAs that the servers use to communicate with the network.

**Note**

These policies are included in service profiles and service profile templates, and can be used to configure multiple servers. So, using static IDs in connectivity policies is not recommended.

Creating or Editing a SAN Connectivity Policy

-
- Step 1** In the Task bar, type **Create SAN Connectivity Policy** and press Enter. This launches the **Create SAN Connectivity Policy** dialog box.
 - Step 2** In **Basic**, click **Organization** and select the location in which you want to create the policy.
 - Step 3** Enter the **Name** and optional **Description**. The name is case sensitive.
 - Step 4** In **Identifiers**, choose the WWNN pool. For more information, see [Creating and Editing a WWN Pool](#), on page 28.
 - Step 5** In **vHBAs**, create one or more vHBAs and select the properties. You can manually create the vHBA or use a vHBA template.
 - Step 6** Click **Create**.
-

Storage Connection Policy

The storage connection policy contains a collection of target storage ports on storage array that you use to configure fibre channel zoning.

From Cisco UCS Central you can create a storage connection policy in an organization.

Creating or Editing a Storage Connection Policy

Before You Begin

-
- Step 1** In the Task bar, type **Create Storage Connection Policy** and press Enter. This launches the **Create Storage Connection Policy** dialog box.

- Step 2** In **Basic**, select **Organization** from the drop down.
- Enter a **Name** and an optional **Description** for this policy.
 - Select a **Zoning Type**. This can be one of the following:
 - None**—FC zoning is not configured.
 - Single Initiator Single Target**—The system automatically creates one zone for each vHBA and storage port pair. Each zone has two members. We recommend that you configure this type of zoning unless you expect the number of zones to exceed the maximum supported.
This is the default.
 - Single Initiator Multiple Targets**—The system automatically creates one zone for each vHBA. We recommend that you configure this type of zoning if you expect the number of zones to reach or exceed the maximum supported.
- Step 3** Click **Endpoints** and click the plus sign to add a **WWPN**.
The WWPN is assigned to the physical target port on the Fibre Channel or FCoE storage array that the server uses to access the LUNs configured on the storage array.
- In the **FC Target Endpoints > Basic** tab, enter an optional description and select the fabric interconnect in the **Path** field.
By default, fabric interconnect A is used for communications with the target endpoint.
 - In the **FC Target Endpoints > VSAN** tab, select the VSAN associated with the FI port and target endpoint.
- Step 4** Click **Create**.
-

What to Do Next

Fibre Channel Zoning

Fibre Channel (FC) zoning allows you to partition the Fibre Channel fabric into one or more zones. Each zone defines the set of FC initiators and FC targets that can communicate with each other in a VSAN.

The access and data traffic control provided by zoning does the following:

- Enhances SAN network security
- Helps prevent data loss or corruption
- Reduces performance issues

Cisco UCS Central FC zoning combines direct attach storage with local zoning. Fibre Channel or FCoE storage is directly connected to the fabric interconnects, and zoning is performed in Cisco UCS Central, using Cisco UCS local zoning.

Configuring Zoning



Note This dialog box is read-only if the global service profile or service profile template you select already has a SAN connectivity policy associated with it.

-
- Step 1** From the **Service Profile** or **Service Profile Template** page, click the **Settings** icon.
 - Step 2** Click **Configure Zoning**.
This launches the **Configure Zoning** dialog box.
 - Step 3** Click the plus icon to add a new vHBA Initiator Group, and type the name that you want to use for the group.
 - Step 4** In **Basic**, enter the optional description.
 - Step 5** In **vHBA Initiators**, select the vHBA initiators that you want to add.
 - Step 6** In **Storage Connection Policy**, select the policy that you want to use.
 - Step 7** Click **Save**.
-

Direct-Attached Storage

Direct-attached storage (DAS) uses FC storage ports to connect an FC storage device to a port on the fabric interconnect.

Configuring Direct-Attached Storage

-
- Step 1** Ensure that the FI is configured in FC Switch Mode.
 - Step 2** Create a VSAN in the Storage cloud.
 - Step 3** Set the port role to FC Switch Mode.
 - Step 4** Perform the following steps to confirm that the storage port WWPN is logged into the fabric interconnect.
 - a) Log in through the secure shell (SSH), or establish a Telnet connection to the UCS Virtual IP (VIP) on the primary FI.
 - b) Enter the connect nxos { a | b } command, where a | b represents FI A or FI B.
 - c) Enter the **show flogi database vsan vsan ID** command, where *vsan ID* is the identifier for the VSAN.
 - Step 5** Create a storage connection policy.
 - Step 6** Create a service profile that uses the storage connection policy you just created.
 - Step 7** Associate the service profile with the server.
-



Storage Profiles

This chapter includes the following sections:

- [Storage Profiles, page 37](#)
- [Disk Groups and Disk Group Configuration Policies, page 42](#)

Storage Profiles

To allow flexibility in defining the number of storage disks, roles and usage of these disks, and other storage parameters, you can create and use storage profiles. A storage profile encapsulates the storage requirements for one or more service profiles. LUNs configured in a storage profile can be used as boot LUNs or data LUNs, and can be dedicated to a specific server. You can also specify a local LUN as a boot device.

Storage profiles allow you to do the following:

- Configure multiple virtual drives and select the physical drives that are used by a virtual drive.
- Configure the storage capacity of a virtual drive.
- Configure the number, type and role of disks in a disk group.
- Associate a storage profile with a service profile.



Note

LUN resizing is not supported.

Virtual Drives

A disk group can be partitioned into virtual drives. Each virtual drive appears as an individual physical device to the Operating System.

All virtual drives in a disk group must be managed by using a single disk group policy.

Configuration States

Indicates the configuration states of a virtual drive. Virtual drives can have the following configuration states:

- Applying—Creation of the virtual drive is in progress.
- Applied—Creation of the virtual drive is complete, or virtual disk policy changes are configured and applied successfully.
- Failed to apply—Creation, deletion, or renaming of a virtual drive has failed due to errors in the underlying storage subsystem.
- Orphaned—The service profile that contained this virtual drive is deleted or the service profile is no longer associated with a storage profile.
- Not in use—The service profile that contained this virtual drive is in the disassociated state.

Deployment States

Indicates the actions that you are performing on virtual drives. Virtual drives can have the following deployment states:

- No action—No pending work items for the virtual drive.
- Creating—Creation of the virtual drive is in progress.
- Deleting—Deletion of the virtual drive is in progress.
- Modifying—Modification of the virtual drive is in progress.
- Apply-Failed—Creation or modification of the virtual drive has failed.

Operability States

Indicates the operating condition of a virtual drive. Virtual drives can have the following operability states:

- Optimal—The virtual drive operating condition is good. All configured drives are online.
- Degraded—The virtual drive operating condition is not optimal. One of the configured drives has failed or is offline.
- Cache-degraded—The virtual drive has been created with a write cache policy of Write Back Good BBU mode, but the BBU has failed, or there is no BBU.



Note This state does not occur if you select Always Write Back mode.

- Partially degraded—The operating condition in a RAID 6 virtual drive is not optimal. One of the configured drives has failed or is offline. RAID 6 can tolerate up to two drive failures.
- Offline—The virtual drive is not available to the RAID controller. This is essentially a failed state.
- Unknown—The state of the virtual drive is not known.

Presence States

Indicates the presence of virtual drive components. Virtual drives have the following presence states:

- Equipped—The virtual drive is available.
- Mismatched—A virtual drive deployed state is different from its configured state.
- Missing—Virtual drive is missing.

Virtual Drive Naming

When you use Cisco UCS Central to create a virtual drive, Cisco UCS Central assigns a unique ID that can be used to reliably identify the virtual drive for further operations. Cisco UCS Central also provides the flexibility to provide a name to the virtual drive at the time of service profile association. Any virtual drive without a service profile or a server reference is marked as an orphan virtual drive.

In addition to a unique ID, a name is assigned to the drive. Names can be assigned in two ways:

- When configuring a virtual drive, you can explicitly assign a name that can be referenced in storage profiles.
- If you have not preprovisioned a name for the virtual drive, Cisco UCS Central generates a unique name for the virtual drive.

You can rename virtual drives that are not referenced by any service profile or server.

RAID Levels

The RAID level of a disk group describes how the data is organized on the disk group for the purpose of ensuring availability, redundancy of data, and I/O performance.

The following are features provided by RAID:

- Striping—Segmenting data across multiple physical devices. This improves performance by increasing throughput due to simultaneous device access.
- Mirroring—Writing the same data to multiple devices to accomplish data redundancy.
- Parity—Storing of redundant data on an additional device for the purpose of error correction in the event of device failure. Parity does not provide full redundancy, but it allows for error recovery in some scenarios.
- Spanning—Allows multiple drives to function like a larger one. For example, four 20 GB drives can be combined to appear as a single 80 GB drive.

The supported RAID levels include the following:

- RAID 0 Striped—Data is striped across all disks in the array, providing fast throughput. There is no data redundancy, and all data is lost if any disk fails.
- RAID 1 Mirrored—Data is written to two disks, providing complete data redundancy if one disk fails. The maximum array size is equal to the available space on the smaller of the two drives.
- RAID 5 Striped Parity—Data is striped across all disks in the array. Part of the capacity of each disk stores parity information that can be used to reconstruct data if a disk fails. RAID 5 provides good data throughput for applications with high read request rates.

RAID 5 distributes parity data blocks among the disks that are part of a RAID-5 group and requires a minimum of three disks.

- RAID 6 Striped Dual Parity—Data is striped across all disks in the array and two sets of parity data are used to provide protection against failure of up to two physical disks. In each row of data blocks, two sets of parity data are stored.

Other than addition of a second parity block, RAID 6 is identical to RAID 5. A minimum of four disks are required for RAID 6.

- RAID 10 Mirrored and Striped—RAID 10 uses mirrored pairs of disks to provide complete data redundancy and high throughput rates through block-level striping. RAID 10 is mirroring without parity and block-level striping. A minimum of four disks are required for RAID 10.
- RAID 50 Striped Parity and Striped—Data is striped across multiple striped parity disk sets to provide high throughput and multiple disk failure tolerance.
- RAID 60 Striped Dual Parity and Striped—Data is striped across multiple striped dual parity disk sets to provide high throughput and greater disk failure tolerance.

Supported LUN Modifications

Some modifications that are made to the LUN configuration when LUNs are already deployed on an associated server are supported.

The following are the types of modifications that can be performed:

- Creation of a new virtual drive.
- Deletion of an existing virtual drive, which is in the orphaned state.
- Non-disruptive changes to an existing virtual drive. These changes can be made on an existing virtual drive without loss of data, and without performance degradation:
 - Policy changes. For example, changing the write cache policy.
 - Modification of boot parameters

The removal of a LUN will cause a warning to be displayed. Ensure that you take action to avoid loss of data.

Unsupported LUN Modifications

Some modifications to existing LUNs are not possible without destroying the original virtual drive and creating a new one. All data is lost in these types of modification, and these modifications are not supported.

Disruptive modifications to an existing virtual drive are not supported. The following are unsupported disruptive changes:

- Any supported RAID level change that can be handled through reconstruction. For example, RAID0 to RAID1.
- Increasing the size of a virtual drive through reconstruction.
- Addition and removal of disks through reconstruction.

Destructive modifications are also not supported. The following are unsupported destructive modifications:

- RAID-level changes that do not support reconstruction. For example, RAID5 to RAID1.
- Shrinking the size of a virtual drive.
- RAID-level changes that support reconstruction, but where there are other virtual drives present on the same drive group.
- Disk removal when there is not enough space left on the disk group to accommodate the virtual drive.
- Explicit change in the set of disks used by the virtual drive.

LUN Dereferencing

A LUN is dereferenced when it is no longer used by any service profile. This can occur as part of the following scenarios:

- The LUN is no longer referenced from the storage profile
- The storage profile is no longer referenced from the service profile
- The server is disassociated from the service profile
- The server is decommissioned

When the LUN is no longer referenced, but the server is still associated, re-association occurs. When the service profile that contained the LUN is disassociated, the LUN state is changed to Not in Use. When the service profile that contained the LUN is deleted, the LUN state is changed to Orphaned. When decommissioning the server, the state of all the LUNs associated with the server is changed to Not in use or Orphaned. However, no action is taken to delete the actual LUNs.

Creating or Editing a Storage Profile

-
- Step 1** In the Task bar, type **Create Storage Profile** and press Enter.
This launches the **Create Storage Profile** dialog box.
- Step 2** In **Basic**, click **Organization** and select the location in which you want to create the storage profile.
- Step 3** Enter the **Name** and optional **Description**.
The name is case sensitive.
- Step 4** Select the server type where you plan to apply the storage profile.
- Step 5** In **Local LUNs**, click **Add** to add a new local LUN.
- Step 6** In the **Basic** tab, do the following:
- a) Enter the size in GB.
The size must be between 1 GB and 10240 GB.
 - b) Choose whether to enable automatic deployment for the local LUN.

- c) Choose whether this LUN can be expanded to use the entire available disk group. For each service profile, only one LUN can use this option.

Step 7 In the **Disk Group** tab, select the **Disk Group Configuration Policy** that you want to apply.

Step 8 In **Controller Defs**, click **Add**.

Step 9 Enable configuration protection in order to prevent a service profile using this local disk policy from being associated to a server with a different physical disk configuration.
If the service profile includes a local disk policy with configuration protection enabled, and there is an attempt to associate that service profile to a server that includes disks with a different local disk configuration, the association will immediately fail with a configuration mismatch error.

Caution We recommend that you enable configuration protection to preserve any data that may exist on local disks. If disabled, any existing volume that does not match the local disk configuration policy will be deleted.

Step 10 Set the RAID level.

Step 11 Click **Create**.

Disk Groups and Disk Group Configuration Policies

Servers in a chassis can use storage that is centralized in that chassis. You can select and configure the disks to be used for storage. A logical collection of these physical disks is called a disk group. Disk groups allow you to organize local disks. The storage controller controls the creation and configuration of disk groups.

A disk group configuration policy defines how a disk group is created and configured. The policy specifies the RAID level to be used for the disk group. It also specifies either a manual or an automatic selection of disks for the disk group, and roles for disks. You can use a disk group policy to manage multiple disk groups. However, a single disk group can be managed only by one disk group policy.

Creating or Editing a Disk Group Configuration Policy

Step 1 In the Task bar, type **Create Disk Group Configuration Policy** and press Enter. This launches the **Create Disk Group Configuration Policy** dialog box.

Step 2 In **Basic**, click **Organization** and select the location in which you want to create the disk group configuration policy.

Step 3 Enter the **Name** and optional **Description**.
The name is case sensitive.

Step 4 Select the **Raid Level**.
This can be one of the following:

- **Platform Default**
- **Simple**
- **RAID**
- **RAID 0 Striped**

- RAID 1 Mirrored
- RAID 5 Striped Parity
- RAID 6 Striped Dual Parity
- RAID 10 Mirrored & Striped
- RAID 50 Striped Parity & Striped
- RAID 60 Striped Dual Parity & Striped

Step 5 In **Disk Group**, select the **Drive Type**, type values for the drive information, and choose whether to use the remaining disks.

Step 6 In **Virtual Drive** icon, complete the fields as necessary.

Step 7 Click **Create**.
