



# Audit Logs

---

- [Audit Logs, on page 1](#)
- [Viewing the Audit Logs, on page 1](#)

## Audit Logs

Audit Logs record system events that occurred, where they occurred, and which users initiated them.

## Viewing the Audit Logs

You can view, export, print, or refresh the audit logs displayed on the **Audit Logs** page.

### SUMMARY STEPS

1. In the **Navigation** pane, click **Admin**.
2. Expand **All > Faults, Events, and Audit Log**.
3. In the work pane, click the **Audit Logs** tab.
4. The **Work** pane displays the audit logs.

### DETAILED STEPS

---

- Step 1** In the **Navigation** pane, click **Admin**.
- Step 2** Expand **All > Faults, Events, and Audit Log**.
- Step 3** In the work pane, click the **Audit Logs** tab.
- Step 4** The **Work** pane displays the audit logs.

Name	Description
<b>ID</b> column	The unique identifier associated with the message.
<b>Affected Object</b> column	The component that is affected by this issue. Click the object name to view the properties for this object.
<b>Trig</b> column	The user role associated with the user that triggered the event.

Name	Description
User column	The type of user.
Session ID column	The session ID associated with the session during which the event occurred.
Created at column	The day and time that the fault occurred.
Indication column	This can be one of the following: <ul style="list-style-type: none"><li>• <b>Creation</b>—A component was added to the system.</li><li>• <b>Modification</b>—An existing component was changed.</li></ul>
Description column	More information about the fault.
Modified Properties column	The system properties that were changed by the event.

---