



CHAPTER 2

Managing Licenses for Cisco Unified Conferencing for TelePresence

Revised: June 22, 2007, OL-11749-01

Topics in this section include:

- [About Licenses, page 2-1](#)
- [Viewing the Server MAC Address, page 2-2](#)
- [Obtaining a License File, page 2-2](#)
- [Uploading a New License File, page 2-3](#)
- [Upgrading Existing Licenses, page 2-3](#)
- [Displaying the Current License Summary, page 2-4](#)
- [Downloading the Current License File, page 2-4](#)
- [Checking License Manager Status, page 2-5](#)
- [Restarting License Manager, page 2-5](#)

About Licenses

Cisco provides a Product Authorization Key (PAK) with the Cisco Unified Conferencing for TelePresence order. After registering the PAK, Cisco Systems e-mails you a license file, and you upload the license file to the server to enable its capabilities. The License Manager service enforces these license limits.

[Table 2-1](#) provides information about Cisco Unified Conferencing for TelePresence licenses.

Table 2-1 *Cisco Unified Conferencing for TelePresence Licenses*

License	Description

Viewing the Server MAC Address

Procedure

Step 1

Step 2 **Maintenance > Licenses** **Install Licenses.** The MAC address displays in the Host ID (MAC address) area.

Related Topics

-
-

Obtaining a License File

Before You Begin

-
-
-

Procedure

Step 1

Step 2

Related Topics

-
-
-
-

Uploading a New License File

Before You Begin

Procedure

Step 1

Step 2

Maintenance > Licenses > Install Licenses

Step 3

Upload new license file



Caution

Step 4

Browse

Step 5

Related Topics

-
-

Upgrading Existing Licenses

Procedure

Step 1

Step 2

Step 3

Append incremental license file

Browse

Install License

Displaying the Current License Summary

Procedure

- Step 1
- Step 2
- Maintenance > Licenses > Licenses Summary

Maintenance > Licenses Licenses Summary

Download License

Save



Note We recommend that you back up this file.

[About Licenses, page 2-1](#)

[Upgrading Existing Licenses, page 2-3](#)

Checking License Manager Status

Use this procedure to verify that License Manager is running if scheduling requests fail or callers are blocked from entering meetings.

Procedure

-
- | | |
|---------------|--|
| Step 1 | Log in to the Administration Center. |
| Step 2 | Click License Manager > License Manager Status . The status displays in the License Manager Status area. |
-

Related Topics

- [About Licenses, page 2-1](#)
- [Restarting License Manager, page 2-5](#)

Restarting License Manager



Tip

```
/etc/init.d/mpx_lm restart
```

Maintenance > Licenses Install Licenses

Restart License Manager
