



Preface

This preface describes the objectives and organization of this guide and contains the following sections:

- [Document Revision History, page v](#)
- [Document Organization, page v](#)
- [Audience, page vi](#)
- [Objective, page vi](#)
- [Conventions, page vi](#)
- [Obtaining Documentation and Submitting a Service Request, page vii](#)

Document Revision History

The Document Revision History table below records technical changes to this document.

Document Version	Date	Change Summary
OL-29484-01	April 2013	This is the first version of this document.
OL-29484-02	May 2013	Changed the Version of the document.

Document Organization

Chapter	Description
Chapter 1, “Alarm and System Message Overview”	Describes the error message and alarm structure and provides sample messages and alarms.
Chapter 2, “Alarms”	Lists the Cisco VDS Service Broker Release 1.0.1 alarms and provides explanations and recommended actions.
Chapter 3, “Error Messages and Recovery Procedures”	Lists the Cisco VDS Service Broker Release 1.0.1 error messages and provides explanations and recommended actions.
Appendix A, “List of Abbreviations and Acronyms”	Lists the abbreviations and acronyms used in this guide and provides their expansions.

Audience

This publication is designed for the installer and user with a working knowledge of the Cisco VDS Service Broker Release 1.0.1 software. Users of this publication might also include network administrators and other people responsible for setting up and maintaining the Service Broker(SB).

Objective

This guide describes the Cisco VDS Service Broker Release 1.0.1 alarms and system error messages that you might encounter. This guide does not describe how to install your VDS-SB or how to configure software features on your system. It also does not provide detailed information about commands that have been created or changed for use by the SB. For hardware installation information, see the hardware installation guide for your SB.

Conventions

This guide uses basic conventions to represent text and table information.

Convention	Description
boldface font	Commands, keywords, and button names are in boldface .
<i>italic</i> font	Variables for which you supply values are in <i>italics</i> . Directory names and filenames are also in italics.
<code>screen font</code>	Terminal sessions and information the system displays are in <code>screen font</code> .
boldface screen font	Information you must enter is in boldface screen font .
<i>italic screen font</i>	Variables you enter are in <i>italic screen font</i> .
^	The symbol ^ represents the key labeled Control. For example, the key combination ^D in a screen display means hold down the Control key while you press the D key.
string	Defined as a nonquoted set of characters. For example, when setting a community string for SNMP to “public,” do not use quotation marks around the string, or the string will include the quotation marks.
vertical bars ()	Vertical bars separate alternative, mutually exclusive, elements.
{ }	Elements in braces are required elements.
[]	Elements in square brackets are optional.
{ x y z }	Required keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional keywords are grouped in brackets and separated by vertical bars.
[{ }]	Braces within square brackets indicate a required choice within an optional element.



Note

Means *reader take note*. Notes contain helpful suggestions or references to materials not contained in the manual.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

