



Cisco ATA 191 Analog Telephone Adapter Release Notes for Firmware Release 12.0(1)

First Published: 2017-11-22

Last Modified: 2018-11-14

Release Notes for Cisco ATA 191 Analog Telephone Adapter for Firmware Release 12.0(1)

These release notes support the Cisco 191 Analog Telephone Adapter (ATA) running Firmware Release 12.0(1).

The following table lists the support and protocol compatibility for the Cisco ATA 191.

Table 1: Cisco ATA 191, Support, and Firmware Release Compatibility

Cisco IP Phone	Protocol	Support Requirements
Cisco ATA 191	SIP	Cisco Unified Communications Manager 10.5(1) and later Cisco Unified Communications Manager DST Olsen version D or later

Cisco ATA 191 Analog Telephone Adapter

The Cisco ATA 191 Analog Telephone Adapter allows you to turn an analogue phone or fax communication devices into an IP phone. With this device, you can retain your investment in your current equipment, but also benefit from an IP-based telephony network.

The ATA 191 supports many of the current telephony features, including shared lines, conferencing, and voicemail. It has two images or partitions in permanent storage, which allows the device to recover if the initial image is corrupted. With the dedicated Problem Report Tool button, you can quickly and easily collect troubleshooting information.

The Cisco ATA 191 also supports IPv6, and SSH.

The ATA 191 is easily integrated into your current network. It has two RJ11 ports, each with a phone number, and one RJ45 port that provides access to an Ethernet network. Phone configuration is done through an IVR system, and you use a web interface to monitor logs and provide device information.

Where to Find More Information

- *Cisco ATA 191 Analog Telephone Adapter Administration Guide for Cisco Unified Communications Manager*

- *Cisco ATA 191 Analog Telephone Adapter User Guide for Cisco Unified Communications Manager*

Related Documentation

Use the following sections to obtain related information.

Cisco Unified Communications Manager Documentation

See the *Cisco Unified Communications Manager Documentation Guide* and other publications that are specific to your Cisco Unified Communications Manager release. Navigate from the following documentation URL:

<https://www.cisco.com/c/en/us/support/unified-communications/unified-communications-manager-callmanager/tsd-products-support-series-home.html>

Installation

Installation Requirements

Before you install the firmware release, you must ensure that your Cisco Unified Communications Manager is running the latest device pack. After you install a device pack on the Cisco Unified Communications Manager servers in the cluster, you need to reboot all the servers.



Note If your Cisco Unified Communications Manager does not have the required device pack to support this firmware release, the firmware may not work correctly.

For information on the Cisco Unified Communications Manager Device Packs, see http://www.cisco.com/c/en/us/td/docs/voice_ip_comm/cucm/compat/devpack_comp_mtx.html.

Install the Firmware Release on Cisco Unified Communications Manager

Before you use the Cisco Analog Telephone Adapter with Cisco Unified Communications Manager 10.5, or higher, you must install the latest firmware on all Cisco Unified Communications Manager servers in the cluster.

Besides Cisco Unified Communications Manager, the Cisco ATA 191 can also work with Cisco Unified Communications Manager Express and Cisco Unified Survivable Remote Site Telephony (SRST). Refer to the [Related Documentation, on page 2](#) section for more information.

Procedure

- Step 1** Go to the following URL:
<https://software.cisco.com/download/navigator.html?mdfid=268437683&flowid=77852>
- Step 2** Choose **ATA 190 Series Analog Telephone Adapters > ATA 191 Analog Telephone Adapter**.
- Step 3** In the Latest Releases folder, choose **12.0(1)**.
- Step 4** Select **cmterm-ata191.12-0-1-29.k3.cop.sgn** firmware, click the Download or Add to cart button, and follow the prompts.

- Step 5** Click the + next to the firmware file name in the Download Cart section to access additional information about this file. The hyperlink for the readme file is in the Additional Information section, which contains installation instructions for the corresponding firmware.
- Step 6** Follow the instructions in the readme file to install the firmware.

Install the Firmware Zip Files

Before you use the Cisco Analog Telephone Adapter with Cisco Unified Communications Manager 10.5, or higher, you must install the latest firmware on all Cisco Unified Communications Manager servers in the cluster.

Besides Cisco Unified Communications Manager, the Cisco ATA 191 can also work with Cisco Unified Communications Manager Express and Cisco Unified Survivable Remote Site Telephony (SRST). Refer to the [Related Documentation, on page 2](#) section for more information.

Procedure

-
- Step 1** Go to the following URL:
<https://software.cisco.com/download/navigator.html?mdfid=268437683&flowid=77852>
- Step 2** Choose **ATA 190 Series Analog Telephone Adapters > ATA 191 Analog Telephone Adapter**.
- Step 3** In the Latest Releases folder, choose **12.0(1)**.
- Step 4** Select **cmterm-ata191.12-0-1-29.zip** firmware, click the Download or Add to cart button, and follow the prompts.
- Step 5** Click the + next to the firmware file name in the Download Cart section to access additional information about this file. The hyperlink for the readme file is in the Additional Information section, which contains installation instructions for the corresponding firmware.
- Step 6** Follow the instructions in the readme file to install the firmware.
-

Limitations and Restrictions

Manufacturing Installed Certificate Signature and SHA-256 Support

The manufacturing installed certificate(MIC) signature has been updated from SHA-128 with RSA to SHA-256 with RSA. You must update and install the new SHA-2 certificates on the Cisco Unified Communications Manager for secure mode to function. You can download the new certificate from <http://www.cisco.com/security/pki/certs/cmca2.cer>.

All applications that authenticate the phone MIC should update the MIC, including the following:

- Cisco Unified Communications Manager
- Cisco Unified Survivable Remote Site Telephony
- Cisco Secure Access Control System
- Cisco Identity Services Engine

For additional information about SHA-2 use and support, see *Security Guide for Cisco Unified Communications Manager* (<https://www.cisco.com/c/en/us/support/unified-communications/unified-communications-manager-callmanager/products-maintenance-guides-list.html>).

Phone Behavior During Times of Network Congestion

- Administrative tasks, such as an internal port scan or security scan
- Attacks that occur on your network, such as a Denial of Service attack

Caveats

This section describes the resolved and open caveats, and provides information on accessing the Cisco Software Bug Toolkit.

View Caveats

You can search for caveats using the Cisco Bug Search.

Known caveats (bugs) are graded according to severity level, and can be either open or resolved.

Before you begin

To view caveats, you need the following items:

- Internet connection
- Web browser
- Cisco.com user ID and password

Procedure

-
- Step 1** Perform one of the following actions:
- Use this URL for all caveats: <https://bst.cloudapps.cisco.com/bugsearch/search?kw=Customer%20visible%20bug%20for%20ATA191%2012.0.1SR1&pf=prdNm&pfVal=286319456&sb=anfr&bt=custV>
 - Use this URL for open caveats: <https://bst.cloudapps.cisco.com/bugsearch/search?kw=Customer%20visible%20bug%20for%20ATA191%2012.0.1SR1&pf=prdNm&pfVal=286319456&sb=null&st=open&bt=custV>
 - Use this URL for resolved caveats: <https://bst.cloudapps.cisco.com/bugsearch/search?kw=Customer%20visible%20bug%20for%20ATA191%2012.0.1SR1&pf=prdNm&pfVal=286319456&sb=null&st=fd&bt=custV>
- Step 2** When prompted, log in with your Cisco.com user ID and password.
- Step 3** (Optional) Enter the bug ID number in the Search for field, then press **Enter**.
-

Cisco IP Phone Firmware Support Policy

For information on the support policy for phones, see <https://cisco.com/go/phonefirmwaresupport>.

Documentation, Service Requests, and Additional Information

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/c/en/us/td/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment causes interference to radio or television reception, which can be determined by turning the equipment off and on, users are encouraged to try to correct the interference by using one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications to this product not authorized by Cisco could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2019 Cisco Systems, Inc. All rights reserved.