



CHAPTER 16

Survivable Remote Site Telephony Configuration

Use the following topics to add, update, copy, or delete a SRST reference:

- [SRST Reference Configuration Settings, page 16-1](#)
- [Related Topics, page 16-3](#)

SRST Reference Configuration Settings

In Cisco Unified Communications Manager Administration, use the **System > SRST** menu path to configure SRST references.

A survivable remote site telephony (SRST) reference comprises the gateway that can provide limited Cisco Unified Communications Manager functionality when all other Cisco Unified Communications Manager servers for a device are unreachable. Typically assigned to device pools, SRST references determine the gateways where calling devices search when they attempt to complete a call if Cisco Unified Communications Manager is unavailable. For more detailed information on SRST references, see the “[Survivable Remote Site Telephony References](#)” section in the *Cisco Unified Communications Manager System Guide*.

Tips About Deleting SRST References

You cannot delete SRST references that device pools or other items are using. To find out which device pools are using the SRST reference, click the **Dependency Records** link from the SRST Reference Configuration window. If the dependency records are not enabled for the system, the dependency records summary window displays a message. For more information about dependency records, see the “[Accessing Dependency Records](#)” section on page A-2. If you try to delete an SRST reference that is in use, Cisco Unified Communications Manager displays an error message. Before deleting an SRST reference that is currently in use, you must perform either or both of the following tasks:

- Assign a different SRST reference to any device pools that are using the SRST reference that you want to delete. See the “[Device Pool Configuration Settings](#)” section on page 8-1.
- Delete the device pools that are using the SRST reference that you want to delete. See the “[Device Pool Configuration Settings](#)” section on page 8-1.



Caution

Before initiating a deletion, check carefully to ensure that you are deleting the correct SRST reference. You cannot retrieve deleted SRST references. If an SRST reference is accidentally deleted, you must rebuild it.

Using the GUI

For instructions on how to use the Cisco Unified Communications Manager Administration Graphical User Interface (GUI) to find, delete, configure, or copy records, see the “[Navigating the Cisco Unified Communications Manager Administration Application](#)” section on page 1-13 and its subsections, which explain how to use the GUI and detail the functions of the buttons and icons.


Configuration Settings Table

Table 16-1 describes the SRST reference configuration settings. For related procedures, see the “[Related Topics](#)” section on page 16-3.

Table 16-1 SRST Reference Configuration Settings

Field	Description
Name	Enter a name in the SRST Reference Name field. The name can comprise up to 50 alphanumeric characters and can contain any combination of spaces, periods (.), hyphens (-), and underscore characters (_). Ensure that each SRST reference name is unique. Note Use concise and descriptive names for your SRST references.
Port	Enter the port number for this SRST reference. Default value specifies 2000. Note Change this value only if it does not match the gateway port setting. This value and the gateway port setting must match.
IP Address	Enter the IP address of the gateway for devices in a device pool to use as an SRST reference.
SIP Network/IP Address	Enter the IP address of the server that the phones that are running SIP will use when in SRST mode. Tip You must configure the SIP Network/IP Address field and the SIP Port field for a SIP device to fall back to the SRST-enabled gateway
SIP Port	Enter the SIP port of the SRST gateway. Default value specifies 5060.
Is SRST Secure?	After you verify that the SRST-enabled gateway contains a self-signed certificate, check this check box. After you configure the SRST and reset the gateway and dependent phones, the Cisco CTL Provider service authenticates to the Certificate Provider service on the SRST-enabled gateway. The Cisco CTL client retrieves the certificate from the SRST-enabled gateway and stores the certificate in the Cisco Unified Communications Manager database. Tip To remove the SRST certificate from the database and phone, uncheck this check box, click Save , and reset the dependent phones.

Table 16-1 SRST Reference Configuration Settings (continued)

Field	Description
SRST Certificate Provider Port	<p>This port monitors requests for the Certificate Provider service on the SRST-enabled gateway. Cisco Unified Communications Manager uses this port to retrieve the certificate from the SRST-enabled gateway. The Cisco SRST Certificate Provider default port equals 2445.</p> <p>After you configure this port on the SRST-enabled gateway, enter the port number in this field.</p> <p>Tip You may need to configure a different port number if the port is currently used or if you use a firewall and you cannot use the port within the firewall.</p>
Update Certificate	<p> Tip This button displays only after you check the Is SRST Secure? check box and click Save.</p> <p>After you click this button, the Cisco CTL client replaces the existing SRST-enabled gateway certificate that is stored in the Cisco Unified Communications Manager database, if a certificate exists in the database. After you reset the dependent phones, the TFTP server sends the cnf.xml file (with the new SRST-enabled gateway certificate) to the phones.</p>

Additional Information

See the “[Related Topics](#)” section on page 16-3.

Related Topics

- [Survivable Remote Site Telephony Configuration, page 16-1](#)
- [SRST Reference Configuration Settings, page 16-1](#)
- [Survivable Remote Site Telephony References, Cisco Unified Communications Manager System Guide](#)

