



Application server setup

This chapter provides information about working with and configuring application servers in Cisco Unified Communications Manager Administration.

- [About application server setup, page 1](#)
- [Application server settings, page 2](#)

About application server setup

In Cisco Unified Communications Manager Administration, use the **System > Application Server** menu path to configure application servers.

You can use the Application Server windows in Cisco Unified Communications Manager Administration to maintain associations between the Cisco Unified Communications Manager and off-cluster, external applications, such as Cisco Unity Connection, Cisco Unified Presence, and Cisco Emergency Responder, and to synchronize Cisco Unified Communications Manager systems and applications, such as Cisco Web Dialer.



Tip

Application server configuration does not support Cisco Unity Connection 2.x. To push a list of valid user templates for Cisco Unity Connection 2.x to Cisco Unified Communications Manager, create an AXL connection via Cisco Unity Connection 2.x, as described in the System Administration Guide for Cisco Unity Connection.

Application server configuration tips

You can configure the application servers in Cisco Unified Communications Manager Administration after both the Cisco Unified Communications Manager servers and any other application servers are set up and fully operational and are running with a valid configuration.



Note

For Cisco Unity Connection, make sure that AXL is running on the Cisco Unified Communications Manager server that was configured to communicate with Cisco Unity Connection.

Application server settings

The following table describes all the available settings in the Application Server window. Because each server requires different settings, not all the settings in the table below apply to each server.

Table 1: Application server settings

Field	Description
Application Server Information	
Application Server Type	Choose the applicable application server for the type of application to which you want to connect (for example, to connect to a presence application servers, choose Cisco Unified Presence). Note Cisco does not support the Cisco Unity Voice Mail 4.x server for Cisco Unified Communications Manager Business Edition 5000 systems.
Name	Enter a name to identify the application server that you are configuring.
IP Address	Enter the IP address of the server that you are configuring. Note Ensure the IP address is numeric with a number pattern between 1-255 (10.255.172.57). Tip For Cisco Unity Connection, you must use the same Administrator user name and password that you defined in Cisco Unity Connection Administration. This user ID provides authentication between Cisco Unity Connection and Cisco Unified Communications Manager Administration.
URL	Enter a URL for the application server.
End User URL	Enter a URL for the end users that are associated with this application server.
Available Application Users	This pane displays the application users that are available for association with this application server. To associate an application user with this application server, select the application user (for example, CCMAAdministrator, CCMSysUser, UnityConnection, and so on) and click the Down arrow below this pane.
Selected Application Users	This pane displays the application users that are associated with the application server. To remove an application user, select the application user and click the Up arrow above this pane. To add an application user, select an application user in the Available Application Users pane and click the Down arrow.

Related Topics

[Application server setup, on page 1](#)