



Maintenance

- [Basic Reset, on page 1](#)

Basic Reset





Performing a basic reset of a Cisco IP Phone provides a way to recover when the phone experiences an error. The reset provides a way to reset or restore various configuration and security settings.



Note When you set up emergency calls, the phone requests an updated location whenever a person restarts the phone.

The following table describes the ways to perform a basic reset. You can reset a phone with any of these operations after the phone has started up. Choose the operation that is applicable for your situation.

Table 1: Basic Reset Methods

Operation	Action	Expla
Restart phone	Press Applications  and choose Admin Settings > Cold Reboot . Press Applications  and choose Admin Settings > Reset settings > Cold Reboot .	Reset writte
Reset settings	To reset settings, press Applications  and choose Admin Settings > Factory Reset . To reset settings, press Applications  and choose Admin Settings > Reset settings > Factory Reset .	Resto



Note When you set up emergency calls, the phone requests an updated location whenever the you do the following actions:

- Registers the phone with the call server.
 - Restarts the phone (phone is registered).
 - Changes the network interface that is used for the SIP registration.
 - Changes the IP address of the phone.
-

Factory Reset the Phone with the Keypad

Use these steps to reset the phone to factory default settings using the phone keypad.

You have two methods to perform the factory reset by using the keypad:

- **Method 1** (recommended): Press # > **123456789*0#**
- **Method 2**: Press **0 > 369#**

Before you begin

You must know if your phone is an original hardware release or if the hardware has been updated and re-released.

Procedure

Step 1 Unplug the phone:

- If using PoE, unplug the LAN cable.
- If using the power cube, unplug the power cube.

Step 2 Wait 5 seconds.

Step 3 Press and hold # and plug the phone back in.

Step 4 Do one of the following actions:

- **Method 1**: Press and hold # and plug the phone back in.
- **Method 2**: Press and hold **0** and plug the phone back in.

Only the Cisco IP Phone 6821 support the method.

Only the Cisco IP Phone 8845, 8865, 8841, 8851 and 8861 support the method. And the hardware version of Cisco IP Phone 8841, 8851, and 8861 must be 15 or later.

The phone begins the reboot process. The headset button and the speaker button light up.

Step 5 On earlier hardware versions, the Mute button lights up. Wait for the Mute button to turn off.

Step 6 Press #, then press **123456789*0#** in sequence.

When you press **1**, the lights on the headset button turns off. The light on the Select button flashes when a button is pressed.

After you press these buttons, the phone goes through the factory reset process.

If you press the buttons out of sequence, the phone powers on normally.

Caution Do not power down the phone until it completes the factory reset process, and the main screen appears.

Step 7 Do one of the following actions:

- **Method 1:** Press **123456789*0#** in sequence.

When you press **1**, the lights on the headset button turns off. The light on the Select button flashes when a button is pressed.

After you press these buttons, the phone goes through the factory reset process.

If you press the buttons out of sequence, the phone powers on normally.

Caution Do not power down the phone until it completes the factory reset process, and the main screen appears.

- **Method 2:** Press **369#** in sequence.

For Cisco IP Phone 6821, after you press these buttons, the phone still remains on the same screen, and all LEDs change to solid green.


For the Cisco IP Phone 8845, 8865, 8841, 8851 and 8861, the phone screen disappears. At the same time, the lights on the Headset, Speaker, and Mute are flashing.

Step 8 If you use the **Method 2**, unplug and plug in the phone again to reboot it.

After the phone reboots, the main screen appears.

Perform Factory Reset from Phone Menu

Procedure

- Step 1** Press **Applications** .
- Step 2** Select **Device administration > Factory reset**.
- Step 3** To restore phone configuration or settings to factory default, press **OK**.
-

Factory Reset the Phone from Phone Web Page

You can restore your phone to its original manufacturer settings from the phone web page. After you reset the phone, you can reconfigure it.

Procedure

Reset your phone from the phone web page from one of the methods:

- Enter the URL in a supported web browser and click **Confirm Factory Reset**.

You can enter URL in the format:

```
http://<Phone IP>/admin/factory-reset
```

where:

Phone IP = actual IP address of your phone.

/admin = path to access admin page of your phone.

factory-reset = command that you need to enter in the phone web page to factory-reset your phone.

- On the phone web page, select **Admin Login > Advanced > Info > Debug Info**. Click **Factory Reset** in the **Factory Reset** section and confirm the factory reset message in the next screen. Click **Submit All Changes**.
-

Identify Phone Issues with a URL in the Phone Web Page

When the phone doesn't work or doesn't register, a network error or any misconfiguration might be the cause. To identify the cause, add a specific IP address or a domain name to the phone admin page. Then, try to access so that the phone can ping the destination and display the cause.

Procedure

In a supported web browser, enter a URL that consists of your phone IP address and the destination IP that you want to ping. Enter the URL using the format:

```
http://<Phone IP>/admin/ping?<ping destination>, where:
```

<Phone IP> = actual IP address of your phone.

/admin = path to the access admin page of your phone.

<ping destination> = any IP address or domain name that you want to ping.

The ping destination allows only alphanumeric characters, '-', and '_' (underscores). Otherwise the phone shows an error on the web page. If the <ping destination> includes spaces, the phone uses only the first part of the address as the pinging destination.

For example, to ping the 192.168.1.1 address:

```
http://<Phone IP>/admin/ping?192.168.1.1
```
