

Configuring the Cisco Unified SIP Proxy

Last updated: April 29, 2019

- [Configuring Logical Networks, page 1](#)
- [Configuring Trigger Conditions, page 2](#)
- [Configuring Server Groups, page 4](#)
- [Configuring Route Tables, page 6](#)
- [Configuring Normalization Policies, page 8](#)
- [Configuring Lookup Policies, page 9](#)
- [Configuring Routing Triggers, page 11](#)
- [Configuring Normalization Triggers, page 12](#)
- [Configuring Listen and Record-Route Ports, page 13](#)
- [Configuring a Hostname, page 14](#)
- [Configuring Transport Layer Security \(TLS\), page 15](#)
- [Configuring Lite Mode, page 19](#)
- [Configuring Performance Control, page 20](#)
- [Committing the Configuration, page 21](#)

Configuring Logical Networks

Each interface on the Cisco Unified SIP Proxy is associated with a logical network. Logical networks are used to organize server groups, listen points, and other properties. SIP messages are associated with the network on which they arrive.

- [Summary Steps, page 1](#)
- [Detailed Steps, page 2](#)
- [Example, page 2](#)

Summary Steps

1. **cuspx**
2. **configure**
3. **sip network *network***
4. **end network**

Detailed Steps

	Command or Action	Purpose
Step 1	<code>culp</code> Example: <code>se-10-0-0-0> culp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: <code>se-10-0-0-0(culp)> configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>sip network network</code> Example: <code>se-10-0-0-0(culp-config)> sip network service-provider</code>	Creates a network and puts you into network command mode. In this case, the network that is being created is called “service provider”.
Step 4	<code>end network</code> Example: <code>se-10-0-0-0(culp-config-network)> end network</code>	Exits network command mode.

Example

The following example creates a network called “service-provider”:

```
se-10-0-0-0> culp
se-10-0-0-0(culp)> configure
se-10-0-0-0(culp-config)> sip network service-provider
se-10-0-0-0(culp-config-network)> end network
```

Configuring Trigger Conditions

You create trigger conditions to allow Cisco Unified SIP Proxy to respond with the appropriate action for various call flows. In general, the more complex the call flow is, the more complex the trigger must be.

- [Summary Steps, page 2](#)
- [Detailed Steps, page 3](#)
- [Example, page 4](#)

Summary Steps

1. `culp`
2. `configure`
3. `trigger condition trigger-condition-name`

4. **sequence** *sequence-number*
5. (Optional) **in-network** *network-name*
6. (Optional) **mid-dialog**
7. end sequence
8. end trigger condition

Detailed Steps

	Command or Action	Purpose
Step 1	<code>culp</code> Example: <code>se-10-0-0-0> culp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: <code>se-10-0-0-0(culp)> configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>trigger condition trigger-condition-name</code> Example: <code>se-10-0-0-0(culp-config)> trigger condition call-from-service-provider</code>	Creates a trigger condition and puts you into trigger command mode. In this case, the trigger that is being created is called “call-from-service-provider”.
Step 4	<code>sequence sequence-number</code> Example: <code>se-10-0-0-0(culp-config-trigger)> sequence 1</code>	Creates a sequence with the specified number and puts you into trigger sequence command mode. The number indicates the order in which triggers are evaluated. In this case, the sequence that is being created is sequence number 1.
Step 5	<code>in-network network-name</code> Example: <code>se-10-0-0-0(culp-config-trigger-seq)> in-network service-provider</code>	Optional. Specifies the incoming network name for the trigger condition. In this case, the incoming network is the “service-provider” network.
Step 6	<code>mid-dialog</code> Example: <code>se-10-0-0-0(culp-config-trigger-seq)> mid-dialog</code>	Optional. A special trigger that bypasses routing policies on mid-dialog messages.

	Command or Action	Purpose
Step 7	<code>end sequence</code> Example: <code>se-10-0-0-0(cusp-config-trigger-seq) > end sequence</code>	Exits the trigger sequence command mode.
Step 8	<code>end trigger condition</code> Example: <code>se-10-0-0-0(cusp-config-trigger) > end trigger condition</code>	Exits the trigger command mode.

Example

In this example, Cisco Unified SIP Proxy only reacts based on the network the call came in on, so the triggers are simple.

```
se-10-0-0-0> cusp
se-10-0-0-0(cusp) > configure
se-10-0-0-0(cusp-config) > trigger condition call-from-service-provider
se-10-0-0-0(cusp-config-trigger) > sequence 1
se-10-0-0-0(cusp-config-trigger-seq) > in-network service-provider
se-10-0-0-0(cusp-config-trigger-seq) > end sequence
se-10-0-0-0(cusp-config-trigger) > end trigger condition

se-10-0-0-0(cusp-config) > trigger condition mid-dialog
se-10-0-0-0(cusp-config-trigger) > sequence 1
se-10-0-0-0(cusp-config-trigger-seq) > mid-dialog
se-10-0-0-0(cusp-config-trigger-seq) > end sequence
se-10-0-0-0(cusp-config-trigger) > end trigger condition
```

Configuring Server Groups

- [About Server Groups, page 4](#)
- [Summary Steps, page 5](#)
- [Detailed Steps, page 5](#)
- [Example, page 6](#)

About Server Groups

Server groups define the elements that Cisco Unified SIP Proxy interacts with for each network. The server group name that is used is inserted into the SIP URI of the outgoing request. Some devices, such as Cisco Unified Communications Manager, validate the URI of requests before processing, which means that the end device might need to be configured with a Fully Qualified Domain Name (FQDN) to allow for this.

Two of the fields for each individual element, q-value and weight, are important to use to specify the priorities of elements, and also for load balancing. Calls are routed to specific elements based on q-value. The element with the highest q-value receives all traffic routed to that server group. If multiple elements have the same q-value, traffic is distributed between them based on the load-balancing option used. The

default load-balancing is based on call-id, but weight can also be used. If weight is used, the percentage of traffic that an element receives is equal to its weight divided by the sum of up elements with the same q-value's weights. The sum of their weights does not need to equal 100. You can change the weights and q-values to configure a different priority or load-balancing scheme.

Summary Steps

1. **cusp**
2. **configure**
3. **server-group sip group *server-group-name network***
4. **element ip-address *ipaddress port {udp | tcp | tls} [q-value *q-value*] [weight *weight*]***
5. **lb-type {global | highest-q | request-uri | call-id | to-uri | weight }**
6. **end server-group**

Detailed Steps

	Command or Action	Purpose
Step 1	cusp Example: se-10-0-0-0> cusp	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-0-0-0(cusp)> configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	server-group sip group <i>server-group-name network</i> Example: se-10-0-0-0(cusp-config)> server-group sip group sp.example.com service-provider	Creates a SIP server group and enters server group command mode. In this case, the server group being created is called “sp.example.com” and it uses the network called “service-provider”.
Step 4	element ip-address <i>ipaddress port {udp tcp tls} [q-value <i>q-value</i>] [weight <i>weight</i>]</i> Example: se-10-0-0-0(cusp-config-sg)> element ip-address 192.168.10.3 5060 tls q-value 1.0 weight 100	Creates an IP element for a SIP server group and determines the characteristics of the SIP server group. Note You can enter this command multiple times.

	Command or Action	Purpose
Step 5	<pre>lb-type {global highest-q request-uri call-id to-uri weight }</pre> <p>Example: se-10-0-0-0(cusp-config-sg) > lb-type weight</p>	Configures the load-balancing algorithm for the SIP server group. In this example, it specifies that the element will be selected proportional to its weight relative to the weights of other elements of the same q-value.
Step 6	<pre>end server-group</pre> <p>Example: se-10-0-0-0(cusp-config-sg) > end server-group</p>	Exits the server group command mode.

Example

```
se-10-0-0-0> cusp
se-10-0-0-0(cusp) > configure
se-10-0-0-0(cusp-config) > server-group sip group sp.example.com service-provider
se-10-0-0-0(cusp-config-sg) > element ip-address 192.168.10.3 5060 tls q-value 1.0 weight
100
se-10-0-0-0(cusp-config-sg) > element ip-address 192.168.10.4 5060 tls q-value 1.0 weight
50
se-10-0-0-0(cusp-config-sg) > element ip-address 192.168.10.5 5060 tls q-value 1.0 weight
50
se-10-0-0-0(cusp-config-sg) > lb-type weight
se-10-0-0-0(cusp-config-sg) > end server-group
```

Configuring Route Tables

- [About Route Tables, page 6](#)
- [Summary Steps, page 6](#)
- [Detailed Steps, page 7](#)
- [Example, page 7](#)

About Route Tables

You must configure route tables to direct SIP requests to their appropriate destinations. Each route table consists of a set of keys that are matched based on the lookup policy. For example, each key might represent the prefix of a phone number dialed.

Summary Steps

1. **cusp**
2. **configure**
3. **route table** *table-name*
4. **key** *key* **response** *response-code*
5. **key** *key* **target-destination** *target-destination network*

6. end route table

Detailed Steps

	Command or Action	Purpose
Step 1	<code>cusp</code> Example: <code>se-10-0-0-0> cusp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: <code>se-10-0-0-0(cusp)> configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>route table table-name</code> Example: <code>se-10-0-0-0(cusp-config)> route table service-provider-table</code>	Creates a route table and enters route table command mode. In this case, it creates a route table called “service-provider-table”.
Step 4	<code>key key response response-code</code> Example: <code>se-10-0-0-0(cusp-config-rt)> key * response 404</code>	Assigns a response code to a lookup key. In this example, it returns a response of “404” to everything.
Step 5	<code>key key target-destination target-destination network</code> Example: <code>se-10-0-0-0(cusp-config-rt)> key 510 target-destination cube-sp.example.com cube-sp</code>	Replaces the key part of the target destination with a specified value. Note You can enter this command multiple times.
Step 6	<code>end route table</code> Example: <code>se-10-0-0-0(cusp-config-rt)> end route table</code>	Exits the route table command mode.

Example

```

se-10-0-0-0> cusp
se-10-0-0-0(cusp)> configure
se-10-0-0-0(cusp-config)> route table service-provider-table
se-10-0-0-0(cusp-config-rt)> key * response 404
se-10-0-0-0(cusp-config-rt)> key 510 target-destination cube-sp.example.com cube-sp
se-10-0-0-0(cusp-config-rt)> end route table

```

Configuring Normalization Policies

Normalization policies modify SIP messages to account for incompatibilities between networks. In this case, the service provider cannot handle phone numbers with the escape sequence “91,” so the sequence must be removed from the request-uri and TO header.

- [Summary Steps, page 8](#)
- [Detailed Steps, page 8](#)
- [Example, page 9](#)

Summary Steps

1. **culp**
2. **configure**
3. **policy normalization** *policy_name*
4. **uri-component update request-uri** {user | host | host-port | phone | uri} {all | match-string} *replace-string*
5. **uri-component update header** {first | last | all} {user | host | host-port | phone | uri} {all | match-string} *replace-string*
6. **end policy**

Detailed Steps

	Command or Action	Purpose
Step 1	culp Example: se-10-0-0-0> culp	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-0-0-0(culp)> configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	policy normalization <i>policy-name</i> Example: se-10-0-0-0(culp-config)> policy normalization outgoing-norm-policy	Creates a normalization policy and enters policy normalization command mode. In this example, the normalization policy is called “outgoing-norm-policy”.
Step 4	uri-component update request-uri {user host host-port phone uri} {all match-string} <i>replace-string</i> Example: se-10-0-0-0(culp-config-norm)> uri-component update request-uri user ^91 ""	Configures a normalization policy step that updates a URI component field within a request URI.

	Command or Action	Purpose
Step 5	<pre>uri-component update header {first last all} {user host host-port phone uri} {all match-string} replace-string</pre> <p>Example: se-10-0-0-0(cusp-config-norm) > uri-component update TO all user ^91 ""</p>	Configures a normalization policy step that updates a URI component field within a header of the source message.
Step 6	<pre>end policy</pre> <p>Example: se-10-0-0-0(cusp-config-norm) > end policy</p>	Exits policy normalization command mode.

Example

```
se-10-0-0-0> cusp
se-10-0-0-0(cusp) > configure
se-10-0-0-0(cusp-config) > policy normalization outgoing-norm-policy
se-10-0-0-0(cusp-config-norm) > uri-component update request-uri user ^91 ""
se-10-0-0-0(cusp-config-norm) > uri-component update TO all user ^91 ""
se-10-0-0-0(cusp-config-norm) > end policy
```

Configuring Lookup Policies

Lookup policies decide how the keys in the route tables are used. Each key represents the beginning of the phone number dialed because each policy states to match the user component of the request-uri against the keys in its route table. The user component of the request-uri is the phone number called. The rule used to match is prefix, which means that the longest prefix match in the route table is used. So if the dialed number is 510-1XX-XXXX, the call is sent to the cme.example.com server group. If the dialed number is 510-XXX-XXXX, the call is sent to the cucm.example.com server group. The four policies in the following example are identical, except that they each refer to their specific table.

- [Summary Steps, page 9](#)
- [Detailed Steps, page 10](#)
- [Example, page 10](#)

Summary Steps

1. **cusp**
2. **configure**
3. **policy lookup** *policy-name*
4. **sequence** *sequence-number table-name* **field** {in-network | local-ip-address | local-ip-port | remote-ip-address | remote-ip-port} | **header** {p-asserted identity| from | to | diversion| remote-party-id} | **request uri** [uri component {param| user | phone | host| host-port| uri}]
5. **rule** {exact | prefix | subdomain | subnet | fixed *length*} [case-insensitive]
6. **end sequence**

7. end policy

Detailed Steps

	Command or Action	Purpose
Step 1	<code>cusp</code> Example: <code>se-10-0-0-0> cusp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: <code>se-10-0-0-0(cusp)> configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>policy lookup policy-name</code> Example: <code>se-10-0-0-0(cusp-config)> policy lookup service-provider-policy</code>	Creates a policy with the specified name and enters policy lookup command mode. In this case, creates a policy called “service-provider-policy”.
Step 4	<code>sequence sequence-number table-name field {in-network local-ip-address local-ip-port remote-ip-address remote-ip-port} header {p-asserted identity from to diversion remote-party-id} request uri [uri component {param user phone host host-port uri}]</code> Example: <code>se-10-0-0-0(cusp-config-lookup)> sequence 1</code>	Creates a sequence with the specified number and enters policy lookup sequence command mode. Sequences are performed according to the order of their number.
Step 5	<code>rule {exact prefix subdomain subnet fixed length} [case-insensitive]</code> Example: <code>se-10-0-0-0(cusp-config-lookup-seq)> rule prefix</code>	Creates a rule that determines the routing algorithm for the lookup policy. In this case, it creates a rule that specifies that the lookup policy searches for the longest prefix match.
Step 6	<code>end sequence</code> Example: <code>se-10-0-0-0(cusp-config-lookup-seq)> end sequence</code>	Exits policy lookup sequence command mode.
Step 7	<code>end policy</code> Example: <code>se-10-0-0-0(cusp-config-lookup)> end policy</code>	Exits policy lookup command mode.

Example

```
se-10-0-0-0> cusp
se-10-0-0-0(cusp)> configure
se-10-0-0-0(cusp-config)> policy lookup service-provider-policy
```

```

se-10-0-0-0(cusp-config-lookup) > sequence 1 service-provider-table request-uri
uri-component user
se-10-0-0-0(cusp-config-lookup-seq) > rule prefix
se-10-0-0-0(cusp-config-lookup-seq) > end sequence
se-10-0-0-0(cusp-config-lookup) > end policy

```

Configuring Routing Triggers

Routing triggers correlate trigger conditions with lookup policies. A single policy is chosen based on which corresponding condition is matched. The conditions are evaluated in ascending order based on sequence number. The mid-dialog condition is the first one so that the policy step is skipped for mid-dialog messages. Based on the following configuration, after the INVITE message is successfully routed, all subsequent messages (which are mid-dialog) bypass routing policies.

- [Summary Steps, page 11](#)
- [Detailed Steps, page 11](#)
- [Example, page 12](#)

Summary Steps

1. **cusp**
2. **configure**
3. **trigger routing sequence** *sequence-number* **{by-pass | policy *policy*}** **[condition** *trigger-condition*]

Detailed Steps

	Command or Action	Purpose
Step 1	cusp Example: se-10-0-0-0 > cusp	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-0-0-0(cusp) > configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	trigger routing sequence <i>sequence-number</i> {by-pass policy <i>policy</i>} [condition <i>trigger-condition</i>] Example: se-10-0-0-0(cusp-config) > trigger routing sequence 2 policy service-provider-policy condition call-from-service-provider	Associates a routing policy with a trigger condition. In this example, the second sequence follows the previously-created policy called “service-provider-policy” and the previously-created trigger called “call-from-service-provider”.

Example

```

se-10-0-0-0> cusp
se-10-0-0-0(cusp)> configure
se-10-0-0-0(cusp-config)> trigger routing sequence 1 by-pass condition mid-dialog
se-10-0-0-0(cusp-config)> trigger routing sequence 2 policy service-provider-policy
condition call-from-service-provider
se-10-0-0-0(cusp-config)> trigger routing sequence 3 policy cube-sp-policy condition
call-from-cube-sp
se-10-0-0-0(cusp-config)> trigger routing sequence 4 policy cube-es-policy condition
call-from-cube-es
se-10-0-0-0(cusp-config)> trigger routing sequence 5 policy enterprise-policy condition
call-from-enterprise

```

Configuring Normalization Triggers

Normalization triggers correlate trigger conditions with normalization policies. There are two types of triggers: pre-normalization, which occurs before routing, and post-normalization, which occurs after routing. Similar to routing policies, a special policy bypasses normalization on mid-dialog messages.

- [Summary Steps, page 12](#)
- [Detailed Steps, page 12](#)
- [Example, page 13](#)

Summary Steps

1. **cusp**
2. **configure**
3. **trigger pre-normalization sequence** *sequence-number* {**by-pass** | **policy** *policy*} [**condition** *trigger-condition*]

Detailed Steps

	Command or Action	Purpose
Step 1	cusp Example: se-10-0-0-0> cusp	Enters Cisco Unified SIP Proxy EXEC mode.

	Command or Action	Purpose
Step 2	<code>configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
	Example: se-10-0-0-0(cusp) > <code>configure</code>	
Step 3	<code>trigger pre-normalization sequence sequence-number</code> { <code>by-pass</code> <code>policy policy</code> } [<code>condition</code> <code>trigger-condition</code>]	Configures a pre-normalization algorithm for incoming SIP messages to a normalization policy. In this example, the second sequence follows the previously-created policy called “outgoing-norm-policy” and the previously-created trigger called “call-from-cube-sp”.
	Example: se-10-0-0-0(cusp-config) > <code>trigger pre-normalization</code> <code>sequence 2 policy outgoing-norm-policy condition</code> <code>call-from-cube-sp</code>	

Example

```
se-10-0-0-0> cusp
se-10-0-0-0(cusp) > configure
se-10-0-0-0(cusp-config) > trigger pre-normalization sequence 1 by-pass condition
mid-dialog
se-10-0-0-0(cusp-config) > trigger pre-normalization sequence 2 policy outgoing-norm-policy
condition call-from-cube-sp
```

Configuring Listen and Record-Route Ports

You must configure listen and record-route ports for each network. For the listen and record-route ports, the actual addresses of the Cisco Unified SIP Proxy module are used. The **sip record-route** command inserts the record-route header into outgoing requests. The **sip listen** command allows for Cisco Unified SIP Proxy to accept incoming requests on that port.

- [Summary Steps, page 13](#)
- [Detailed Steps, page 14](#)
- [Example, page 14](#)

Summary Steps

1. `cusp`
2. `configure`
3. `sip record-route network_name {tcp | tls | udp} ip_address [port]`
4. `sip listen network_name {tcp | tls | udp} ip_address port`

Detailed Steps

	Command or Action	Purpose
Step 1	<code>cusp</code> Example: <code>se-10-0-0-0> cusp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: <code>se-10-0-0-0(cusp)> configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>sip record-route network_name {tcp tls udp} ip_address [port]</code> Example: <code>se-10-0-0-0(cusp-config)> sip record-route service-provider udp 10.10.10.99 5060</code>	Enables record-routing for a SIP network. In this example, the “service-provider” network is associated with a record-route configuration and the IP address that populates the record-route header field is “10.10.10.99” and the port that populates the record-route header is 5060.
Step 4	<code>sip listen network_name {tcp tls udp} ip_address port</code> Example: <code>se-10-0-0-0(cusp-config)> sip listen service-provider udp 10.10.10.99 5060</code>	Creates a listener that listens for SIP traffic on a specific SIP network, host, and port.

Example

```
se-10-0-0-0> cusp
se-10-0-0-0(cusp)> configure
se-10-0-0-0(cusp-config)> sip record-route service-provider udp 10.10.10.99 5060
se-10-0-0-0(cusp-config)> sip listen service-provider udp 10.10.10.99 5060
```

Configuring a Hostname

If the upstream element is using DNS SRV for routing to the two Cisco Unified SIP Proxies in a network, you must configure the two Cisco Unified SIP Proxies to have the same FQDN by entering the **sip alias** command in Cisco Unified SIP Proxy configuration mode on both Cisco Unified SIP Proxies.

- [Summary Steps, page 14](#)
- [Detailed Steps, page 15](#)
- [Example, page 15](#)

Summary Steps

1. `cusp`

2. **configure**
3. **sip alias** *hostname*

Detailed Steps

	Command or Action	Purpose
Step 1	cusps Example: se-10-0-0-0> cusps	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-0-0-0(cusp)> configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	sip alias <i>hostname</i> Example: se-10-0-0-0(cusp-config)> sip alias <i>myhost</i>	Configures the hostname of this instance.

Example

```
se-10-0-0-0> cusps
se-10-0-0-0(cusp)> configure
se-10-0-0-0(cusp-config)> sip alias myhost
```

Configuring Transport Layer Security (TLS)

- [Creating and Importing a Signed Certificate, page 15](#)
- [Configuring TLS on Cisco Unified SIP Proxy, page 17](#)

Creating and Importing a Signed Certificate

Cisco Unified SIP Proxy supports TLS, Transmission Control Protocol (TCP), and User Datagram Protocol (UDP). Establishing TLS connections requires some extra steps because the connections require authentication using signed certificates.

- [Prerequisites, page 16](#)
- [Summary Steps, page 16](#)
- [Detailed Steps, page 16](#)
- [Example of Creating a Signed Certificate, page 17](#)

Prerequisites

You need an FTP server or HTTP to import certificate requests.

Summary Steps

1. **configure terminal**
2. **crypto key generate [rsa {label *label-name* | modulus *modulus-size*} | default]**
3. **crypto key certreq label *label-name* url {ftp: | http:}**
4. **crypto key import rsa label *label-name* {der url {ftp: | http: } | pem { terminal | url {ftp: | http: }} [default]**
5. **crypto key import cer label *mykey* url ftp:**

Detailed Steps

	Command or Action	Purpose
Step 1	<code>configure terminal</code> Example: <code>se-10-0-0-0# configure terminal</code>	Enters configuration mode.
Step 2	<code>crypto key generate [rsa {label <i>label-name</i> modulus <i>modulus-size</i>} default]</code> Example: <code>se-10-0-0-0(config)> crypto key generate rsa label mykey modulus 512 default</code>	Creates an RSA private key.
Step 3	<code>crypto key certreq label <i>label-name</i> url {ftp: http:}</code> Example: <code>se-10-0-0-0(config)> crypto key certreq label mykey url ftp:</code>	Creates a certificate request to be signed.
Step 4	<code>crypto key import rsa label <i>label-name</i> {der url {ftp: http: } pem { terminal url {ftp: http: }} [default]</code> Example: <code>se-10-0-0-0(config)> crypto key import trustcert label rootCA url ftp:</code>	After the certificate request is signed, imports the trusted certificate authority (CA) certificate that you used to sign the request.
Step 5	<code>crypto key import cer label <i>label-name</i> {der url {ftp: http: } pem { terminal url {ftp: http: }} [default]</code> Example: <code>se-10-0-0-0(config)> crypto key import cer label mykey url ftp:</code>	After the root CA is imported, imports the signed certificate.

Example of Creating a Signed Certificate

```
se-10-0-0-0# configure terminal
se-10-0-0-0(config)# crypto key generate rsa label mykey modulus 512 default
Key generation in progress. Please wait...
The label name for the key is mykey

se-10-0-0-0(config)# crypto key certreq label mykey url ftp:
Address or name of remote host? 192.168.202.216
Username (ENTER if none)? anonymous
Password (not shown)?
Destination path? netmod/mykey.csr
Uploading CSR file succeed

se-10-0-0-0(config)# crypto key import trustcacert label rootCA url ftp:
Import certificate file...
Address or name of remote host? 192.168.202.216
Source filename? netmod/rootCA/cacert.pem
1212 bytes received.

se-10-0-0-0(config)# crypto key import cer label mykey url ftp:
Import certificate file...
Address or name of remote host? 192.168.202.216
Source filename? netmod/mycert.cer
952 bytes received.
Import succeeded
```

What To Do Next

- Import the trusted CA certificates for any of the TLS peer elements.

Configuring TLS on Cisco Unified SIP Proxy

After you import the certificates, you must enable TLS connections. If you want more security, you can create a list of trusted peers. If you create such a list, only connections from those peers are accepted. The peer's hostname entry must be the peer's subjectAltName in its certificate. If subjectAltName is not used in the certificate, the peer's hostname entry must be CN.

- [Summary Steps, page 17](#)
- [Detailed Steps, page 18](#)
- [Example of Configuring TLS, page 18](#)

Summary Steps

1. `cusp`
2. `configure`
3. `sip tls`
4. `sip tls trusted-peer {peer's-hostname}`
5. `sip tls connection-setup-timeout {value in seconds}`
6. `sip tls [v1.0 | v1.1 | v1.2]`

Detailed Steps

	Command or Action	Purpose
Step 1	<code>culp</code> Example: <code>se-10-0-0-0> culp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: <code>se-10-0-0-0(culp)> configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>sip tls</code> Example: <code>se-10-0-0-0(culp-config)> sip tls</code>	Enables the use of SIP TLS connections with other SIP entities, providing secure communication over the Internet.
Step 4	<code>sip tls trusted-peer {peer's-hostname}</code> Example: <code>se-10-0-0-0(culp-config)> sip tls trusted-peer example.com</code>	Creates a list of trusted peers.
Step 5	<code>sip tls connection-setup-timeout {value in seconds}</code> Example: <code>se-10-0-0-0(culp-config)> sip tls connection-setup-timeout <1-60></code>	It is the time specified in Cisco Unified SIP Proxy by the user to establish connection with the trusted peer. The default value is 1 second. The range of values is 1 to 60 seconds.
Step 6	<code>sip tls [v1.0 v1.1 v1.2]</code> Example: <code>se-10-0-0-0(culp-config)> sip tls v1.0</code>	Enables SIP TLS versions. The default value is all TLS versions with fall-back. The connection between the user and the trusted peer fails to establish when the user tries to connect using the TLS version that the trusted peer does not support. In the case where the trusted peer does not support a specific TLS version, the user retries the connection with the trusted peer using the downgraded version of TLS. For example, if the trusted peer does not support TLS v1.2, then the user retries the connection using TLS v1.1.

Example of Configuring TLS

```

se-10-0-0-0> culp
se-10-0-0-0(culp)> configure
se-10-0-0-0(culp-config)> sip tls
se-10-0-0-0(culp-config)> sip tls trusted-peer example.com
se-10-0-0-0(culp-config)> sip tls connection-setup-timeout <1-60>
se-10-0-0-0(culp-config)> sip tls v1.2

```

Configuring Lite Mode

One of the ways you can configure the performance of the Cisco Unified SIP Proxy is to switch the module to Lite Mode. In Lite Mode, which requires you to disable record-route, the module's performance is boosted. In standard mode, the module processes calls up to the licensed limit.

By default, the module is in standard mode.

For information on the performance difference when using Lite Mode versus standard mode, see the [Release Notes for Cisco Unified SIP Proxy Release 10.0](#).

- [Summary Steps, page 19](#)
- [Detailed Steps, page 19](#)
- [Example, page 19](#)

Summary Steps

1. `culp`
2. `configure`
3. `lite-mode`

Detailed Steps

	Command or Action	Purpose
Step 1	<code>culp</code> Example: <code>se-10-0-0-0 > culp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: <code>se-10-0-0-0(culp) > configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>lite-mode</code> Example: <code>se-10-0-0-0(culp-config) > lite-mode</code>	Puts the Cisco Unified SIP Proxy module into Lite Mode.

Example

The following example puts the module into Lite Mode:

```
se-10-0-0-0 > culp
se-10-0-0-0(culp) > configure
se-10-0-0-0(culp-config) > lite-mode
```

Configuring Performance Control

- [About Performance Control, page 20](#)
- [Summary Steps, page 20](#)
- [Detailed Steps, page 20](#)
- [Example, page 10](#)

About Performance Control

One of the ways you can configure the performance of the Cisco Unified SIP Proxy is to restrict the number of calls that the Cisco Unified SIP Proxy can handle.

Summary Steps

1. `culp`
2. `configure`
3. `call-rate-limit limit`

Detailed Steps

	Command or Action	Purpose
Step 1	<code>culp</code> Example: <code>se-10-0-0-0> culp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: <code>se-10-0-0-0(culp)> configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>call-rate-limit limit</code> Example: <code>se-10-0-0-0(culp-config)> call-rate-limit 50</code>	Sets the maximum call rate that the Cisco Unified SIP Proxy can handle.

Example

The following example limits the number of calls that the system can process to 50:

```
se-10-0-0-0> culp
se-10-0-0-0(culp)> configure
se-10-0-0-0(culp-config)> call-rate-limit 50
```

Committing the Configuration

Now you must commit the configuration. Committing the configuration serves two purposes: the configuration becomes active, and is persisted.

- To see the current active configuration, enter the **show configuration active** command.
- To see what the active configuration will be after you commit your changes, enter the **show configuration candidate** command.
- To commit the configuration for this example, enter the following command:

```
se-10-0-0-0(cusp-config)> commit
```

