



Configuring Cisco Unity Express Software

Last Updated: December 10, 2010

After ensuring that the prerequisites described in the “[Prerequisites for Installing Cisco Unity Express Software](#)” section on page 9 are completed, the Cisco Unity Express software is ready to be configured. This chapter describes the installation procedure and contains the following information and procedures:

- [Task List](#), page 17
- [Activating IP Connectivity to Cisco Unity Express Software](#), page 18
- [Adding or Removing Languages](#), page 20

Task List



Note

When you order Cisco Unity Express, Cisco Unity Express software and the purchased license are installed on the module at the factory. Spare modules also ship with the software and license installed.

The following procedures are required to configure a new installation of Cisco Unity Express:

Table 2 *Task List for Configuring a New Installation of Cisco Unity Express*

Checklist	Checkoff
1. Create the Cisco Unity Express administrator username and password and specify the IP addresses for the DNS server and NTP server. This username and password is needed to log in to the initialization wizard. See the Cisco Unity Express 7.0 Voice-Mail and Auto-Attendant CLI Administrator Guide and the Cisco Unity Express 7.0 GUI Administrator Guide .	<input type="checkbox"/>
2. Configure the IP addressing between the module and the router. See the “ Activating IP Connectivity to Cisco Unity Express Software ” section on page 18.	<input type="checkbox"/>
3. Add or remove languages. See the “ Adding or Removing Languages ” section on page 20.	<input type="checkbox"/>

Table 2 Task List for Configuring a New Installation of Cisco Unity Express (continued)

Checklist	Checkoff
<p>4. Begin configuring the Cisco Unity Express software. See the Cisco Unity Express 7.0 Voice-Mail and Auto-Attendant CLI Administrator Guide and the Cisco Unity Express 7.0 GUI Administrator Guide for the configuration tasks.</p> <p>Note The Cisco Unity Express 7.0 GUI Administrator Guide describes the procedure for performing initial configuration tasks using the initialization wizard tool, which uses a graphical user interface (GUI). If you want to use CLI commands to perform the configuration tasks covered by the initialization wizard (for example, if you want to use a configuration script), you can skip the initialization wizard by using the web skipinitwizard command in Cisco Unity Express EXEC mode. This command turns off the initialization wizard. You cannot turn it on or restart it unless you reimage the Cisco Unity Express module.</p>	<input type="checkbox"/>

Activating IP Connectivity to Cisco Unity Express Software

Before installing the Cisco Unity Express NM-CUE or AIM-CUE module, activate the Cisco Unified Communications Manager IP communication link between the system and the Cisco Unity Express application.

Prerequisites

The following information is required for activating the software:

- Slot and unit numbers of the Cisco Unity Express module on the Cisco IOS router that hosts Cisco Unity Express.
- IP address and subnet mask of the Cisco IOS router that hosts Cisco Unity Express or the unnumbered interface type and number.
- IP address of the Cisco Unity Express module. This IP address must be on the same subnet as the Cisco IOS router that hosts Cisco Unity Express.
- IP address of the default gateway of the Cisco Unity Express router. This IP address must be the same IP address as the Cisco IOS router that hosts Cisco Unity Express.

SUMMARY STEPS

1. **interface service-engine** *slot/unit*
or
interface integrated-service-engine *slot/unit*
2. **ip address** *router-ip-addr subnet-mask*
or
ip unnumbered *type number*
3. **service-module ip address** *cue-side-ip-addr subnet-mask*
4. **service-module ip default-gateway** *gw-ip-addr*
5. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Choose one of the following:	
	<pre>interface service-engine slot/unit</pre> <p>Example: Router(config)# interface service-engine 2/0</p> <p>or</p> <pre>interface integrated-service-engine slot/unit</pre> <p>Example: Router(config)# interface integrated-service-engine 2/0</p>	<p>Enters interface configuration mode on the AIM-CUE, NM-CUE, or NM-CUE-EC.</p> <p>Enters interface configuration mode on the NME-CUE.</p>
Step 2	Choose one of the following:	
	<pre>ip address router-ipaddr subnet-mask</pre> <p>Example: Router(config-if)# ip address 172.16.231.195 255.255.0.0</p> <p>or</p> <pre>Router(config-if)# ip unnumbered type number</pre> <p>Example: Router(config-if)# ip unnumbered FastEthernet 0/0</p>	<p>Specifies the IP address and subnet mask of the Cisco IOS router hosting Cisco Unity Express.</p> <p>Specifies the interface <i>type</i> and <i>number</i> for the Cisco IOS router hosting Cisco Unity Express.</p>
Step 3	<pre>service-module ip address cue-side-ipaddr subnet-mask</pre> <p>Example: Router(config)# service-module ip address 172.16.231.190 255.255.0.0</p>	Specifies the IP address of the Cisco Unity Express module interface. This IP address must be on the same subnet as the Cisco IOS router that hosts Cisco Unity Express.
Step 4	<pre>service-module ip default-gateway gw-ipaddr</pre> <p>Example: Router(config)# service-module ip default-gateway 172.16.231.195</p>	Specifies the IP address of the Cisco IOS router that hosts Cisco Unity Express.
Step 5	<pre>exit</pre> <p>Example: Router(config-if)# exit</p>	Exits interface configuration mode.

Examples

The following example illustrates the IP connectivity activation procedure:

```
Router(config)# interface Service-Engine 1/0
Router(config-if)# ip address 10.0.0.9 255.0.0.0
Router(config-if)# service-module ip address 10.0.0.10 255.0.0.0
Router(config-if)# service-module ip default-gateway 10.0.100.10
Router(config-if)# exit
```

Adding or Removing Languages

Installing additional languages or removing languages must be done in online mode only. You cannot add or remove languages using the boothelper except when you perform a complete installation of the Cisco Unity Express software. For instructions on doing this, see [“Configuring Cisco Unity Express Software” on page 17](#).

Installing Additional Languages

Prerequisites

The following information is required for installing languages:

- URL of the FTP server.

Restrictions

- You are limited to 2 concurrent languages with an AIM-CUE module license
- To install a second language on the AIM-CUE, you might need to perform some additional steps. See the [“Adding a Second Language on the AIM-CUE” section on page 21](#).
- You are limited to 5 concurrent languages with an NM-CUE, NM-CUE-EC, or NME-CUE module license



Note

See the [“Upgrading or Downgrading the Cisco Unity Express License in the Same Version” section on page 49](#).

SUMMARY STEPS

1. **config t**
2. **software download server url ftp://server-ip-address[/dir] [username username password password]**
3. **exit**
4. **software install add cue-vm-lang-langpack.plat.ver.pkg** (language package file)

The key to the placeholders in the above-mentioned filename is in [Table 3 on page 21](#).

Table 3 Download File Variable Key

Placeholder	Explanation
<i>plat</i>	Platform for which the image is built. Examples are nm-aim, nme, and so on.
<i>ver</i>	Package version. Examples are 2.3.1, 3.0.1, 3.1.1, and so on.
<i>lang</i>	Language code. Examples are en_US, fr_FR, it_IT, and so on.

DETAILED STEPS

-
- Step 1** Use **config t** to enter configuration mode.
- Step 2** Enter **software download server url ftp://server-ip-address[/dir][username username password password]** where
- *server-ip-address* is the URL of the FTP server
 - *username* is the name of the valid user on the FTP server
 - *password* is the username's password to allow access to the FTP server
- Step 3** Enter **exit** to exit configuration mode.
- Step 4** Enter **software install add cue-vm-lang-langpack.plat.ver.pkg.**
-

Adding a Second Language on the AIM-CUE

To install a second language on the AIM-CUE, you might need to perform additional steps. You must reduce the voice-mail capacity to 480 minutes before you can install the second language. Perform the following steps.

SUMMARY STEPS

1. **show voicemail limits**
2. **config t**
3. **voicemail capacity time 480**

DETAILED STEPS

-
- Step 1** In EXEC mode, enter the **show voicemail limits** command to display the voice-mail system capacity configured on the AIM-CUE.
- If the system capacity on the AIM-CUE is configured to 480 minutes, then no further action is needed. If the system capacity is configured to 840 minutes, then proceed to the next step.
- Step 2** Type **config t** to enter configuration mode.
- Step 3** Enter the **voicemail capacity time 480** command to reduce the voice-mail system capacity to 480 minutes, which will free up enough space to install the second language.
- After completing this step, you can install the second language on the AIM-CUE.
-

Examples

The following example illustrates choosing additional languages.

```

Language add-ons found on the system (1):
Installed SKU Name (version)
-----
* ENU CUE Voicemail US English (7.0.1.0)
Maximum 5 language add-ons allowed for this platform.
You may install 4 more language(s) from the following list:
Language Installation Menu:
# Selected SKU Language Name (version)
-----
1 PTB CUE Voicemail Brazilian Portuguese (7.0.1.0)
2 RUS CUE Voicemail Russian (7.0.1.0)
3 DEU CUE Voicemail German (7.0.1.0)
4 NLD CUE Voicemail Dutch (7.0.1.0)
5 FRC CUE Voicemail Canadian French (7.0.1.0)
6 KOR CUE Voicemail Korean (7.0.1.0)
7 CHS CUE Voicemail Mandarin Chinese (7.0.1.0)
8 ESO CUE Voicemail Latin American Spanish (7.0.1.0)
9 ITA CUE Voicemail Italian (7.0.1.0)
10 ESM CUE Voicemail Mexican Spanish (7.0.1.0)
11 ESP CUE Voicemail European Spanish (7.0.1.0)
12 TUR CUE Voicemail Turkish (7.0.1.0)
13 ENG CUE Voicemail UK English (7.0.1.0)
14 ARA CUE Voicemail Arabic (7.0.1.0)
15 SVE CUE Voicemail Swedish (7.0.1.0)
16 FRA CUE Voicemail European French (7.0.1.0)
17 DAN CUE Voicemail Danish (7.0.1.0)
18 JPN CUE Voicemail Japanese (7.0.1.0)
-----
Available commands are:
# - enter the number for the language to select one
r # - remove the language for given #
i # - more information about the language for given #
x - Done with language selection
Enter Command:3
Language Installation Menu:
# Selected SKU Language Name (version)
-----
1 PTB CUE Voicemail Brazilian Portuguese (7.0.1.0)
2 RUS CUE Voicemail Russian (7.0.1.0)
3 * DEU CUE Voicemail German (7.0.1.0)
4 NLD CUE Voicemail Dutch (7.0.1.0)
5 FRC CUE Voicemail Canadian French (7.0.1.0)
6 KOR CUE Voicemail Korean (7.0.1.0)
7 CHS CUE Voicemail Mandarin Chinese (7.0.1.0)
8 ESO CUE Voicemail Latin American Spanish (7.0.1.0)
9 ITA CUE Voicemail Italian (7.0.1.0)
10 ESM CUE Voicemail Mexican Spanish (7.0.1.0)
11 ESP CUE Voicemail European Spanish (7.0.1.0)
12 TUR CUE Voicemail Turkish (7.0.1.0)
13 ENG CUE Voicemail UK English (7.0.1.0)
14 ARA CUE Voicemail Arabic (7.0.1.0)
15 SVE CUE Voicemail Swedish (7.0.1.0)
16 FRA CUE Voicemail European French (7.0.1.0)
17 DAN CUE Voicemail Danish (7.0.1.0)
18 JPN CUE Voicemail Japanese (7.0.1.0)
-----

```

```

Available commands are:
# - enter the number for the language to select one
r # - remove the language for given #
i # - more information about the language for given #
x - Done with language selection
Enter Command:X ui_install scripts executed successfully.
Starting payload download

```

Removing a Language

To remove languages, enter the **software uninstall** command in EXEC mode as shown in the following example.

```

se-10-50-40-125> software uninstall ?
<cr>
  uid-list      List of UIDs of Subsystems to be uninstalled
se-10-50-40-125> software uninstall

Add-On Uninstallation Menu:
# Selected Add-On SSID Add-On Name (version)
-----
1 3f968fd0-6598-48e2-be1c-4af6c2e02e02 CUE Voicemail German (7.0.1.0)
2 27e5e2ab-1622-4c02-8a0a-cfad0d932148 CUE Voicemail US English (7.0.1.0)
-----

Available commands are:
r # - remove Add On for given #
i # - more information about Add On for given #
c # - clear Add On selection for given #
x - Done with Add On selection
Enter Command:r 1

Add-On Uninstallation Menu:
# Selected Add-On SSID Add-On Name (version)
-----
1 * 3f968fd0-6598-48e2-be1c-4af6c2e02e02 CUE Voicemail German (7.0.1.0)
2 27e5e2ab-1622-4c02-8a0a-cfad0d932148 CUE Voicemail US English (7.0.1.0)
-----

Available commands are:
r # - remove Add On for given #
i # - more information about Add On for given #
c # - clear Add On selection for given #
x - Done with Add On selection
Enter Command:x
Are you sure? [y/n]: y
There are add-on subsystems on uninstall list.
Running Script Processor for ui_uninstall
ui_uninstall scripts executed successfully.
Generating the add-on-uninstall work order :
Validating installed manifests .....
.complete.
:::/sw/installed/manifest/de_DE_lang_manifest.sig:remove
:::/usr/wfavvid/Prompts/system/de_DE:remove
:::/usr/wfavvid/Prompts/user/de_DE:remove
:::/usr/wfavvid/Grammars/system/de:remove
:::/usr/wfavvid/Grammars/system/de_DE:remove
:::/usr/wfavvid/i18n/com/cisco/prompt/impl/PromptGenerators_de_DE.properties:remove
:::/usr/wfavvid/i18n/com/cisco/grammar/impl/DigitRecognitionStrings_de_DE.
properties:remove
:::/usr/tomcat/webapps/voicemail/prompts/DEU:remove
Starting to uninstall:

```

What to Do Next

After configuring connectivity to the Cisco Unity Express module or changing languages, run the initialization wizard to begin configuring the Cisco Unity Express database. See the [Cisco Unity Express 7.0 GUI Administrator Guide](#).



Note

To use CLI commands to perform the configuration tasks covered by the initialization wizard (for example, to use a configuration script), you can skip the initialization wizard by using the **web skipinitwizard** command in Cisco Unity Express EXEC mode. This command turns off the initialization wizard. You cannot turn it on or restart it unless you reimage the Cisco Unity Express module.
