



Monitor

This chapter describes how to display status and statistics of the WAP device. It contains the following topics:

- [Dashboard, on page 1](#)
- [Clients, on page 4](#)
- [Guests, on page 6](#)

Dashboard

The Dashboard will display the throughput status, and will provide you with easy steps to configure or monitor your network device. This page is updated every 30 seconds.

Connected Clients

The total number of clients currently associated with the WAP device. Click the box, to be redirected to the Clients page.

Internet/LAN/Wireless

Round icons on the top right of the page, show Internet, LAN and wireless connection status.

Internet

- **Red round** — No Internet connection.
- **Green round** — Internet connection is good.

LAN

- **Red round** — No wired connection.
- **Green round** — Wired connection.

Click the **LAN** link to view the **LAN Status** page.

Wireless

- **Red round** — All radios are disabled.
- **Green round** — At least one radio is working. One or two radios are enabled.

Click the **Wireless** link to view the **Wireless Status** page.

2.4G Radio Throughput

This line chart displays 2.4G Radio Throughput and updates every 30 seconds.

- **Upload**—Throughput of the last 30 seconds transmitted.
- **Download**—Throughput of the last 30 seconds received.

Click **Upload** or **Download** to not display data.

5G Radio Throughput

This line chart displays 5G Radio Throughput and updates every 30 seconds.

- **Upload**—Throughput of the last 30 seconds transmitted.
- **Download**—Throughput of the last 30 seconds received.

Click **Upload** or **Download** to not display data.

Top Clients

According to the traffic order, this bar chart displays the top 5 Traffic clients devices

- **Upload**—Throughput of the last 30 seconds transmitted.
- **Download**—Throughput of the last 30 seconds received.

Click **Upload** or **Download** to not display data.

SSID Utilization

According to the traffic order, this pie chart displays the top 5 Traffic SSID

- **Traffic** —total number of bytes transmitted and received.

Network Usage

This line chart displays the eth throughput

- **Upload**—Throughput of the last 30 seconds transmitted.
- **Download**—Throughput of the last 30 seconds received.

Click **Upload** or **Download** to not display data.

Quick Access

To simplify the device configuration through quick navigation, the **Getting Started** page provides links for performing common tasks. For more details, see [Quick Start Configuration](#).

LAN Status

Click on the LAN circle to display the following configuration and status settings on the LAN interface.

- **MAC Address** — The MAC address of the WAP device.
- **IP Address** — The IP address of the WAP device.
- **Subnet Mask** — The subnet mask of the WAP device
- **Default Gateway** — The default gateway of the WAP device.

- **Domain Name Server-1** — The IP address of the domain name server 1 used by the WAP device.
- **Domain Name Server-2** — The IP address of the domain name server 2 used by the WAP device.
- **Green Ethernet Mode** — Green Ethernet mode of the Ethernet interface.
- **IPv6 Address** — The IPv6 address of the WAP device.
- **IPv6 Autoconfigured Global Addresses** — The IPv6 autoconfigured global addresses.
- **IPv6 Link Local Address** — The IPv6 link local address of the WAP device.
- **Default IPv6 Gateway** — The default IPv6 gateway of the WAP device.
- **IPv6-DNS-1** — The IPv6 address of the IPv6 DNS server 1 used by the WAP device.
- **IPv6-DNS-2** — The IPv6 address of the IPv6 DNS server 2 used by the WAP device.
- **VLAN ID** — Identifier of the VLAN.



Note These settings apply to the internal interface. Click **Edit** to change any of these settings. You will be redirected to the **LAN** page.

Click **Refresh** to refresh the screen and show the most current information.

Click **Back** to return to the **Dashboard** page.

Wireless Status

Click the **Wireless** circle to display the wireless radio interfaces, such as:

- **Wireless Radio** — The wireless radio mode is enabled or disabled for the radio interface.
- **MAC Address** — The MAC address associated with the radio interface.
- **Mode** — The 802.11 mode (a/b/g/n/ac) used by the radio interface.
- **Channel** — The channel used by the radio interface.
- **Operational Bandwidth** — The operational bandwidth used by the radio interface.
- Click **Edit** to change any of these settings. You will be redirected to the **Radio** page.

Click **Refresh** to refresh the screen and show the most current information.

Click **Back** to return to the **Dashboard** page.

Interface Status

The Interface Status table displays the following status information for each Virtual Access Point (VAP) and on each Wireless Distribution System (WDS) interface:

- **Network Interface** — The wireless interface of the WAP device.
- **Name (SSID)** — The wireless interface name.
- **Status** — The administrative status (up or down) of the VAP.

- **MAC Address** — The MAC address of the radio interface.
- **VLAN ID** — The VLAN ID of the radio interface.
- **Profile** — The name of any associated scheduler profile.
- **State** — The current state (active or inactive). The state indicates whether the VAP is exchanging data with a client.

Traffic Statistics

The **Traffic Statistics** page shows the real-time transmit and receive statistics for the Ethernet interface, the Virtual Access Points (VAPs), and all WDS interfaces. All transmit and receive statistics reflect the totals since the WAP device was last started. If you reboot the WAP device, these figures indicate the transmit and receive totals since the reboot.

To view traffic statistics, select **Monitor > Dashboard > Quick Access > Traffic Statistics**.

The following information is displayed:

- **Interface**—Name of the Ethernet interface, each VAP interface, and each WDS interface. The name for each VAP interface is followed by its SSID in parentheses
- **Total Packets**—The total number of packets sent and received by the WAP device is displayed in the **Transmit Traffic Statistics** table and the **Receive Traffic Statistics** table respectively.
- **Total Bytes**—The total number of bytes sent and received by the WAP device is displayed in the **Transmit Traffic Statistics** table and the **Receive Traffic Statistics** table respectively.
- **Total Dropped Packets**—The total number of dropped packets sent and received by the WAP device is displayed in the **Transmit Traffic Statistics** table and the **Receive Traffic Statistics** table respectively.
- **Total Dropped Bytes**—The total number of dropped bytes sent and received by the WAP device is displayed in the **Transmit Traffic Statistics** table and the **Receive Traffic Statistics** table respectively.
- **Errors**—The total number of errors related to sending and receiving data on the WAP device.



Note You can click **Refresh** to view the updated information.

Clients

Clients

The Clients page displays the client stations associated with the device.

Total Number Of Associated Clients—The total number of clients on the WAP device.

Client Summary

Displays the client summary by 802.11 client type currently on the device.

Average Bandwidth

Displays the average client bandwidth in Mbps.

- **Upload** — Throughput of the last 30 seconds transmitted.
- **Download** — Throughput of the last 30 seconds received.



Note Click **Upload** or **Download** to not display data.

Lowest Signal-to-Noise (SNR) Clients

List the lowest 5 devices according to SNR.

Lowest Speed Clients

List the lowest 5 devices according to speed order.

Associated Clients

- **Clients Details** — The hostname and MAC address of the associated wireless client.
- **IP Address** — The IP address of the associated wireless client.
- **Network (SSID)** — The Service Set Identifier (SSID) for the WAP device. The SSID is an alphanumeric string of up to 32 characters that uniquely identifies a wireless local area network. It is also referred to as the Network Name.
- **Mode** — The IEEE 802.11 mode being used on the client, such as IEEE 802.11a, IEEE 802.11b, IEEE 802.11g.
- **Data Rate** — The current transmitting data rate.
- **Channel** — The channel on which the Client is current in connection with. The channel defines the portion of the radio spectrum that the radio uses for transmitting and receiving. You can use the Radio page to set the channel.
- **Traffic (Up /Down)** — The total number of bytes sent (Up) or received (Down) by the client device.
- **SNR (dB)** — Displays the SNR strength in decibels (dB).
- **Throughput Meter** — The last 30 seconds' throughput / Data Rate.



Note You can order the clients through Clients Details, Network (SSID), and so on.
You can filter clients the through Clients Details, Network (SSID), and so on.

Guests

The **Guests** page provides two tables. One is the Authenticated Clients table, which displays the clients that have authenticated on any Captive Portal instance. The other one is the Failed Authenticated Clients table, which displays information on the clients that attempted to authenticate on a Captive Portal and failed.

To view the list of authenticated clients or the list of clients who failed the authentication, select **Monitor > Guests**.

The following information is displayed:

- **MAC** — The MAC address of the client.
- **IP Address** — The IP address of the client.
- **User Name** — The Captive Portal user name of the client.
- **Protocol** — The protocol that the user used to establish the connection (HTTP or HTTPS).
- **Verification** — The method used to authenticate the user on the Captive Portal, which can be one of these values:
 - **Guest** — The user does not need to be authenticated by a database.
 - **Local** — The WAP device uses a local database to authenticate the users.
 - **RADIUS** — The WAP device uses a database on a remote RADIUS server to authenticate the users.
- **VAP/Radio ID** — The VAP and radio that the user is associated with.
- **Timeout** — The time remaining, in seconds, for the CP session to be valid. After the time reaches zero, the client is de-authenticated.
- **Away Time** — The time remaining, in seconds, for the client entry to be valid. The timer starts when the client dissociates from the CP. After the time reaches zero, the client is de-authenticated.
- **UP/Down (MB)** — The number of bytes transmitted and received by the WAP device from the user station.
- **Failure Time** — The time that the authentication failure occurred. A timestamp is included that shows the time of the failure.

You can click **Export** to upload the current Authenticated or Failed clients message.



Note

Ensure that you select the Authenticated client or Failed client to upload and then click **Export**.
