



LTE Handover Restriction List Configuration Mode Commands

The LTE Handover Restriction List Configuration Mode is used to create and manage the LTE handover restriction lists for LTE/SAE networks. Handover restriction lists are used to restrict user equipment (UE) from participating in specified handovers. The MME creates the handover restriction lists as part of its local policy and provides them to the eNodeB where the restrictions are enforced.

Command Modes Exec > Global Configuration > LTE Policy Configuration > LTE HO Restriction List Configuration
configure > lte-policy > ho-restrict-list *list_name*

Entering the above command sequence results in the following prompt:

```
[local] host_name(ho-restrict-list)#
```



Important The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [end, on page 1](#)
- [exit, on page 2](#)
- [forbidden, on page 2](#)

end

Exits the current configuration mode and returns to the Exec mode.

Product All

Privilege Security Administrator, Administrator

Syntax Description **end**

Usage Guidelines Use this command to return to the Exec mode.

exit

Exits the current mode and returns to the parent configuration mode.

Product

All

Privilege

Security Administrator, Administrator

Syntax Description

exit

Usage Guidelines

Use this command to return to the parent configuration mode.

forbidden

Configures the handover restriction lists provided to eNodeBs where handover restrictions are enforced for UEs.

Product

MME

Privilege

Administrator

Command Modes

Exec > Global Configuration > LTE Policy Configuration > LTE HO Restriction List Configuration

configure > lte-policy > ho-restrict-list *list_name*

Entering the above command sequence results in the following prompt:

```
[local]host_name(ho-restrict-list)#
```

Syntax Description

```
[ no ] forbidden { inter-rat { all | cdma2000 | geran | utran } |
location-area plmnid id | tracking-area plmnid id }
default forbidden inter-rat
```

default

Removes the forbidden inter-RAT configuration from the LTE policy.

no

Removes the forbidden configuration from the LTE policy.

inter-rat { all | cdma2000 | geran | utran }

Specifies that one or all Radio Access Technology (RAT) handovers are to be prohibited for UEs associated with the LTE policy.

all: Specifies that all inter-RAT handovers are to be prohibited for UEs associated with the LTE policy.

cdma2000: Specifies that all CDMA2000 handovers are to be prohibited for UEs associated with the LTE policy.

geran: Specifies that all GSM EDGE Radio Access Network (GERAN) handovers are to be prohibited for UEs associated with the LTE policy.

utran: Specifies that all UMTS Terrestrial Radio Access Network (UTRAN) handovers are to be prohibited for UEs associated with the LTE policy.

location-area plmnid *id*

Specifies that handovers to 3G location area codes defined through this keyword and subsequent configuration mode are to be prohibited for UEs associated with the LTE policy. Enters the LTE Forbidden Location Area Configuration Mode. *id* must be a valid PLMN ID expressed as an integer comprised of an MCC (Mobile Country Code) and MNC (Mobile Network Code) [five-digit minimum, six-digit maximum].



Important

Up to 16 forbidden location area PLMN IDs can be configured per handover restriction list.

Entering this command results in the following prompt:

```
[context_name]hostname(forbidden_la)#
```

The related commands are defined in the *LTE Forbidden Location Area Configuration Mode Commands* chapter.

tracking-area plmnid *id*

Specifies that handovers to 4G tracking area codes defined through this keyword and subsequent configuration mode are to be prohibited for UEs associated with the LTE policy. Enters the LTE Forbidden Tracking Area Configuration Mode. *id* must be a valid PLMN ID and be an integer value comprising an MCC and MNC (five-digit minimum, six-digit maximum).



Important

Up to 16 forbidden tracking area PLMN IDs can be configured per handover restriction list.

Entering this command results in the following prompt:

```
[context_name]hostname(forbidden_ta)#
```

The related commands are defined in the *LTE Forbidden Tracking Area Configuration Mode Commands* chapter.

Usage Guidelines

Use this command to create the list of restricted handover types that apply to all UEs associated with the LTE policy.

Example

The following command prohibits UEs associated with this LTE policy from participating in a handover to a GERAN network type:

```
forbidden inter-rat geran
```

The following command prohibits UEs, associated with this LTE policy and a mobile network with a PLMN ID of *12345*, from participating in a handover to location area codes defined in the Location Area Configuration Mode:

forbidden

```
forbidden location-area plmnid 12345
```