



# SAEGW Service Configuration Mode Commands

## Command Modes

The System Architecture Evolution Gateway (SAEGW) Service Configuration Mode is used to create and manage the relationship between specified services used for S-GW and P-GW network traffic.

Exec > Global Configuration > Context Configuration > SAEGW Service Configuration

**configure** > **context** *context\_name* > **saegw-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-saegw-service)#
```



## Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [associate](#), on page 1
- [do show](#), on page 2
- [gtpc handle-collision upc nrupc](#), on page 3
- [end](#), on page 4
- [exit](#), on page 4

## associate

Associates the SAEGW service with specific pre-configured services configured in the same context.

## Product

SAEGW

## Privilege

Administrator

## Command Modes

Exec > Global Configuration > Context Configuration > SAEGW Service Configuration

**configure** > **context** *context\_name* > **saegw-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-saegw-service)#
```

## Syntax Description

```
[ no ] associate { pgw-service name | sgw-service name }
```

**no**

Removes the selected association from this service.

**pgw-service name**

Specifies that the SAEGW service is to be associated with an existing P-GW service within this context. *name* must be an alphanumeric string of 1 through 63 characters and be an existing P-GW service.

**sgw-service name**

Specifies that the SAEGW service is to be associated with an existing S-GW service within this context. *name* must be an alphanumeric string of 1 through 63 characters and be an existing S-GW service.

**Important**

S-GW egress eGTP service must be in the same context as this SAEGW service. In addition, PMIP is not supported for the S-GW service egress.

**Usage Guidelines**

Use this command to associate the SAEGW service with other pre-configured services configured in the same context.

**Important**

Each P-GW or S-GW service may only be associated with one SAEGW service; however, there may be multiple SAEGW services configured on a system in separate contexts.

**Example**

The following commands associate this SAEGW service with a P-GW service called *pgw1* and a S-GW service called *sgw2*:

```
associate pgw-service pgw1
associate sgw-service sgw2
```

## do show

Executes all **show** commands while in Configuration mode.

**Product**

All

**Privilege**

Security Administrator, Administrator

**Syntax Description**

**do show**

**Usage Guidelines**

Use this command to run all Exec mode **show** commands while in Configuration mode. It is not necessary to exit the Config mode to run a **show** command.

The pipe character | is only available if the command is valid in the Exec mode.

**Caution**

There are some Exec mode **show** commands which are too resource intensive to run from Config mode. These include: **do show support collection**, **do show support details**, **do show support record** and **do show support summary**. If there is a restriction on a specific **show** command, the following error message is displayed:

```
Failure: Cannot execute 'do show support' command from Config mode.
```

## gtpc handle-collision upc nrupc

This command helps in enabling or disabling collision handling between SGSN initiated UPC and NRUPC request.

**Product**

SAEGW

**Privilege**

Security Administrator, Administrator

**Command Modes**

Exec &gt; Global Configuration &gt; Context Configuration &gt; SAEGW Service Configuration

```
configure > context context_name > saegw-service service_name
```

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-saegw-service)#
```

**Syntax Description**

```
[ no | default ] gtpc handle-collision upc nrupc
```

**no**

Disables collision handling between SGSN initiated UPC and NRUPC request.

**default**

Sets default collision handling behavior between SGSN initiated UPC and NRUPC request. By default, collision handling is enabled.

**handle-collision upc nrupc**

Enables/Disables collision handling between SGSN initiated UPC and network requested UPC. By default, collision handling is enabled.

**Usage Guidelines**

This command is used to enable or disable collision handling between SGSN initiated UPC and NRUPC request.

**Example**

The following example disables collision handling between SGSN initiated UPC and NRUPC request.

```
no gtpc handle-collision upc nrupc
```

## end

Exits the current configuration mode and returns to the Exec mode.

---

**Product** All

---

**Privilege** Security Administrator, Administrator

---

**Syntax Description** `end`

---

**Usage Guidelines** Use this command to return to the Exec mode.

## exit

Exits the current mode and returns to the parent configuration mode.

---

**Product** All

---

**Privilege** Security Administrator, Administrator

---

**Syntax Description** `exit`

---

**Usage Guidelines** Use this command to return to the parent configuration mode.