



GT-Format4 Configuration Mode Commands

Command Modes

The GT-Format4 configuration mode is a sub-mode for either the Global Title Translation Association configuration mode or the Global Title Translation Address-Map configuration mode. This sub-mode configures a set of rules used in the global title translation (GTT) process.

Exec > Global Configuration > GTT Association Configuration > GT-Format4 Configuration

configure > **global title translation association instance** *instance_number* > **gt-format** *format_number*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-instance-format4)#
```



Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [do show](#), on page 2
- [encoding-scheme](#), on page 3
- [end](#), on page 4
- [exit](#), on page 5
- [nature-of-address](#), on page 6
- [numbering-plan](#), on page 7
- [translation-type](#), on page 8

do show

Executes all **show** commands while in Configuration mode.

Product

All

Privilege

Security Administrator, Administrator

Syntax Description

do show

Usage Guidelines

Use this command to run all Exec mode **show** commands while in Configuration mode. It is not necessary to exit the Config mode to run a **show** command.

The pipe character | is only available if the command is valid in the Exec mode.



Caution

There are some Exec mode **show** commands which are too resource intensive to run from Config mode. These include: **do show support collection**, **do show support details**, **do show support record** and **do show support summary**. If there is a restriction on a specific **show** command, the following error message is displayed:

```
Failure: Cannot execute 'do show support' command from Config mode.
```

encoding-scheme

This command configures the encoding scheme to use during global title translation (GTT).

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > GTT Association Configuration > GT-Format4 Configuration

configure > **global title translation association instance** *instance_number* > **gt-format** *format_number*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-instance-format4)#
```

Syntax Description

encoding-scheme { **bcd-even** | **bcd-odd** | **nw-specific** | **unknown** }

bcd-even

Configures the BCD even encoding scheme.

bcd-odd

Configures the BCD odd encoding scheme.

nw-specific

Configures the network specific encoding scheme.

unknown

Configures the unknown encoding scheme.

Usage Guidelines

Use this command to select one of the encoding scheme types to determine the encoding type to be used during GTT.

Example

The following command configures the **bcd-even** encoding scheme for GTT:

```
encoding-scheme bcd-even
```

end

Exits the current configuration mode and returns to the Exec mode.

Product All

Privilege Security Administrator, Administrator

Syntax Description `end`

Usage Guidelines Use this command to return to the Exec mode.

exit

Exits the current mode and returns to the parent configuration mode.

Product

All

Privilege

Security Administrator, Administrator

Syntax Description

exit

Usage Guidelines

Use this command to return to the parent configuration mode.

nature-of-address

This command configures the indicator to identify the nature of the address.

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > GTT Association Configuration > GT-Format4 Configuration

configure > **global title translation association instance** *instance_number* > **gt-format** *format_number*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-instance-format4)#
```

Syntax Description

nature-of-address { international | national | subscriber }

international

Identifies the international numbers.

national

Identifies the national significant numbers.

subscriber

Identifies the subscriber numbers.

Usage Guidelines

Use this command to identify the nature of address indicator.

Example

The following command configures the nature of address indicator as *national*:

```
nature-of-address national
```

numbering-plan

This command configures the numbering plan to apply during the GT translation process.

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > GTT Association Configuration > GT-Format4 Configuration

configure > **global title translation association instance** *instance_number* > **gt-format** *format_number*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-instance-format4)#
```

Syntax Description

numbering-plan *plan_type*

plan_type

Select one of the following numbering plans be employed during GTT:

- **data**: Data numbering plan
- **generic**: Generic number plan
- **isdn**: ISDN tel numbering plan
- **isdn-mobile**: ISDN mobile numbering plan
- **land-mobile**: Land mobile numbering plan
- **maritime-mobile**: Maritime mobile numbering plan
- **nw-specific**: Private network/network-specific numbering plan
- **telex**: Telex numbering plan
- **unknown**: Unknown numbering plan

Usage Guidelines

Use this command to select the required number plan for GTT process.

Example

The following command sets the numbering plan to use during GTT processing to **isdn**:

```
numbering-plan isdn
```

translation-type

This command configures the translation type to be applied during the translation process.

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > GTT Association Configuration > GT-Format4 Configuration

configure > **global title translation association instance** *instance_number* > **gt-format** *format_number*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-instance-format4)#
```

Syntax Description

translation-type *number*

number

Enter the translation type value as an integer from 0 to 255.

Default: 0

Usage Guidelines

Use this command to define the translation type to be applied during the global title translation process.

Example

The following command configures the translation type with value set to 235:

```
translation-type 235
```