



# Local Policy Actiondef Configuration Mode Commands

---

## Command Modes

The Local Policy Actiondef Configuration Mode is used to define the action definitions to be used for local QoS policies.

Exec > Global Configuration > Local Policy Service Configuration > Local Policy Actiondef Configuration  
**configure** > **local-policy-service** *service\_name* > **actiondef** *actiondef\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-local-policy-actiondef)#
```



## Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [action](#), on page 2
- [end](#), on page 6
- [exit](#), on page 7

# action

This command configures the action priority for an actiondef.

---

## Product

P-GW  
SAEGW

---

## Privilege

Security Administrator, Administrator

---

## Command Modes

Exec > Global Configuration > Local Policy Service Configuration > Local Policy Actiondef Configuration  
**configure** > **local-policy-service** *service\_name* > **actiondef** *actiondef\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-local-policy-actiondef)#
```

---

## Syntax Description

**action priority** *priority* *action\_name* *arguments*  
**no action priority** *priority*

### **priority** *priority*

Specifies a priority for the specified action.

*priority* must be a unique integer from 1 to 2048.

### **action\_name** *arguments*

The following actions are supported. *arguments* specify a set of parameters to be used when invoking the action.

- **activate-ambr uplink** *bandwidth* **downlink** *bandwidth*

Sets the aggregated maximum bit rate (AMBR) for the APN.

Configures uplink and downlink bandwidth. *bandwidth* must be an integer from 1 to 1000000000.

- **activate-flow-detection** { **initiation** | **termination** } **ruledef** *ruledef\_name*

Detects a flow and takes action.

**initiation ruledef**: Checks for flow initiation and adds a rule definition.

**termination ruledef**: Checks for flow termination and adds a rule definition.

*ruledef\_name* must be an existing ruledef.

- **activate-lp-rule** **name** *lprule\_name*

Activates a local-policy rule within service scheme when a subscriber is in the configured RAI or TAI range.

*lprule\_name* must be an existing local-policy rule within the service scheme expressed as an alphanumeric string of 1 through 63 characters.




---

**Important** Local-Policy can support up to 7 lp-rules to be activated for a given session.

---

When the subscriber moves out of the configured RAI or TAI range, the local-policy rule is deactivated. This option is added as part of Location Based QoS Override feature. For more information on this feature, see the *ECS Administration Guide*.

- **activate-rule name** *rule\_name*

Activates a rule within ECS rulebase for a subscriber.

*rule\_name* must be an existing rule within this local QoS policy service expressed as an alphanumeric string of 1 through 63 characters.

- **activate-rulebase name** *rulebase\_name*

Associates the session with a specific rulebase.

*rulebase\_name* must be an existing rulebase within this local QoS policy service expressed as an alphanumeric string of 1 through 63 characters.

- **allow-requested-qos**

Allow a specific UE initiated QoS request.

- **allow-session**

Allows the session to continue.

- **deactivate-flow-detection { initiation | termination } ruledef** *ruledef\_name*

Deactivates detection of flow and takes action.

**initiation ruledef:** Checks for flow initiation and adds a rule definition.

**termination ruledef:** Checks for flow termination and adds a rule definition.

*ruledef\_name* must be an existing ruledef.

- **deactivate-rule name** *rule\_name*

Deactivates a rule within ECS.

*rule\_name* must be an existing rule within this local QoS policy service expressed as an alphanumeric string of 1 through 63 characters.

- **deactivate-rulebase name** *rulebase\_name*

Disassociates the rulebase from a session.

*rulebase\_name* must be an existing rulebase within this local QoS policy service expressed as an alphanumeric string of 1 through 63 characters.

- **default-qos qci value arp value**

Sets the default QoS parameters for the session

**qci value** must be an integer from 1 through 254.

**arp value** must be an integer from 1 through 15 (StarOS v12.1 and earlier) or 1 through 127 (StarOS v12.2 and later).

- **event-triggers { default-bearer-qos-change | ecgi-change | qos-change | tai-change | uli-change }**

This action specifies to enable the event triggers – Default EPS bearer QoS change event trigger, ECGI-Change event trigger and QoS change event trigger.

The ECGI-Change event trigger is added as part of Location Based Local-Policy Rule Enforcement feature. For more information on this feature, see the *Gx Interface Support* chapter in the administration guide for the product you are deploying.

The TAI-Change and ULI-Change event triggers are added as part of Location Based QoS Override feature. For more information on this feature, see the *ECS Administration Guide*.

- **reconnect-to-server [ send-usage-report ]**

Reconnects to the PCRF server to handle fallback scenario. That is, when the session falls back to local policy, this action specifies to retry connecting to the PCRF server.

**send-usage-report:** Triggers CCR-U with volume report immediately. The default behavior is that the CCR-U will not be triggered immediately.

On timer-expiry, if the initial failure is due to CCR-U failure, and if **send-ccru-immediate** is configured, then CCR-U will be sent with the usage report immediately.

- **reject-requested-qos**

Rejects UE QoS resource request.

- **retry-count value**

Retry action. This applies to start-timer/activate-rule/activate-ruledef.

*value* must be an integer from 0 through 65535.

- **start-timer name duration value retry-count value**

Starts a named timer. On expiry of this timer, the local policy engine is contacted to initiate the appropriate action, such as termination of a session.

**duration value:** Enter a timer duration from 0 through 28800 seconds. A value of 0 can be used to leave the local policy until the subscriber disconnects. Default timer value is 14400 (seconds).

**retry-count** specifies the maximum number of times the server will be retried before terminating the call.

**retry-count value** must be an integer from 0 through 65535. Default retry count is 3.

- **stop-timer name**

Stops the designated timer.

- **terminate-session**

Terminates the session.

**no action priority priority**

Deletes the specified action.

### Usage Guidelines

Use this command to enable the setting of parameters to be used when invoking actions. Actions are a series of operations that are triggered by activated rules.

This command can be entered multiple times to configure multiple actions for an actiondef. The actions are examined in priority order until a match is found and the corresponding action is applied.

**Example**

The following command creates an action to allow a session to continue with priority set to *125*:

```
action priority 125 allow-session
```

# end

Exits the current configuration mode and returns to the Exec mode.

---

**Product** All

---

**Privilege** Security Administrator, Administrator

---

**Syntax Description** `end`

---

**Usage Guidelines** Use this command to return to the Exec mode.

# exit

Exits the current mode and returns to the parent configuration mode.

---

**Product**

All

---

**Privilege**

Security Administrator, Administrator

---

**Syntax Description**

**exit**

---

**Usage Guidelines**

Use this command to return to the parent configuration mode.

■ exit