



IMS Sh Service Configuration Mode Commands

PDIF to communicate with the HSS server. HSS server is used for MAC address validation in the IKEv2 exchanges to set up SAs and for storing part of the user profile. SCM to communicate with the HSS server. HSS server is used for retrieval and update of call feature parameters and call restriction data.

Command Modes

The IMS Sh Interface Configuration Mode is used to configure various Diameter parameters in order for:

Exec > Global Configuration > Context Configuration > IMS Sh Interface Configuration

configure > context *context_name* > **ims-sh-service** *service_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-ims-sh-service) #
```



Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [diameter, on page 1](#)
- [end, on page 2](#)
- [exit, on page 3](#)
- [failure-handling, on page 3](#)
- [request, on page 4](#)

diameter

This command configures Diameter parameters.

Product

PDIF
SCM

Privilege

Administrator

Command Modes

Exec > Global Configuration > Context Configuration > IMS Sh Interface Configuration

configure > context *context_name* > **ims-sh-service** *service_name*

Entering the above command sequence results in the following prompt:

end

```
[context_name]host_name(config-ims-sh-service)#
```

Syntax Description

```
diameter { dictionary { custom1 | standard | endpoint string }
default diameter { dictionary | endpoint }
no diameter endpoint
```

no

Removes previously configured endpoint.

default

Configures parameters to the default value.

dictionary

Specifies the dictionary to use.

- **custom1**: A custom dictionary
- **standard**: The standard dictionary

**Important**

SCM uses only the standard dictionary.

endpoint *string*

Selects an endpoint to use in the configuration.

string must be the endpoint name, and must be an alpha and/or numeric string of 1 through 63 characters in length.

Usage Guidelines

The Diameter endpoint contains information on the peer names and IP addresses and port, and the local IP address to use for Diameter.

You can have more than one Diameter endpoint configured on the chassis and the `ims-sh-service` needs to know which Diameter endpoint to use. This command is to select the appropriate Diameter endpoint, even if only one has been configured.

Example

The following example selects a diameter endpoint *diam1*:

```
diameter endpoint diam1
```

end

Exits the current mode and returns to the Exec Mode.

Product

All

Privilege	Security Administrator, Administrator
Syntax Description	end
Usage Guidelines	Use this command to change to the Exec Mode.

exit

Exits the current mode and returns to the parent configuration mode.

Product	All
Privilege	Security Administrator, Administrator
Syntax Description	exit
Usage Guidelines	Use this command to return to the parent configuration mode.

failure-handling

This command configures the action to take in the event of an HSS server request failure.

Product	PDIF SCM
Privilege	Administrator
Command Modes	Exec > Global Configuration > Context Configuration > IMS Sh Interface Configuration configure > context <i>context_name</i> > ims-sh-service <i>service_name</i> Entering the above command sequence results in the following prompt: <i>[context_name]host_name(config-ims-sh-service)#</i>
Syntax Description	<pre>[default] failure-handling { profile-update-request user-data-request } { { diameter-result-code result_code [to result_code] } timeout } action { continue retry-and-terminate terminate } }</pre> default Resets configuration for the specified keyword to the default setting. profile-update-request Configures failure-handling as a result of a profile update request error. user-data-request Configures failure-handling as a result of a user data request.

diameter-result-code *result_code* [to *result_code*]

The Result-Code data field contains a space representing errors. Diameter provides the following classes of errors, all identified by the thousands digit in the decimal notation:

- 3xxx (Protocol Errors)
- 4xxx (Transient Failures)
- 5xxx (Permanent Failure)

result_code specifies either a result code value (**diameter-result-code 3001**) or a range of result code values (**diameter-result-code 3000 to 9999**) to which the failure-handling applies.

action

Configures the action to take depending on the diameter-result-code:

- Continue the session
- Retry and then terminate
- Terminate the session

request-timeout action

Configures the action to take as a result of a request timeout error:

- Continue the session
- Retry and then terminate
- Terminate the session

Usage Guidelines

Configures all failure-handling parameters.

Example

The following command configures profile-update-request failure-handling using a result-code configuration with the terminate session option:

```
failure-handling profile-update-request diameter-result-code 3005 to 3600 action terminate
```

request

Configures application request timeout.

Product

PDIF
SCM

Privilege

Administrator

Command Modes

Exec > Global Configuration > Context Configuration > IMS Sh Interface Configuration

configure > context *context_name* > **ims-sh-service** *service_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-ims-sh-service) #
```

Syntax Description

request timeout *secs*
[**no** | **default**] **request timeout**

no

Disables a configured timeout request.

default

Default: 300 seconds

Resets configuration to the default setting.

request timeout secs

Configures the request timeout in seconds.

secs must be an integer from 1 through 300.

Usage Guidelines

Specifies the session request timeout period in seconds after which the request is deemed to have failed.

Example

The following example configures the default timeout request of 300 seconds:

```
default request timeout
```

request