



# Linkset Configuration Mode Commands

## Command Modes

The Linkset configuration mode defines the MTP3 linkset parameters for a specific SS7 routing domain instance.

Exec > Global Configuration > SS7 Routing Domain Configuration > Linkset Configuration

**configure > ss7-routing-domain** *domain\_id* **variant** *var\_type* > **linkset id** *linkset\_id*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-ss7-rd-linkset-linkset_id) #
```



### Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).



### Important

For information on common commands available in this configuration mode, refer to the [Common Commands](#) chapter.

- [adjacent-point-code](#), on page 1
- [link](#), on page 2
- [self-point-code](#), on page 3

## adjacent-point-code

This command defines the point-code for the adjacent (next) network element in the SS7 network.

### Product

SGSN

### Privilege

Security Administrator, Administrator


### Command Modes

Exec > Global Configuration > SS7 Routing Domain Configuration > Linkset Configuration

**configure > ss7-routing-domain** *domain\_id* **variant** *var\_type* > **linkset id** *linkset\_id*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-ss7-rd-linkset-linkset_id) #
```

Syntax Description	<b>adjacent-point-code</b> <i>point-code</i> <b>no adjacent-point-code</b>  <b>point-code</b> Point-code is an SS7 address for an element in the SS7 network. Point-codes must be defined in dotted-decimal format in a string of 1 to 11 digits. Format options include: <ul style="list-style-type: none"> <li>• 0.0.1 to 7.255.7 for point-code in the ITU range.</li> <li>• 0.0.1 to 255.255.255 for point-code in the ANSI range.</li> <li>• 0.0.1 to 15.31.255 for point-code in the TTC range.</li> <li>• a string of 1 to 11 digits in dotted-decimal to represent a point-code in a different range.</li> </ul> <b>no</b> Removes the adjacent-point-code configuration for this linkset in the SS7 routing domain
 Important	Removing the linkset configuration will result in the termination of all of the links within the linkset.
Usage Guidelines	Use this command to define the point-code for the adjacent element in the SS7 network.
Example	<b>adjacent-point-code</b> <i>6.202.7</i>

# link

This command creates an MTP3 link configuration for the SS7 linkset and enters the Link configuration mode.

Product	SGSN
Privilege	Security Administrator, Administrator
Command Modes	Exec > Global Configuration > SS7 Routing Domain Configuration > Linkset Configuration <b>configure &gt; ss7-routing-domain</b> <i>domain_id</i> <b>variant</b> <i>var_type</i> > <b>linkset id</b> <i>linkset_id</i> Entering the above command sequence results in the following prompt: <pre>[local]host_name(config-ss7-rd-linkset-linkset_id)#</pre>
Syntax Description	<b>link id</b> <i>id</i> [ <b>link-type</b> [ <b>atm-broadband</b>   <b>highspeed-narrowband</b>   <b>lowspeed-narrowband</b> ] ] <b>no link id</b> <i>id</i>

**no**

Disables the specified link configuration.

**Important**

Removing the link configuration will result in the termination of traffic on the specified link.

**#\_octets**

Sets the number of octets for the length of the LSSU.

**id**

This number uniquely identifies the link in the linkset.

*id*: an integer between 1 and 16.

**link-type**

Identifies the signalling type for this link; options include:

- ATM broadband -- ATM AAL5 over an optical line card (OLC2)
- high speed-narrowband -- 64 kbps over a channelized optical line card (CLC2)
- low speed-narrowband -- 4.8 kbps over a channelized optical line card (CLC2)

**Important**

Be default link-type is ATM-broadband. To support narrowband SS7, one of the other options must be set.

**Usage Guidelines**

Access the Link configuration mode to configure the parameters for the the link.

**Example**

Access configuration for link 4:

```
link id 4
```

## self-point-code

This command defines the SS7 network point-code to identify this SGSN.

**Product**

SGSN

**Privilege**

Security Administrator, Administrator

**Command Modes**

Exec > Global Configuration > SS7 Routing Domain Configuration > Linkset Configuration

```
configure > ss7-routing-domain domain_id variant var_type > linkset id linkset_id
```

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-ss7-rd-linkset-linkset_id) #
```

---

**Syntax Description**

**self-point-code** *point-code*  
**no self-point-code**

***point-code***

Point-code is an SS7 address for an element in the SS7 network. Point-codes must be defined in dotted-decimal format in a string of 1 to 11 digits. Format options include:

- 0.0.1 to 7.255.7 for point-code in the ITU range.
- 0.0.1 to 255.255.255 for point-code in the ANSI range.
- 0.0.1 to 15.31.255 for point-code in the TTC range.
- a string of 1 to 11 digits in dotted-decimal to represent a point-code in a different range.

**no**

Removes the self-point-code configuration for this linkset in the SS7 routing domain.



---

**Important**

Removing the self-point-code will result in the termination of all traffic on this link.

---

---

**Usage Guidelines**

Use this command to define the SS7 point-code to identify this system.

**Example**

**self-point-code** *6.192.7*