



EIR Profile Configuration Mode Commands

The EIR is used for authentication and authorization of a subscriber's equipment during an Attach. The EIR database includes information about the subscriber's equipment (UE), such as the International Mobile Equipment Identity (IMEI) and the UE manufacturer's software version number (SV) which is usually paired with the IMEI. The IMEI(SV) can be in one of three lists in the EIR:

- white list - the subscriber equipment is permitted access
- black list - the subscriber equipment is not permitted access
- grey list - the subscriber equipment is being tracked for evaluation or other purposes

To view the configured values of the EIR profile, use the Exec mode **show sgsn-mode** command.

To associate the EIR profile with call control profile, see the call control profile mode's **eir-profile** command.

Command Modes

The EIR Profile configuration mode provides the commands to define Equipment Identify Register (EIR) parameters that can be used by the SGSN on a global level. The SGSN supports a total of 16 instances of the EIR profile.

Exec > Global Configuration > SGSN Global Configuration > EIR Profile Configuration

configure > sgsn-global > eir-profile *eir_profile_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-eir-profile-eir_profile_name)#
```



Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [check-imei-every-n-events](#), on page 2
- [end](#), on page 2
- [eir-address](#), on page 3
- [exit](#), on page 4
- [include-imsi](#), on page 4
- [map-include-imsi](#), on page 4

check-imei-every-n-events

This command performs IMEI check for every N events.

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > SGSN Global Configuration > EIR Profile Configuration

configure > **sgsn-global** > **eir-profile** *eir_profile_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-eir-profile-eir_profile_name)#
```

Syntax Description

check-imei-every-n-events *check_frequency*
no check-imei-every-n-events

no

Removes the IMEI check definition from the EIR profile configuration.

check_frequency

The frequency must be an integer from 1 to 15.

When a value is configured, the SGSN skips sending the 'check IMEI' message for the first N-1 event where IMDI/IMEISV is received.

Usage Guidelines

Use this command to perform IMEI check for every N events. If a value is not defined, then by default, the SGSN sends a 'check IMEI' message for every event.

Example

The following command removes the check frequency configuration from the EIR profile:

```
no check-imei-every-n-events
```

end

Exits the current configuration mode and returns to the Exec mode.

Product

All

Privilege

Security Administrator, Administrator

Syntax Description

end

Usage Guidelines

Use this command to return to the Exec mode.

eir-address

This command configures the address of the equipment identify register (EIR).

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > SGSN Global Configuration > EIR Profile Configuration

configure > **sgsn-global** > **eir-profile** *eir_profile_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-eir-profile-eir_profile_name)#
```

Syntax Description

```
eir-address { isdn isdn_address | point-code point_code } [ source-ssn source_ssn ]
no eir-address
```

no

Removes the EIR address from this EIR profile.

isdn *isdn_address*

Configures a standard ISDN E.164 address to identify the EIR. *isdn_address* is an integer from 0 to 9.

point-code *point_code*

Configures a standard SS7 formatted point-code address to identify the EIR. *point_code* must be in dotted-decimal or decimal format. Format options include:

- 0.0.1 to 7.255.7 for point-code in the ITU range.
- 0.0.1 to 255.255.255 for point-code in the ANSI range.
- 0.0.1 to 15.31.255 for point-code in the TTC Range.
- A string of 1 to 11 digits in dotted-decimal to represent a point-code in a different range.

source-ssn *source_ssn*

Configures the source SSN value to be used, to define the subsystem number of the element being identified. *source_ssn* is an integer from 1 to 255. The default value is 149 (SGSN).

Usage Guidelines

Use this command to define a single EIR address to be used for multiple EIRs when this EIR profile is associated with a call control profile.

Example

The following command configures the point-code 255.255.255 with source SSN value 250 for the EIR address :

```
eir-address point-code 255.255.255 source-ssn 250
```

exit

Exits the current mode and returns to the parent configuration mode.

Product	All
Privilege	Security Administrator, Administrator
Syntax Description	exit
Usage Guidelines	Use this command to return to the parent configuration mode.

include-imsi

This command enables inclusion of IMSI in the TCAP message.

Product	SGSN
Privilege	Security Administrator, Administrator
Command Modes	Exec > Global Configuration > SGSN Global Configuration > EIR Profile Configuration configure > sgsn-global > eir-profile <i>eir_profile_name</i> Entering the above command sequence results in the following prompt: <i>[context_name]host_name(config-eir-profile-eir_profile_name)#</i>
Syntax Description	[no] include-imsi no Disables inclusion of IMSI in the TCAP message.
Usage Guidelines	Use this command to enable or disable the inclusion of IMSI in the TCAP message for IMSI checking during the IMEI check operation. By default, IMSI checking is not included.

map-include-imsi

This command enables adding IMSI in the MAP message.

Product	SGSN
Privilege	privilege
Command Modes	Exec > Global Configuration > SGSN Global Configuration > EIR Profile Configuration configure > sgsn-global > eir-profile <i>eir_profile_name</i> Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-eir-profile-eir_profile_name)#
```

Syntax Description

[no] **map-include-imsi**

no

Disables inclusion of IMSI in the MAP message.

Usage Guidelines

Use this command to enable or disable inclusion of IMSI checking during the check IMEI procedure. By default, IMSI checking is not part of the IMEI check procedure.

map-include-imsi