



EAP Configuration Mode Commands

The EAP Configuration Mode is used to configure parameters comprising an Extensible Authentication Protocol (EAP) used to support authentication on the system.

Command Modes

Exec > Global Configuration > Context Configuration > EAP Profile Configuration

configure > context *context_name* > **eap-profile** *profile_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(cfg-ctx-eap-profile)#
```



Important The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [end, on page 1](#)
- [exit, on page 1](#)
- [max-retry, on page 2](#)
- [mode, on page 2](#)

end

Exits the current configuration mode and returns to the Exec mode.

Product All

Privilege Security Administrator, Administrator

Syntax Description **end**

Usage Guidelines Use this command to return to the Exec mode.

exit

Exits the current mode and returns to the parent configuration mode.

Product	All
Privilege	Security Administrator, Administrator
Syntax Description	exit
Usage Guidelines	Use this command to return to the parent configuration mode.

max-retry

Configures the maximum number of times the system will retry communicating with another EAP device.

Product	ASN-GW PDIF
Privilege	Security Administrator, Administrator
Command Modes	Exec > Global Configuration > Context Configuration > EAP Profile Configuration configure > context <i>context_name</i> > eap-profile <i>profile_name</i> Entering the above command sequence results in the following prompt: <i>[context_name]host_name (cfg-ctx-eap-profile) #</i>

Syntax Description	max-retry <i>num</i> default max-retry max-retry <i>num</i> Specifies the number of times to retry EAP communication with another device as an integer from 1 to 65535. Default: 16
Usage Guidelines	Use this command to set a maximum retry number for communicating with other EAP devices.

Example

The following command sets the maximum number of retries to 50:

```
max-retry 50
```

mode

Configures the system as one of three types of EAP devices: authenticator pass-through, authenticator server, or peer.

Product	ASN-GW PDIF
----------------	----------------

Privilege	Security Administrator, Administrator
Command Modes	Exec > Global Configuration > Context Configuration > EAP Profile Configuration configure > context <i>context_name</i> > eap-profile <i>profile_name</i> Entering the above command sequence results in the following prompt: <i>[context_name]host_name(cfg-ctx-eap-profile)#</i>
Syntax Description	mode { authenticator-pass-through authenticator-server peer } default mode default Configures the default mode of Authenticator-pass-through. authenticator-pass-through Configures the system as an authenticator pass-through allowing EAP authentication to be performed by another server. This is the default setting for this command. authenticator-server Configures the system as an authenticator server. This allows the system to respond to EAP requests. peer Configures the system as a peer device requiring it to make EAP requests of another server or pass-through device.
Usage Guidelines	Use this command to configure the system to perform as one of three types of EAP devices and configure settings in an EAP mode. EAP Mode Configuration Mode commands are defined in the EAP Mode Configuration Mode Commands chapter. Example The following command configures the system to perform as an authenticator pass-through: mode authenticator-pass-through

mode