

Configuring Access Point Groups

- Finding Feature Information, on page 1
- Prerequisites for Configuring AP Groups, on page 1
- Restrictions on Configuring Access Point Groups, on page 2
- Information About Access Point Groups, on page 2
- How to Configure Access Point Groups, on page 3
- Additional References, on page 5
- Feature History and Information for Access Point Groups, on page 6

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to http://www.cisco.com/go/cfn. An account on Cisco.com is not required.

Prerequisites for Configuring AP Groups

The following are the prerequisites for creating access point groups on a controller:

- The required access control list (ACL) must be defined on the router that serves the VLAN or subnet.
- Multicast traffic is supported with access point group VLANs. However, if the client roams from one access point to another, the client might stop receiving multicast traffic, unless IGMP snooping is enabled.

Related Topics

Information About Access Point Groups, on page 2 Restrictions on Configuring Access Point Groups, on page 2

Restrictions on Configuring Access Point Groups



Note

Cisco IOS XE Release 3.7.7 modifies the behavior of mapping AP-group to a WLAN. From this release onwards, you must configure a WLAN before you can map it to an AP-group. Likewise, before deleting a WLAN, you should un-map the AP-group from the WLAN.

Earlier, you could map a WLAN to an AP-group, even when WLAN was not configured. Also, you delete a WLAN, even when it was mapped to an AP-group.

Suppose that the interface mapping for a WLAN in the AP group table is the same as the WLAN interface.
 If the WLAN interface is changed, the interface mapping for the WLAN in the AP group table also changes to the new WLAN interface.

Suppose that the interface mapping for a WLAN in the AP group table is different from the one defined for the WLAN. If the WLAN interface is changed, then the interface mapping for the WLAN in the AP group table does not change to the new WLAN interface.

- If you clear the configuration on the controller, all of the access point groups disappear except for the default access point group "default-group," which is created automatically.
- The default access point group can have up to 16 WLANs associated with it. The WLAN IDs for the default access point group must be less than or equal to 16. If a WLAN with an ID greater than 16 is created in the default access point group, the WLAN SSID will not be broadcasted. All WLAN IDs in the default access point group must have an ID that is less than or equal to 16. WLANs with IDs greater than 16 can be assigned to custom access point groups.
- We recommend that you configure all Flex+Bridge APs in a mesh tree (in the same sector) in the same AP group and the same FlexConnect group, to inherit the WLAN-VLAN mappings properly.
- Whenever you add a new WLAN to an AP group, radio reset occurs and if any client is in connected state, the client is deauthenticated and is required to reconnect. We recommend that you add or modify the WLAN configuration of an AP group only during maintenance windows to avoid outages.
- The number of AP groups that you can configure cannot be more than the number of ap-count licenses on Cisco WLC. For example, if your Cisco WLC has 5 ap-count licenses, the maximum number of AP groups that you can configure is 5, including the default AP group.

Related Topics

Information About Access Point Groups, on page 2 Prerequisites for Configuring AP Groups, on page 1

Information About Access Point Groups

After you create up to 512 WLANs on the controller, you can selectively publish them (using access point groups) to different access points to better manage your wireless network. In a typical deployment, all users on a WLAN are mapped to a single interface on the controller. Therefore, all users that are associated with that WLAN are on the same subnet or VLAN. However, you can choose to distribute the load among several interfaces or to a group of users based on specific criteria such as individual departments (such as Marketing)

by creating access point groups. Additionally, these access point groups can be configured in separate VLANs to simplify network administration.

Related Topics

Creating Access Point Groups, on page 3

Viewing Access Point Group, on page 5

Assigning an Access Point to an AP Group, on page 4

Prerequisites for Configuring AP Groups, on page 1

Restrictions on Configuring Access Point Groups, on page 2

How to Configure Access Point Groups

Creating Access Point Groups

Before you begin

You must have administrator privileges to perform this operation.

SUMMARY STEPS

- 1. configure terminal
- **2. ap group** *ap-group-name*
- 3. wlan wlan-name
- 4. (Optional) vlan vlan-name
- 5. end

DETAILED STEPS

| | Command or Action | Purpose |
|--------|--|---|
| Step 1 | configure terminal | Enters global configuration mode. |
| | Example: | |
| | Controller# configure terminal | |
| Step 2 | ap group ap-group-name | Creates an access point group. |
| | Example: | |
| | Controller(config)# ap group my-ap-group | |
| Step 3 | wlan wlan-name | Associates the AP group to a WLAN. |
| | Example: | |
| | Controller(config-apgroup)# wlan wlan-name | |
| Step 4 | (Optional) vlan vlan-name | Assigns the access point group to a VLAN. |
| | Example: | |
| | Controller(config-apgroup)# vlan test-vlan | |

| | Command or Action | Purpose |
|--------|-------------------------|---|
| Step 5 | end | Returns to privileged EXEC mode. Alternatively, you can |
| | Example: | also press Ctrl-Z to exit global configuration mode. |
| | Controller(config)# end | |

Example

This example shows how to create an AP group:

```
Controller# configure terminal
Controller(config-apgroup)# ap group test-ap-group-16
Controller(config-wlan-apgroup)# wlan test-ap-group-16
Controller(config-wlan-apgroup)# vlan VLAN1300
```

Related Topics

Information About Access Point Groups, on page 2

Assigning an Access Point to an AP Group

Before you begin

You must have administrator privileges to perform this operation.

SUMMARY STEPS

1. ap name ap-name ap-group-name ap-group

DETAILED STEPS

| | Command or Action | Purpose |
|--------|---|---|
| Step 1 | ap name ap-name ap-group-name ap-group Example: Controller# ap name 1240-101 ap-groupname apgroup_16 | Assigns the access point to the access point group. The keywords and arguments are as follows: • name—Specifies that the argument following this keyword is the name of an AP that is associated to the controller. • ap-name—AP that you want to associate to the AP group. • ap-group-name—Specifies that the argument following this keyword is the name of the AP group that is configured on the controller. • ap-group—Name of the access point group that is configured on the controller. |

Related Topics

Information About Access Point Groups, on page 2

Viewing Access Point Group

Before you begin

You must have administrator privileges to perform this operation.

SUMMARY STEPS

1. show ap groups [extended]

DETAILED STEPS

| | Command or Action | Purpose | |
|----------|----------------------------|---|--|
| Step 1 | show ap groups [extended] | Displays the AP groups configured on the controller. The | |
| Fvamnio. | | extended keyword displays all AP Groups information defined in the system in detail. | |
| | Controller# show ap groups | | |

Related Topics

Information About Access Point Groups, on page 2

Additional References

Related Documents

| Related Topic | Document Title | |
|--|--|--|
| WLAN commands | WLAN Command Reference, Cisco IOS XE Release 3SE (Cisco WLC 5700 Series)WLAN Command Reference, Cisco IOS XE Release 3SE (Catalyst 3850 Switches)WLAN Command Reference, Cisco IOS XE Release 3SE (Catalyst 3650 Switches) | |
| Lightweight Access Point configuration | Lightweight Access Point Configuration Guide, Cisco IOS XE Release 3SE (Cisco WLC 5700 Series)Lightweight Access Point Configuration Guide, Cisco IOS XE Release 3SE (Catalyst 3850 Switches)Lightweight Access Point Configuration Guide, Cisco IOS XE Release 3SE (Catalyst 3650 Switches) | |
| Lightweight Access Point commands | Lightweight Access Point Command Reference, Cisco IOS XE Release 3SE (Cisco WLC 5700 Series)Lightweight Access Point Command Reference, Cisco IOS XE Release 3SE (Catalyst 3850 Switches)Lightweight Access Point Command Reference, Cisco IOS XE Release 3SE (Catalyst 3650 Switches) | |

Error Message Decoder

| Description | Link |
|---|--|
| To help you research and resolve system error messages in this release, use the Error Message Decoder tool. | https://www.cisco.com/cgi-bin/Support/Errordecoder/index.cgi |

MIBs

| MIB | MIBs Link | |
|--|---|--|
| All the supported MIBs for this release. | To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: | |
| | http://www.cisco.com/go/mibs | |

Technical Assistance

| Description | Link |
|---|------------------------------|
| The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies. | http://www.cisco.com/support |
| To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds. | |
| Access to most tools on the Cisco Support website requires a Cisco.com user ID and password. | |

Feature History and Information for Access Point Groups

This table lists the features in this modules and provides links to specific configuration information.

| Feature Name | Release | Feature Information |
|--------------|--|------------------------------|
| AP Groups | Cisco IOS XE 3.2SECisco IOS XE 3.3SECisco IOS XE 3.3SE | This feature was introduced. |