

# Show Commands: 802.11

- show 802.11, on page 2
- show 802.11, on page 4
- show 802.11 cleanair, on page 6
- show 802.11 cleanair air-quality summary, on page 8
- show 802.11 cleanair air-quality worst, on page 9
- show 802.11 cleanair device ap, on page 10
- show 802.11 cleanair device type, on page 11
- show 802.11 cu-metrics, on page 13
- show 802.11 extended, on page 14
- show 802.11 media-stream, on page 15

### show 802.11

To display basic 802.11a, 802.11b/g, or 802.11h network settings, use the **show 802.11** command.

show 802.11 {  $a \mid b \mid h$  }

Syntax Description	a	Specifies the 802.11a network.
	b	Specifies the 802.11b/g network.
	h	Specifies the 802.11h network.

Command Default

None.

This example shows to display basic 802.11a network settings:

> show 802.11a	
802.11a Network	Enabled
11nSupport	Enabled
802.11a Low Band	Enabled
802.11a Mid Band	Enabled
802.11a High Band	Enabled
802.11a Operational Rates	
802.11a 6M Rate	Mandatory
802.11a 9M Rate	Supported
802.11a 12M Rate	Mandatory
802.11a 18M Rate	Supported
802.11a 24M Rate	Mandatory
802.11a 36M Rate	Supported
802.11a 48M Rate	Supported
802.11a 54M Rate	Supported
802.11n MCS Settings:	
MCS 0	Supported
MCS 1	Supported
MCS 2	Supported
MCS 3	Supported
MCS 4	Supported
MCS 5	Supported
MCS 6	Supported
MCS 7	Supported
MCS 8	Supported
MCS 9	Supported
MCS 10	Supported
MCS 11	Supported
MCS 12	Supported
MCS 13	Supported
MCS 14	Supported
MCS 15	Supported
802.11n Status:	
A-MPDU Tx:	
Priority 0	Enabled
Priority 1	Disabled
Priority 2	Disabled
Priority 3	Disabled
Priority 4	Disabled
Priority 5	Disabled
Priority 6	Disabled

Priority 7	Disabled
Beacon Interval	100
CF Pollable mandatory	Disabled
CF Poll Request mandatory	Disabled
More or (q)uit	
CFP Period	4
CFP Maximum Duration	60
Default Channel	36
Default Tx Power Level	0
DTPC Status E	Inabled
Fragmentation Threshold	2346
TI Threshold	-50
Legacy Tx Beamforming setting	Disabled
Traffic Stream Metrics Status	Enabled
Expedited BW Request Status	Disabled
World Mode	Enabled
EDCA profile type	default-wmm
Voice MAC optimization status	Disabled
Call Admission Control (CAC) configuration	
Voice AC:	
Voice AC - Admission control (ACM)	Disabled
Voice max RF bandwidth	75
Voice reserved roaming bandwidth	6
Voice load-based CAC mode	Disabled
Voice tspec inactivity timeout	Disabled
Voice Stream-Size	84000
Voice Max-Streams	2
Video AC:	
Video AC - Admission control (ACM)	Disabled
Video max RF bandwidth	Infinite
Video reserved roaming bandwidth	0

This example shows how to display basic 802.11h network settings:

#### > show 802.11h

show ap stats

802.11h	 powerconstraint	: :	0		
802.11h	 channelswitch :	D	isa	abl	.e
802.11h	 channelswitch m	nod	e	: 0	)

#### Related Commands

show ap summary show client summary show network show network summary show port show wlan

### show 802.11

To display basic 802.11a, 802.11b/g, or 802.11h network settings, use the **show 802.11** command.

show 802.11 {  $a \mid b \mid h$  }

Syntax Description	a	Specifies the 802.11a network.
	b	Specifies the 802.11b/g network.
	h	Specifies the 802.11h network.

Command Default

None.

This example shows to display basic 802.11a network settings:

> show 802.11a	
802.11a Network	Enabled
11nSupport	Enabled
802.11a Low Band	Enabled
802.11a Mid Band	Enabled
802.11a High Band	Enabled
802.11a Operational Rates	
802.11a 6M Rate	Mandatory
802.11a 9M Rate	Supported
802.11a 12M Rate	Mandatory
802.11a 18M Rate	Supported
802.11a 24M Rate	Mandatory
802.11a 36M Rate	Supported
802.11a 48M Rate	Supported
802.11a 54M Rate	Supported
802.11n MCS Settings:	
MCS 0	Supported
MCS 1	Supported
MCS 2	Supported
MCS 3	Supported
MCS 4	Supported
MCS 5	Supported
MCS 6	Supported
MCS 7	Supported
MCS 8	Supported
MCS 9	Supported
MCS 10	Supported
MCS 11	Supported
MCS 12	Supported
MCS 13	Supported
MCS 14	Supported
MCS 15	Supported
802.11n Status:	
A-MPDU Tx:	
Priority 0	Enabled
Priority 1	Disabled
Priority 2	Disabled
Priority 3	Disabled
Priority 4	Disabled
Priority 5	Disabled
Priority 6	Disabled

Priority 7 Disabled
Beacon Interval 100
CF Pollable mandatory Disabled
CF Poll Request mandatory Disabled
More or (q)uit
CFP Period
CFP Maximum Duration
Default Channel
Default Tx Power Level
DTPC Status Enabled
Fragmentation Threshold 2346
TI Threshold50
Legacy Tx Beamforming setting Disabled
Traffic Stream Metrics Status Enabled
Expedited BW Request Status Disabled
World Mode Enabled
EDCA profile type default-wmm
Voice MAC optimization status Disabled
Call Admission Control (CAC) configuration
Voice AC:
Voice AC - Admission control (ACM) Disabled
Voice max RF bandwidth 75
Voice reserved roaming bandwidth 6
Voice load-based CAC mode Disabled
Voice tspec inactivity timeout Disabled
Voice Stream-Size 84000
Voice Max-Streams 2
Video AC:
Video AC - Admission control (ACM) Disabled
Video max RF bandwidth Infinite
Video reserved roaming bandwidth 0

This example shows how to display basic 802.11h network settings:

#### > show 802.11h

show ap stats

802.11h	 powerconstraint	: :	0		
802.11h	 channelswitch :	D	isa	abl	.e
802.11h	 channelswitch m	nod	e	: 0	)

#### Related Commands

show ap summary show client summary show network show network summary show port show wlan

### show 802.11 cleanair

To display the multicast-direct configuration state, use the show 802.11 cleanair command.

show 802.11 {  $a \mid b \mid h$  } cleanair config

Syntax Description	a	Specifies the 802.11a network.
	b	Specifies the 802.11b/g network.
	h	Specifies the 802.11h network.
	config	Displays the network Cleanair configuration.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

The following example shows how to display the 802.11a cleanair configuration:

(Cisco Controller) > <b>show 802.11a cleanair</b>	
Clean Air Solution	Enabled
Air Quality Settings:	
Air Quality Reporting	Enabled
Air Quality Reporting Period (min)	15
Air Quality Alarms	Enabled
Air Quality Alarm Threshold	35 Interference Device
Settings:	
Interference Device Reporting	Enabled
Interference Device Types:	
TDD Transmitter	Disabled
Jammer	Disabled
Continuous Transmitter	Disabled
DECT-like Phone	Disabled
Video Camera	Disabled
WiFi Inverted	Disabled
WiFi Invalid Channel	Disabled
SuperAG	Disabled
Radar	Disabled
Canopy	Disabled
WiMax Mobile	Disabled
WiMax Fixed	Disabled
Interference Device Alarms Enal	bled
Interference Device Types Triggering Alarms:	
TDD Transmitter	Disabled
Jammer	Disabled

Continuous Transmitter	Disabled
DECT-like Phone	Disabled
Video Camera	Disabled
WiFi Inverted	Disabled
WiFi Invalid Channel	Disabled
SuperAG	Disabled
Radar	Disabled
Canopy	Disabled
WiMax Mobile	Disabled
WiMax Fixed	Disabled Additional
Clean Air Settings:	
CleanAir Event-driven RRM State	Enabled
CleanAir Driven RRM Sensitivity	Medium
CleanAir Persistent Devices state	Disabled

## show 802.11 cleanair air-quality summary

To display the air quality summary information for the 802.11 networks, use the **show 802.11 cleanair** air-quality summary command.

show 802.11 {a | b | h} cleanair air-quality summary

Syntax Description	a	Specifies the 802.11a network.
	b	Specifies the 802.11b/g network.
	h	Specifies the 802.11h network.
	summary	Displays a summary of 802.11 radio band air quality information.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
	The following example shows ho network:	ow to display a summary of the air quality information for the 802.11a

```
(Cisco Controller) > show 802.11a cleanair air-quality summary
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name Channel Avg AQ Min AQ Interferers DFS
------ ---- ---- ---- ---- ----- ----
CISCO_AP3500 36 95 70 0
CISCO_AP3500 40 93 75 0
```

## show 802.11 cleanair air-quality worst

To display the worst air quality information for the 802.11 networks, use the **show 802.11 cleanair air-quality worst** command.

show 802.11 {a | b | h} cleanair air-quality worst

_	
а	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
h	Specifies the 802.11h network.
worst	Displays the worst air quality information for 802.11 networks.
None	
Release	Modification
7.6	This command was introduced in a release earlier than Release 7.6.
	a         b         h         worst         None         Release         7.6

# show 802.11 cleanair device ap

To display the information of the device access point on the 802.11 radio band, use the **show 802.11 cleanair device ap** command.

show 802.11 { a + b + h } cleanair device ap *cisco\_ap* 

Syntax Description	a		Specifies the 802.11a netwo	ork.						
	<b>b</b> Specifies the 802.11b/g network.									
	h		Specifies the 802.11h netwo	ork.						
	cisco_ap		Specified access point name	e.						
Command Default	None									
Command History	Release		Modification							
	7.6		This command was introduced in a release earlier than Release 7.6.							
	The following example shows how to display the device access point for the 802.11a network:									
	(Cisco Controller) > <b>show</b> ( DC = Duty Cycle (%) ISI = Interference Se Interference)	<b>802.11a cleanair de</b> verity Index (1	<b>vice ap AP_3500</b> -Low Interference,	100-Hi	gh					
	RSSI = Received Signal Strength Index (dBm)									
	No ClusterID RSSI DC Channel	DevID Type	AP Name			ISI				
	1 c2:f7:40:00:00:03	0x8001 DECT p	hone CISCO_AP3500	1	-43	3				
	2 c2:f7:40:00:00:51	0x8002 Radar	CISCO_AP3500	1	-81	2				
	3 c2:f7:40:00:00:03 153,157,161,165	0x8005 Canopy	CISCO_AP3500	2	-62	2				

## show 802.11 cleanair device type

To display the information of all the interferers device type detected by a specific access point on the 802.11 radio band, use the **show 802.11 cleanair device type** command.

show 802.11 { a | b | h } cleanair device type *device\_type* 

Syntax Description	a	Specifies the 802.11a network.
	b	Specifies the 802.11b/g network.
	h	Specifies the 802.11h network.
	device_type	Interferer device type for a specified radio band. The device type is one of the following:
		• tdd-tx—Tdd-transmitter device information.
		• jammer—Jammer device information.
		• cont-tx—Continuous-transmitter devices information.
		• dect-like—Dect-like phone devices information.
		• video—Video devices information.
		• 802.11-inv—WiFi inverted devices information.
		• 802.11-nonstd—Nonstandard WiFi devices information.
		• superag—Superag devices information.
		• canopy—Canopy devices information.
		• wimax-mobile—WiMax mobile devices information.
		• wimax-fixed—WiMax fixed devices information.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
	The following example shows l	now to display the information of all the interferers detected by a

(Cisco Controller) > show 802.11a cleanair device type canopy DC = Duty Cycle ( $\frac{\circ}{\circ}$ )

<pre>ISI = Interference Severity Index (1-Low</pre>	Interference, 100-Hig	gh
Interference)		
RSSI = Received Signal Strength Index (	dBm)	
DevID = Device ID		
No ClusterID DevID Type	AP Name	ISI
RSSI DC Channel		
1c2:f7:40:00:00:03 0x8005 Canopy	CISCO_AP3500 2	-62 2
153,157,161,165		

L

### show 802.11 cu-metrics

**Release Modification** 

To display access point channel utilization metrics, use the show 802.11 cu-metrics command.

```
show 802.11{a | b} cu-metrics cisco_ap
```

#### **Syntax Description**

on	a	Specifies the 802.11a network.
	b	Specifies the 802.11b/g network.
	cisco_ap	Access point name.

None **Command Default** 

#### **Command History**

7.6 This command was introduced in a release earlier than Release 7.6.

The following is a sample output of the show 802.11a cu-metrics command:

```
(Cisco Controller) > show 802.11a cu-metrics AP1
AP Interface Mac:
                    30:37:a6:c8:8a:50
Measurement Duration:
                    90sec
Timestamp
                  Thu Jan 27 09:08:48 2011
  Channel Utilization stats
  _____
   Picc (50th Percentile)..... 0
   Picc (90th Percentile)..... 0
   Pib (90th Percentile)..... 77
                  Thu Jan 27 09:34:34 2011
Timestamp
```

#### show 802.11 extended

To display access point radio extended configurations, use the **show 802.11 extended** command.

show 802.11 {a | b} extended

Syntax Description	a	Specifies the 802.11a network.
	b	Specifies the 802.11b/g network.
	extended	Displays the 802.11a/b radio extended configurations.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
	8.0	The command output was expanded to include the Rx SOP threshold.

The following example shows how to display radio extended configurations:

```
(Cisco Controller) > show 802.11a extended
Default 802.11a band radio extended configurations:
    beacon period 300, range 60;
    multicast buffer 45, rate 200;
    RX SOP -80; CCA threshold -90;
AP0022.9090.b618 00:24:97:88:99:60
    beacon period 300, range 60; multicast buffer 45, rate 200;
    RX SOP -80; CCA threshold -77
AP0022.9090.bb3e 00:24:97:88:c5:d0
    beacon period 300, range 0; multicast buffer 0, rate 0;
    RX SOP -80; CCA threshold -0
ironRap.ddbf 00:17:df:36:dd:b0
    beacon period 300, range 0; multicast buffer 0, rate 0;
    RX SOP -80; CCA threshold -0
```

The following example shows how to display radio extended configurations and the Rx SOP threshold:

```
(Cisco Controller) > show 802.11a extended
Default 802.11a band Radio Extended Configurations:
  Beacon period: 100, range: 0 (AUTO);
  Multicast buffer: 0 (AUTO), rate: 0 (AUTO);
  RX SOP threshold: -76; CCA threshold: 0 (AUTO);
AP3600-XALE3 34:a8:4e:6a:7b:00
  Beacon period: 100, range: 0 (AUTO);
  Multicast buffer: 0 (AUTO), rate: 0 (AUTO);
  RX SOP threshold: -76; CCA threshold: 0 (AUTO);
```

## show 802.11 media-stream

To display the multicast-direct configuration state, use the show 802.11 media-stream command.

show	802.11	{ <b>a</b>		b		<b>h</b> }	media-stream	media_	_stream_	_name
------	--------	------------	--	---	--	------------	--------------	--------	----------	-------

Syntax Description	a	Specifies the 802.11a network.					
	b	Specifies the 802.11b/g network.					
	h	Specifies the 802.11h network.					
	media_stream_name	Specified media stream name.					
Command Default	None.						
Command History	Release	Modification					
	7.6	This command was introduced in a release earlier than Release 7.6.					
	This example shows how to display the media-stream configuration:						
	> show 802.11a media-stream rrc						
	Multicast-direct						
	Best Effort Disabled						
	Video Re-Direct	Enabled					
	Max Allowed Streams Per Radio	Auto					
	Max Allowed Streams Per Client	Auto					

Max	Video	Bandwidth	0
Max	Voice	Bandwidth	75
Max	Media	Bandwidth	85

**Related Commands** 

show media-stream group summary

I