



DHCP for WLANs

- [Dynamic Host Configuration Protocol, on page 1](#)
- [Restrictions for configuring DHCP for WLANs, on page 4](#)
- [How to Configure DHCP for WLANs, on page 5](#)
- [Configuring the Internal DHCP Server, on page 7](#)

Dynamic Host Configuration Protocol

Dynamic Host Configuration Protocol (DHCP) is a network protocol that

- dynamically assigns IP addresses to devices on a network for IP communication
- enables configuration of WLANs to use the same or different DHCP servers or no DHCP server, and
- provides two types of DHCP servers—internal and external.

Internal DHCP servers

An internal DHCP server is a device-based DHCP service that

- provides DHCP addresses to wireless clients, direct-connect APs, and DHCP requests that are relayed from APs
- supports only lightweight APs, and
- requires SVI configuration for the client VLAN with the IP address set as DHCP server IP address.

General guidelines

The device contains an internal DHCP server. This server is typically used in branch offices that do not have a DHCP server.

DHCP option 43 is not supported on the internal server. Therefore, the APs must use an alternative method to locate the management interface IP address of the device, such as local subnet broadcast, Domain Name System (DNS), or priming.

When clients use the internal DHCP server of the device, IP addresses are not preserved across reboots. As a result, multiple clients can be assigned to the same IP address. To resolve any IP address conflicts, clients must release their existing IP address and request a new one.

Key configuration requirements:

- Internal DHCP server serves both wireless client and wired client (wired client includes AP).
- To serve wireless client with internal DHCP server, an unicast DHCP server IP address must be configured for wireless client. Internal DHCP server IP address must be configured under the server facing interface, which can be loopback interface, SVI interface, or L3 physical interface.
- To use internal DHCP server for both wireless and wired client VLAN, an IP address must be configured under client VLAN SVI interface.
- For wireless client, in DHCP helper address configuration, the IP address of the internal DHCP server must be different from address of wireless client VLAN SVI interface.
- For wireless client with internal DHCP server support, the internal DHCP server can be configured using global configuration command, under the client VLAN SVI interface or under the wireless policy profile.
- An internal DHCP server pool can also serve clients of other controllers .



Note

- VRF is not supported in the internal DHCP servers.
 - DHCPv6 is not supported in the internal DHCP servers.
-

External DHCP servers

An external DHCP server is a separate server outside the device that

- dynamically assigns IP addresses within a network
- operates with industry-standard DHCP Relay support, and
- maintains client IP addresses during roaming scenarios.

External DHCP server operation

The operating system is designed to appear as a DHCP relay to the network and as a DHCP server to clients with industry-standard external DHCP servers that support DHCP Relay, which means that each controller appears as a DHCP relay agent to the DHCP server, and as a DHCP server in the virtual IP address to wireless clients.

Because the controller captures the client IP address that is obtained from a DHCP server, it maintains the same IP address for that client during intra controller, inter controller, and inter-subnet client roaming.



Note

External DHCP servers support DHCPv6.

DHCP assignments

A DHCP assignment is a network configuration method that

- configures DHCP servers on a per-interface or per-WLAN basis,
- allows assignment of primary and secondary DHCP servers to individual interfaces, and
- enables DHCP server definition on WLANs to override interface-level DHCP server addresses.

DHCP assignment configuration

You can configure DHCP on a per-interface or per-WLAN basis. We recommend that you use the primary DHCP server address that is assigned to a particular interface.

You can assign DHCP servers for individual interfaces. You can configure the management interface, AP manager interface, and dynamic interface for a primary and secondary DHCP server, and configure the service-port interface to enable or disable DHCP servers. You can also define a DHCP server on a WLAN (in this case, the server overrides the DHCP server address on the interface assigned to the WLAN).

Security considerations

For enhanced security, we recommend that you ask all clients to obtain their IP addresses from a DHCP server. To enforce this requirement, you can configure all the WLANs with a DHCP Address Assignment Required setting, which disallows client static IP addresses. If DHCP Address Assignment Required is selected, clients must obtain an IP address through DHCP. Any client with a static IP address is not allowed on the network. The controller monitors DHCP traffic because it acts as a DHCP proxy for the clients.



Note

- WLANs that support management over wireless must allow management (device-servicing) clients to obtain an IP address from a DHCP server.
- The operating system is designed to appear as a DHCP relay to the network and as a DHCP server to clients with industry-standard external DHCP servers that support DHCP relay. This means that each controller appears as a DHCP relay to the DHCP server and as a DHCP server at the virtual IP address to wireless clients.

You can create WLANs with DHCP Address Assignment Required disabled. If you do this, clients have the option of using a static IP address or obtaining an IP address from a designated DHCP server. However, note that this might compromise security.



Note

DHCP Address Assignment Required is not supported for wired guest LANs.

You can create separate WLANs with DHCP Address Assignment Required configured as disabled. This is applicable only if DHCP proxy is enabled for the controller. You must not define the primary or secondary configuration DHCP server instead you should disable the DHCP proxy. These WLANs drop all the DHCP requests and force clients to use a static IP address. These WLANs do not support management over wireless connections.

DHCP option 82

DHCP option 82 is a DHCP relay agent feature that

- provides additional security when DHCP is used to allocate network addresses

- enables the controller to act as a DHCP relay agent to prevent DHCP client requests from untrusted sources, and
- allows the controller to add option 82 information to DHCP requests from clients before forwarding the requests to the DHCP server.

DHCP option 82 operation

The AP forwards all the DHCP requests from a client to the controller. The controller adds the DHCP option 82 payload and forwards the request to the DHCP server. The payload can contain the MAC address or the MAC address and SSID of the AP, depending on how you configure this option.



Note DHCP packets that already include a relay agent option are dropped at the controller.

For DHCP option 82 to operate correctly, DHCP proxy must be enabled.

Figure 1: DHCP Option 82



Restrictions for configuring DHCP for WLANs

When configuring DHCP for WLANs, ensure proper server reachability and service enablement to avoid connectivity issues.

- If you override the DHCP server in a WLAN, you must ensure that you configure the underlying Cisco IOS configuration to make sure that the DHCP server is reachable.
- WLAN DHCP override works only if DHCP service is enabled on the controller.

You can configure DHCP service in either of the following ways:

- Configuring the DHCP pool on the controller.
- Configuring a DHCP relay agent on the SVI. Note that the VLAN of the SVI must be mapped to the WLAN where DHCP override is configured.

How to Configure DHCP for WLANs

Configure DHCP scopes (GUI)

Configure DHCP scopes to automatically assign IP addresses and network configuration parameters to wireless clients on your network.

DHCP scopes define the range of IP addresses available for assignment to clients, along with associated network configuration parameters such as subnet masks, default routers, and DNS servers.

Procedure

- Step 1** Choose **Administration > DHCP Pools**.
- Step 2** In the **Pools** section, click **Add** to add a new DHCP pool.
The **Create DHCP Pool** dialog box is displayed.
- Step 3** In the **DHCP Pool Name** field, enter a name for the new DHCP pool.
- Step 4** From the **IP Type** drop-down list, choose the IP address type.
- Step 5** In the **Network** field, enter the network served by this DHCP scope.
This IP address is used by the management interface with netmask applied, as configured in the **Interfaces** window.
- Step 6** In the **Subnet Mask** field, enter the subnet mask assigned to all the wireless clients.
- Step 7** In the **Starting IP** field, enter the starting IP address.
- Step 8** In the **Ending IP** field, enter the trailing IP address.
- Step 9** In the **Reserved Only** field, enable or disable it.
- Step 10** From the **Lease** drop-down list, choose the lease type as either **User Defined** or **Never Expires**.
If you choose User Defined, you can enter the amount of time that an IP address is granted to a client.
- Step 11** To perform advanced configuration for DHCP scope, click **Advanced**.
- Step 12** Check the **Enable DNS Proxy** check box to enable DNS proxy.
- Step 13** In the **Default Router(s)** field, enter the IP address of the optional router or routers that connect to the device and click the + icon to add them to the list.
Each router must include a DHCP forwarding agent that enables a single device to serve the clients of multiple devices.
- Step 14** In the **DNS Server(s)** field, enter the IP address of the optional DNS server or servers and click the + icon to add them to the list.
Each DNS server must be able to update a client's DNS entry to match the IP address assigned by the DHCP scope.
- Step 15** In the **NetBios Name Server(s)** field, enter the IP address of the optional Microsoft NetBIOS name server or servers, such as Microsoft Windows Internet Naming Service (WINS) server, and click the + icon to add them to the list.

- Step 16** In the **Domain** field, enter the optional domain name of the DHCP scope for use with one or more DNS servers.
- Step 17** To add **DHCP** options, click **Add** in the **DHCP Options List** section.
DHCP provides an internal framework for passing configuration parameters and other control information, such as DHCP options, to the clients on your network. DHCP options carry parameters as tagged data stored within protocol messages exchanged between the DHCP server and its clients.
- Step 18** Enter the **DHCP** option that you want to add.
- Step 19** Click **Save & Apply to Device**.

The DHCP scope is configured and ready to assign IP addresses and network configuration parameters to wireless clients.

Configure DHCP scopes (CLI)

Set up DHCP scopes to automatically assign IP addresses and network configuration to client devices.

DHCP scopes define the range of IP addresses and network parameters that a DHCP server can assign to clients. This configuration is essential for automated network address management in enterprise environments.

Procedure

- Step 1** Enter global configuration mode.
Example:
Device# configure terminal
- Step 2** Configure the DHCP pool address.
Example:
Device(config)# ip dhcp pool *pool-name*
Example:
Device(config)# ip dhcp pool test-pool
- Step 3** Specify the network number in dotted-decimal notation and the mask address.
Example:
Device(dhcp-config)# network *network-name mask-address*
Example:
Device(dhcp-config)# network 209.165.200.224 255.255.255.0
- Step 4** Specify the DNS name server.
Example:
Device(dhcp-config)# dns-server *hostname*
Example:
Device(dhcp-config)# dns-server example.com
You can specify an IP address or a hostname.

Step 5 Return to privileged EXEC mode.

Example:

```
Device(dhcp-config)# end
```

The DHCP scope is now configured and ready to assign IP addresses, network masks, and DNS server information to DHCP clients.

Configuring the Internal DHCP Server

Configure the internal DHCP server under client VLAN SVI (GUI)

This task configures the internal DHCP server settings for a client VLAN Switched Virtual Interface (SVI) to enable DHCP relay functionality.

Use this procedure when you need to set up DHCP relay on an SVI to forward DHCP requests to a designated helper address. This configuration is typically performed on network switches to enable DHCP services across VLANs.

Procedure

- Step 1** Choose **Configuration > Layer2 > VLAN > SVI**.
 - Step 2** Click an SVI.
 - Step 3** Click the **Advanced** tab.
 - Step 4** Under **DHCP Relay** settings, enter the **IPV4 Helper Address**.
 - Step 5** Click **Update & Apply to Device**.
-

The internal DHCP server is configured under the client VLAN SVI with the specified helper address, enabling DHCP relay functionality for the selected SVI.

Configure the internal DHCP server under client VLAN SVI (CLI)

Set up an internal DHCP server to provide IP address assignment for wireless and wired clients through the client VLAN SVI configuration.

The internal DHCP server can be configured under the client VLAN SVI to serve both wireless and wired clients. This configuration requires proper IP addressing and helper configuration to function correctly with the wireless infrastructure.

Before you begin

- For wireless clients, only two DHCP servers are supported.
- To use the internal DHCP server for both wireless and wired client VLAN, an IP address must be configured under the client VLAN SVI.

- For wireless clients, the IP address of the internal DHCP server must be different from the address of the wireless client VLAN SVI (in the DHCP helper address configuration).
- For wireless clients, the internal DHCP server can be configured under the client VLAN SVI or under the wireless policy profile.

Procedure

Step 1 Enter global configuration mode.

Example:

```
Device# configure terminal
```

Step 2 Create a loopback interface and enter interface configuration mode.

Example:

```
Device(config)# interface loopback interface-number
```

Example:

```
Device(config)# interface Loopback0
```

Step 3 Configure the IP address for the interface.

Example:

```
Device(config-if)# ip address ip-address subnet-mask
```

Example:

```
Device(config-if)# ip address 10.10.10.1 255.255.255.255
```

Step 4 Exit interface configuration mode.

Example:

```
Device(config-if)# exit
```

Step 5 Configure the VLAN ID.

Example:

```
Device(config)# interface vlan vlan-id
```

Example:

```
Device(config)# interface vlan 32
```

Step 6 Configure the IP address for the interface.

Example:

```
Device(config-if)# ip address ip-address subnet-mask
```

Example:

```
Device(config-if)# ip address 192.168.32.100 255.255.255.0
```

Step 7 Configure the destination address for UDP broadcasts.

Example:

```
Device(config-if)# ip helper-address ip-address
```

Example:

```
Device(config-if)# ip helper-address 10.10.10.1
```

Note

If the IP address used in the **IP helper-address** command is an internal address of the controller an internal DHCP server is used. Otherwise, the external DHCP server is used.

Step 8 Disable the Maintenance Operation Protocol (MOP) for an interface.

Example:

```
Device(config-if)# no mop enabled
```

Step 9 Disable the task of sending MOP periodic system ID messages.

Example:

```
Device(config-if)# no mop sysid
```

Step 10 Exit interface configuration mode.

Example:

```
Device(config-if)# exit
```

Step 11 Specify the IP address that the DHCP server should not assign to DHCP clients.

Example:

```
Device(config)# ip dhcp excluded-address ip-address
```

Example:

```
Device(config)# ip dhcp excluded-address 192.168.32.1
```

Step 12 Specify the IP addresses that the DHCP server should not assign to DHCP clients.

Example:

```
Device(config)# ip dhcp excluded-address ip-address
```

Example:

```
Device(config)# ip dhcp excluded-address 192.168.32.100
```

Step 13 Configure the DHCP pool address.

Example:

```
Device(config)# ip dhcp pool pool-name
```

Example:

```
Device(config)# ip dhcp pool pool-vlan32
```

Step 14 Specify the network number in dotted-decimal notation, along with the mask address.

Example:

```
Device(dhcp-config)# network network-address subnet-mask
```

Example:

```
Device(dhcp-config)# network 192.168.32.0 255.255.255.0
```

Step 15 Specify the IP address of the default router for a DHCP client.

Example:

```
Device(dhcp-config)# default-router ip-address
```

Example:

```
Device(dhcp-config)# default-router 192.168.32.1
```

Step 16 Exit DHCP configuration mode.

Example:

```
Device(dhcp-config)# exit
```

Step 17 Configure the WLAN policy profile and enter wireless policy configuration mode.

Example:

```
Device(config)# wireless profile policy profile-policy
```

Example:

```
Device(config)# wireless profile policy default-policy-profile
```

Step 18 Configure central association for locally switched clients.

Example:

```
Device(config-wireless-policy)# central association
```

Step 19 Configure the central DHCP for locally switched clients.

Example:

```
Device(config-wireless-policy)# central dhcp
```

Step 20 Configure WLAN for central switching.

Example:

```
Device(config-wireless-policy)# central switching
```

Step 21 Add a description for the policy profile.

Example:

```
Device(config-wireless-policy)# description "policy-profile-description"
```

Example:

```
Device(config-wireless-policy)# description "default policy profile"
```

Step 22 Assign the profile policy to the VLAN.

Example:

```
Device(config-wireless-policy)# vlan vlan-id
```

Example:

```
Device(config-wireless-policy)# vlan 32
```

Step 23 Enable the wireless profile policy.

Example:

```
Device(config-wireless-policy)# no shutdown
```

The internal DHCP server is now configured under the client VLAN SVI and can provide IP address assignment to both wireless and wired clients connected to the specified VLAN.

Configure the internal DHCP server under a wireless policy profile (GUI)

Configure DHCP settings to enable automatic IP address assignment for wireless clients connected to the network under a specific policy profile.

Use this procedure when you need to set up internal DHCP server functionality within a wireless policy profile to provide IP address allocation for connected wireless devices.

Procedure

- Step 1** Choose **Configuration > Tags & Profiles > Policy**.
 - Step 2** Click a policy name.
 - Step 3** Click the **Advanced** tab.
 - Step 4** Under **DHCP** settings, check or uncheck the **IPv4 DHCP Required** check box and enter the **DHCP Server IP Address**.
 - Step 5** Click **Update & Apply to Device**.
-

The internal DHCP server is configured under the wireless policy profile and the settings are applied to the device.

Configure the internal DHCP server under a wireless policy profile (CLI)

Enable DHCP services for wireless clients by configuring an internal DHCP server within a wireless policy profile.

The internal DHCP server provides IP address assignment and network configuration to wireless clients. This configuration includes setting up loopback and VLAN interfaces, defining DHCP pools, and associating the DHCP server with a wireless policy profile.

Procedure

- Step 1** Enter global configuration mode.
Example:

```
Device# configure terminal
```
- Step 2** Create a loopback interface and enter interface configuration mode.
Example:

```
Device(config)# interface loopback interface-number
```


Example:

```
Device(config)# interface Loopback0
```
- Step 3** Configure the IP address for the interface.
Example:

```
Device(config-if)# ip address ip-address subnet-mask
```

Example:

```
Device(config-if)# ip address 10.10.10.1 255.255.255.255
```

Step 4 Exit interface configuration mode.

Example:

```
Device(config-if)# exit
```

Step 5 Configure the VLAN ID.

Example:

```
Device(config)# interface vlan vlan-id
```

Example:

```
Device(config)# interface vlan 32
```

Step 6 Configure the IP address for the interface.

Example:

```
Device(config-if)# ip address ip-address subnet-mask
```

Example:

```
Device(config-if)# ip address 192.168.32.100 255.255.255.0
```

Step 7 Disable the Maintenance Operation Protocol (MOP) for an interface.

Example:

```
Device(config-if)# no mop enabled
```

Step 8 Disable the task of sending MOP periodic system ID messages.

Example:

```
Device(config-if)# no mop sysid
```

Step 9 Exit interface configuration mode.

Example:

```
Device(config-if)# exit
```

Step 10 Specify the IP address that the DHCP server should not assign to DHCP clients.

Example:

```
Device(config)# ip dhcp excluded-address ip-address
```

Example:

```
Device(config)# ip dhcp excluded-address 192.168.32.100
```

Step 11 Configure the DHCP pool address.

Example:

```
Device(config)# ip dhcp pool pool-name
```

Example:

```
Device(config)# ip dhcp pool pool-vlan32
```

Step 12 Specify the network number in dotted-decimal notation along with the mask address.

Example:

```
Device(dhcp-config)# network network-address subnet-mask
```

Example:

```
Device(dhcp-config)# network 192.168.32.0 255.255.255.0
```

Step 13 Specify the IP address of the default router for a DHCP client.

Example:

```
Device(dhcp-config)# default-router ip-address
```

Example:

```
Device(dhcp-config)# default-router 192.168.32.1
```

Step 14 Exit DHCP configuration mode.

Example:

```
Device(dhcp-config)# exit
```

Step 15 Configure a WLAN policy profile and enter wireless policy configuration mode.

Example:

```
Device(config)# wireless profile policy profile-policy
```

Example:

```
Device(config)# wireless profile policy default-policy-profile
```

Step 16 Configure central association for locally switched clients.

Example:

```
Device(config-wireless-policy)# central association
```

Step 17 Configure local switching.

Example:

```
Device(config-wireless-policy)# central switching
```

Step 18 Add a description for the policy profile.

Example:

```
Device(config-wireless-policy)# description "policy-profile-name"
```

Example:

```
Device(config-wireless-policy)# description "default policy profile"
```

Step 19 Enable DHCP Option 82 for the wireless clients.

Example:

```
Device(config-wireless-policy)# ipv4 dhcp opt82
```

Step 20 Enable ASCII on DHCP Option 82.

Example:

```
Device(config-wireless-policy)# ipv4 dhcp opt82 ascii
```

Step 21 Enable VLAN ID.

Example:

```
Device(config-wireless-policy)# ipv4 dhcp opt82 format vlan-id
```

Example:

```
Device(config-wireless-policy)# ipv4 dhcp opt82 format vlan32
```

Step 22 Support the addition of Cisco 2-byte Remote ID (RID) for DHCP Option 82.

Example:

```
Device(config-wireless-policy)# ipv4 dhcp opt82 rid
```

Step 23 Configure the WLAN's IPv4 DHCP server.

Example:

```
Device(config-wireless-policy)# ipv4 dhcp server ip-address
```

Example:

```
Device(config-wireless-policy)# ipv4 dhcp server 10.10.10.1
```

Step 24 Assign the profile policy to the VLAN.

Example:

```
Device(config-wireless-policy)# vlan vlan-id
```

Example:

```
Device(config-wireless-policy)# vlan 32
```

Step 25 Enable the wireless profile policy.

Example:

```
Device(config-wireless-policy)# no shutdown
```

The internal DHCP server is now configured and operational within the wireless policy profile, ready to provide IP addresses and network configuration to wireless clients.

Configure the internal DHCP server globally (GUI)

Configure a DHCP pool to enable automatic IP address assignment for network devices through the internal DHCP server.

Use this procedure when you need to set up centralized IP address management for your network infrastructure using the GUI interface.

Procedure

Step 1 Choose **Administration > DHCP Pools > Pools**.

Step 2 Click **Add**.

The **Create DHCP Pool** window is displayed.

Step 3 Enter the **DHCP Pool Name**, **Network**, **Starting IP**, and **Ending IP**.

Step 4 From the **IP Type**, **Subnet Mask**, and **Lease** drop-down lists, choose a value.

Step 5 Click the **Reserved Only** toggle button.

Step 6 Click **Apply to Device**.

The DHCP pool is created and applied to the device, enabling automatic IP address assignment within the specified range.

Configure the internal DHCP server globally (CLI)

Enable centralized DHCP services for wireless clients by configuring the internal DHCP server with appropriate network pools and policies.

The internal DHCP server configuration allows the wireless controller to provide IP addresses to wireless clients directly, eliminating the need for external DHCP servers in certain network deployments.

Procedure

Step 1 Enter global configuration mode.

Example:

```
Device# configure terminal
```

Step 2 Create a loopback interface and enter interface configuration mode.

Example:

```
Device(config)# interface loopback interface-number
```

Example:

```
Device(config)# interface Loopback0
```

Step 3 Configure the IP address for the interface.

Example:

```
Device(config-if)# ip address ip-address subnet-mask
```

Example:

```
Device(config-if)# ip address 10.10.10.1 255.255.255.255
```

Step 4 Exit interface configuration mode.

Example:

```
Device(config-if)# exit
```

Step 5 Configure the VLAN ID.

Example:

```
Device(config)# interface vlan vlan-id
```

Example:

```
Device(config)# interface vlan 32
```

Step 6 Configure the IP address for the interface.

Example:

```
Device(config-if)# ip address ip-address subnet-mask
```

Example:

```
Device(config-if)# ip address 192.168.32.100 255.255.255.0
```

Step 7 Disable the Maintenance Operation Protocol (MOP) for an interface.

Example:

```
Device(config-if)# no mop enabled
```

Step 8 Disable the task of sending the MOP periodic system ID messages.

Example:

```
Device(config-if)# no mop sysid
```

Step 9 Exit the interface configuration mode.

Example:

```
Device(config-if)# exit
```

Step 10 Specify the target DHCP server parameters.

Example:

```
Device(config)# ip dhcp-server ip-address
```

Example:

```
Device(config)# ip dhcp-server 10.10.10.1
```

Step 11 Specify the IP address that the DHCP server should not assign to DHCP clients.

Example:

```
Device(config)# ip dhcp excluded-address ip-address
```

Example:

```
Device(config)# ip dhcp excluded-address 192.168.32.100
```

Step 12 Configure the DHCP pool address.

Example:

```
Device(config)# ip dhcp pool pool-name
```

Example:

```
Device(config)# ip dhcp pool pool-vlan32
```

Step 13 Specify the network number in dotted-decimal notation along with the mask address.

Example:

```
Device(dhcp-config)# network network-address subnet-mask
```

Example:

```
Device(dhcp-config)# network 192.168.32.0 255.255.255.0
```

Step 14 Specify the IP address of the default router for a DHCP client.

Example:

```
Device(dhcp-config)# default-router ip-address
```

Example:

```
Device(dhcp-config)# default-router 192.168.32.1
```

Step 15 Exit DHCP configuration mode.

Example:

```
Device(dhcp-config)# exit
```

Step 16 Configure a WLAN policy profile and enter wireless policy configuration mode.

Example:

```
Device(config)# wireless profile policy profile-policy
```

Example:

```
Device(config)# wireless profile policy default-policy-profile
```

Step 17 Configure central association for locally switched clients.

Example:

```
Device(config-wireless-policy)# central association
```

Step 18 Configure central DHCP for locally switched clients.

Example:

```
Device(config-wireless-policy)# central dhcp
```

Step 19 Configure local switching.

Example:

```
Device(config-wireless-policy)# central switching
```

Step 20 Add a description for the policy profile.

Example:

```
Device(config-wireless-policy)# description policy-profile-description
```

Example:

```
Device(config-wireless-policy)# description "default policy profile"
```

Step 21 Assign the profile policy to the VLAN.

Example:

```
Device(config-wireless-policy)# vlan vlan-id
```

Example:

```
Device(config-wireless-policy)# vlan 32
```

Step 22 Enable the profile policy.

Example:

```
Device(config-wireless-policy)# no shutdown
```

The internal DHCP server is now configured globally with the specified pool, exclusions, and wireless policy profile settings to serve DHCP requests from wireless clients.

Verify internal DHCP configuration

Verify internal DHCP configuration using specific show commands to check client binding, DHCP relay statistics for wireless clients, and DHCP packet punt statistics.

Client binding verification

To verify client binding, use this command:

```
Device# show ip dhcp binding
```

```
Bindings from all pools not associated with VRF:
IP address      Client-ID/      Lease expiration      Type      State
Interface
                Hardware address/
                User name
192.168.32.3    0130.b49e.491a.53    Mar 23 2018 06:42 PM    Automatic    Active
Loopback0
```

DHCP relay statistics verification

To verify the DHCP relay statistics for a wireless client, use this command:

```
Device# show wireless dhcp relay statistics
```

```
DHCP Relay Statistics
-----

DHCP Server IP : 10.10.10.1

Message          Count
-----
DHCPDISCOVER    : 1
BOOTP FORWARD   : 137
BOOTP REPLY     : 0
DHCPOFFER       : 0
DHCPPREQUEST    : 54
DHCPACK         : 0
DHCPNAK         : 0
DHCPDECLINE     : 0
DHCPRELEASE     : 0
DHCPINFORM      : 82

Tx/Rx Time :
-----
LastTxTime : 18:42:18
LastRxTime : 00:00:00

Drop Counter :
-----
TxDropCount : 0
```

DHCP packet punt statistics verification

To verify the DHCP packet punt statistics in CPP, use this command:

```
Device# show platform hardware chassis active qfp feature wireless punt statistics
```

```
CPP Wireless Punt stats:
```

App Tag	Packet Count
-----	-----
CAPWAP_PKT_TYPE_DOT11_PROBE_REQ	14442
CAPWAP_PKT_TYPE_DOT11_MGMT	50
CAPWAP_PKT_TYPE_DOT11_IAPP	9447
CAPWAP_PKT_TYPE_DOT11_RFID	0
CAPWAP_PKT_TYPE_DOT11_RRM	0
CAPWAP_PKT_TYPE_DOT11_DOT1X	0
CAPWAP_PKT_TYPE_CAPWAP_KEEPALIVE	2191
CAPWAP_PKT_TYPE_MOBILITY_KEEPALIVE	0
CAPWAP_PKT_TYPE_CAPWAP_CNTRL	7034
CAPWAP_PKT_TYPE_CAPWAP_DATA	0
CAPWAP_PKT_TYPE_MOBILITY_CNTRL	0
WLS_SMD_WEBAUTH	0
SISF_PKT_TYPE_ARP	5292
SISF_PKT_TYPE_DHCP	140
SISF_PKT_TYPE_DHCP6	1213
SISF_PKT_TYPE_IPV6_ND	350
SISF_PKT_TYPE_DATA_GLEAN	44
SISF_PKT_TYPE_DATA_GLEAN_V6	51
SISF_PKT_TYPE_DHCP_RELAY	122
CAPWAP_PKT_TYPE_CAPWAP_RESERVED	0

