

Access Points Modes

- Information about Sniffer, on page 2
- Information About XOR Radio Role Sniffer Support, on page 2
- Feature History for Sniffer Mode, on page 3
- Prerequisites for Sniffer, on page 3
- Restrictions on Sniffer, on page 3
- How to Configure Sniffer, on page 4
- Verifying Sniffer Configurations, on page 7
- Verifying XOR Radio Role Sniffer Configuration, on page 7
- Examples for Sniffer Configurations and Monitoring, on page 8
- Introduction to Monitor Mode, on page 9
- Enable Monitor Mode (GUI), on page 9
- Enable Monitor Mode (CLI), on page 10
- Feature History for Management Mode Migration in Cisco Catalyst Wireless 916X Access Points, on page 10
- Information About Management Mode Migration in Cisco Catalyst Wireless 916X Series Access Points, on page 11
- Regulatory Domain, on page 11
- Configuring Management Mode Migration (GUI), on page 15
- Configuring the AP Management Mode (CLI), on page 16
- Verifying the Management Mode Migration Details, on page 17
- Information About FlexConnect, on page 17
- Guidelines and Restrictions for FlexConnect, on page 21
- Configuring a Site Tag, on page 25
- Configuring a Policy Tag (CLI), on page 26
- Attaching a Policy Tag and a Site Tag to an Access Point (GUI), on page 27
- Attaching Policy Tag and Site Tag to an AP (CLI), on page 27
- Linking an ACL Policy to the Defined ACL (GUI), on page 28
- Applying ACLs on FlexConnect, on page 29
- Configuring FlexConnect, on page 30
- Flex AP Local Authentication (GUI), on page 36
- Flex AP Local Authentication (CLI), on page 37
- Flex AP Local Authentication with External Radius Server, on page 39
- Configuration Example: FlexConnect with Central and Local Authentication, on page 42
- NAT-PAT for FlexConnect, on page 42

- Split Tunneling for FlexConnect, on page 46
- VLAN-based Central Switching for FlexConnect, on page 53
- OfficeExtend Access Points for FlexConnect, on page 55
- Proxy ARP, on page 60
- Overlapping Client IP Address in Flex Deployment, on page 61
- Information About FlexConnect High Scale Mode, on page 64
- Flex Resilient with Flex and Bridge Mode Access Points, on page 65
- Feature History for OEAP Link Test, on page 70
- Information About OEAP Link Test, on page 71
- Configuring OEAP Link Test (CLI), on page 71
- Performing OEAP Link Test (GUI), on page 72
- Verifying OEAP Link Test, on page 72
- Feature History for Cisco OEAP Split Tunneling, on page 72
- Information About Cisco OEAP Split Tunneling, on page 73
- Prerequisites for Cisco OEAP Split Tunneling, on page 74
- Restrictions for Cisco OEAP Split Tunneling, on page 74
- Use Cases for Cisco OEAP Split Tunneling, on page 75
- Workflow to Configure Cisco OEAP Split Tunneling, on page 75
- Create an IP Address ACL (CLI), on page 75
- Create a URL ACL (CLI), on page 76
- Add an ACL to a FlexConnect Profile, on page 77
- Enable Split Tunnelling in a Policy Profile, on page 78
- Verifying the Cisco OEAP Split Tunnel Configuration, on page 78
- AP Survey Mode, on page 79

Information about Sniffer

The controller enables you to configure an access point as a network "sniffer", which captures and forwards all the packets on a particular channel to a remote machine that runs packet analyzer software. These packets contain information on time stamps, signal strength, packet sizes, and so on.

Sniffers allow you to monitor and record network activity, and detect problems.

The packet analyzer machine configured receives the 802.11 traffic encapsulated using the Airopeek protocol from the controller management IP address with source port UDP/5555 and destination UDP/5000.

You must use **Clear** in AP mode to return the AP back to client-serving mode, for example the local mode or FlexConnect mode depending on the remote site tag configuration.



Note

It is recommended not to use the AP command to change the CAPWAP mode.

Information About XOR Radio Role Sniffer Support

The XOR radio in APs like Cisco 2800, 3800, 4800, and the 9100 series AP models support sniffer role in single radio interface.

The XOR radio offers the ability to operate as a single radio interface in many modes. This eliminates the need to place the entire AP into a mode. When this concept is applied to a single radio level, it is termed as role.

From this release onwards, Sniffer is the new supported role along with the Client Serving and Monitor roles.



Note

The radio role is supported in Local and FlexConnect modes.

Feature History for Sniffer Mode

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Table 1: Feature History for Sniffer Mode

Release	Feature	Feature Information
Cisco IOS XE 17.8.1	XOR Radio Role Sniffer Support on the Access Point	The XOR radio in APs like Cisco 2800, 3800, 4800, and the 9100 series AP models support sniffer role in single radio interface.

Prerequisites for Sniffer

To perform sniffing, you need the following hardware and software:

- A dedicated access point—An access point configured as a sniffer cannot simultaneously provide wireless
 access service on the network. To avoid disrupting coverage, use an access point that is not part of your
 existing wireless network.
- A remote monitoring device—A computer capable of running the analyzer software.
- Software and supporting files, plug-ins, or adapters—Your analyzer software may require specialized files before you can successfully enable.

Restrictions on Sniffer

- Supported third-party network analyzer software applications are as follows:
 - · Wildpackets Omnipeek or Airopeek
 - AirMagnet Enterprise Analyzer
 - · Wireshark

- The latest version of Wireshark can decode the packets by going to the Analyze mode. Select **decode** as, and switch UDP5555 to decode as PEEKREMOTE..
- Sniffer mode is not supported when the controller L3 interface is the Wireless Management Interface (WMI).
- When an AP or a radio operates in the sniffer mode, irrespective of its current channel width settings, the AP sniffs or captures only on the primary channel.



Note

As both Cisco Catalyst 9166I and 9166D APs have XOR radios, a Board Device File (BDF) has to be loaded to initialize radio 2 for the radios of these APs to work as expected. While the BDF is being loaded and for the file to be loaded correctly, the firmware has to be made non-operational and radios have to be reset. This operation of radio reset due to firmware being non-operational for the purposes of loading the BDFs is deliberate and is an expected behavior. This operation can be observed in both the controller and Cisco Catalyst Center. We recommend that you ignore the core dump that is generated due to this deliberate operation.

How to Configure Sniffer

Configuring an Access Point as Sniffer (GUI)

Procedure

- **Step 1** Choose Configuration > Wireless > Access Points.
- **Step 2** On the **General** tab, update the name of the AP. The AP name can be ASCII characters from 33 to 126, without leading and trailing spaces.
- **Step 3** Specify the physical location where the AP is present.
- **Step 4** Choose the **Admin Status** as **Enabled** if the AP is to be in enabled state.
- **Step 5** Choose the mode for the AP as *Sniffer*.
- Step 6 In the Tags section, specify the appropriate policy, site, and RF tags that you created on the Configuration > Tags & Profiles > Tags page.

Note If the AP is in sniffer mode, you do not want to assign any tag.

- Step 7 Click Update & Apply to Device.
- **Step 8** Choose the mode for the AP as **Clear** to return the AP back to the client-serving mode depending on the remote site tag configuration.

All the radios will be set to manual mode when you change the AP mode to Sniffer mode. Simultaneously, a warning message will be displayed informing you to convert the radio submode back to AUTO, if required, while changing the mode from Sniffer to other.

Configuring an Access Point as Sniffer (CLI)

Procedure

	Command or Action	Purpose	
Step 1	enable	Enables privileged EXEC mode.	
	Example:		
	Device> enable		
Step 2	ap name ap-name mode sniffer	Configures the access point as a sniffer.	
	Example:	Where,	
	Device# ap name access1 mode sniffer	<i>ap-name</i> is the name of the Cisco lightweight access point.	
		Use the no form of this command to disable the access point as a sniffer.	

Enabling or Disabling Sniffing on the Access Point (GUI)

Before you begin

Change the access point AP mode to sniffer mode.

Procedure

- $\textbf{Step 1} \qquad \textbf{Choose Configuration} > \textbf{Wireless} > \textbf{Access Points}.$
- **Step 2** On the **Access Points** page, click the AP name from the 6 GHz, 5 GHz, or 2.4 GHz list.
- **Step 3** In the **Role Assignment** section, select the **Assignment Method** as *Sniffer*.
- Step 4 In the Sniffer Channel Assignment section, check the Sniffer Channel Assignment checkbox to enable.

Uncheck the checkbox to disable sniffing on the access point.

- **Step 5** From the **Sniff Channel** drop-down list, select the channel.
 - Note By default, the **Snif Channel** is set to 36 for the **5 GHz** and 1 for the **2.4 GHz**.
- **Step 6** Enter the IP address in the **Sniffer IP** field.

To validate the IP address, click **Update & Apply to Device**. If the IP address is valid, the **Sniffer IP Status** displays *Valid*.

Step 7 Click Update & Apply to Device.

Enabling or Disabling Sniffing on the Access Point (CLI)

Procedure

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example: Device> enable	
Step 2	ap name ap-name sniff {dot11 6Ghz slot 3 channel server-ip-address dot11a channel server-ip-address dot11b channel server-ip-address dual-band channel server-ip-address} Example: Device# ap name access1 sniff dot11b 1 9.9.48.5	Enables sniffing on the access point. • channel is the valid channel to be sniffed. For 802.11a, the range is 36 to 165. For 802.11b, the range is 1 to 14. For dot11 6Ghz, the range is between 1 and 233. • server-ip-address is the IP address of the remote machine running Omnipeek, Airopeek, AirMagnet, or Wireshark software.
Step 3	ap name ap-name no sniff {dot116Ghz dot11a dot11b dual-band} Example: Device#ap name access1 no sniff dot116ghz	Disables sniffing on the access point.

Configuring XOR Radio Role Sniffer Support on the Access Point (CLI)

	Command or Action	Purpose		
Step 1	enable	Enables privileged EXEC mode. Enter your password, if prompted.		
	Example:	password, if prompted.		
	Device> enable			
Step 2	ap name ap-name dot11 {dual-band} shutdown	Shutdown the XOR radio.		
	Example:			
	Device# ap name AP687D.B45C.189C dot11 dual-band shutdown			
Step 3	ap name ap-name dot11 {dual-band} role manual {client-serving}	Converts the XOR radio role to manual.		
	Example:			
	Device# ap name ap-name dot11 dual-band role manual client-serving			

	Command or Action	Purpose		
Step 4	ap name ap-name dot11 {dual-band} band {5ghz 24ghz}	Configures XOR radio to manually operate a specific band.		
	Example:			
	Device# ap name AP687D.B45C.189C dot11 dual-band band 5ghz			
Step 5	ap name ap-name dot11 {dual-band} radio role manual sniffer channel channel-number ip ip-address	Enables XOR radio role Sniffer support on AP from the controller.		
	Example:	Where,		
	Device# ap name AP687D.B45C.189C dot11 dual-band radio role manual sniffer channel 100 ip 9.4.197.85	 <i>ap-name</i> is the name of the Cisco lightweight access point. <i>channel-number</i> is the channel number. 		
Step 6	ap name ap-name no dot11 {dual-band} shutdown	Unshuts the XOR radio.		
	Example:			
	Device# ap name AP687D.B45C.189C no dot11 dual-band shutdown			
Step 7	end	Returns to privileged EXEC mode.		
	Example: Device# end	When configuring the radio to work as a Sniffer in the 5-GHz band, you will need to change the band of the radio manually as in Step 4.		

Verifying Sniffer Configurations

Table 2: Commands for verifying sniffer configurations

Commands	Description
show ap name ap-name config dot11 {24ghz 5ghz 6ghz dual-band}	Displays the sniffing details.
show ap name ap-name config slot slot-ID	Displays the sniffing configuration details. slot-ID ranges from 0 to 3. All access points have slot 0 and 1.

Verifying XOR Radio Role Sniffer Configuration

To verify the XOR radio role sniffer configuration for a given AP, use the following command:

```
Device# show ap name AP687D.B45C.189C config slot 0
                                               : Enabled
Sniff Channel
                                               : 6
Sniffer IP
                                               : 9.4.197.85
Sniffer IP Status
                                               : Valid
ATF Mode
                                               : Disable
ATE Optimization
                                              : N/A
AP Submode
                                             : Not Configured
Remote AP Debug
                                             : Disabled
Logging Trap Severity Level
                                              : information
Software Version
                                               : 17.9.0.18
                                              : 1.1.2.4
Boot Version
Mini IOS Version
                                              : 0.0.0.0
Stats Reporting Period
                                              : 60
                                              : 120
primary discovery timer
LED State
LED Flash State
                                               : Enabled
LED Flash Timer
                                              : 0
PoE Pre-Standard Switch
                                             : Disabled
PoE Power Injector MAC Address
                                             : Disabled
Power Type/Mode
                                              : PoE/Full Power
Number of Slots
AP Model
                                              : C9136T-B
                                              : 17.9.0.18
IOS Version
Reset Button
                                              : Disabled
AP Serial Number

    FOC25322JJZ

                                              : Manufacturer Installed Certificate
AP Certificate Type
AP Certificate Expiry-time
                                               : 08/09/2099 20:58:26
AP Certificate issuer common-name
                                             : High Assurance SUDI CA
AP Certificate Policy
                                              : Default
AP CAPWAP-DTLS LSC Status
   Certificate status : Not Available
AP 802.1x LSC Status
   Certificate status : Not Available
AP User Name
                                               : admin
AP 802.1X User Mode
                                              : Global
AP 802.1X User Name
                                              : Not Configured
                                               : 255.255.255.255
Cisco AP System Logging Host
AP Up Time
                                               : 4 hours 20 minutes 55 seconds
AP CAPWAP Up Time
                                              : 4 hours 16 minutes 17 seconds
Join Date and Time
                                              : 01/19/2022 03:06:12
Attributes for Slot 0
                                              : 802.11ax - 2.4 GHz
 Radio Type
 Radio Mode
                                              : Sniffer
 Radio Role
                                              : Sniffer
 Maximum client allowed
                                              : 400
 Radio Role Op
                                              : Manual
 Radio SubType
 Administrative State
                                               : Enabled
  Operation State
```

Examples for Sniffer Configurations and Monitoring

This example shows how to configure an access point as Sniffer:

```
Device# ap name access1 mode sniffer
```

This example shows how to enable sniffing on the access point:

```
Device# ap name access1 sniff dot11b 1 9.9.48.5
```

This example shows how to disable sniffing on the access point:

```
Device# ap name access1 no sniff dot11b
```

This example shows how to display the sniffing configuration details:

```
Device# show ap name access1 config dot11 24ghz
Device# show ap name access1 config slot 0
```

Introduction to Monitor Mode

To optimize the monitoring and location calculation of RFID tags, you can enable tracking optimization on up to four channels within the 2.4-GHz band of an 802.11b/g/x access point radio. This feature allows you to scan only the channels on which tags are usually programmed to operate (such as channels 1, 6, and 11).



Note

You can move an AP to a particular mode (sensor mode to local mode or flex mode) using the site tag with the corresponding mode. If the AP is not tagged to any mode, it will fall back to the mode specified in the default site tag.

You must use clear in AP mode to return the AP back to client-serving mode, for example the local mode or FlexConnect mode depending on the remote site tag configuration.

Enable Monitor Mode (GUI)

- **Step 1** Choose Configuration > Wireless > Access Points.
- **Step 2** In the **Access Points** page, expand the **All Access Points** section and click the name of the AP to edit.
- **Step 3** In the **Edit AP** page, click the **General** tab and from the **AP Mode** drop-down list, choose **Monitor**.
- Step 4 Click Update & Apply to Device.
- **Step 5** Choose the mode for the AP as **clear** to return the AP back to the client-serving mode depending on the remote site tag configuration.

Enable Monitor Mode (CLI)

Procedure

	Command or Action	Purpose
Step 1	ap name ap-name mode monitor Example: Device# ap name 3602a mode monitor	Enables monitor mode for the access point.
Step 2	<pre>ap name ap-name monitor tracking-opt Example: Device# ap name 3602a monitor tracking-opt</pre>	Configures the access point to scan only the Dynamic Channel Assignment (DCA) channels supported by its country of operation.
Step 3	ap name ap-name monitor-mode dot11b fast-channel [first-channel second-channel third-channel fourth-channel] Example: Device# ap name 3602a monitor dot11b 1 2 3 4 ap name ap-name dot11 6ghz slot 3 radio role manual monitor Example:	Configures the 802.11 6-Ghz radio role manual
	Example: Device# ap name cisco-ap dot11 6ghz slot 3 radio role manual monitor	monitor
Step 5	show ap dot11 {24ghz 5ghz 6ghz} channel Example: Device# show ap dot11 5ghz channel	Shows configuration and statistics of 802.11a or 802.11b or 6-GHz channel assignment.
Step 6	show ap dot11 6ghz summary Example: Device# show ap dot11 6ghz summary	Shows configuration and statistics summary of 6 the GHz band Cisco APs.

Feature History for Management Mode Migration in Cisco Catalyst Wireless 916X Access Points

This table provides release and related information for the feature explained in this module.

This feature is also available in all the releases subsequent to the one in which they are introduced in, unless noted otherwise.

Table 3: Feature History for Management Mode Migration in Cisco Wireless Catalyst Wireless 916X Series Access Points

Release	Feature	Feature Information	
Cisco IOS XE Cupertino 17.9.1	Management Mode Migration in Cisco Catalyst Wireless 916X Series Access Points	This feature allows you to convert the AP mode between DNA Management mode and Meraki Management mode, depending on your requirements. Note The document explains the conversion from DNA Management mode to Meraki Management mode and not vice versa.	

Information About Management Mode Migration in Cisco Catalyst Wireless 916X Series Access Points

Cisco Catalyst Wireless 916x APs (CW9164I-x and CW9166I-x) support both cloud and controller architecture. You can migrate between cloud and controller deployments, depending on your requirements. The CW916x APs join and operate either in the DNA Management mode or in the Meraki Management mode. You can configure the management mode migration with the help of CLI commands in the privileged EXEC mode, at the AP level, and from the controller GUI.

CW916x APs support dual-band slot 3 radios, which in turn support both 6-GHz and 5-GHz bands.



Note

The section explains the migration from DNA Management mode to the Meraki Management mode and not vice versa.

Regulatory Domain

For regulatory domain support, Cisco Catalyst 916x (CW916x) supports Rest of the World (RoW) and a few other fixed domains as shown here:

- -B
- -E
- -A
- -Z
- -Q
- -I
- -R

During the AP join flow, the regulatory domain details and the details of the country that is configured is passed on to the controller from the AP. The controller assigns or validates the right country of operation.


After the country is validated based on the decision tree, the controller informs the AP about which country the AP should be configured with.

The following are the scenarios that determine the country that an AP should be configured with:

AP Configured with Non-RoW Regulatory Domain

Case 1: AP does not report a country as part of the join procedure.

AP Does Not Report a Country as Part of the Join Procedure



In the non-RoW regulatory domain, when an AP does not report a country as part of the join procedure, the following takes place:

- AP profile has a country configured.
 - If the country configured in the AP profile is present in the global country list, and is valid as per the AP regulatory domain, the country that is configured in the AP profile is assigned to the AP. Radios become operational as per the country or regulatory domain support.
 - If the country configured the AP profile is not present in the global country list, and is not valid as per the AP regulatory domain, the AP is disconnected.
- AP profile does not have a country configured. Find a valid country from the global country list (the first match), as per the AP regulatory domain.
 - If the country is found, the country is assigned to the AP and the radios become operational as per the country or regulatory domain support.
 - If the country is not found, the AP is disconnected.

Case 2: AP reports a country as part of the join procedure.

Country is presen in the global Radios are operation as per regulatory domain support Valid as per AP Regulatory Domain Country assigned to the AP Country is configured in the AP profile Check if country AP retains Not Valid as per AP present in the global country list reported is found previous country in the global misconfiguration flag is s the AP Country is present in the global Valid as per AP Regulatory Domain adios are operationa Country assigned to Country is not configured in the AP profile Country assigned to the AP Search for first country present in the global country list match from the globa

AP Reports Country as Part of the Join Procedure


In the non-RoW regulatory domain, when an AP reports a country as part of the join procedure, the following takes place:

- The AP profile has a country configured.
 - If the country configured in the AP profile is present in the global country list, and it is valid as per the AP regulatory domain, the country that is configured in the AP profile is assigned to the AP. Radios become operational as per the country or regulatory domain support.
 - If the country configured in the AP profile is not present in the global country list, and is not valid as per the AP regulatory domain, check the global country list to confirm if the country is present in the list. If the country is present in the global list, the AP retains the previous country configuration and the radios are not operational with the country misconfiguration flag set. If the country is not located in the global list, the AP is disconnected.
- The AP profile does not have a country configured.
 - If the country reported by the AP is found in the global country list, and is valid as per the AP regulatory domain, the country is assigned to the AP and the radios become operational as per the country or regulatory domain support.
 - If the country is not present in the list, search for the first country match from the global list. If the country is found, the country is assigned to the AP and the radios become operational. If the country is not found, the AP is disconnected.

AP Configured with RoW Regulatory Domain

Case 1: The AP does not report a country as part of the join procedure.

AP Does Not Report a Country as Part of the Join Procedure



Radios operationally down.

Country misconfiguration

flag is set.

In the RoW regulatory domain, when an AP does not report a country as part of the join procedure, the following takes place:

• The AP profile has a country configured.

No country is

assigned to the AP

Country is not


configured in the AP

profile

- If the country configured in the AP profile is present in the global country list, and is valid as per the AP regulatory domain, country that is configured in the AP profile is assigned to the AP. Radios become operational as per the country or regulatory domain support.
- If the country configured in the AP profile is not present in the global country list, and is not valid as per the AP regulatory domain, country is not assigned to the AP and radios are not operational, and the country misconfiguration flag is set.
- If the AP profile does not have a country configured, the country is not assigned to the AP and radios are not operational, and the country misconfiguration flag is set.

Case 2: The AP reports a country as part of the join procedure.

AP Reports a Country as Part of the Join Procedure



In the RoW regulatory domain, when an AP reports a country as part of the join procedure, the following takes place:

• The AP profile has a country configured.

- If the country configured in the AP profile is present in the global country list, and it is valid as per the AP regulatory domain, the country that is configured in the AP profile is assigned to the AP. Radios become operational as per the country or regulatory domain support.
- If the country configured in the AP profile is not present in the global country list, and is not valid as per the AP regulatory domain, the AP retains the previous country configuration and the radios are not operational with the country misconfiguration flag set.
- The AP retains the previous country configuration and the radios are not operational with the country misconfiguration flag set.

Configuring Management Mode Migration (GUI)

Before you begin

The country code must be configured on the AP profile. To configure the country code, navigate to **Configuration** > **Tags & Profiles** > **AP Join** page. Click an AP profile to edit. In the **General** tab, select the country code from the drop-down list.

Procedure

- Step 1 Choose Configuration > Wireless > Migrate to Meraki Management Mode.
- **Step 2** Select the required APs by clicking on the check box(es), from the displayed APs.

The **Migrate to Meraki Management Mode** button is enabled.

- Step 3 Click Migrate to Meraki Management Mode button to perform a validation check on the selected APs. If the validation check is successful, the Next button is enabled.
- **Step 4** Click **Next** to start the process.
- **Step 5** On the **Confirm Management Mode Migration** window, do the following:
 - a. Select the Agree and continue check box.
 - **b.** Click **Yes** to confirm.

The **Management Mode Migration Successful** section displays the APs that were migrated to the Meraki management mode. The **Management Mode Migration Failed** section displays the APs that were retained in DNA management mode.

Step 6 Click **Restart Workflow** to restart the workflow for APs that did not migrate from DNA management mode to Meraki management mode.

Exporting Meraki Management Mode-Migrated APs (GUI)

You can export the details about the Meraki management mode-migrated APs either from the **Change to Meraki Persona** tab after the workflow is completed or from the **Previously changed APs** tab.

Procedure

	Command or Action	Purpose)
Step 1	Choose Configuration > Wireless > Migrate to Meraki Management Mode.		
Step 2	Click the Export button to export the list of APs.		
Step 3	Select whether you want to export only the current page or all pages. Click Yes to continue.		
Step 4	On the Export window, select the export method. The available options are:	• JS	rial Number ON port to Meraki Dashboard We recommend the Export to Meraki Dashboard option as you can directly export the migrated APs information into the Meraki Dashboard.
Step 5	Click Copy to copy the migrated APs. Click Download and save the file location.		

Configuring the AP Management Mode (CLI)

Before you begin

• Ensure that the AP is Meraki-capable to run any of the EXEC commands. To view the list of Meraki-capable APs, use the **show ap management-mode meraki capability summary** command.



Note

If the country code is misconfigured, the change of management mode will not be allowed for any of the EXEC commands, except the **force** command.

If the regulatory domain is misconfigured for any slot, the change of management mode is not allowed for any of the EXEC commands, except the **force** command.

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode. Enter the
	Example:	password, if prompted.
	Device> enable	

	Command or Action	Purpose
Step 2	ap name Cisco-AP-name management-mode meraki [force] [noprompt] Example: Device# ap name Cisco-AP-name management-mode meraki Device# ap name Cisco-AP-name management-mode meraki force Device# ap name Cisco-AP-name management-mode meraki noprompt Device# ap name Cisco-AP-name management-mode meraki force noprompt	Changes the AP management mode to Meraki. Here, force skips the validations at the controller and attempts Meraki management mode change at the AP. noprompt skips the user prompt for attempting AP management mode change.
Step 3	(Optional) clear ap meraki stats Example: Device# clear ap meraki stats	Clears the Meraki AP-related data.

Verifying the Management Mode Migration Details

To view the summary of the Meraki-capable AP information, run the following command:

Device# show	v ap mana	gement-mode meraki ca	apability summary		
AP Name		AP Model	Radio MAC	MAC Address	AP Serial
Number	Meraki	Serial Number			
APXXXD.BXXX	.1XXX	CW9162I	6XXd.bXXe.eXX0	6XXd.bXXe.eXX0	FOCXXXXXB90

To view the failure summary of the AP along with the migration attempt timestamp, run the following command:

Device#	# show ap mar	nagement-mod	de merak	i failure summa	ry	
AP Name	9	AP Model		Radio MAC	MAC Address	Conversion Attempt
	AP Serial 1	Number	Meraki	Serial Number	Reason Code	
APXXXD.	.BXXC.1	CW9162I		6XXd.bXXe.eXX0	6XXd.bXXe.eXX0	03/03/2022 17:17:42
IST	FOCXXXXXB90		FOCXXXX	XB90	Regulatory domain	not set

To view the successful Meraki management mode migration attempts of all the APs, run the following command:


Device# show ap	management-mode meraki	change summary		
AP Name	AP Model	Radio MAC	MAC Address	Conversion
Timestamp	AP Serial Number	Meraki Serial Numbe	er	
APXXXX.3XXX.EXX	X CW9166I-B	1XXX.2XXX.1100	ccXX.3XXX.eXX0	05/02/2022
07:48:56 CST KWC2XXXXX5G		Q5XX-4XXX-K7XX		

Information About FlexConnect

FlexConnect is a wireless solution for branch office and remote office deployments. It enables customers to configure and control access points (AP) in a branch or remote office from the corporate office through a wide area network (WAN) link without deploying a controller in each office. The FlexConnect access points

can also switch client data traffic locally and perform client authentication locally when their connection to the controller is lost. When they are connected to the controller, they can also send traffic back to the controller. FlexConnect access points support multiple SSIDs. In the connected mode, the FlexConnect access point can also perform local authentication.

Figure 1: FlexConnect Deployment



The controller software has a more robust fault tolerance methodology to FlexConnect access points. In previous releases, whenever a FlexConnect access point disassociates from a controller, it moves to the standalone mode. The clients that are centrally switched are disassociated. However, the FlexConnect access point continues to serve locally switched clients. When the FlexConnect access point rejoins the controller (or a standby controller), all the clients are disconnected and are authenticated again. This functionality has been enhanced and the connection between the clients and the FlexConnect access points are maintained intact and the clients experience seamless connectivity. When both the access point and the controller have the same configuration, the connection between the clients and APs is maintained.

After the client connection is established, the controller does not restore the original attributes of the client. The client username, current rate and supported rates, and listen interval values are reset to the default or new configured values only after the session timer expires.

The controller can send multicast packets in the form of unicast or multicast packets to an access point. In FlexConnect mode, an access point can receive only multicast packets.

In Cisco Catalyst 9800 Series Wireless Controller, you can define a flex connect site. A flex connect site can have a flex connect profile associate with it. You can have a maximum of 100 access points for each flex connect site.

FlexConnect access points support a 1-1 network address translation (NAT) configuration. They also support port address translation (PAT) for all features except true multicast. Multicast is supported across NAT boundaries when configured using the Unicast option. FlexConnect access points also support a many-to-one NAT or PAT boundary, except when you want true multicast to operate for all centrally switched WLANs.

Workgroup bridges and Universal Workgroup bridges are supported on FlexConnect access points for locally switched clients.

FlexConnect supports IPv6 clients by bridging the traffic to local VLAN, similar to an IPv4 operation. FlexConnect supports Client Mobility for a group of up to 100 access points.

An access point does not have to reboot when moving from local mode to FlexConnect mode and vice-versa.

FlexConnect Authentication

When an access point boots up, it looks for a controller. If it finds one, it joins the controller, downloads the latest software image and configuration from the controller, and initializes the radio. It saves the downloaded configuration in nonvolatile memory for use in standalone mode.



Note

Once the access point is rebooted after downloading the latest controller software, it must be converted to the FlexConnect mode.



Note

802.1X is not supported on the AUX port for Cisco Aironet 2700 series APs.

A FlexConnect access point can learn the controller IP address in one of these ways:

 If the access point has been assigned an IP address from a DHCP server, it can discover a controller through the regular CAPWAP or LWAPP discovery process.



Note

OTAP is not supported.

- If the access point has been assigned a static IP address, it can discover a controller through any of the discovery process methods except DHCP option 43. If the access point cannot discover a controller through Layer 3 broadcast, we recommend DNS resolution. With DNS, any access point with a static IP address that knows of a DNS server can find at least one controller.
- If you want the access point to discover a controller from a remote network where CAPWAP or LWAPP discovery mechanisms are not available, you can use priming. This method enables you to specify (through the access point CLI) the controller to which the access point is to connect.



Note

The LEDs on the access point change as the device enters different FlexConnect modes. See the hardware installation guide for your access point for information on LED patterns.

When a client associates to a FlexConnect access point, the access point sends all authentication messages to the controller and either switches the client data packets locally (locally switched) or sends them to the controller (centrally switched), depending on the WLAN configuration. With respect to client authentication (open, shared, EAP, web authentication, and NAC) and data packets, the WLAN can be in any one of the following states depending on the configuration and state of controller connectivity:



Note

For the FlexConnect local switching, central authentication deployments, whenever passive client is enabled, the IP Learn timeout is disabled by default.

• central authentication, central switching—In this state, the controller handles client authentication, and all client data is tunneled back to the controller. This state is valid only in connected mode.

- central authentication, local switching—In this state, the controller handles client authentication, and the FlexConnect access point switches data packets locally. After the client authenticates successfully, the controller sends a configuration command with a new payload to instruct the FlexConnect access point to start switching data packets locally. This message is sent per client. This state is applicable only in connected mode.
- local authentication, local switching—In this state, the FlexConnect access point handles client
 authentication and switches client data packets locally. This state is valid in standalone mode and connected
 mode

In connected mode, the access point provides minimal information about the locally authenticated client to the controller. The following information is not available to the controller:

- Policy type
- Access VLAN
- VLAN name
- Supported rates
- · Encryption cipher

Local authentication is useful where you cannot maintain a remote office setup of a minimum bandwidth of 128 kbps with the round-trip latency no greater than 100 ms and the maximum transmission unit (MTU) no smaller than 576 bytes. In local authentication, the authentication capabilities are present in the access point itself. Local authentication reduces the latency requirements of the branch office.

- Notes about local authentication are as follows:
 - Guest authentication cannot be done on a FlexConnect local authentication-enabled WLAN.
 - Local RADIUS on the controller is not supported.
 - Once the client has been authenticated, roaming is only supported after the controller and the other FlexConnect access points in the group are updated with the client information.
- authentication down, switch down—In this state, the WLAN disassociates existing clients and stops sending beacon and probe requests. This state is valid in both standalone mode and connected mode.
- authentication down, local switching—In this state, the WLAN rejects any new clients trying to authenticate, but it continues sending beacon and probe responses to keep existing clients alive. This state is valid only in standalone mode.

When a FlexConnect access point enters standalone mode, WLANs that are configured for open, shared, WPA-PSK, or WPA2-PSK authentication enter the "local authentication, local switching" state and continue new client authentications. This configuration is also correct for WLANs that are configured for 802.1X, WPA-802.1X, WPA2-802.1X, or Cisco Centralized Key Management, but these authentication types require that an external RADIUS server be configured.

Other WLANs enter either the "authentication down, switching down" state (if the WLAN was configured for central switching) or the "authentication down, local switching" state (if the WLAN was configured for local switching).

When FlexConnect access points are connected to the controller (rather than in standalone mode), the controller uses its primary RADIUS servers and accesses them in the order specified on the RADIUS Authentication Servers page or in the **config radius auth add** CLI command (unless the server order is overridden for a

particular WLAN). However, to support 802.1X EAP authentication, FlexConnect access points in standalone mode need to have their own backup RADIUS server to authenticate clients.



Note

A controller does not use a backup RADIUS server. The controller uses the backup RADIUS server in local authentication mode.

You can configure a backup RADIUS server for individual FlexConnect access points in standalone mode by using the controller CLI or for groups of FlexConnect access points in standalone mode by using either the GUI or CLI. A backup server configured for an individual access point overrides the backup RADIUS server configuration for a FlexConnect.

When web-authentication is used on FlexConnect access points at a remote site, the clients get the IP address from the remote local subnet. To resolve the initial URL request, the DNS is accessible through the subnet's default gateway. In order for the controller to intercept and redirect the DNS query return packets, these packets must reach the controller at the data center through a CAPWAP connection. During the web-authentication process, the FlexConnect access points allows only DNS and DHCP messages; the access points forward the DNS reply messages to the controller before web-authentication for the client is complete. After web-authentication for the client is complete, all the traffic is switched locally.

When a FlexConnect access point enters into a standalone mode, the following occurs:

• The access point checks whether it is able to reach the default gateway via ARP. If so, it will continue to try and reach the controller.

If the access point fails to establish the ARP, the following occurs:

- The access point attempts to discover for five times and if it still cannot find the controller, it tries to renew the DHCP on the ethernet interface to get a new DHCP IP.
- The access point will retry for five times, and if that fails, the access point will renew the IP address of the interface again, this will happen for three attempts.
- If the three attempts fail, the access point will fall back to the static IP and will reboot (only if the access point is configured with a static IP).
- Reboot is done to remove the possibility of any unknown error the access point configuration.

Once the access point reestablishes a connection with the controller, it disassociates all clients, applies new configuration information from the controller, and allows client connectivity again.

Guidelines and Restrictions for FlexConnect

- FlexConnect mode can support only 16 VLANs per AP.
- You can deploy a FlexConnect access point with either a static IP address or a DHCP address. In the
 context of DHCP, a DHCP server must be available locally and must be able to provide the IP address
 for the access point at bootup.
- FlexConnect supports up to 4 fragmented packets, or a minimum 576-byte maximum transmission unit (MTU) WAN link.

- Round-trip latency must not exceed 300 milliseconds (ms) between the access point and the controller, and CAPWAP control packets must be prioritized over all other traffic. In scenarios where you cannot achieve the 300-ms round-trip latency, configure the access point to perform local authentication.
- Client connections are restored only for locally switched clients that are in the RUN state when the access
 point moves from standalone mode to connected mode. After the access point moves, the access point's
 radio is also reset.
- When multiple APs come from standalone mode to connected mode on FlexConnect and all the APs send the client entry in hybrid-REAP payload to the controller. In this scenario, the controller sends disassociation messages to the WLAN client. However, the WLAN client comes back successfully and joins the controller.
- When APs are in standalone mode, if a client roams to another AP, the source AP cannot determine
 whether the client has roamed or is just idle. So, the client entry at source AP will not be deleted until
 idle timeout.
- The configuration on the controller must be the same between the time the access point went into standalone mode and the time the access point came back to connected mode. Similarly, if the access point is falling back to a secondary or backup controller, the configuration between the primary and the secondary or backup controller must be the same.
- A newly connected access point cannot be booted in FlexConnect mode.
- FlexConnect mode requires that the client send traffic before learning the client's IPv6 address. Compared
 to in local mode where the controller learns the IPv6 address by snooping the packets during Neighbor
 Discovery to update the IPv6 address of the client.
- 802.11r fast transition roaming is not supported on APs operating in local authentication.
- The primary and secondary controllers for a FlexConnect access point must have the same configuration.
 Otherwise, the access point might lose its configuration, and certain features, such as WLAN overrides, VLANs, static channel number, and so on, might not operate correctly. In addition, make sure you duplicate the SSID of the FlexConnect access point and its index number on both controllers.
- If you configure a FlexConnect access point with a syslog server configured on the access point, after the access point is reloaded and the native VLAN other than 1, at the time of initialization, a few syslog packets from the access point are tagged with VLAN ID 1.
- MAC filtering is not supported on FlexConnect access points in standalone mode. However, MAC filtering is supported on FlexConnect access points in connected mode with local switching and central authentication. Also, Open SSID, MAC Filtering, and RADIUS NAC for a locally switched WLAN with FlexConnect access points is a valid configuration, where MAC is checked by Cisco ISE.
- FlexConnect does not display any IPv6 client addresses in the Client Detail window.
- FlexConnect access points with locally switched WLANs cannot perform IP source guard and prevent ARP spoofing. For centrally switched WLANs, the wireless controller performs IP source guard and ARP spoofing.
- To prevent ARP spoofing attacks in FlexConnect APs with local switching, we recommend that you use ARP inspection.
- Proxy ARP for VM clients (with any wireless host) does not work since the client includes many IP addresses for the same MAC. To avoid this issue, disable the ARP-caching option in the Flex profile.

• When you enable local switching on policy profile for FlexConnect APs, the APs perform local switching. However, for the APs in local mode, central switching is performed.

In a scenario where the roaming of a client between FlexConnect mode AP and Local mode AP is not supported, the client may not get the correct IP address due to VLAN difference after the move. Also, L2 and L3 roaming between FlexConnect mode AP and Local mode AP are not supported.

FlexConnect local switching is not supported on Cisco Aironet Cisco 1810T and 1815T (Teleworker) Access Points.

- Cisco Centralized Key Management (CCKM) is not supported in FlexConnect standalone mode. Hence, CCKM enabled client will not be able to connect when AP is in FlexConnect standalone mode.
- For Wi-Fi Protected Access Version 2 (WPA2) in FlexConnect standalone mode or local authentication in connected mode or Cisco Centralized Key Management fast roaming in connected mode, only Advanced Encryption Standard (AES) is supported.
- For Wi-Fi Protected Access (WPA) in FlexConnect standalone mode or local-auth in connected mode or Cisco Centralized Key Management fast-roaming in connected mode, only Temporal Key Integrity Protocol (TKIP) is supported.
- WPA2 with TKIP and WPA with AES is not supported in standalone mode, local-auth in connected mode, and Cisco Centralized Key Management fast-roaming in connected mode.
- WPA with TKIP is supported in non-FIPS mode.
- Only open, WPA (PSK and 802.1x), and WPA2 (AES) authentication is supported on the Cisco Aironet 1830 Series and 1850 Series APs.
- Only 802.11r fast-transition roaming is supported on the Cisco Aironet 1830 Series and 1850 Series APs.
- AVC on locally switched WLANs is supported on second-generation APs.
- Local authentication fallback is not supported when a user is not available in the external RADIUS server.
- For WLANs configured for FlexConnect APs in local switching and local authentication, synchronization of dot11 client information is supported.
- DNS override is not supported on the Cisco Aironet 1830 Series and 1850 Series APs.
- The Cisco Aironet 1830 Series and 1850 Series APs do not support IPv6. However, a wireless client can pass IPv6 traffic across these APs.
- VLAN group is not supported in Flex mode under flex-profile.
- Configuring maximum number of allowed media streams on individual client or radio is not supported in FlexConnect mode.
- The WLAN client association limit will not work when the AP is in FlexConnect mode (connected or standalone) and is performing local switching and local authentication.
- A local switching client on FlexConnect mode will not get IP address for RLAN profile on the Cisco Aironet 1810 Series AP.
- Standard ACL is not supported on FlexConnect AP mode.
- IPv6 RADIUS Server is not configurable for FlexConnect APs. Only IPv4 configuration is supported.
- In Flex mode, IPv4 ACLs configured on WLAN gets pushed to AP but IPv6 ACLs does not.

- The client delete reason counters that are a part of the **show wireless stats client delete reasons** command, will be incremented only when the client record entry persists for join.
- For example, when an AP in the FlexConnect mode performs local authentication with ACL mismatch, then the AP deletes the client, and the controller does not create any client record.
- Cisco Centralized Key Management (CCKM) is supported in wave 1 APs in FlexConnect when you use local association.
- If the client roams from one AP to another and the roaming is successful, the following occurs:
 - The client does not send any traffic to the new AP.
 - The client's state is IP LEARN pending.
 - The client is deauthenticated after 180 seconds, if there is no traffic for the entire duration. In case the DHCP Required flag is set, the deauthentication occurs after 60 seconds.
- Using custom VLANs under the policy profile of the FlexConnect locally switched WLANs stops the SSID broadcast. In such scenarios, run the **shut** and **no shut** commands on the policy profile to start the SSID broadcast.

SSIDs are broadcasted when you:

- Perform VLAN name to id mapping under FlexConnect profile and map the custom VLAN name under the policy profile.
- Use VLAN id or standard VLAN name, for example, VLANxxxx.
- In the FlexConnect mode, the group temporal key (GTK) timer is set to 3600 seconds by default on Cisco Wave 2 AP, and this value cannot be reconfigured.
- For Flex mode deployments, local association configured policy profiles are not supported at a given time on the WLAN. Only the local association command must be enabled.
- From Cisco IOS XE Amsterdam 17.1.1 release onwards, the police rate per client in the flex connect APs in the controller, is represented as **rate_out** for Ingress (input) and **rate_in** for Egress (output). To verify police rate on the flex AP, use the **show rate-limit client** command.
- FlexConnect APs do not forward the DHCP packets after Change of Authorization (CoA) and change of VLANs using 802.1X encryption. You must disconnect the client from the WLAN and reconnect the client to enable the client to get an IP address in the second VLAN.
- Cisco Wave 2 and Catalyst Wi-Fi6 APs in FlexConnect local switching mode do not support Layer2(PSK, 802.1X) + Layer3(LWA, CWA, redirection-based posturing) + Dynamic AAA override + NAC.
- In Cisco Catalyst 9136I APs, in FlexConnect local authentication, the ongoing session timeout for a client gets reset after every roam.
- Network access control (NAC) is not supported in FlexConnect local authentication.
- Multicast traffic on an AAA overridden VLAN is not supported. Using this configuration may result in potential traffic leaks between VLANs.

Configuring a Site Tag

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	wireless tag site site-name	Configures site tag and enters site tag	
	Example:	configuration mode.	
	Device(config)# wireless tag site default-site-tag		
Step 3	flex-profile flex-profile-name	Maps a flex profile to a site tag.	
	Example:		
	Device(config-site-tag)# flex-profile rr-xyz-flex-profile		
Step 4	ap-profile ap-profile	Assigns an AP profile to the wireless site.	
	Example:		
	Device(config-site-tag)# ap-profile xyz-ap-profile		
Step 5	description site-tag-name	Adds a description for the site tag.	
	Example:		
	Device(config-site-tag)# description "default site tag"		
Step 6	no local-site	Moves the access point to FlexConnect mode.	
	Example:		
	Device(config-site-tag)# no local-site		
Step 7	end	Saves the configuration, exits the configuration	
	Example:	mode, and returns to privileged EXEC mode.	
	Device(config-site-tag)# end		
Step 8	show wireless tag site summary	(Optional) Displays the summary of site tags.	
	Example:		
	Device# show wireless tag site summary		

Configuring a Policy Tag (CLI)

Follow the procedure given below to configure a policy tag:

	Command or Action	Purpose	
Step 1	enable	Enables privileged EXEC mode.	
	Example:	Enter your password if prompted.	
	Device> enable		
Step 2	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 3	wireless tag policy policy-tag-name	Configures policy tag and enters policy tag	
	Example:	configuration mode.	
	Device(config-policy-tag)# wireless tag policy default-policy-tag	When performing LWA, the clients connected to a controller gets disconnected intermittently before session timeout.	
Step 4	description description	Adds a description to a policy tag.	
	Example:		
	Device(config-policy-tag)# description "default-policy-tag"		
Step 5	remote-lan name policy profile-policy-name {ext-module port-id }	Maps a remote-LAN profile to a policy profile.	
	Example:		
	Device(config-policy-tag)# remote-lan rr-xyz-rlan-aa policy rr-xyz-rlan-policy1 port-id 2		
Step 6	wlan wlan-name policy profile-policy-name	Maps a policy profile to a WLAN profile.	
	Example:	Note Ensure that the WLAN profile is	
	Device(config-policy-tag)# wlan rr-xyz-wlan-aa policy rr-xyz-policy-1	not used by any other profiles. If the AP uses the default profile, ensure that the no central switching command is configured on other profiles.	
Step 7	end	Exits policy tag configuration mode, and returns	
=	Example:	to privileged EXEC mode.	
	, •		

	Command or Action	Purpose	1	
Step 8	show wireless tag policy summary		(Optional) Displays the configured policy tags.	
	Example: Device# show wireless tag policy summary	Note	To view detailed information about a policy tag, use the show wireless tag policy detailed policy-tag-name command.	

Attaching a Policy Tag and a Site Tag to an Access Point (GUI)

Procedure

Step 1	Choose Configuration > Wireless > Access Points.
Step 2	Click the Access Point name.
Step 3	Go to the Tags section.
Step 4	Choose the Policy Tag from the Policy drop-down list.
Step 5	Choose the Site Tag from the Site drop-down list.
Step 6	Click Update and Apply to Device.

Attaching Policy Tag and Site Tag to an AP (CLI)

Follow the procedure given below to attach a policy tag and a site tag to an AP:

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	ap mac-address	Configures a Cisco AP and enters AP profile	
	Example:	configuration mode.	
	Device(config)# ap F866.F267.7DFB	Note The <i>mac-address</i> should be a wired mac address.	
Step 3	policy-tag policy-tag-name	Maps a policy tag to the AP.	
	Example:		
	Device(config-ap-tag)# policy-tag rr-xyz-policy-tag		

	Command or Action	Purpose	
Step 4	site-tag site-tag-name	Maps a site tag to the AP.	
	Example:		
	<pre>Device(config-ap-tag) # site-tag rr-xyz-site</pre>		
Step 5	rf-tag rf-tag-name	Associates the RF tag.	
	Example:		
	Device(config-ap-tag)# rf-tag rf-tag1		
Step 6	end	Saves the configuration, exits configuration	
	Example:	mode, and returns to privileged EXEC mode.	
	Device(config-ap-tag)# end		
Step 7	show ap tag summary	(Optional) Displays AP details and the tags	
	Example:	associated to it.	
	Device# show ap tag summary		
Step 8	show ap name <ap-name> tag info</ap-name>	(Optional) Displays the AP name with tag	
	Example:	information.	
	Device# show ap name ap-name tag info		
Step 9	show ap name <ap-name> tag detail</ap-name>	(Optional) Displays the AP name with tag	
	Example:	details.	
	Device# show ap name ap-name tag detail		

Linking an ACL Policy to the Defined ACL (GUI)

- **Step 1** Choose **Configuration** > **Tags & Profiles** > **Flex**.
- Step 2 Click Add.
- **Step 3** In the **General** tab, enter the **Name** of the Flex Profile. The name can be ASCII characters from 32 to 126, without leading and trailing spaces.
- Step 4 In the Policy ACL tab, click Add.
- **Step 5** Select the ACL from the **ACL Name** drop-down list and click **Save**.
- Step 6 Click Apply to Device.

Applying ACLs on FlexConnect

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	wireless profile flex flex-profile-name	Configures a wireless flex profile and enters	
	Example:	wireless flex profile configuration mode.	
	Device(config)# wireless profile flex Flex-profile-1		
Step 3	acl-policy acl-policy-name	Configures an ACL policy. Access control lists	
	Example:	(ACLs) perform packet filtering to control the movement of packets through a network.	
	<pre>Device(config-wireless-flex-profile)# acl-policy ACL1</pre>	inovenient of packets unough a network.	
Step 4	exit	Returns to wireless flex profile configuration	
	Example:	mode.	
	Device(config-wireless-flex-profile-acl)# exit		
Step 5	native-vlan-id	Configures native vlan-id information.	
	Example:		
	Device(config-wireless-flex-profile)# native-vlan-id 25		
Step 6	vlan vlan-name	Configures a VLAN.	
	Example:		
	Device(config-wireless-flex-profile)# vlan-name VLAN0169		
Step 7	acl acl-name	Configures an ACL for the interface.	
	Example:		
	Device(config-wireless-flex-profile-vlan)# acl ACL1		
Step 8	vlan-idvlan-id	Configures VLAN information.	
	Example:		
	Device(config-wireless-flex-profile-vlan)# vlan-id 169		

Configuring FlexConnect

Configuring a Switch at a Remote Site

Procedure

Step 1 Attach the access point, which will be enabled for FlexConnect, to a trunk or access port on the switch.

Note The sample configuration in this procedure shows the FlexConnect access point connected to a trunk port on the switch.

Step 2 The following example configuration shows you how to configure a switch to support a FlexConnect access point.

In this sample configuration, the FlexConnect access point is connected to the trunk interface FastEthernet 1/0/2 with native VLAN 100. The access point needs IP connectivity on the native VLAN. The remote site has local servers or resources on VLAN 101. A DHCP pool is created in the local switch for both the VLANs in the switch. The first DHCP pool (NATIVE) is used by the FlexConnect access point, and the second DHCP pool (LOCAL-SWITCH) is used by the clients when they associate to a WLAN that is locally switched.

```
ip dhcp pool NATIVE
   network 209.165.200.224 255.255.255.224
   default-router 209.165.200.225
   dns-server 192.168.100.167
ip dhcp pool LOCAL-SWITCH
   network 209.165.201.224 255.255.255.224
   default-router 209.165.201.225
   dns-server 192.168.100.167
interface \operatorname{Gig1}/0/1
description Uplink port
 no switchport
ip address 209.165.202.225 255.255.255.224
interface Gig1/0/2
description the Access Point port
 switchport trunk encapsulation dot1q
switchport trunk native vlan 100
switchport trunk allowed vlan 101
switchport mode trunk
interface Vlan100
 ip address 209.165.200.225 255.255.255.224
interface Vlan101
ip address 209.165.201.225 255.255.255.224
end
```

.

Configuring the Controller for FlexConnect

You can configure the controller for FlexConnect in two environments:

- Centrally switched WLAN
- · Locally switched WLAN

The controller configuration for FlexConnect consists of creating centrally switched and locally switched WLANs. This table shows three WLAN scenarios.

Table 4: WLAN Scenarios

WLAN	Security	Authentication	Switching	Interface Mapping (GUEST VLAN)
Employee	WPA1+WPA2	Central	Central	Management (centrally switched GUEST VLAN)
Employee-local	WPA1+WPA2 (PSK)	Local	Local	101 (locally switched GUEST VLAN)
Guest-central	Web authentication	Central	Central	Management (centrally switched GUEST VLAN)
Employee-local-auth	WPA1+WPA2	Local	Local	101 (locally switched VLAN)

Configuring Local Switching in FlexConnect Mode (GUI)

- **Step 1** Choose Configuration > Tags & Profiles > Policy.
- **Step 2** On the **Policy Profile** page, click the name of a policy profile to edit it or click **Add** to create a new one.
- **Step 3** In the **Add/Edit Policy Profile** window that is displayed, uncheck the **Central Switching** check box.
- Step 4 Click Update & Apply to Device.

Configuring Local Switching in FlexConnect Mode (CLI)

Procedure

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	wireless profile policy profile-policy	Configures WLAN policy profile and enters the	
	Example:	wireless policy configuration mode.	
	Device(config)# wireless profile policy rr-xyz-policy-1		
Step 3	no central switching	Configures the WLAN for local switching.	
	Example:		
	<pre>Device(config-wireless-policy) # no central switching</pre>		
Step 4	end	Returns to privileged EXEC mode.	
•	Example:	Alternatively, you can also press Ctrl-Z to exit	
	Device(config)# end	global configuration mode.	

Configuring Central Switching in FlexConnect Mode (GUI)

Before you begin

Ensure that the policy profile is configured. If the policy profile is not configured, see *Configuring a Policy Profile (GUI)* section.

- **Step 1** Choose Configuration > Tags & Profiles > Policy.
- **Step 2** On the **Policy Profile** page, select a policy.
- **Step 3** In the **Edit Policy Profile** window, in General Tab, use the slider to enable or disable **Central Switching**.
- Step 4 Click Update & Apply to Device.

Configuring Central Switching in FlexConnect Mode

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless profile policy profile-policy	Configures WLAN policy profile and enters the
	Example:	wireless policy configuration mode.
	<pre>Device(config)# wireless profile policy rr-xyz-policy-1</pre>	
Step 3	central switching	Configures the WLAN for central switching.
	Example:	
	Device(config-wireless-policy)# central switching	
Step 4	end	Returns to privileged EXEC mode.
	Example:	Alternatively, you can also press Ctrl-Z to exit
	Device(config)# end	global configuration mode.

Configuring an Access Point for FlexConnect

For more information, see Configuring a Site Tag (CLI) topic in New Configuration Model chapter.

Configuring an Access Point for Local Authentication on a WLAN (GUI)

- **Step 1** Choose Configuration > Tags & Profiles > Policy.
- **Step 2** In the **Policy Profile** page, select a policy profile name. The **Edit Policy Profile** window is displayed.
- **Step 3** In the General tab, deselect **Central Authentication** check box.
- Step 4 Click Update & Apply to Device.

Configuring an Access Point for Local Authentication on a WLAN (CLI)

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless profile policy profile-policy	Configures WLAN policy profile and enters the wireless policy configuration mode.
	Example:	
	Device(config)# wireless profile policy rr-xyz-policy-1	
Step 3	no central authentication	Configures the WLAN for local authentication.
	Example:	
	<pre>Device(config-wireless-policy)# no central authentication</pre>	
Step 4	end	Returns to privileged EXEC mode.
	Example:	Alternatively, you can also press Ctrl-Z to exit global configuration mode.
	Device(config)# end	

Connecting Client Devices to WLANs

Follow the instructions for your client device to create profiles to connect to the WLANs you created, as specified in the #unique 414.

In the example scenarios (see #unique 414), there are three profiles on the client:

- 1. To connect to the *employee* WLAN, create a client profile that uses WPA or WPA2 with PEAP-MSCHAPV2 authentication. After the client is authenticated, the client is allotted an IP address by the management VLAN of the controller.
- **2.** To connect to the *local-employee* WLAN, create a client profile that uses WPA or WPA2 authentication. After the client is authenticated, the client is allotted an IP address by VLAN 101 on the local switch.
- **3.** To connect to the *guest-central* WLAN, create a client profile that uses open authentication. After the client is authenticated, the client is allocated an IP address by VLAN 101 on the network local to the access point. After the client connects, a local user can enter any HTTP address in the web browser. The user is automatically directed to the controller to complete the web authentication process. When the web login window appears, the user should enter the username and password.

Configuring FlexConnect Ethernet Fallback

Information About FlexConnect Ethernet Fallback

You can configure an AP to shut down its radio when the Ethernet link is not operational. When the Ethernet link comes back to operational state, you can configure the AP to set its radio back to operational state. This feature is independent of the AP being in connected or standalone mode. When the radios are shut down, the AP does not broadcast the WLANs, and therefore, the clients cannot connect to the AP, either through first association or through roaming.

Configuring FlexConnect Ethernet Fallback

Before you begin

This feature is not applicable to APs with multiple ports.

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless profile flex flex-profile-name	Configures a wireless flex profile and enters wireless flex profile configuration mode.
	Example:	
	Device(config)# wireless profile flex test	
Step 3	fallback-radio-shut	Enables radio interface shutdown.
	Example:	
	<pre>Device(config-wireless-flex-profile)# fallback-radio-shut</pre>	
Step 4	end	Exits configuration mode and returns to privileged EXEC mode.
	Example:	
	<pre>Device(config-wireless-flex-profile) # end</pre>	
Step 5	show wireless profile flex detailed flex-profile-name	(Optional) Displays detailed information about the selected profile.
	Example:	
	Device# show wireless profile flex detailed test	

Flex AP Local Authentication (GUI)

Procedure

- **Step 1** Choose Configuration > Tags & Profiles > Flex.
- **Step 2** In the **Flex** page, click the name of the **Flex Profile** or click **Add** to create a new one.
- Step 3 In the Add/Edit Flex Profile window that is displayed, click the Local Authentication tab.

When local authentication and association is enabled in Access Point with Flex mode, the following occurs:

- AP handles the authentication.
- AP handles the rejection of client joins (in Mobility).

Note The controller does not increment statistics when AP rejects client association.

- **Step 4** Choose the server group from the **RADIUS Server Group** drop-down list.
- Step 5 Use the Local Accounting Radius Server Group drop down to select the RADIUS server group.
- **Step 6** Check the **Local Client Roaming** check box to enable client roaming.
- **Step 7** Choose the profile from the **EAP Fast Profile** drop-down list.
- **Step 8** Choose to enable or disable the following:
 - LEAP: Lightweight Extensible Authentication Protocol (LEAP) is an 802.1X authentication type for wireless LANs and supports strong mutual authentication between the client and a RADIUS server using a logon password as the shared secret. It provides dynamic per-user, per-session encryption keys.
 - PEAP: Protected Extensible Authentication Protocol (PEAP) is a protocol that encapsulates the Extensible Authentication Protocol (EAP) within an encrypted and authenticated Transport Layer Security (TLS) tunnel.
 - TLS: Transport Layer Security (TLS) is a cryptographic protocol that provide communications security over a computer network.
 - RADIUS: Remote Authentication Dial-In User Service (RADIUS) is a networking protocol that provides centralized Authentication, Authorization, and Accounting (AAA or Triple A) management for users who connect and use a network service.
- **Step 9** In the **Users** section, click **Add**.
- **Step 10** Enter username and password details and click **Save**.
- Step 11 Click Save & Apply to Device.

Flex AP Local Authentication (CLI)



Note

The Cisco Catalyst 9800 Series Wireless Controller + FlexConnect local authentication + AP acting as RADIUS are not supported on Cisco COS and IOS APs.

	Command or Action	Purpose
Step 1	aaa new-model	Creates a AAA authentication model.
	Example:	
	Device(config)# aaa new-model	
Step 2	aaa session-id common	Ensures that all the session IDs information
	Example:	that is sent out from the RADIUS group for a
	Device(config)# aaa session-id common	given call are identical.
Step 3	dot1x system-auth-control	Enables system authorization control for the
	Example:	RADIUS group.
	Device(config)# dot1x	
	system-auth-control	
Step 4	eap profile name	Creates an EAP profile.
	Example:	
	Device(config)# eap profile aplocal-test	
Step 5	method fast	Configures the FAST method on the profile.
	Example:	
	Device(config-eap-profile)# method fast	
Step 6	exit	Returns to configuration mode.
	Example:	
	Device(config-radius-server)# exit	
Step 7	wireless profile flex flex-profile	Configures the flex policy.
	Example:	
	Device(config)# wireless profile flex default-flex-profile	
Step 8	local-auth ap eap-fast name	Configures EAP-FAST profile details.
	Example:	
	Device(config-wireless-flex-profile)# local-auth ap eap-fast aplocal-test	

	Command or Action	Purpose
Step 9	local-auth ap leap	Configures the LEAP method.
	Example:	
	Device(config-wireless-flex-profile)# local-auth ap leap	
Step 10	local-auth ap peap	Configures the PEAP method.
	Example:	
	Device(config-wireless-flex-profile)# local-auth ap peap	
Step 11	local-auth ap username username	Configures username and password.
	Example:	
	Device(config-wireless-flex-profile)# local-auth ap username test1 test1	
Step 12	local-auth ap username username password	Configures another username and password.
	Example:	
	Device(config-wireless-flex-profile)# local-auth ap username test2 test2	
Step 13	exit	Returns to configuration mode.
	Example:	
	<pre>Device(config-wireless-flex-profile)# exit</pre>	
Step 14	wireless profile policy policy-profile	Configures profile policy.
	Example:	
	Device(config) # wireless profile policy default-policy-profile	
Step 15	shutdown	Disables the policy profile.
	Example:	
	Device(config-wireless-policy)# shutdown	
Step 16	no central authentication	Disables central (controller) authentication.
	Example:	
	Device(config)# no central authentication	
Step 17	vlan-id vlan-id	Configures VLAN name or VLAN ID.
	Example:	
	Device(config)# vlan-id 54	
Step 18	no shutdown	Enables the configuration.
	Example:	
	Device(config)# no shutdown	

Flex AP Local Authentication with External Radius Server

In this mode, an access point handles client authentication and switches client data packets locally. This state is valid in standalone mode and connected mode.

	Command or Action	Purpose
Step 1	aaa new-model	Creates a AAA authentication model.
	Example:	
	Device(config)# aaa new-model	
Step 2	aaa session-id common	Ensures that all the session ID's information
	Example:	that is sent out, from the RADIUS group for given call are identical.
	Device(config)# aaa session-id common	given can are identical.
Step 3	dot1x system-auth-control	Enables the system authorization control for
	Example:	the RADIUS group.
	Device(config)# dot1x system-auth-control	
Step 4	radius server server-name	Specifies the RADIUS server name.
	Example:	Note To authenticate clients with
	Device(config)# radius server Test-SERVER1	freeradius over RADSEC, you should generate an RSA key longer than 1024 bit. Use the crypto key generate rsa general-keys exportable label name command to achieve this.
		Do not configure key-wrap option under the radius server and radius server group, as it may lead to clients getting stuck in authentication state.
Step 5	address {ipv4 ipv6} ip address {auth-port port-number acct-port port-number }	Specifies the primary RADIUS server parameters.
	Example:	
	Device(config-radius-server)# address ipv4 124.3.50.62 auth-port 1112 acct-port 1113	
	Device(config-radius-server)# address ipv6 2001:DB8:0:20::15 auth-port 1812 acct-port 1813	

	Command or Action	Purpose
Step 6	<pre>key string Example: Device(config-radius-server) # key test123</pre>	Specifies the authentication and encryption key used between the device and the RADIUS daemon running on the RADIUS server. Note The maximum number of characters allowed for the shared secret is 63.
Step 7	<pre>radius server server-name Example: Device(config) # radius server Test-SERVER2</pre>	Specifies the RADIUS server name.
Step 8	address {ipv4 ipv6} ip address {auth-port port-number acct-port port-number } Example: Device(config-radius-server) # address ipv4 124.3.52.62 auth-port 1112 acct-port 1113 Device(config-radius-server) # address ipv6 2001:DB8:0:21::15 auth-port 1812 acct-port 1813	Specifies the secondary RADIUS server parameters.
Step 9	<pre>key string Example: Device(config-radius-server) # key test113</pre>	Specifies the authentication and encryption key used between the device and the RADIUS daemon running on the RADIUS server.
Step 10	<pre>exit Example: Device(config-radius-server) # exit</pre>	Returns to configuration mode.
Step 11	<pre>aaa group server radius server-group Example: Device(config) # aaa group server radius aaa_group_name</pre>	Creates a RADIUS server group identification. Note
Step 12	<pre>radius server server-name Example: Device(config) # radius server Test-SERVER1</pre>	Specifies the RADIUS server name.
Step 13	radius server server-name Example: Device(config-radius-server) # radius server Test-SERVER2	Specifies the RADIUS server name.

	Command or Action	Purpose
Step 14	exit	Exit from RADIUS server configuration mode
	Example:	
	Device(config-radius-server)# exit	
Step 15	wireless profile flex flex-profile	Creates a new flex policy.
	Example:	
	Device(config)# wireless profile flex default-flex-profile	
Step 16	local-auth radius-server-group server-group	Configures the authentication server group
	Example:	name.
	<pre>Device(config-wireless-flex-profile)# local-auth radius-server-group aaa_group_name</pre>	
Step 17	exit	Returns to configuration mode.
	Example:	
	<pre>Device(config-wireless-flex-profile)# exit</pre>	
Step 18	wireless profile policy policy-profile	Configures a WLAN policy profile.
	Example:	
	Device(config) # wireless profile policy default-policy-profile	
Step 19	shutdown	Disables a policy profile.
	Example:	
	Device(config-wireless-policy)# shutdown	
Step 20	no central authentication	Disables central (controller) authentication.
	Example:	
	Device(config-wireless-policy)# no central authentication	
Step 21	vlan-id vlan-id	Configures a VLAN name or VLAN Id.
	Example:	
	Device(config-wireless-policy)# vlan-id 54	
Step 22	no shutdown	Enables the configuration.
	Example:	
	Device(config-wireless-policy)# no shutdown	

Configuration Example: FlexConnect with Central and Local Authentication

To see configuration example on how to configure a controller for FlexConnect central and local authentication, see the FlexConnect Configuration with Central and Local Authentication on Catalyst 9800 Wireless Controllers document.

NAT-PAT for FlexConnect

If you want to use a central DHCP server to service clients across remote sites, NAT-PAT should be enabled. An AP translates the traffic coming from a client and replaces the client's IP address with its own IP address.



Note

You must enable local switching, central DHCP, and DHCP required using the (**ipv4 dhcp required**) command to enable NAT and PAT.

Configuring NAT-PAT for a WLAN or a Remote LAN

Creating a WLAN

Follow the steps given here to create a WLAN.

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wlan wlan-name wlan-id SSID-name	Enters the WLAN configuration sub-mode.
	Example:	• wlan-name—Enter the profile name. The
	Device(config)# wlan wlan-demo 1 ssid-demo	range is from 1 to 32 alphanumeric characters.
		• wlan-id—Enter the WLAN ID. The range is from 1 to 512.
		• <i>SSID-name</i> —Enter the Service Set Identifier (SSID) for this WLAN. If the SSID is not specified, the WLAN profile name is set as the SSID.

	Command or Action	Purpose	
		Note If you have already com WLAN, enter wlan wla command.	_
Step 3	no shutdown	Shut down the WLAN.	
	Example:		
	Device(config-wlan)# no shutdown		
Step 4	end	Returns to privileged EXEC mode.	
	Example:	Alternatively, you can also press Ctrl-Z	rl-Z to exit
	Device(config-wlan)# end	global configuration mode.	

Configuring a Wireless Profile Policy and NAT-PAT (GUI)

Procedure

Step 1	Choose Configuration > Tags & Profiles > Policy.
Step 2	Click Add.
Step 3	In the General tab, enter the Name of the policy.
Step 4	Disable the Central Switching toggle button.
Step 5	Enable the Central DHCP toggle button.
Step 6	Enable the Flex NAT/PAT toggle button.
Step 7	In the Advanced tab, under the DHCP Settings, check the IPv4 DHCP Required check box.
Step 8	Click Apply to Device.

Configuring a Wireless Profile Policy and NAT-PAT

Follow the procedure given below to configure a wireless profile policy and NAT-PAT:

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless profile policy profile-policy	Configures the policy profile for NAT.
	Example:	
	<pre>Device(config)# wireless profile policy nat-enabled-policy</pre>	

	Command or Action	Purpose
Step 3	no central switching	Configures the WLAN for local switching.
	Example:	
	Device(config-wireless-policy)# no central switching	
Step 4	ipv4 dhcp required	Configures the DHCP parameters for WLAN.
	Example:	
	Device(config-wireless-policy)# ipv4 dhcprequired	
Step 5	central dhcp	Configures the central DHCP for locally
	Example:	switched clients.
	Device(config-wireless-policy)# central dhcp	
Step 6	flex nat-pat	Enables NAT-PAT.
	Example:	
	<pre>Device(config-wireless-policy)# flex nat-pat</pre>	
Step 7	no shutdown	Enables policy profile.
	Example:	
	Device(config-wireless-policy)# no shutdown	
Step 8	end	Returns to privileged EXEC mode.
	Example:	Alternatively, you can also press Ctrl-Z to exit
	Device(config-wireless-policy)# end	global configuration mode.

Mapping a WLAN to a Policy Profile

Follow the procedure given below to map a WLAN to a policy profile:

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2 wireless tag policy policy-tag-name Configures a	Configures a policy tag and enters policy tag	
	Example:	configuration mode.
	Device(config)# wireless tag policy demo-tag	

	Command or Action	Purpose
Step 3	wlan wlan-name policy profile-policy-name	Maps a policy profile to a WLAN profile.
	Example:	
	Device(config-policy-tag)# wlan wlan-demo policy nat-enabled-policy	
Step 4	end	Returns to privileged EXEC mode.
	<pre>Example: Device(config-policy-tag)# end</pre>	Alternatively, you can also press Ctrl-Z to exit global configuration mode.

Configuring a Site Tag

Follow the procedure given below to configure a site tag:

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless tag site site-name	Configures a site tag and enters site tag
	Example:	configuration mode.
	Device(config)# wireless tag site flex-site	
Step 3	no local-site	Moves an access point to FlexConnect mode.
	Example:	
	Device(config-site-tag) # no local-site	
Step 4	end	Returns to privileged EXEC mode.
	Example:	Alternatively, you can also press Ctrl-Z to
	Device(config-site-tag)# end	global configuration mode.

Attaching a Policy Tag and a Site Tag to an Access Point (GUI)

- **Step 1** Choose **Configuration** > **Wireless** > **Access Points**.
- Step 2 Click the Access Point name.
- **Step 3** Go to the **Tags** section.
- **Step 4** Choose the **Policy Tag** from the **Policy** drop-down list.
- **Step 5** Choose the **Site Tag** from the **Site** drop-down list.

Step 6 Click Update and Apply to Device.

Attaching a Policy Tag and a Site Tag to an Access Point

Follow the procedure given below to attach a policy tag and a site tag to an access point:

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	ap mac-address	Configures Cisco APs and enters ap-tag
	Example:	configuration mode.
	Device(config)# ap F866.F267.7DFB	
Step 3	policy-tag policy-tag-name	Maps a policy tag to the AP.
	Example:	
	Device(config-ap-tag) # policy-tag demo-tag	
Step 4	site-tag site-tag-name	Maps a site tag to the AP.
	Example:	
	Device(config-ap-tag)# site-tag flex-site	
Step 5	end	Returns to privileged EXEC mode.
	Example:	
	Device(config-ap-tag)# end	

Split Tunneling for FlexConnect

If a client that connects over a WAN link that is associated with a centrally switched WLAN has to send traffic to a device present in the local site, this traffic should be sent over CAPWAP to the controller, and the same traffic is sent back to the local site either over CAPWAP or with the help of some off-band connectivity.

This process consumes WAN link bandwidth unnecessarily. To avoid this, you can use the Split Tunneling feature, which allows the traffic sent by a client to be classified based on the packet contents. The matching packets are locally switched and the rest of the traffic is centrally switched. The traffic that is sent by the client that matches the IP address of the device present in the local site can be classified as locally switched traffic, and the rest of the traffic as centrally switched.

To configure local split tunneling on an AP, ensure that you have enabled DCHP Required on the policy profile using the (**ipv4 dhcp required**) command. This ensures that the client that is associating with the split WLAN does DHCP.



Note

Apple iOS clients need option 6 (DNS) to be set in DHCP offer for split tunneling to work.



Note

- FlexConnect split tunneling (vlan-based central switching for FlexConnect) on auto-anchor deployment is not supported.
- Split tunneling does not work on RLAN clients. When the **split-tunnel** option is enabled on RLAN, traffic denied by the split tunnel ACL is not translated based on the IP address, instead the traffic is sent back to the controller through CAPWAP.
- URL filter must not be configured with wildcard URLs such as * and *.*

Configuring Split Tunneling for a WLAN or Remote LAN

Defining an Access Control List for Split Tunneling (GUI)

Procedure

- **Step 1** Choose **Configuration** > **Security** > **ACL**.
- Step 2 Click Add.
- Step 3 In the Add ACL Setup dialog box, enter the ACL Name.
- **Step 4** Choose the ACL type from the **ACL Type** drop-down list.
- **Step 5** Under the **Rules** settings, enter the **Sequence** number and choose the **Action** as either **permit** or **deny**.
- **Step 6** Choose the required source type from the **Source Type** drop-down list.
 - a) If you choose the source type as **Host**, then you must enter the **Host Name/IP**.
 - b) If you choose the source type as **Network**, then you must specify the **Source IP** address and **Source Wildcard** mask.
- **Step 7** Check the **Log** check box if you want the logs.
- Step 8 Click Add.
- **Step 9** Add the rest of the rules and click **Apply to Device**.

Defining an Access Control List for Split Tunneling

Follow the procedure given below to define an Access Control List (ACL) for split tunneling:

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	ip access-list extended name	Defines an extended IPv4 access list using a
	Example:	name, and enters access-list configuration mode.
	<pre>Device(config)# ip access-list extended split_mac_acl</pre>	
Step 3	deny ip any host hostname	Allows the traffic to switch centrally.
	Example:	
	Device(config-ext-nacl)# deny ip any host 9.9.2.21	
Step 4	permit ip any any	Allows the traffic to switch locally.
	Example:	
	Device(config-ext-nacl)# permit ip any any	
Step 5	end	Exits configuration mode and returns to
	Example:	privileged EXEC mode.
	Device(config-ext-nacl)# end	

Linking an ACL Policy to the Defined ACL

Follow the procedure given below to link an ACL policy to the defined ACL:

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless profile flex flex-profile	Configures the Flex profile and enters flex
	Example:	profile configuration mode.
	Device(config)# wireless profile flex flex-profile	
Step 3	acl-policy acl policy name	Configures an ACL policy for the defined ACL.
	Example:	
	<pre>Device(config-wireless-flex-profile)# acl-policy split_mac_acl</pre>	

	Command or Action	Purpose
Step 4	end	Exits configuration mode and returns to
	Example:	privileged EXEC mode.
	Device(config-wireless-flex-profile)# end	

Creating a WLAN

Follow the procedure given below to create a WLAN.

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wlan wlan-name wlan-id SSID-name	Specifies the WLAN name and ID:
	<pre>Example: Device(config)# wlan wlan-demo 1 ssid-demo</pre>	 wlan-name—Enter the profile name. The range is from 1 to 32 alphanumeric characters. wlan-id—Enter the WLAN ID. The range is from 1 to 512. SSID-name—Enter the Service Set Identifier (SSID) for this WLAN. If the SSID is not specified, the WLAN profile
<u> </u>	1.41	name is set as the SSID.
Step 3	no shutdown	Enables the WLAN.
	Example:	
	Device(config-wlan) # no shutdown	
Step 4	end	Returns to privileged EXEC mode.
	Example:	Alternatively, you can also press Ctrl-Z to exit
	Device(config-wlan)# end	global configuration mode.
		I.

Configuring a Wireless Profile Policy and a Split MAC ACL Name (GUI)

- **Step 1** Choose **Configuration** > **Tags & Profiles** > **Policy**.
- Step 2 Click Add.
- **Step 3** In the **General** tab, enter the **Name** of the policy.

- **Step 4** Enable the **Central Switching** toggle button.
- **Step 5** Enable the **Central DHCP** toggle button.
- Step 6 In the Advanced tab, under the DHCP settings, check the IPv4 DHCP Required check box and enter the DHCP Server IP Address.
- Step 7 Under the WLAN Flex Policy settings, choose the split MAC ACL from the Split MAC ACL drop-down list.
- Step 8 Click Apply to Device.

Configuring a Wireless Profile Policy and a Split MAC ACL Name

Follow the procedure given below to configure a wireless profile policy and a split MAC ACL name:

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless profile policy profile-policy	Configures a WLAN policy profile and enters wireless policy configuration mode.
	Example:	
	Device(config)# wireless profile policy split-tunnel-enabled-policy	
Step 3	flex split-mac-acl split-mac-acl-name	Configures a split MAC ACL name.
	Example:	Note You should use the same ACL
	<pre>Device(config-wireless-policy)# flex split-mac-acl split_mac_acl</pre>	name for linking the flex and the policy profile.
Step 4	central switching	Configures WLAN for central switching.
	Example:	
	<pre>Device(config-wireless-policy)# central switching</pre>	
Step 5	central dhcp	Enables central DHCP for centrally switched clients.
	Example:	
	<pre>Device(config-wireless-policy)# central dhcp</pre>	
Step 6	ipv4 dhcp required	Configures the DHCP parameters for a WLAN.
	Example:	
	Device(config-wireless-policy)# ipv4 dhcp required	
Step 7	ipv4 dhcp server ip_address	Configures the override IP address of the DHCP
	Example:	server.

	Command or Action	Purpose
	Device(config-wireless-policy)# ipv4 dhcp server 9.1.0.100	
Step 8	no shutdown	Enables a policy profile.
	Example:	
	Device(config-wireless-policy) # no shutdown	

Mapping a WLAN to a Policy Profile (GUI)

Procedure

Step 1	Choose Configuration > Tags & Profiles > Tags.
Step 2	Click Add.
Step 3	Enter the Name of the Tag Policy.
Step 4	Under WLAN-POLICY Maps tab, click Add.
Step 5	Choose the WLAN Profile from the WLAN Profile drop-down list.
Step 6	Choose the Policy Profile from the Policy Profile drop-down list.
Step 7	Click the Tick Icon .
Step 8	Click Apply to Device.

Mapping WLAN to a Policy Profile

Follow the procedure given below to map WLAN to a policy profile.

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless tag policy policy-tag-name	Configures a policy tag and enters policy tag
	Example:	configuration mode.
	Device(config)# wireless tag policy split-tunnel-enabled-tag	
Step 3	wlan wlan-name policy profile-policy-name	Maps a policy profile to a WLAN profile.
	Example:	
	Device(config-policy-tag)# wlan wlan-demo	

	Command or Action	Purpose
Step 4	end	Returns to privileged EXEC mode.
	Example:	Alternatively, you can also press Ctrl-Z to exit global configuration mode.
	Device(config-policy-tag)# end	given comigatation mode.

Configuring a Site Tag

Follow the procedure given below to configure a site tag:

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless tag site site-name	Configures a site tag and enters site tag
	Example:	configuration mode.
	Device(config)# wireless tag site flex-site	
Step 3	no local-site	Local site is not configured on the site tag.
	Example:	
	Device(config-site-tag)# no local-site	
Step 4	flex-profile flex-profile-name	Configures a flex profile.
	Example:	
	Device(config-site-tag)# flex-profile flex-profile	
Step 5	end	Returns to privileged EXEC mode.
	Example:	Alternatively, you can also press Ctrl-Z to exit
	Device(config-site-tag)# end	global configuration mode.

Attaching a Policy Tag and Site Tag to an Access Point

Follow the procedure given below to attach a policy tag and site tag to an access point.

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	

	Command or Action	Purpose
Step 2	ap ethernet-mac-address	Configures an AP and enters ap tag
	Example:	configuration mode.
	Device(config)# ap 188b.9dbe.6eac	
Step 3	policy-tag policy-tag-name	Maps a policy tag to an AP.
	Example:	
	Device(config-ap-tag) # policy-tag split-tunnel-enabled-tag	
Step 4	site-tag site-tag-name	Maps a site tag to an AP.
	Example:	
	Device(config-ap-tag)# site-tag flex-site	
Step 5	end	Returns to privileged EXEC mode.
	Example:	Alternatively, you can also press Ctrl-Z to exit
	Device(config-ap-tag)# end	global configuration mode.

VLAN-based Central Switching for FlexConnect

In FlexConnect local switching, if the VLAN definition is not available in an access point, the corresponding client does not pass traffic. This scenario is applicable when the AAA server returns the VLAN as part of client authentication.

When a WLAN is locally switched in flex and a VLAN is configured on the AP side, the traffic is switched locally. When a VLAN is not defined in an AP, the VLAN drops the packet.

When VLAN-based central switching is enabled, the corresponding AP tunnels the traffic back to the controller. The controller then forwards the traffic to its corresponding VLAN.



Note

- For VLAN-based central switching, ensure that VLAN is defined on the controller.
- VLAN-based central switching is not supported by mac filter.
- For local switching, ensure that VLAN is defined on the policy profile and FlexConnect profile.
- VLAN-based central switching with central web authentication enabled in Flex profile is not supported.

Configuring VLAN-based Central Switching (GUI)

Procedure

Step 1 Choose Configuration > Tags & Profiles > Policy.

- **Step 2** Click the name of the policy profile.
- **Step 3** In the **Edit Policy Profile** window, perform these tasks:
 - a) Set Central Switching to Disabled state.
 - b) Set Central DHCP to Disabled state.
 - c) Set Central Authentication to Enabled state.
- Step 4 Click the Advanced tab.
- Step 5 Under AAA Policy, check the Allow AAA Override check box to enable AAA override.
- Step 6 Under WLAN Flex Policy, check the VLAN Central Switching check box, to enable VLAN-based central switching on the policy profile.
- Step 7 Click Update & Apply to Device.

Configuring VLAN-based Central Switching (CLI)

Follow the procedure given below to configure VLAN-based central switching.

	Command or Action	Purpose		
Step 1	configure terminal	Enters global configuration mode.		
	Example:			
	Device# configure terminal			
Step 2	wireless profile policy profile-policy	Configures a wireless policy profile.		
	Example:			
	Device(config)# wireless profile policy default-policy-profile			
Step 3	no central switching	Configures a WLAN for local switching.		
	Example:			
	Device(config-wireless-policy)# no central switching			
Step 4	no central dhcp	Configures local DHCP mode, where the DHCP		
	Example:	is performed in an AP.		
	Device(config-wireless-policy)# no central dhcp			
Step 5	central authentication	Configures a WLAN for central authentication.		
	Example:			
	Device(config-wireless-policy)# central authentication			
Step 6	aaa-override	Configures AAA policy override.		
	Example:			

	Command or Action	Purpose
	Device(config-wireless-policy)# aaa-override	
Step 7	flex vlan-central-switching	Configures VLAN-based central switching.
	Example:	
	Device(config-wireless-policy)# flex vlan-central-switching	
Step 8	end	Returns to privileged EXEC mode.
	Example:	
	Device(config-wireless-policy)# end	
Step 9	show wireless profile policy detailed default-policy-profile	(Optional) Displays detailed information of the policy profile.
	Example:	
	Device# show wireless profile policy detailed default-policy-profile	

OfficeExtend Access Points for FlexConnect

A Cisco OfficeExtend access point (OEAP) provides secure communications from a controller to a Cisco AP at a remote location, seamlessly extending the corporate WLAN over the Internet to an employee's residence. A user's experience at the home office is exactly the same as it would be at the corporate office. Datagram Transport Layer Security (DTLS) encryption between an access point and the controller ensures that all communications have the highest level of security.



Note

Preconfigure the controller IP for a zero-touch deployment with OEAP. All other home users can use the same access point to connect for home use by configuring the local SSID from AP.



Note

In releases prior to Cisco IOS XE Amsterdam 17.3.2, when an AP is converted to OEAP, the local DHCP server on the AP is enabled by default. If the DHCP server on home router has a similar configuration, a network conflict occurs and AP will not be able to join back to the controller. In such a scenario, we recommend that you change the default DHCP server on the Cisco AP using OEAP GUI.



Note

For OEAP, when configuration changes are made from the OEAP GUI to the following: Radio Status, Radio Interface Status, 802.11 n-mode, 802.11 ac-mode, Bandwidth, and Channel Selection (2.4 GHz or 5 GHz), CAPWAP should be restarted for the configuration sync to take place between the AP and the controller. During this interval, the AP GUI may not respond until the AP rejoins the controller. We recommend that you wait for the AP to rejoin the controller (for about 1-2 minutes), before you make further changes from the OEAP GUI.



Note

In Cisco OfficeExtend access point (Cisco OEAP), if the OEAP local DHCP server is enabled and the user configures DNS IP from OEAP GUI, the wireless and wired clients connected to Cisco OEAP will receive that IP as DNS server IP in DHCP ACK.

Configuring OfficeExtend Access Points

Follow the procedure given below to configure OfficeExtend access points.

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless profile flex flex-profile-name	Configures a wireless flex profile and enters
	Example:	wireless flex profile configuration mode.
	Device(config)# wireless profile flex test	
Step 3	office-extend	Enables the OfficeExtend AP mode for a
	Example:	FlexConnect AP.
	<pre>Device(config-wireless-flex-profile)# office-extend</pre>	
Step 4	end	Exits configuration mode and returns to
	Example:	privileged EXEC mode.
	Device(config-wireless-flex-profile)# end	Note After creating a flex profile, ensure that OEAP is in flex connect mode and mapped to its corresponding site tag.
		OfficeExtend is disabled by default. To clear the access point's configuration and return it to the factory-defaults, use the clear ap config <i>cisco-ap</i> command.

Disabling OfficeExtend Access Point

Follow the procedure given below to disable an OfficeExtend access point.

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless profile flex flex-profile-name	Configures a wireless flex profile and enters
	Example:	wireless flex profile configuration mode.
	Device(config)# wireless profile flex test	
Step 3	no office-extend	Disables OfficeExtend AP mode for a
	Example:	FlexConnect AP.
	Device(config-wireless-flex-profile)# no office-extend	
Step 4	end	Exits configuration mode and returns to
	Example:	privileged EXEC mode.
	Device(config-wireless-flex-profile)# end	

Support for OEAP Personal SSID

Information About OEAP Personal SSID Support

The Cisco OfficeExtend Access Point supports personal SSID. This enables a local home client to use the same OfficeExtend Access Point for local networking and internet connectivity. With the help of the OEAP personal SSID feature, you can enable or disable personal SSID, enable or disable Datagram Transport Layer Security (DTLS) encryption between an access point and the controller, and enable rogue detection, using the knobs that are present on the AP profile page in the GUI. The local network access and DTLS encryption are enabled by default. The configurations described in this chapter is applicable for OEAP or for APs in the OEAP mode.

Configuring OEAP Personal SSID (GUI)

- **Step 1** Choose Configuration > AP Tags & Profiles > AP Join.
 - The **AP Join Profile** section displays all the AP Join profiles.
- **Step 2** To edit the configuration details of an AP Join profile, select APs in the OEAP mode. The **Edit AP Join Profile** window is displayed.
- Step 3 In the General tab, under the OfficeExtend AP Configuration section, configure the following:
 - a) Check the **Local Access** check box to enable the local network. By default, **Local Access** is enabled. After the AP joins the controller using AP join profile where local access is enabled, the AP will not

- broadcast the default personal SSID. Since the local access is enabled, you can login to the AP GUI and configure the personal SSID.
- b) Check the Link Encryption check box to enable data DTLS. By default, Link Encryption is enabled.
- c) Check the Rogue Detection check box to enable rogue detection. Rogue detection is disabled by default for OfficeExtend APs because these APs, deployed in a home environment, are likely to detect a large number of rogue devices.

Configuring OEAP Personal SSID (CLI)

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	ap profile ap-profile	Configures an AP profile and enters the AP
	Example:	profile configuration mode.
	Device(config)# ap profile ap-profile	
Step 3	[no] oeap local-access	Enables the local access to AP. Local access
	Example:	consist of local AP GUI, LAN ports and personal SSID. The no form of this command
	Device(config-ap-profile)# oeap	disables the feature. If the local access is disabled, you will not be able to access the A
	local-access	
		GUI, the local LAN port will be disabled, and personal SSID will not be broadcasted.
Step 4	[no] oeap link-encryption	Enables DTLS encryption for OEAP APs or
	Example:	APs moving to the OEAP mode. The no form of this command disables the feature. This
	Device(config-ap-profile) # oeap link-encryption	feature is enabled by default.
Step 5	[no] oeap rogue-detection	Enables OEAP DTLS encryption in the AP
	Example:	profile configuration mode. This feature is disabled by default.
	Device(config-ap-profile)# no oeap rogue-detection	disabled by default.

Viewing OEAP Personal SSID Configuration

To view the OEAP personal SSID configuration, run the following command.

```
Device# show ap profile name default-ap-profile detailed . . . . . . OEAP Mode Config Link Encryption : ENABLED
```

Rogue Detection : DISABLED Local Access : ENABLED

Clearing Personal SSID from an OfficeExtend Access Point

To clear the personal SSID from an access point, run the following command:

ap name Cisco_AP clear-personal-ssid

Example: Viewing OfficeExtend Configuration

This example displays an OfficeExtend configuration:

```
Device# show ap config general
```

```
Cisco AP Name : ap_name
______
Cisco AP Identifier
                                              : 70db.986d.a860
Country Code
                                              : Multiple Countries : US, IN
                                            : 802.11bg:-A 802.11a:-ABDN
Regulatory Domain Allowed by Country
AP Country Code
                                             : US - United States
AP Regulatory Domain
 Slot 0
                                              : -A
 Slot 1
                                              : -D
                                             : 002c.c899.7b84
MAC Address
IP Address Configuration
                                             : DHCP
IP Address
                                             : 9.9.48.51
                                             : 255.255.255.0
TP Netmask
Gateway IP Address
                                              : 9.9.48.1
CAPWAP Path MTU
Telnet State
                                             : Disabled
SSH State
                                             : Disabled
Jumbo MTU Status
                                             : Disabled
                                             : default location
Cisco AP Location
Site Tag Name
                                             : flex-site
                                             : default-rf-tag
RF Tag Name
Policy Tag Name
                                             : split-tunnel-enabled-tag
AP join Profile
                                            : default-ap-profile
Primary Cisco Controller Name
Primary Cisco Controller IP Address
                                            : uname-controller
                                            : 9.9.48.34
Secondary Cisco Controller Name
                                             : uname-controller1
Secondary Cisco Controller IP Address
                                            : 0.0.0.0
Tertiary Cisco Controller Name
                                            : uname-ewlc2
                                            : 0.0.0.0
Tertiary Cisco Controller IP Address
Administrative State
                                             : Enabled
Operation State
AP Mode
                                             : FlexConnect
AP Submode
                                             : Not Configured
Office Extend Mode
                                             : Enabled
                                             : Disabled
Remote AP Debug
Logging Trap Severity Level
                                             : information
Software Version
                                             : 16.8.1.1
Boot Version
                                             : 1.1.2.4
Mini IOS Version
                                             : 0.0.0.0
Stats Reporting Period
                                             : 0
                                             : Enabled
LED State
PoE Pre-Standard Switch
                                             : Disabled
PoE Power Injector MAC Address
                                             : Disabled
Power Type/Mode
                                             : PoE/Full Power (normal mode)
```

Proxy ARP

Proxy address resolution protocol (ARP) is the most common method for learning about MAC address through a proxy device. Enabling Proxy ARP known as ARP caching in Cisco Catalyst 9800 Series Wireless Controller means that the AP owning client is the destination of the ARP request, replies on behalf of that client and therefore does not send the ARP request to the client over the air. Access points not owning the destination client and receiving an ARP request through their wired connection will drop the ARP request. When the ARP caching is disabled, the APs bridge the ARP requests from wired-to-wireless and vice-versa increasing the air time usage and broadcasts over wireless.

The AP acts as an ARP proxy to respond to ARP requests on behalf of the wireless clients.

Enabling Proxy ARP for FlexConnect APs (GUI)

Procedure

- Step 1 Choose Configuration > Tags & Profiles > Flex.
- Step 2 Click Add.
- Step 3 In the General tab, enter the Name of the Flex Profile and check the ARP Caching check box. The name can be ASCII characters from 32 to 126, without leading and trailing spaces.
- Step 4 Click Apply to Device.

Enabling Proxy ARP for FlexConnect APs

Follow the procedure given below to configure proxy ARP for FlexConnect APs.

	Command or Action	Purpose		
Step 1	configure terminal	Enters global configuration mode.		
	Example:			
	Device# configure terminal			
Step 2	wireless profile flex flex-policy	Configures WLAN policy profile and enters		
	Example:	wireless flex profile configuration mode.		
	Device(config)# wireless profile flex flex-test			
Step 3	arp-caching	Enables ARP caching.		
	Example:	Note Use the no arp-caching command		
	<pre>Device(config-wireless-flex-profile)# arp-caching</pre>	to disable ARP caching.		

	Command or Action	Purpose
Step 4	end	Returns to privileged EXEC mode.
	Example:	
	<pre>Device(config-wireless-flex-profile)# end</pre>	
Step 5	show running-config section wireless profile flex	Displays ARP configuration information.
	Example:	
	Device# show running-config section wireless profile flex	
Step 6	show wireless profile flex detailed flex-profile-name	(Optional) Displays detailed information of the flex profile.
	Example:	
	Device# show wireless profile flex detailed flex-test	
Step 7	show arp summary	(Optional) Displays ARP summary.
	Example:	
	Device# show arp summary	

Overlapping Client IP Address in Flex Deployment

Overview of Overlapping Client IP Address in Flex Deployment

In flex deployments, you can use cookie cutter configuration across sites and branches which also includes local DHCP servers configured with the same subnet. In this topology, controllers detect multiple client sessions with the same IP as IP THEFT and clients are put in blocked list.

The Overlapping Client IP Address in Flex Deployment feature offers overlapping IP address across various flex sites and provides all the functionalities that are supported in flex deployments.

Enabling Overlapping Client IP Address in Flex Deployment (GUI)

- Step 1 Choose Configuration > Tags & Profiles > Flex and click Add.
- Step 2 On the Add Flex Profile window and General tab.
- **Step 3** Check the **IP Overlap** check box to enable overlapping client IP Address in Flex deployment.
- Step 4 Click Apply to Device.

Enabling Overlapping Client IP Address in Flex Deployment

Procedure

	Command or Action	Purpose		
Step 1	configure terminal	Enters global configuration mode.		
	Example:			
	Device# configure terminal			
Step 2	wireless profile flex flex-profile	Configures a Flex profile and enters Flex prof		
	Example:	configuration mode.		
	Device(config)# wireless profile flex flex1			
Step 3	[no] ip overlap	Enables overlapping client IP address in flex		
	Example:	deployment.		
	Device(config-wireless-flex-profile)# [no] ip overlap	Note By default, the configuration is disabled.		

Verifying Overlapping Client IP Address in Flex Deployment (GUI)

Procedure

- **Step 1** Choose **Monitoring** > **Wireless** > **Clients**.
- **Step 2** Click the client in the table to view properties and statistics for each client.
- **Step 3** On the **Client** window and **General** tab, click **Client Statistics** tab to view the following details:
 - Number of Bytes Received from Client
 - Number of Bytes Sent to Client
 - · Number of Packets Received from Client
 - Number of Packets Sent to Client
 - Number of Policy Errors
 - Radio Signal Strength Indicator
 - Signal to Noise Ratio
 - IP Zone ID Mapping

Step 4 Click OK.

Verifying Overlapping Client IP Address in Flex Deployment

To verify if the overlapping client IP address in Flex deployment feature is enabled or not, use the following command:

```
Device# show wireless profile flex detailed flex1
Fallback Radio shut : DISABLED
ARP caching : ENABLED
Efficient Image Upgrade : ENABLED
OfficeExtend AP : DISABLED
Join min latency : DISABLED
IP overlap status : DISABLED
```

To view additional details about the overlapping client IP address in Flex deployment feature, use the following command:

Device# show wireless device-tracking database ip

IP	ZONE-ID	STATE	DISCOVERY	MAC
9.91.59.154	0x00000002	Reachable	IPv4 Packet	
6038.e0dc.3182				
1000:1:2:3:90d8:dd1a:11ab:23c0	0x00000002	Reachable	IPv6 Packet	
58ef.680d.c6c3				
1000:1:2:3:f9b5:3074:d0da:f93b	0x00000002	Reachable	IPv6 Packet	
58ef.680d.c6c3				
2001:9:3:59:90d8:ddla:11ab:23c0	0x00000002	Reachable	IPv6 NDP	
58ef.680d.c6c3				
2001:9:3:59:f9b5:3074:d0da:f93b	0x00000002	Reachable	IPv6 NDP	
58ef.680d.c6c3				
fe80::f9b5:3074:d0da:f93b	0x80000001	Reachable	IPv6 NDP	
58ef.680d.c6c3				

To view APs in various site tags, use the following command:

```
Device# show ap tag summary Number of APs: 5
```

AP Name AP Mac Site Tag Name Policy Tag Name RF Tag Name Misconfigured Tag Source

```
AP3802 70b3.17f6.37aa flex_ip_overlap-site-tag-auto-3 flex_ip_overlap_policy_tag_1 default-rf-tag No Static AP-9117AX 0cd0.f894.0f8c default-site-tag default-policy-tag default-rf-tag No Default AP1852JJ9 38ed.18ca.2b48 flex_ip_overlap-site-tag-auto-2 flex_ip_overlap_policy_tag_2 default-rf-tag No Static AP1852I 38ed.18cc.61c0 flex_ip_overlap-site-tag-auto-1 flex_ip_overlap_policy_tag_1 default-rf-tag No Static AP1542JJ9 700f.6a84.1b30 flex_ip_overlap-site-tag-auto-2 flex_ip_overlap_policy_tag_2 default-rf-tag No Static
```

To view APs in FlexConnect mode, use the following command:

Device# show ap status					
AP Name	Status	Mode	Country		
AP3802	Disabled	FlexConnect	IN		
AP1852I	Enabled	FlexConnect	US		
AP-9117AX	Enabled	FlexConnect	IN		
AP1542JJ9	Disabled	FlexConnect	US		
AP1852JJ9	Enabled	FlexConnect	US		

Troubleshooting Overlapping Client IP Address in Flex Deployment

To verify the WNCD instance for each of the APs, use the following command:

Device# show wireless loadbalance ap			affinity wncd 0	
	AP Mac	Discovery Timestamp	Join Timestamp	Tag
	0cd0.f894.0f8c	10/27/20 22:11:05	10/27/20 22:11:14	default-site-tag
	38ed.18ca.2b48	10/27/20 22:06:09	10/27/20 22:06:19	flex ip overlap-site-tag-auto-2
	700f.6a84.1b30	10/27/20 22:25:03	10/27/20 22:25:13	flex ip overlap-site-tag-auto-2

Information About FlexConnect High Scale Mode

This feature helps to scale up the FlexConnect site capacity to accommodate 300 APs and 3000 802.1x clients per site. The FlexConnect site capability is scaled up by using the Pairwise Master Key (PMK) option to skip Extensible Authentication Protocol (EAP) exchange while performing client roaming.

When a client associates with an AP under an 802.1x authentication architecture, an EAP exchange takes place, followed by a four-way handshake to verify the encryption keys. Using PMK caching, an AP can cache the PMK identifier of the EAP exchange, and for the subsequent client join. In PMK caching, the EAP exchange process is eliminated, and the authentication time process is decreased.

The PMK propagation feature is disabled by default. Until Cisco IOS XE Cupertino 17.7.1, the wireless controller used to push the PMK cache to every FlexConnect AP in the site. From Cisco IOS XE Cupertino 17.8.1 onwards, when PMK propagation is enabled, the controller pushes the PMK cache only to selective FlexConnect APs. These FlexConnect APs then forward the PMK identifier to the other FlexConnect APs within the same site.

Enabling PMK Propagation (CLI)

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless profile flex test-flex-profile	Creates a FlexConnect profile.
	Example:	
	<pre>Device(config) # wireless profile flex test-flex-profile</pre>	
Step 3	pmk propagate	Propagates PMK information to the other APs
	Example:	in the site.
	Device(config-wireless-flex-profile)# pmk propogate	Note The PMK propagation feature is disabled by default.

Examples

Device# configure terminal
Device(config)# wireless profile flex test-flex-profile
Device(config-wireless-flex-profile)# pmk propagate

Flex Resilient with Flex and Bridge Mode Access Points

Information About Flex Resilient with Flex and Bridge Mode Access Points

The Flex Resilient with Flex and Bridge Mode Access Points describe how to set up a controller with Flex+Bridge mode Access Points (APs) and Flex Resilient feature. The Flex Resilient feature works only in Flex+Bridge mode APs. The feature resides in Mesh link formed between RAP - MAP, once the link is UP and RAP loses connection to the CAPWAP controller, both RAP and MAP continue to bridge the traffic. A child Mesh AP (MAP) maintains its link to a parent AP and continues to bridge till the parent link is lost. A child MAP cannot establish a new parent or child link till it reconnects to the CAPWAP controller.



Note

Existing wireless clients in locally switching WLAN can stay connected with their AP in this mode. No new or disconnected wireless client can associate to the Mesh AP in this mode. Client traffic in Flex+Bridge MAP is dropped at RAP switchport for the locally switched WLANs.

Configuring a Flex Profile (GUI)

- $\textbf{Step 1} \qquad \text{Choose Configuration } > \textbf{Tags \& Profiles} > \textbf{Flex}.$
- Step 2 Click a Flex Profile Name. The Edit Flex Profile dialog box appears.
- **Step 3** Under the **General** tab, choose the **Flex Resilient** check box to enable the Flex Resilient feature.
- **Step 4** Under the **VLAN** tab, choose the required VLANs.
- Step 5 (Optionally) Under the Local Authentication tab, choose the desired server group from the Local Accounting RADIUS Server Group drop-down list. Also, choose the RADIUS check box.
- Step 6 Click Update & Apply to Device.

Configuring a Flex Profile (CLI)

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode
	Example:	
	Device# configure terminal	
Step 2	wireless profile flex flex-profile	Configures a Flex profile and enters Flex profile
	Example:	configuration mode.
	Device(config)# wireless profile flex new-flex-profile	
Step 3	arp-caching	Enables ARP caching.
	Example:	
	Device(config-wireless-flex-profile)# arp-caching	
Step 4	description description	Enables default parameters for the Flex profile.
	Example:	
	Device (config-wireless-flex-profile) # description "new flex profile"	
Step 5	native-vlan-id	Configures native vlan-id information.
	Example:	
	Device(config-wireless-flex-profile)# native-vlan-id 2660	
Step 6	resilient	Enables the resilient feature.
	Example:	
	<pre>Device (config-wireless-flex-profile) # resilient</pre>	
Step 7	vlan-name vlan_name	Configures VLAN name.
	Example:	
	Device(config-wireless-flex-profile)# vlan-name VLAN2659	
Step 8	vlan-id vlan_id	Configures VLAN ID.
	Example:	The valid VLAN ID ranges from 1 to 4096.
	Device(config-wireless-flex-profile)# vlan-id 2659	
Step 9	end	Exits configuration mode and returns to
	Example:	privileged EXEC mode.
	Device(config-wireless-flex-profile)# end	

Configuring a Site Tag (CLI)

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode
	Example:	
	Device# configure terminal	
Step 2	wireless tag site site-name	Configures a site tag and enters site tag
	Example:	configuration mode.
	Device(config)# wireless tag site new-flex-site	
Step 3	flex-profile flex-profile-name	Configures a flex profile.
	Example:	
	Device(config-site-tag)# flex-profile new-flex-profile	
Step 4	no local-site	Local site is not configured on the site tag
	Example:	
	Device(config-site-tag)# no local-site	
Step 5	site-tag site-tag-name	Maps a site tag to an AP.
	Example:	
	Device(config-site-tag)# site-tag new-flex-site	
Step 6	end	Exits configuration mode and returns to
	Example:	privileged EXEC mode.
	Device(config-site-tag)# end	

Configuring a Mesh Profile (CLI)

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode
	Example:	
	Device# configure terminal	
Step 2	wireless profile mesh profile-name	Configures a Mesh profile and enters the Mesh
	Example:	profile configuration mode.
	Device(config)# wireless profile mesh Mesh_Profile	

	Command or Action	Purpose
Step 3	no ethernet-vlan-transparent	Disables VLAN transparency to ensure that the bridge is VLAN aware.
	Example:	
	Device(config-wireless-profile-mesh)# no ethernet-vlan-transparent	
Step 4	end	Exits configuration mode and returns to privileged EXEC mode.
	Example:	
	Device(config-wireless-profile-mesh)# end	

Associating Wireless Mesh to an AP Profile (CLI)

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode	
	Example:		
	Device# configure terminal		
Step 2	ap profile ap-profile-name	Configures the AP profile and enters AP profile	
	Example:	configuration mode.	
	Device(config)# ap profile new-ap-join-profile		
Step 3	mesh-profile mesh-profile-name	Configures the Mesh profile in AP profile	
	Example:	configuration mode.	
	<pre>Device(config-ap-profile) # mesh-profile Mesh_Profile</pre>		
Step 4	ssh	Configures the Secure Shell (SSH).	
	Example:		
	Device(config-ap-profile)# ssh		
Step 5	mgmtuser username username password {0	Specifies the AP management username and password for managing all of the access points configured to the controller.	
	8} password		
	Example:		
	Device(config-ap-profile)# mgmtuser username Cisco password 0 Cisco secre 0 Cisco	• 0: Specifies an UNENCRYPTED password.	
		• 8: Specifies an AES encrypted password.	
		Note While configuring an username, ensure that special characters are not used as it results in error with bad configuration.	

	Command or Action	Purpose
Step 6	end	Exits configuration mode and returns to
	Example:	privileged EXEC mode.
	Device(config-ap-profile)# end	

Attaching Site Tag to an Access Point (CLI)

Procedure

·	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode	
	Example:		
	Device# configure terminal		
Step 2	ap mac-address	Configures Cisco APs and enters ap-tag configuration mode.	
	Example:		
	Device(config)# ap F866.F267.7DFB		
Step 3	site-tag site-tag-name	Maps a site tag to the AP.	
	Example:	Note Associating Site Tag causes the	
	Device(config-ap-tag)# site-tag new-flex-site	associated AP to reconnect.	
Step 4	end	Exits configuration mode and returns to	
	Example:	privileged EXEC mode.	
	Device(config-ap-tag)# end		

Configuring Switch Interface for APs (CLI)

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode
	Example:	
	Device# configure terminal	
Step 2	interface interface-id	Enters the interface to be added to the VLAN.
	Example:	
	Device(config)# interface <int-id></int-id>	
Step 3	switchport trunk native vlan vlan-id	Assigns the allowed VLAN ID to the port when
	Example:	it is in trunking mode.

	Command or Action	Purpose	
	Device(config-if)# switchport trunk native vlan 2660		
Step 4	<pre>switchport trunk allowed vlan vlan-id Example: Device(config-if)# switchport trunk allowed vlan 2659,2660</pre>	Assigns the allowed VLAN ID to the port whe it is in trunking mode.	
Step 5	<pre>switchport mode trunk Example: Device(config-if) # switchport mode trunk</pre>	Note When the controller works as a host for spanning tree, ensure that you configure portfast trunk, using spanning-tree portfast trunk command, in the uplink switch to ensure faster convergence.	
Step 6	<pre>end Example: Device(config-if)# end</pre>	Exits configuration mode and returns to privileged EXEC mode.	

Verifying Flex Resilient with Flex and Bridge Mode Access Points Configuration

To view the AP mode and model details, use the following command:

```
Device# show ap name <ap-name> config general | inc AP Mode
AP Mode

AP Model : Flex+Bridge
AP Model : AIR-CAP3702I-A-K9
```

To view the MAP mode details, use the following command:

```
Device# show ap name MAP config general | inc AP Mode

AP Mode

AP Model : Flex+Bridge

AP Model : AIR-CAP3702I-A-K9
```

To view the RAP mode details, use the following command:

To view if the Flex Profile - Resilient feature is enabled or not, use the following command:

```
Device# show wireless profile flex detailed FLEX_TAG | inc resilient Flex resilient : ENABLED
```

Feature History for OEAP Link Test

This table provides release and related information for the feature explained in this module.

This feature is also available in all the releases subsequent to the one in which they are introduced in, unless noted otherwise.

Table 5: Feature History for OEAP Link Test

Release	Feature	Feature Information
Cisco IOS XE Bengaluru 17.5.1	OEAP Link Test	The Cisco OEAP Link Test feature allows you to determine the DTLS upload, link latency, and jitter of the link between an AP and the controller.

Information About OEAP Link Test

The Cisco OEAP Link Test feature allows you to determine the DTLS upload speed of the link between an AP and the controller. This feature helps in identifying network bottlenecks and reasons for functionality failures. You can determine the link latency by running a test on demand.

A link test is used to determine the quality of the link between the controller and an AP in OEAP mode. The AP sends synthetic packets to the controller and the controller echoes them back to the AP, which can then estimate the link quality.

Feature Scenarios

Cisco OfficeExtend Access Point (OEAP) users are complaining of poor performance when connected to a teleworker AP.

Use Cases

This feature allows OEAP network admins to troubleshoot low throughput from the Cisco Catalyst 9800 Controller GUI by running OEAP link test.

The OEAP link test provides DTLS upload speed, link latency, and link jitter, all of which help the network administrators to narrow down the problem.

Configuring OEAP Link Test (CLI)

	Command or Action	Purpose
Step 1	enable	Enters privileged EXEC mode.
	Example:	
	Device> enable	
Step 2	ap name ap-name network-diagnostic	Triggers network diagnostics on an
	Example:	OfficeExtend AP.
	Device# ap name ap18 network-diagnostic	

Performing OEAP Link Test (GUI)

Procedure

Step 1 Choose Monitoring > Wireless > AP Statistics.

In the list of APs, a Link Test icon is displayed in the AP Name column for OEAP-capable APs.

Note The **Link Test** icon is displayed only if an AP is OEAP capable and is configured to operate as OEAP.

Step 2 Click Link Test.

A link test is run and the results are shown.

Verifying OEAP Link Test

The following example shows how to verify network diagnostics information:

Feature History for Cisco OEAP Split Tunneling

This table provides release and related information for the feature explained in this module.

This feature is available in all the releases subsequent to the one in which it is introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Cupertino 17.8.1	IPv6 Support	IPv6 addressing is supported on the Cisco OEAP Split Tunneling feature.
Cisco IOS XE Cupertino 17.7.1	Cisco OEAP Split Tunneling	The Split Tunneling feature in Cisco OfficeExtend Access Point (OEAP) provides a mechanism to classify client traffic, based on packet content, using access control lists (ACLs).

Table 6: Feature History for Cisco OEAP Split Tunneling

Information About Cisco OEAP Split Tunneling

The global pandemic has redefined the way people interact and work. The workplace has shifted from office cubicles to home desks, which requires applications that enable seamless collaboration among the workforce. For home-based workers, access to business services must be reliable, consistent, and secure. It should provide an experience that is similar to the office facility. Routing all of the traffic through the corporate network using traditional VPNs increases the traffic volume, slows down access to resources, and negatively impacts the remote user experience.

Cisco OEAP provides secure communications from a controller to an access point (AP) at a remote location, seamlessly extending the corporate WLAN over the internet to an employee's residence. Cisco OEAP provides segmentation of home and corporate traffic using the Split Tunnelling feature, which allows for home device connectivity without security risks to corporate policy.

Split tunnelling classifies the traffic sent by a client, based on packet content, using ACLs. Matching packets are switched locally from Cisco OEAP, and other packets are centrally switched over CAPWAP. Clients on a corporate SSID can talk to devices on a local network (printers, wireless devices on a personal SSID, and so on) directly without consuming WAN bandwidth, by sending packets over CAPWAP.

Traffic to Software as a Service (Saas) applications such as Cisco WebEx, Microsoft SharePoint, Microsoft Office365, Box, Dropbox, and so on that is required as part of the work routine, need not go through the corporate network, by using the Split Tunnelling feature.

The Cisco OEAP advertises two SSIDs, one corporate and one personal. Corporate SSID clients obtain their IP address from the central DHCP server in the corporate network. If split tunneling is enabled and a client wants to access a device in the home network, the AP performs NAT (PAT) translation between the wireless client corporate network subnet and the home network where the AP is located.

The personal SSID is configurable by a Cisco OEAP user. Clients will either get their IP address from the home router (when the AP personal SSID firewall is disabled) or from the internal AP DHCP server (when the AP personal SSID firewall is enabled). In the latter scenario, if the clients want to reach the home network devices, the AP perform sNAT (PAT) translation between the wireless client's internal network and the home network where the AP is located.

IPv6 Address Support

From Cisco IOS XE Cupertino 17.8.1, IPv6 addressing is supported. You can disable IPv6 addressing only by disabling the feature.



Note

The end-to-end network should support IPv6, that is, both the corporate network (controller, corporate gateway, and so on) and the home network (wireless clients, home router, and so on) should support IPv6.

Prerequisites for Cisco OEAP Split Tunneling

- Cisco Wave 2 APs or Cisco Catalyst 9100AX Series Access Points
- URL filter list that matches the ACL name configured in split tunneling

Restrictions for Cisco OEAP Split Tunneling

- Cisco OEAPs are not supported when Cisco Embedded Wireless Controller on Catalyst Access Points (EWC) is used as a controller.
- · Mesh topology is not supported.
- Clients connected on personal SSID or on home network (AP native VLAN) cannot discover devices on the corporate network.
- Split tunnelling is not supported in standalone mode.
- URL split tunnelling supports only up to 512 URLs.
- Action (deny or permit) can be specified only on the URL filter list, not for each individual entry.
- If URL-based ACL contains wild-card URLs, a maximum of 10 URLs are supported.
- The amount of snooped DNS IP addresses is limited as follows:
 - An AP can snoop 4095 IP addresses per DNS response, if IP addresses are less than 150,000.
 - An AP can snoop 10 IP addresses per DNS response, if IP addresses are between 150,000 and 200,000.
 - An AP can snoop five IP addresses per DNS response, if IP addresses are between 200,000 and 250,000.
 - An AP can snoop one IP address per DNS response, if IP addresses are greater than 250,000.
- A maximum of 128 IP address ACE (rules) can be used in the IP ACL for split tunnelling.
- URL-based split tunnelling only works with IPv4 addresses.
- The following restrictions are specific to IPv6 addressing
 - Multihoming (multiple router advertisement prefixes) is not supported (If a home network receives multiple prefixes, the one used by the AP that is connected to the controller is used.)
 - Roaming is not supported.
 - Filtering is not supported on the upstream traffic towards the wireless client.

- Split tunneling is disabled for clients with duplicate IPv6 addresses. Traffic for these clients is forwarded centrally to the controller.
- DHCPv6 prefix delegation is not supported for wireless clients.
- If the corporate prefix length is smaller than the home prefix length, split tunneling for a particular client is disabled.

Use Cases for Cisco OEAP Split Tunneling

Before Release 17.7.1, split tunneling used IP ACLs. This meant that cloud services such as Cisco Webex were accessed directly without going through the corporate network. The network administrator maintained the list of IP addresses that Cisco Webex used, which was a daunting task. From Release 17.7.1, using the Cisco OEAP Split Tunneling feature, the network administrator needs to provide only the DNS names that Cisco Webex uses. The AP ensures that traffic from these DNS names is routed directly to the internet without using the corporate network.

Workflow to Configure Cisco OEAP Split Tunneling

- 1. Create an IP address ACL or URL ACL
- 2. Add ACL to FlexConnect Profile
- 3. Enable Split Tunnelling on Policy Profile
- **4.** Verify the Configuration

Create an IP Address ACL (CLI)

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example: Device# configure terminal		
Step 2	<pre>ip access-list extended name Example: Device(config) # ip access-list extended vlan_oeap</pre>	Defines an extended IPv4 access list using a name. Note IP ACL can be used to define a default action if there is no match in the URL ACL.	
Step 3	seq-num deny ip any host hostname Example:	Denies IP traffic from any host.	

	Command or Action	Purpose
	Device(config-ext-nacl) # 10 deny ip any 10.10.0.0 0.0.255.255	
Step 4	seq-num permit ip any any hostname	Permits IP traffic from any source or destination
	Example:	host.
	Device(config-ext-nacl)# 20 permit ip any any	
Step 5	end	Exits configuration mode and returns to
	Example:	privileged EXEC mode.
	Device(config-ext-nacl)# end	

Create a URL ACL (CLI)

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	urlfilter list list-name	Configures the URL filter list.	
	Example:	The list name must not exceed 32 alphanumeric	
	Device(config)# urlfilter list vlan_oeap	characters.	
Step 3	action permit	Configures the action: Permit (traffic is allowed	
	Example:	directly on the home network) or Deny (traffic is directed to the corporate network).	
Device(config-urlfilte	Device(config-urlfilter-params)# action permit		
Step 4	filter-type post-authentication	Configures the URL list as post authentication	
	Example:	filter.	
	Device(config-urlfilter-params)# filter-type post-authentication		
Step 5	url url-name	Configures a URL.	
	Example:		
	Device(config-urlfilter-params)# url wiki.cisco.com		
Step 6	url url-name	(Optional) Configures a URL.	
	Example:	Use this option when you want to add multip	
	<pre>Device(config-urlfilter-params)# url example.com</pre>	URLs.	

	Command or Action	Purpose
Step 7	end	Exits configuration mode and returns to
	Example:	privileged EXEC mode.
	Device(config-urlfilter-params)# end	

Add an ACL to a FlexConnect Profile

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	wireless profile flex flex-profile	Configures a FlexConnext profile.	
	Example:		
	Device(config)# wireless profile flex default-flex-profile		
Step 3	acl-policy acl-policy-name	Configures an ACL policy.	
	Example:		
	<pre>Device(config-wireless-flex-profile)# acl-policy vlan_oeap</pre>		
Step 4	urlfilter list url-filter	Configures a URL filter list.	
	Example:		
	Device(config-wireless-flex-profile-acl)# urlfilter list vlan_oeap		
Step 5	exit	Returns to FlexConnect profile configuration	
	Example:	mode	
	<pre>Device(config-wireless-flex-profile-acl)# exit</pre>		
Step 6	office-extend	Enables the OEAP mode for a FlexConnect A	
	Example:		
	<pre>Device(config-wireless-flex-profile)# office-extend</pre>		
Step 7	end	Exits configuration mode and returns to	
	Example:	privileged EXEC mode.	
	Device(config-wireless-flex-profile)# end		

Enable Split Tunnelling in a Policy Profile

Procedure

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	wireless profile flex flex-profile	Configures a FlexConnect profile.	
	Example:		
	<pre>Device(config)# wireless profile flex default-flex-profile</pre>		
Step 3	no central association	Disables central association and enables loca	
	Example:	association for locally switched clients.	
	Device(config-wireless-flex-profile) # no central association		
Step 4	flex split-mac-acl split-mac-acl-name	Configures a split MAC ACL name.	
	Example:	Note Ensure that you use the same	
	<pre>Device(config-wireless-flex-profile)# flex split-mac-acl vlan_oeap</pre>	acl-policy-name in the FlexConnect profile.	
Step 5	end	Exits configuration mode and returns to privileged EXEC mode.	
	Example:		
	Device(config-wireless-flex-profile)# end		

Verifying the Cisco OEAP Split Tunnel Configuration

To verify the split tunneling DNS ACLs per wireless client on the AP side, use the following command:

```
Device# show split-tunnel client 00:11:22:33:44:55 access-list

Split tunnel ACLs for Client: 00:11:22:33:44:55

IP ACL: SplitTunnelACL

Tunnel packets Tunnel bytes NAT packets NAT bytes

1 242 3 768

URL ACL: SplitTunnelACL

Tunnel packets Tunnel bytes NAT packets NAT bytes
3 778 0 0

Resolved IPs for Client: 00:11:22:33:44:55 for Split tunnel
```

HIT-COUNT	URL	ACTION	IP-LIST
1	base1.com	deny.	20.0.1.1 20.0.1.10
2	base2.com	deny.	20.0.1.2
3	base3.com	deny.	20.0.1.3

To verify the current binding between a WLAN and an ACL, use the following command:

Device# show split-tunnel mapping

VAP-Id ACL Name
0 SplitTunnelACL

To verify the content of the current URL ACL, use the following command:

Device# show flexconnect url-acl

ACL-NAME ACTION URL-LIST
SplitTunnelACL deny base.com

AP Survey Mode

To enable the Cisco Catalyst 9136 Series APs and other upcoming AP models for site survey at customer sites, a new AP command is introduced to help APs to switch to survey mode. When an AP is in survey mode, the AP GUI is enabled and is used for configuring the RF parameters for site survey investigation.

To enable survey mode on an AP, run the ap-type site-survey command from the AP CLI.

The following features in the AP GUI are hidden, when the AP is in the survey mode:

- WAN
- Firewall
- Network Diagnostics



Note

To make the hidden features visible on the AP GUI, you must switch the AP back to the CAPWAP mode, by running the **ap-type capwap** command from the AP CLI. In CAPWAP mode, the AP GUI becomes available only when the **OfficeExtend AP** field is enabled in the flex profile page associated to that AP.



Note

To access the AP survey mode from the GUI, you must enter the default login as 'admin' and the default password as 'admin' (both case sensitive).

When the AP is in survey mode, it broadcasts an SSID by default. The default password to connect to this SSID is 'password' (case sensitive).

AP Survey Mode