



AP Fallback to Controllers Configured Under AP Priming Profile

- [Feature History for AP Fallback to Controllers Using AP Priming Profile, on page 1](#)
- [Information About AP Fallback to Controllers Using AP Priming Profile, on page 1](#)
- [Restrictions for AP Fallback to Controllers Using AP Priming Profile, on page 2](#)
- [Configure AP Priming Profile, on page 2](#)
- [Configure AP Priming Using Filters, on page 3](#)
- [Configure Per-AP Priming, on page 4](#)
- [Verify the Configuration, on page 4](#)

Feature History for AP Fallback to Controllers Using AP Priming Profile

This table provides release and related information for the feature explained in this module.

Table 1: Feature History for AP Fallback to Controllers Using AP Priming Profile

Release	Feature	Feature Information
Cisco IOS XE Cupertino 17.9.2	AP Fallback to Controllers Using AP Priming Profile	This feature helps to configure primary, secondary, and tertiary controllers for a group of APs matching regular expression or for an individual AP using priming profiles.

Information About AP Fallback to Controllers Using AP Priming Profile

In large networks, accessing every AP console and configuring AP priming for primary, secondary, and tertiary controllers are not easy tasks. The AP Fallback to Controllers Using AP Priming Profile feature allows you to simplify the task of priming APs by using profiles defined in the controller.

Using the AP priming profile under the AP filter profile, you can configure primary, secondary, and tertiary controllers for a group of APs matching regular expressions, or for an individual AP using AP Ethernet MAC. When the AP joins the controller, the AP priming configuration gets pushed to the AP depending on whether priming override is enabled or not.



Note When the controller sends a priming profile to the AP, the AP disconnects from the current controller and joins the controller in the priming profile. A CAPWAP restart or device reboot is not required.

Restrictions for AP Fallback to Controllers Using AP Priming Profile

- Rolling AP upgrade will not work if priming override is enabled.
- The maximum number of priming profiles permitted is 128. The length of each profile can be up to 32 ASCII characters.

Configure AP Priming Profile

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	wireless profile ap priming <i>profile-name</i> Example: Device(config)# wireless profile ap priming Prime-FX	Configures the profile to prime APs.
Step 3	primary <i>controller-name ip-address</i> Example: Device(config-priming)# primary aaaa 209.165.201.2	Configures name and IP address of the primary controller for AP fallback.
Step 4	secondary <i>controller-name ip-address</i> Example: Device(config-priming)# secondary bbbb 209.165.201.3	Configures name and IP address of the secondary controller for AP fallback.
Step 5	tertiary <i>controller-name ip-address</i> Example:	Configures name and IP address of the tertiary controller for AP fallback.

	Command or Action	Purpose
	Device(config-priming)# tertiary bbbb 209.165.201.4	
Step 6	<p>priming-override</p> <p>Example:</p> <pre>Device(config-priming)# priming-override</pre>	<p>Sends the priming details to the AP.</p> <p>Priming override is disabled by default. When disabled, information stored in the AP priming profile is not sent to the APs. .</p> <p>Note N+1 upgrade may not work as expected when priming override is enabled. Before using N+1 upgrade, ensure that priming override is disabled using the no priming-override command.</p>

Configure AP Priming Using Filters

Procedure

	Command or Action	Purpose
Step 1	<p>configure terminal</p> <p>Example:</p> <pre>Device# configure terminal</pre>	Enters global configuration mode.
Step 2	<p>ap filter name <i>filter-name</i> type priming</p> <p>Example:</p> <pre>Device(config)# ap filter name test-filter type priming</pre>	<p>Configures the AP filter and sets the type as priming.</p> <p>Ensure that you set type as priming because the default filter type is tag.</p> <p>Note The existing filter type cannot be modified unless the filter is deleted and created with a different type. Use the no ap filter name command to delete a filter.</p>
Step 3	<p>ap name-regex <i>reg-ex</i></p> <p>Example:</p> <pre>Device(config-ap-pr-filter)# ap name-regex BGL18</pre>	Configures the AP name regular expression match.
Step 4	<p>profile <i>profile-name</i></p> <p>Example:</p> <pre>Device(config-ap-pr-filter)# profile Prime-FX</pre>	Maps the priming profile to the filter.

	Command or Action	Purpose
Step 5	exit Example: Device(config-ap-pr-filter)# exit	Returns to global configuration.
Step 6	ap filter priority <i>priority</i> filter-name <i>filter-name</i> Example: Device(config)# ap filter priority 12 filter-name test-filter	Configures priority for a named AP filter. You can configure multiple AP priming profiles with unique priority levels. This allows you to set different priority levels for each AP priming profile.

Configure Per-AP Priming

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	ap <i>mac-address</i> Example: Device(config)# ap 00:00:5e:00:53:af	Enters AP profile configuration mode.
Step 3	priming <i>profile-name</i> Example: Device(config-ap-tag)# priming Prime-FX	Maps a priming profile to an AP.

Verify the Configuration

To view the list of all the priming filters, use the following command:

```
Device# show ap filters all type priming
```

```
Filter Name                regex                Priming profile
-----
FLR1                       *AP-FLOOR-1*       AP-PRIMING-1
FLR2                       *AP-FLOOR-2*       AP-PRIMING-2
```

To view the list of all the active priming filters, use the following command:

```
Device# show ap filters active type priming
```

```
Priority  Filter Name                regex                Priming profile
```

```

-----
0          FLR2          *AP-FLOOR-2*          AP-PRIMING-2
1          FLR1          *AP-FLOOR-1*          AP-PRIMING-1

```

To view the summary of the priming profiles, use the following command:

```
Device# show wireless profile ap priming summary
```

```

Number of AP Priming Profiles: 2
Priming profile
-----
AP-PRIMING-1
AP-PRIMING-2

```

To view the details of the priming profiles, use the following command:

```
Device# show wireless profile ap priming all
```

```

Profile Name  Primary Controller Name  Primary Controller IP  Secondary Controller Name
Secondary Controller IP  Tertiary Controller Name  Tertiary Controller IP  Override
-----
AP-PRIMING-1  BGL18-wlc                209.165.201.1         BGL17-wlc
209.165.201.2                                0.0.0.0                Disabled
AP-PRIMING-2  BGL18-wlc                209.165.201.2         BGL17-wlc
209.165.201.2          BGL12-wlc                209.165.201.3         Disabled

```

To view the priming information for each AP, use the following command:

```
Device# show ap ap1 config general | sec Priming
```

```

Priming Profile           : AP-PRIMING-1
Priming Override          : Disabled
Priming Source            : MAC/FILTER/NONE
Filter Name               : FLR1

```

