



## Volume Metering

The Volume Metering feature allows you to configure the interval at which an access point (AP) updates client accounting statistics to the embedded wireless controller and in turn to the RADIUS server. Currently, the report is sent from an AP to the controller every 90 seconds. With this feature, you can configure the time from 5 to 90 seconds. This helps reduce the delay in accounting data usage by a device.

- [Configuring Volume Metering, on page 1](#)

## Configuring Volume Metering

Follow the procedure given below to configure volume metering:

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 2</b>	<b>ap profile profile-name</b>  <b>Example:</b> Device(config)# ap profile yy-ap-profile	Configures an AP profile and enters ap profile configuration mode.
<b>Step 3</b>	<b>dot11 24ghz reporting-interval reporting-interval</b>  <b>Example:</b> Device(config-ap-profile)# dot11 24ghz reporting-interval 60	Configures the dot11 parameters.
<b>Step 4</b>	<b>dot11 5ghz reporting-interval reporting-interval</b>  <b>Example:</b> Device(config-ap-profile)# dot11 5ghz reporting-interval 60	Configures the dot11 parameters.

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 5</b>	<b>exit</b> <b>Example:</b> Device(config-ap-profile)# exit	Returns to global configuration mode.
<b>Step 6</b>	<b>aaa accounting update periodic</b> <i>interval-in-minutes</i> <b>Example:</b> Device(config)# aaa accounting update periodic 75	Sets the time interval (in minutes) at which the embedded wireless controller sends interim accounting updates of the client to the RADIUS server.
<b>Step 7</b>	<b>exit</b> <b>Example:</b> Device(config)# exit	Exits configuration mode and returns to privileged EXEC mode.