



# Standard QCI Support

- [Revision History, on page 1](#)
- [Feature Description, on page 1](#)
- [Configure QCI, on page 2](#)
- [Monitoring and Troubleshooting, on page 3](#)

## Revision History



**Note** Revision history details are not provided for features introduced before release 21.24.

Revision Details	Release
First introduced.	Pre 21.24

## Feature Description

The standardized QCI values—65, 66, 67, 69, and 70 support Mission Critical and Push-to-Talk (MC/PTT) applications. The standard QCIs are based on 3GPP TS 23.203 Release 12.

This feature supports the following functionality:

- Creates, deletes, and updates default and dedicated bearers.
- All applicable charging records include the standard QCI values.
- All features related to QCIs work with the standard QCI values.
- Creates, deletes, and updates Dynamic rules from PCRF with QCI 67.
- Creates and deletes Pre-defined rules with QCI 67
- Allows WiFi HO for bearer with QCI 67
- Supports S2B/S2A HO with MC QCIs
- Allows LTE to Wi-Fi Handover for Bearer with QCI

- Supports Bulkstats for APN and SAEGW
- MC-QCI values supports X-header insertion, DSCP marking, and EDR

**Important**

The standard QCIs supported and qualified in the CUPS architecture are 1-9, 65, 66, 67, 69, 70, 80, 82, 83.

## Limitations

The following are the known limitations of this feature:

- Does not support the overall eMPS functionality.
- If **require ecs credit-control session-mode per-subscriber** is configured, then URR is treated for entire subscriber session including secondary bearers which can lead to a problem in some applications. In CUPS, use the **credit-control-client override session-mode per-sub-session** command at the APN level to override the session mode configuration.

## Configure QCI

Use the **qci-qos-mapping** CLI command to configure the DSCP marking for QCI.

```

config
  qci-qos-mapping name
    qcinum { gbr } [ { downlink | uplink } [ user-datagram dscp-marking
dscp-marking-value ] [ encaps-header { copy-inner | copy-outer | dscp-marking
dscp-marking-value } ] ]
  end

```

**NOTES:**

- **qcinum**: Specify standard QoS Class Identifier between 1-9, 65,66,67,69,70,80,82,83 - integer 1..83.
- **gbr**: Specifies that this QCI type is Guaranteed Bit Rate (GBR).
- **downlink**: Configures parameters for downlink traffic.
- **uplink**: Configures parameters for uplink traffic.
- **encaps-header { copy-inner | copy-outer | dscp-marking dscp-marking-value }**: Specifies that the DSCP marking must be set on the encapsulation header for IP-in-IP, GRE, or GTP encapsulation.
  - **copy-inner** : Specifies that the DSCP marking is to be acquired from the UDP headers within the encapsulation.
  - **copy-outer** used to copy the DSCP value coming in the data packet from S1u interface to the data packet sent on the S5 interface and vice-versa.
  - **dscp-marking dscp-marking-value** : Specifies that the DSCP marking is to be defined by this keyword.  
*dscp-marking-value* is expressed as a hexadecimal number from 0x00 through 0x3F.

- **user-datagram dscp-marking** *dscp-marking-value*: Specifies that the IP DSCP marking is to be defined by this keyword.

*dscp-marking-value* is expressed as a hexadecimal number from 0x00 through 0x3F.

## Monitoring and Troubleshooting

This section provides information regarding monitoring and troubleshooting the feature.

### Show Command(s) and/or Outputs

This section provides information regarding show commands and/or their outputs in support of this feature.

#### show subscribers saegw-only imsi <imsi>

The output of this command includes QCI field under Bearer QoS and PCRF Authorized Bearer QoS as shown in the following example:

```
Bearer QoS      :
  QCI           : 67
  ARP           : 0x054
  PCI           : 1 (Disabled)
  PL            : 5
  PVI           : 0 (Enabled)
  MBR Uplink(bps) : 0
  GBR Uplink(bps) : 0
  MBR Downlink(bps) : 0
  GBR Downlink(bps) : 0

PCRF Authorized Bearer QoS:
  QCI: 67
  ARP: 0x054
  PCI: 1 (Disabled)
  PL : 5
  PVI: 0 (Enabled)
  MBR uplink (bps): n/a
  GBR uplink (bps): n/a
  Uplink APN AMBR (bps): 200000
  MBR downlink (bps): n/a
  GBR downlink (bps): n/a
  Downlink APN AMBR (bps): 300000
```

#### show apn statistics

The output of this command includes the following fields:

QCI 67:

- Bearer Active
- Bearer setup
- Bearer Released
- Bearer Rejected
- Uplink Bytes forwarded
- Downlink Bytes forwarded
- Uplink pkts forwarded

**show active-charging sessions full all**

- Downlink pkts forwarded
- Uplink Bytes dropped
- Downlink Bytes dropped
- Uplink pkts dropped
- Downlink pkts dropped
- Uplink Bytes dropped(MBR Excd)
- Downlink Bytes dropped(MBR Excd)
- Uplink pkts dropped(MBR Excd)
- Downlink pkts dropped(MBR Excd)

```

QCI 67:
  Bearer Active: 0 Bearer setup:
  Bearer Released: 0 Bearer Rejected:

  Uplink Bytes forwarded: 0 Downlink Bytes forwarded:
  Uplink pkts forwarded: 0 Downlink pkts forwarded:
  Uplink Bytes dropped: 0 Downlink Bytes dropped:
  Uplink pkts dropped: 0 Downlink pkts dropped:
  Uplink Bytes dropped(MBR Excd): 0 Downlink Bytes dropped(MBR Excd):
  Uplink pkts dropped(MBR Excd): 0 Downlink pkts dropped(MBR Excd):

```

**show active-charging sessions full all**

The output of this command includes the following fields:

```

Dynamic Charging Rule Definition(s) Configured:
Name          Prior Content-Id Chrg-Type Rule Parameters
-----
mcptt_audio_rule9  129      13009      Both Gate Status:      Allow All
                                   QoS Class Identifier:  67
                                   ARP Priority Level:    2
                                   Reporting Level: Rating Grp
                                   Metering Method: Durn + Vol
                                   Uplink MBR:                49000
                                   Downlink MBR:                49000
                                   Uplink GBR:                49000
                                   Downlink GBR:                49000

```

**show qci-qos-mapping table name *name***

The output of this command displays QCI 67 is configured in the **qci-qos-mapping** table.

```

[local]qvp-si# show qci-qos-mapping table
all          name
[local]qvp-si# show qci-qos-mapping table name qci-qos1
QCI-QOS Table Name: qci-qos1

```

```

Qci:          67
uplink:  user-datagram dscp-marking 0x2e encaps-header dscp-marking 0x2e
downlink: user-datagram dscp-marking 0x2e encaps-header dscp-marking 0x2e
pre-rel8-qos-mapping: n/a          qci type:          gbr

```

## Bulk Statistics

Run the following CLI to check the counters available for APN and SAEGW schema.

### show bulkstats variables saegw | grep qci67

The following list of bulkstats variables are added in **saegw** schema.

- sgw-totepsbearact-qci67
- sgw-totepsbearset-qci67
- sgw-totepsbearrel-qci67
- sgw-totepsbearmod-qci67
- sgw-totepsbearrel-dedrsn-pgw-qci67
- sgw-totepsbearrel-dedrsn-slerr-qci67
- sgw-totepsbearrel-dedrsn-s5err-qci67
- sgw-totepsbearrel-dedrsn-s4err-qci67

#### Example:

```

[local]qvpc-si# show bulkstats variables saegw | grep qci67
189 saegw %sgw-totepsbearact-qci67%      Int32    0    Gauge
204 saegw %sgw-totepsbearset-qci67%      Int32    0    Counter
221 saegw %sgw-totepsbearrel-qci67%      Int32    0    Counter
236 saegw %sgw-totepsbearmod-qci67%      Int32    0    Counter
252 saegw %sgw-totepsbearrel-dedrsn-pgw-qci67% Int32    0    Counter
269 saegw %sgw-totepsbearrel-dedrsn-slerr-qci67% Int32    0    Counter
285 saegw %sgw-totepsbearrel-dedrsn-s5err-qci67% Int32    0    Counter
301 saegw %sgw-totepsbearrel-dedrsn-s4err-qci67% Int32    0    Counter

```

Similarly, you can use the **show bulkstats variables apn | grep qci67** command to view list of bulkstats variables in **apn** schema.

```
show bulkstats variables saegw | grep qci67
```