



A

About Aironet Client Utility screen [5-28](#)

access points

- associating to [5-16](#)
- determining number and placement [7-12, 7-19, E-3](#)
- in wireless infrastructure [1-6](#)
- mismatches [7-8](#)
- positioning [E-2](#)
- problems associating to [9-3](#)
- role in wireless network [1-4](#)
- running link test from [7-12](#)
- sending out beacons [7-6, 7-15, E-4](#)
- setting MAC addresses [5-16](#)
- set to mixed WEP [5-14, 6-18](#)
- Use of Data Encryption by Stations parameter [5-14, 6-18](#)
- See also associated access point

Ack packets

- number received [7-10](#)
- number transmitted [7-10](#)

ad hoc

- mode, setting
 - in Home Network [5-23](#)
 - in Mac OS 9.x [5-3, 5-10](#)
 - in Mac OS X [6-4, 6-12](#)
- network [5-18, 7-5](#)
- parameters, advanced
 - setting [5-18 to 5-20](#)
- parameters, setting [6-4 to 6-6](#)
- wireless LAN [1-5](#)

Advanced screen [5-15, 6-10](#)

Aironet Client Utility (ACU)

- Help pull-down menu [5-27, 5-28, 6-22](#)
- Help screen [5-29, 6-22](#)

antenna

- current selection [7-5](#)
- gains [D-3](#)
- receive [5-16, 6-15](#)
- transmit [5-16, 6-15](#)

Antenna Mode (Receive) parameter

- ad hoc mode [5-19](#)
- infrastructure mode [5-16](#)

Antenna Mode (Transmit) parameter

- ad hoc mode [5-19](#)
- infrastructure mode [5-16](#)

antennas

- placement [E-2](#)
- safety guidelines [2-2](#)
- specifications [A-4](#)
- types [1-3](#)

associated access point

- current [6-3, 6-14, 7-6, 7-18, E-7](#)
- in link test [7-14](#)

IP address

- in link test [7-12, 7-13](#)

MAC address

- current [7-6, 7-18, E-7](#)
- in link test [7-14](#)
- on LSM graphical display [7-12](#)

association

- rejections [7-9](#)
- timeouts [7-9](#)

authentication

rejections 7-9

timeouts 7-9

Authentication Type status 7-4

Auto data rate setting 5-12, 5-24, 7-4

B

bandwidth 5-11, 5-17, 5-19, 5-20

base station 5-23

beacon packets

number received 7-8

number transmitted 7-10

percentage received

current 7-6

in link test 7-15

in passive site survey E-4

setting duration between 5-20

Beacon Period parameter 5-20

boot block version 7-3

broadcast packets

number received 7-8

number transmitted 7-10

bytes

number received 7-8

number transmitted 7-10

C

CAM 6-16, 7-5

Canadian compliance statement C-3

Cancel button 1-9, 1-11

caution, defined xi

channel

current 7-5, 7-17, 7-22, E-7

in passive site survey E-5

parameter with Mac OS 9.x 5-13

parameter with Mac OS X 6-4, 6-12

set 7-4

channels D-2

Client 6-23

client name

current 7-4

for home network 5-22

Client Name parameter 5-8, 6-11

client utility

removing 8-4

updating 8-2

collisions

immunity to 5-17, 5-20

multiple 7-10

recovering from 5-17, 5-19

single 7-10

configuring PC cards 5-6 to 5-26, 6-3 to 6-6

Constantly Awake Mode

See CAM

Continue button 1-9

Continuous Linktest parameter 7-13, 7-20

controlling transmission and reception of data 5-11, 6-14

conventions, document xi

CRC error

in packet 7-8

in PLCP header 7-8

CTS packets

not received 5-17, 5-20

number received 7-10

number transmitted 7-10

Current Profile parameter 5-10

D

data rate

current 7-4, 7-17, E-7

for RF link test 7-12

mismatches 7-8

parameter 5-12

supported speeds A-3, E-2

Data Retries parameter 5-11

Defaults button 1-9

diagnostics, performing 7-2, 7-16

dipole antenna 1-3

diversity antenna 1-3

diversity mode 5-16, 5-19, 6-15

driver

- problems after installation 9-3
- removing 8-4
- updating 8-2
- verifying installation 4-12, 4-17

driver verification 7-12, 7-20

duplicate packets, number received 7-8

E

Edit Properties command 4-9 to 5-7, 5-21, 5-26

EIRP, maximum D-3

enterprise

- network, setting 5-10
- parameters

 - described 5-6
 - setting 5-6 to 5-20

enter WEP keys

- command 4-4

errors

- MAC CRC 7-8
- overrun 7-8
- PLCP

 - CRC 7-8
 - format 7-8
 - length 7-8

exit

- ACU 5-29, 6-23
- screens 1-9, 1-11, 6-23

F

FCC

- declaration of conformity statement C-2
- safety compliance statement 2-2

firmware

- loading 5-4, 6-8
- version 7-3, 7-17, E-7

fragmented packets

- number discarded 7-8
- setting threshold 5-11

Fragment Threshold parameter 5-11

frequencies D-2

frequency

- access point 7-22
- current 7-5, 7-17, E-5, E-7
- home network 5-25
- Mac OS 9.x 5-13
- Mac OS X 6-4, 6-12

G

guidelines for site survey E-3

H

help

- accessing 1-9, 1-11
- ACU 5-28, 6-22

Help button 1-9, 1-11

Help pull-down menu 6-22

history of RF performance, displayed 7-12, 7-19

Home Computer Name parameter 5-22

home network 5-23

- configuration, specifying 5-26
- parameters

 - described 5-6
 - setting 5-21

- screen 4-10, 5-21

host devices [1-2, 2-3](#)

I

infrastructure

mode, setting [5-3, 5-10, 6-4, 6-12](#)

network [5-15, 7-5](#)

parameters, advanced

described [5-6](#)

setting [5-15](#)

interference

from other devices [2-4](#)

guidlines for Japan [C-6](#)

loss packets [5-11](#)

multipath environment [5-17, 5-20](#)

IP address

in link test [7-12, 7-13, 7-20](#)

L

LEAP [4-11, 4-16](#)

LEDs

description [1-4](#)

interpreting [9-2](#)

link quality

current [7-6, 7-17](#)

in link test [7-15](#)

in passive site survey [E-5](#)

link speed

current [7-4, 7-17](#)

in passive site survey [E-5](#)

Link Status Meter (LSM)

opening [7-11, 7-18](#)

screen explained [7-12, 7-19](#)

link test [7-13, 7-20](#)

LM card client adapter

antenna [1-3](#)

loading new firmware [5-4, 6-8](#)

Load New Firmware command [5-5, 6-9](#)

long radio headers, using [5-13](#)

M

MAC address

access point

current [7-6, 7-18, 7-22, E-7](#)

in link test [7-14](#)

client adapter [7-4, 7-17](#)

multiple access points [5-16](#)

PC card [E-7](#)

MAC CRC errors [7-8](#)

matching WEP keys [4-5, 4-14](#)

Max PSP [7-5](#)

microcellular network [1-6](#)

mismatches

Access Point [7-8](#)

data rate [7-8](#)

SSID [7-8](#)

modifying WEP keys [4-7, 4-15](#)

multicast packets

number received [7-8](#)

number transmitted [7-10](#)

N

NDIS driver version [7-3](#)

network

configurations [1-4 to 1-6](#)

problems connecting to [9-4](#)

Network Type

parameter [5-10, 6-4](#)

status [7-5](#)

note, defined [xi](#)

Number of Packets parameter [7-13, 7-20](#)

O

OK button [1-9](#)
 open authentication [5-12, 5-25, 6-17, 7-4](#)
 operational mode, current [7-6](#)
 overrun errors [7-8](#)
 overview [1-2](#)

P

packets

aged [7-9, 7-11](#)
 delayed
 due to 802.11 protocol reasons [7-10](#)
 due to RF energy [7-10](#)
 discarded due to time [7-9, 7-11](#)
 failed to be transmitted [7-10](#)
 for which CTS packet was not received [7-10](#)
 fragmented [5-11](#)
 partial, received [7-8](#)
 received
 of specified size in link test [7-14, 7-17, 7-21, E-7](#)
 when receive buffers not available [7-8](#)
 retransmitted
 more than once [7-10](#)
 once [7-10](#)
 retransmitting [5-11](#)
 size
 issued to RTS packet [5-17, 5-19](#)
 used for link test [7-13](#)
 to be sent
 by link test [7-13](#)
 total received [7-8](#)
 transmitted
 of specified size in link test [7-14, 7-17, 7-21, E-7](#)
 without Ack received [7-10](#)
 without delay [7-10](#)
 Packets Aged statistic [7-9, 7-11](#)
 Packet Size parameter [7-13](#)

Packets Received OK statistic in link test [7-14, 7-17, E-7](#)
 Packets Transmitted OK statistic in link test [7-14, 7-17, E-7](#)
 Partial Packets Received statistic [7-8](#)
 parts [1-3](#)
 passive mode of site survey
 described [E-3](#)
 using [E-3 to E-5](#)
 Pause button [1-9](#)
 PC card client adapter
 antenna [1-3](#)
 inserting into computing device [3-9 to 3-10](#)
 removing [8-6](#)
 PC card power save mode [7-5](#)
 PCI client adapter
 antenna [1-3](#)
 inserting into computing device [3-10 to 3-11](#)
 peer-to-peer wireless LAN [1-5](#)
 persistent WEP keys [4-6](#)
 PLCP
 CRC errors [7-8](#)
 format errors [7-8](#)
 length errors [7-8](#)
 power consumption setting [5-9, 6-16](#)
 power level, maximum [D-3](#)
 Power Save Mode
 status [7-5](#)
 See Fast PSP
 Power Save Mode parameter
 options [5-9, 6-16](#)
 setting [5-9, 6-16](#)

R

radio
 description [1-3](#)
 range [5-12, 5-13, 5-16, 5-24, 6-17](#)
 specifications [A-3](#)
 turning on or off [5-26, 6-18](#)
 Radio Off command [5-26, 6-19](#)

- Radio On command [5-26, 6-20](#)
 - radio type [7-3](#)
 - recognition problems [9-3](#)
 - regulatory
 - domains [D-2](#)
 - information [C-1 to C-6](#)
 - related publications [xiii](#)
 - Reset button [1-9](#)
 - RF exposure declaration of conformity statement [C-5](#)
 - RF link test
 - running [7-12 to 7-15, 7-20 to 7-21](#)
 - RF network
 - parameters described [5-6](#)
 - traffic, obtaining information about [E-3, E-6](#)
 - RF network coverage, determining [7-12](#)
 - RF Network screen [5-11, 6-14](#)
 - RF obstructions [2-4, E-2](#)
 - roaming [1-6](#)
 - RTS packets
 - and RTS threshold [5-17, 5-19](#)
 - number retransmitted [7-10](#)
 - number transmitted [7-10](#)
 - resending [5-17, 5-20](#)
 - RTS Retry Limit parameter
 - ad hoc mode [5-20](#)
 - infrastructure mode [5-17](#)
 - RTS Threshold parameter
 - ad hoc mode [5-19](#)
 - infrastructure mode [5-17](#)
 - running an RF link test [7-12 to 7-20](#)
 - Advanced Ad Hoc [5-18](#)
 - Advanced Connection [6-20](#)
 - Advanced Connection Parameters [6-11](#)
 - Advanced RF Settings [6-14](#)
 - Advanced Scanner [7-21](#)
 - Advanced Status [6-21, 7-16](#)
 - Basic Properties [6-19](#)
 - File Menu [6-19](#)
 - Help Menu [6-22](#)
 - Home Networking [4-10, 5-21](#)
 - LEAP Username and Password [4-11, 4-16](#)
 - Link Status Meter [7-11, 7-19](#)
 - Linktest [7-13, 7-14](#)
 - LSM [7-19](#)
 - RF Network [4-9, 5-11](#)
 - Set WEP Password [4-6](#)
 - Status [7-3, 7-16](#)
 - WEP Keys [4-7, 4-15](#)
 - seamless roaming [1-6](#)
 - selecting an existing WEP key [4-7](#)
 - sensitivity [A-3, E-2](#)
 - setting
 - ad hoc mode [5-10](#)
 - ad hoc parameters [5-18 to 5-20, 6-12](#)
 - advanced connection parameters [6-10 to 6-13](#)
 - advanced infrastructure parameters [5-15 to 5-17](#)
 - advanced RF parameters [6-14 to 6-18](#)
 - basic parameters [6-3 to 6-6](#)
 - enterprise network [5-10](#)
 - enterprise parameters [5-8](#)
 - home networking parameters [5-26](#)
 - infrastructure mode [5-3, 5-10, 6-4, 6-12](#)
 - location profiles [6-6 to 6-7](#)
 - power consumption [5-9, 6-16](#)
 - RF network parameters [5-11 to 5-14](#)
 - system parameters [5-7 to 5-10](#)
 - shared key authentication [5-12, 5-25, 6-17, 7-4](#)
 - short radio headers, using [5-13](#)
-
- S
- safety
 - information [2-2 to 2-3](#)
 - saving changes [1-9](#)
 - screens
 - About Aironet Client Utility [5-28, 6-21](#)
 - ACU Help [6-22](#)

signal strength
 current [7-6, 7-17](#)
 in link test [7-14, 7-17, 7-22, E-7](#)
 in passive site survey [E-4](#)
 on LSM graphical display [7-12, 7-19](#)
 site requirements [2-4](#)
 site survey [E-2](#)
 exiting [E-5](#)
 guidelines [E-3](#)
 passive mode [?? to E-5](#)
 performing [E-3](#)
 Site Survey command [E-3](#)
 specifications [A-2 to A-5](#)
 specified access points [5-16](#)
 spread spectrum [1-3](#)
 SSID
 mismatches [7-8](#)
 parameter [5-8, 6-5, 6-12](#)
 status [7-6, 7-18](#)
 Start button [1-9, 7-13, 7-20](#)
 statistics
 for PC card [7-7 to 7-11](#)
 transmit [7-10 to 7-11](#)
 Statistics command [7-7, 7-9](#)
 Status
 command [7-2, 7-16](#)
 statistic in link test [7-14](#)
 system parameters
 described [5-6](#)
 screen [4-8, 5-7](#)
 setting [5-7 to 5-10](#)
 system requirements [2-3](#)

T

TAC, contacting [4-15](#)
 TCP/IP
 required for link test [7-12, 7-20](#)
 verification [7-12, 7-20](#)

technical specifications [A-2 to A-5](#)
 Telnet, running link test from [7-12](#)
 temporary WEP keys [4-6](#)
 testing the RF link [7-12, 7-19, 7-20](#)
 throughput [5-9, 5-11 to 5-13, 5-24](#)
 transmit key, selecting [4-5, 4-14](#)
 Transmit Power parameter [5-13, 6-17](#)
 transmit statistics [7-10 to 7-11](#)
 troubleshooting information
 location on CCO [9-2](#)
 procedures [9-2](#)
 turning radio on or off [5-26, 6-18](#)

U

unicast packets
 number received [7-8](#)
 number transmitted [7-10](#)
 up time [7-9, 7-11](#)

V

version
 boot block [7-3](#)
 firmware [7-3, 7-17, E-7](#)
 NDIS 3 device driver [7-3](#)

W

Wake Duration parameter [5-20](#)
 warnings [2-3, B-2 to B-4](#)
 WEP
 determining status of [7-4](#)
 enabling [4-4, 4-12](#)

WEP keys

- assigning to same numbers [4-5, 4-14](#)
 - characteristics of [4-5, 4-14](#)
 - entering [4-4 to 4-5, 4-12 to 4-14](#)
 - for home network [5-22](#)
 - matching [4-5, 4-14](#)
 - modifying [4-5](#)
 - persistent [4-6](#)
 - selecting an existing key [4-7, 4-14](#)
 - temporary [4-6](#)
- wireless infrastructure [1-6](#)
- workstations
- defined [1-3](#)
 - positioning [E-2](#)