

Procedimiento para recuperación de contraseña para los Catalyst 6500/6000 Series Switch que funcionan con el software del sistema del Cisco IOS

Contenido

[Introducción](#)

[prerrequisitos](#)

[Requisitos](#)

[Componentes Utilizados](#)

[Antecedente](#)

[Convenciones](#)

[Procedimiento Paso a Paso](#)

[Ejemplo de Salida](#)

[Información Relacionada](#)

Introducción

Este documento explica cómo recuperar una contraseña en los switches Catalyst 6500/6000 Series y los routers Cisco 7600 Series que funcionan con el software del sistema Cisco IOS®.

prerrequisitos

Requisitos

No hay requisitos específicos para este documento.

Componentes Utilizados

Este documento se aplica al Supervisor 1, al supervisor 2, al supervisor 720, y al sistema de transferencia virtual (VSS) 1440 sistemas basados. Para los sistemas basados del supervisor 720, este documento se aplica cuando funciona con el Cisco IOS Software Release 12.2(17)SX o más adelante. Si su supervisor 720 funciona con una versión antes de esto, refiera al [procedimiento para recuperación de contraseña para el Catalyst 6500 con el software corriente del software del sistema del Cisco IOS del supervisor 720 antes de 12.2\(17\)SX](#).

Note: El software admitido para el sistema de transferencia virtual (VSS) 1440 sistemas basados es Software Release 12.2(33)SXH1 o Posterior de Cisco IOS®.

Antecedente

La secuencia de arranque es diferente en el Catalyst 6500/6000 y el Cisco 7600 que funcionan con el software del sistema del Cisco IOS que el Cisco 7200 Series Router porque el hardware es diferente. Después de que usted ciclo de la potencia el cuadro, el switch processor (SP) arranque primero. Después de una pequeña cantidad de hora (aproximadamente 25 a 60 segundos) transfiere la propiedad de la consola al Route Processor ((MSFC) RP). El RP continúa cargando la imagen del software unida. Es crucial que usted presiona el **Ctrl-brk** enseguida después que el SP entrega el control de la consola al RP. Si usted envía la secuencia de interrupción demasiado pronto, usted termina para arriba en el ROMMON del SP, que no es donde usted debe ser. Envíe la secuencia de interrupción después de que usted vea este mensaje en la consola:

```
00:00:03: %OIR-6-CONSOLE: Changing console ownership to route processor
```

Después de este punto, la recuperación de contraseña es similar a un router normal.

Note: Desde aquí, el Catalyst 6000 Series Switch que funciona con el software del sistema del Cisco IOS se refiere como router.

Convenciones

Para obtener más información sobre las convenciones del documento, consulte las [Convenciones de Consejos Técnicos de Cisco](#).

Procedimiento Paso a Paso

El Switch se configura como un router debido al sistema operativo que se ejecuta en el Switch. El procedimiento para recuperación de contraseña sigue los mismos pasos que un Cisco 7200 Series Router, salvo que usted tiene que esperar aproximadamente 25 a 60 segundos más de largo antes de que usted comience la secuencia de interrupción.

1. Conecte un terminal o una PC con emulación de terminal al puerto de consola del router.
Use estas configuraciones de terminal:
9600 baud rate
No parity
8 data bits
1 stop bit
No flow control
[Las especificaciones para el cable de la consola requerido se describen en el documento Especificaciones del cable](#). Las instrucciones en cómo conectar con el puerto de la consola están en la [guía de instalación de módulos](#). [La conexión con la Sección Sólo puerto de la consola/Supervisor Engine](#) proporciona la información útil.
2. Si aún tiene acceso al router, ejecute el comando show version y grabe la configuración del registro de la configuración. En general es 0x2102 o 0x102. [Haga clic aquí para ver el resultado de un comando show version](#).
3. Si usted no tiene acceso al router (debido a un nombre de usuario o contraseña de TACACS perdido), su registro de la configuración se fija a 0x2102.
4. Apague al router y después devuélvalo encendido con la ayuda del botón interruptor de encendido.
5. **Caution:** La secuencia de interrupción debe ser iniciada solamente después que el RP gana

el control del puerto de la consola. Presione la **rotura** en el teclado de la terminal justo después de que el RP gana el control del puerto de la consola. En el Catalyst 6000 que funciona con el Cisco IOS Software, el SP inicia primero. Después de que haya iniciado, da la vuelta al control al RP. Después de que el RP gane el control, inicie la secuencia de interrupción. El RP gana el control del puerto de la consola cuando usted ve este mensaje. (No iniciar la secuencia de interrupción hasta ver este mensaje):

```
00:00:03: %OIR-6-CONSOLE: Changing console ownership to route processor
```

Desde aquí, el procedimiento para recuperación de contraseña es lo mismo que para cualquier otro router. Si la secuencia de interrupción no trabaja, refiera a las [combinaciones de secuencias de teclas de interrupción estándar durante la recuperación de contraseña](#) para otras combinaciones de claves.

6. Escriba `confreg 0x2142` cuando aparezca el mensaje `rommon 1>` para reiniciar desde Flash sin cargar la configuración.
7. Escriba **reset** cuando aparezca la indicación `rommon 2>`. Las reinicializaciones del router. Sin embargo, ignora la configuración guardada.
8. Escriba `no` luego de cada pregunta de configuración, o presione `Ctrl-C` para saltar el procedimiento de configuración inicial.
9. Escriba `enable` cuando aparezca la indicación `Router>`. Usted está en el **enable mode** y ve el prompt del `Router-`.
10. **Importante:** Publique los **comandos `configure memory` o `copy start running`** de copiar memoria RAM no volátil (NVRAM) en la memoria. No ejecute el comando `configure terminal`.
11. Ejecute el comando `write terminal` o `show running`. Los comandos `show running` y `write terminal` muestran la configuración del router. En esta configuración, usted ve bajo todas las interfaces el **comando `shutdown`**. Esto significa que todas las interfaces están apagadas actualmente. Usted ve las contraseñas cualquier adentro formato encriptado o no encriptado.
12. Publique el **comando `configure terminal`** de ingresar al modo de configuración global y de realizar los cambios. El mensaje ahora es `hostname(config)#`.
13. Publique el **comando `enable secret < password >`** en el modo de configuración global de cambiar la **contraseña habilitada**.
14. Ejecute el comando `config-register 0x2102` o el valor registrado en el Paso 2 en el modo de configuración global (`Router(config)#`) para restablecer el valor de configuración a su valor original.
15. Cambie las contraseñas de terminal virtual, si presente:

```
Router(config)#line vty 0 4
Router(config-line)#password cisco
Router(config-line)#^Z
Router#
```

16. Publique el **comando `no shutdown`** en cada interfaz que sea normalmente funcionando. Publique un **comando `show ip interface brief`** de ver una lista de interfaces y su estado actual. Para ejecutar el comando `show ip interface brief`, debe estar en modo habilitar (`Router#`). Aquí tiene un ejemplo para una interfaz:

```
Router#show ip interface brief
Interface                IP-Address      OK? Method Status      Pro1
Vlan1                    172.17.10.10   YES TFTP    administratively down dow
Vlan10                   10.1.1.1       YES TFTP    administratively down dow
GigabitEthernet1/1      unassigned     YES unset   administratively down dow
GigabitEthernet1/2      unassigned     YES TFTP    administratively down dow
GigabitEthernet2/1      unassigned     YES TFTP    administratively down dow
GigabitEthernet2/2      unassigned     YES TFTP    administratively down dow
```

```
FastEthernet3/1          172.16.84.110   YES TFTP   administratively down dow
<snip>...
```

```
Router#configure terminal
```

```
Enter configuration commands, one per line.  End with CNTL/Z.
```

```
Router(config)#interface fastEthernet 3/1
```

```
Router(config-if)#no shutdown
```

```
Router(config-if)#exit
```

```
Router(config)# <do other interfaces as necessary...>
```

17. Presione Ctrl-z para salir del modo de configuración.El mensaje ahora es hostname##.

18. Publique los **comandos write memory o copy running startup** de confiar los cambios.

Ejemplo de Salida

El ejemplo aquí muestra un procedimiento para recuperación de contraseña real. Este ejemplo se crea con la ayuda de un Catalyst 6000 Series Switch. Comience con los **comandos show version and show module** de ver qué componentes se utilizan en este ejemplo.

```
Press RETURN to get started.
```

```
Router>enable
```

```
Password:
```

```
Router#show version
```

```
Cisco Internetwork Operating System Software
```

```
IOS (tm) c6sup1_rp Software (c6sup1_rp-JSV-M), Version 12.1(6)E, EARLY DEPLOYME
```

```
TAC Support: http://www.cisco.com/cgi-bin/ibld/view.pl?i=support
```

```
Copyright (c) 1986-2001 by cisco Systems, Inc.
```

```
Compiled Sat 17-Mar-01 00:14 by eaarmas
```

```
Image text-base: 0x60020950, data-base: 0x6165E000
```

```
ROM: System Bootstrap, Version 12.0(3)XE, RELEASE SOFTWARE
```

```
BOOTFLASH: MSFC Software (C6MSFC-BOOT-M), Version 12.1(6)E, EARLY DEPLOYMENT RE)
```

```
Router uptime is 14 minutes
```

```
System returned to ROM by power-on (SP by reload)
```

```
System image file is "sup-bootflash:c6sup11-jsv-mz.121-6.E"
```

```
Cisco Catalyst 6000 (R5000) processor with 114688K/16384K bytes of memory.
```

```
Processor board ID SAD04281AF6
```

```
R5000 CPU at 200Mhz, Implementation 35, Rev 2.1, 512KB L2 Cache
```

```
Last reset from power-on
```

```
Bridging software.
```

```
X.25 software, Version 3.0.0.
```

```
SuperLAT software (copyright 1990 by Meridian Technology Corp).
```

```
TN3270 Emulation software.
```

```
24 Ethernet/IEEE 802.3 interface(s)
```

```
2 Virtual Ethernet/IEEE 802.3 interface(s)
```

```
48 FastEthernet/IEEE 802.3 interface(s)
```

```
4 Gigabit Ethernet/IEEE 802.3 interface(s)
```

```
381K bytes of non-volatile configuration memory.
```

```
4096K bytes of packet SRAM memory.
```

```
16384K bytes of Flash internal SIMM (Sector size 256K).
```

```
Configuration register is 0x2102
```

```
Router#
```

```
Router#show module
```

```
Slot Ports Card Type
```

```
Model
```

```
Serial Number
```

```
-----
```

```

1      2      Cat 6000 sup 1 Enhanced QoS (active)      WS-X6K-SUP1A-2GE      SAD043301JS
2      2      Cat 6000 sup 1 Enhanced QoS (standby)    WS-X6K-SUP1A-2GE      SAD03510114
3      48     48 port 10/100 mb RJ45                   WS-X6348-RJ-45        SAD04230FB6
6      24     24 port 10baseFL                           WS-X6024-10FL-MT      SAD03413322

```

```

Slot MAC addresses                Hw   Fw           Sw
-----
1   00d0.c0d2.5540 to 00d0.c0d2.5541  3.2  unknown      6.1(0.105)OR
2   00d0.bcf1.9bb8 to 00d0.bcf1.9bb9  3.2  unknown      6.1(0.105)OR
3   0002.7ef1.36e0 to 0002.7ef1.370f  1.1  5.3(1) 1999- 6.1(0.105)OR
6   00d0.9738.5338 to 00d0.9738.534f  0.206 5.3(1) 1999- 6.1(0.105)OR

```

Router#

Router#**reload**

Proceed with reload? [confirm]

```

!--- Here you turn off the power and then turn it back on. !--- Here it is done with a reload
instead of a hard power-cycle. 00:15:28: %SYS-SP-3-LOGGER_FLUSHING: System pausing to ensure
console debugging. 00:15:27: %C6KPWR-SP-4-DISABLED: power to module in slot 2 set off (admin
reque) 00:15:28: %C6KPWR-SP-4-DISABLED: power to module in slot 3 set off (admin reque)
00:15:28: %C6KPWR-SP-4-DISABLED: power to module in slot 6 set off (admin reque) 00:15:28: %OIR-
SP-6-CONSOLE: Changing console ownership to switch processor 00:15:28: %SYS-SP-3-LOGGER_FLUSHED:
System was paused for 00:00:00 to ensure co. 00:15:30: %SYS-SP-3-LOGGER_FLUSHING: System pausing
to ensure console debugging. *** *** --- SHUTDOWN NOW --- *** 00:15:30: %SYS-SP-5-RELOAD: Reload
requested 00:15:30: %OIR-SP-6-CONSOLE: Changing console ownership to switch processor 00:15:30:
%SYS-SP-3-LOGGER_FLUSHED: System was paused for 00:00:00 to ensure co. 00:15:31: %OIR-SP-6-
REMCARD: Card removed from slot 1, interfaces disabled !--- First, the switch processor comes
up. System Bootstrap, Version 5.3(1) Copyright (c) 1994-1999 by cisco Systems, Inc. c6k_sup1
processor with 65536 Kbytes of main memory Autoboot executing command: "boot bootflash:c6sup11-
jsv-mz.121-6.E" Self decompressing the image : #####]
Restricted Rights Legend Use, duplication, or disclosure by the Government is subject to
restrictions as set forth in subparagraph (c) of the Commercial Computer Software - Restricted
Rights clause at FAR sec. 52.227-19 and subparagraph (c) (1) (ii) of the Rights in Technical
Data and Computer Software clause at DFARS sec. 252.227-7013. Cisco Systems, Inc. 170 West
Tasman Drive San Jose, California 95134-1706 Cisco Internetwork Operating System Software IOS
(TM) c6sup1_sp Software (c6sup1_sp-SPV-M), Version 12.1(6)E, EARLY DEPLOYME) TAC Support:
http://www.cisco.com/cgi-bin/ibld/view.pl?i=support Copyright (c) 1986-2001 by cisco Systems,
Inc. Compiled Sat 17-Mar-01 00:52 by eaarmas Image text-base: 0x60020950, database: 0x605FC000
Start as Primary processor 00:00:03: %SYS-3-LOGGER_FLUSHING: System pausing to ensure console
debugging ou. 00:00:03: %OIR-6-CONSOLE: Changing console ownership to route processor

```

```

!--- The RP now has control of the console. !--- This is when you send the break sequence.
System Bootstrap, Version 12.0(3)XE, RELEASE SOFTWARE Copyright (c) 1998 by cisco Systems, Inc.
*** Address Error (Load/Fetch) Exception *** Access address = 0x5e PC = 0x5e, Cause = 0x10,
Status Reg = 0x3040d003 ROM Monitor Can Not Recover From Exception A Board Reset Is Issued ***
Software NMI *** PC = 0xbfc0b6b0, SP = 0x00002a90 Cat6k-MSFC platform with 131072 Kbytes of main
memory Self decompressing the image : #####] ***
System received an abort due to Break Key *** signal= 0x3, code= 0x0, context= 0x6049ed68 PC =
0x601011ac, Cause = 0x20, Status Reg = 0x34008002 !--- You are now in ROMMON mode on the RP.
Continue the password !--- recovery procedure just as on any router. Changing the configuration
!--- register from 0x2102 to 0x2142 causes the router to ignore the existing !--- configuration.
You want it to be ignored because it has passwords that you do not !--- know. rommon 1 > confreg
0x2142

```

You must reset or power cycle for new config to take effect
rommon 2 > **reset**

```

System Bootstrap, Version 12.0(3)XE, RELEASE SOFTWARE
Copyright (c) 1998 by cisco Systems, Inc.
Cat6k-MSFC platform with 131072 Kbytes of main memory

```

Self decompressing the image : #####]

Attempt to download 'sup-bootflash:c6sup11-jsv-mz.121-6.E' ... okay
Starting download of 'sup-bootflash:c6sup11-jsv-mz.121-6.E': 8722810 bytes!!!!!!
Chksum: Verified!
Self decompressing the image : #####]

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) of the Commercial Computer Software - Restricted Rights clause at FAR sec. 52.227-19 and subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS sec. 252.227-7013.

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, California 95134-1706

Cisco Internetwork Operating System Software
IOS (TM) c6sup1_RP Software (c6sup1_rp-JSV-M), Version 12.1(6)E, EARLY DEPLOYME
TAC Support: <http://www.cisco.com/cgi-bin/ibld/view.pl?i=support>
Copyright (c) 1986-2001 by Cisco Systems, Inc.
Compiled Sat 17-Mar-01 00:14 by eaarmas
Image text-base: 0x60020950, database: 0x6165E000

Cisco Catalyst 6000 (R5000) processor with 114688K/16384K bytes of memory.
Processor board ID SAD04281AF6
R5000 CPU at 200Mhz, Implementation 35, Rev 2.1, 512KB L2 Cache
Last reset from power-on
Bridging software.
X.25 software, Version 3.0.0.
SuperLAT software (copyright 1990 by Meridian Technology Corp).
TN3270 Emulation software.
24 Ethernet/IEEE 802.3 interface(s)
1 Virtual Ethernet/IEEE 802.3 interface(s)
48 FastEthernet/IEEE 802.3 interface(s)
4 Gigabit Ethernet/IEEE 802.3 interface(s)
381K bytes of nonvolatile configuration memory.
4096K bytes of packet SRAM memory.

16384K bytes of Flash internal SIMM (Sector size 256K).

--- System Configuration Dialog ---

Would you like to enter the initial configuration dialog? [yes/no]: n

!--- The router ignores the saved configuration and enters !--- the initial configuration mode.
Press RETURN to get started! 00:00:03: %SYS-3-LOGGER_FLUSHED: System was paused for 00:00:00 to ensure conso. 00:00:04: %C6KPWR-4-PSINSERTED: power supply inserted in slot 1. 00:00:04: %C6KPWR-4-PSOK: power supply 1 turned on. 00:02:08: %SYS-SP-5-RESTART: System restarted -- Cisco Internetwork Operating System Software IOS (TM) c6sup1_SP Software (c6sup1_sp-SPV-M), Version 12.1(6)E, EARLY DEPLOYME) TAC Support: <http://www.cisco.com/cgi-bin/ibld/view.pl?i=support> Copyright (c) 1986-2001 by cisco Systems, Inc. Compiled Sat 17-Mar-01 00:52 by eaarmas 00:02:13: L3-MGR: 12 flush entry installed 00:02:13: L3-MGR: 13 flush entry installed 00:02:14: %SYS-5-RESTART: System restarted -- Cisco Internetwork Operating System Software IOS (TM) c6sup1_RP Software (c6sup1_rp-JSV-M), Version 12.1(6)E, EARLY DEPLOYME) TAC Support: <http://www.cisco.com/cgi-bin/ibld/view.pl?i=support> Copyright (c) 1986-2001 by Cisco Systems, Inc. Compiled Sat 17-Mar-01 00:14 by eaarmas 00:02:17: %C6KPWR-SP-4-DISABLED: power to module in slot 1 set off (admin reque) 00:02:18: %C6KPWR-SP-4-ENABLED: power to module in slot 3 set on 00:02:18: %C6KPWR-SP-4-ENABLED: power to module in slot 6 set on 00:02:28: sm_set_moduleFwVersion: nonexistent module (1) 00:02:38: %SNMP-5-MODULETRAP: Module 1 [Up] Trap 00:02:38: %OIR-SP-6-INSCARD: Card inserted in slot 1, interfaces are now online 00:02:56: %SNMP-5-MODULETRAP: Module 6 [Up] Trap 00:02:56: %OIR-SP-6-INSCARD: Card inserted in slot 6, interfaces are now online 00:02:59: SP: SENDING INLINE_POWER_DAUGHTERCARD_MSG SCP MSG 00:02:59:

%SNMP-5-MODULETRAP: Module 3 [Up] Trap 00:02:59: %OIR-SP-6-INSCARD: Card inserted in slot 3, interfaces are now online Router>**enable**
Router#

!--- You go right into privilege mode without needing a password. !--- At this point, the configuration running-config is a default configuration !--- with all the ports administratively down (shutdown). Router#**copy startup-config running-config**
Destination filename [running-config]? <press enter>

!--- This pulls in the original configuration. Since you are already in privilege !--- mode, the passwords in this configuration do not affect you. 4864 bytes copied in 2.48 secs (2432 bytes/sec) Router#**configure terminal**
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#**enable secret < password > [Choose a strong password with at least one capital letter, one number, and one special character.]**

!--- Overwrite the password that you do not know. This is your new enable password.
Router(config)#**^Z**
Router#

Router#**show ip interface brief**

Interface	IP-Address	OK?	Method	Status	Pro
Vlan1	172.17.10.10	YES	TFTP	administratively down	dow
Vlan10	10.1.1.1	YES	TFTP	administratively down	dow
GigabitEthernet1/1	unassigned	YES	unset	administratively down	dow
GigabitEthernet1/2	unassigned	YES	TFTP	administratively down	dow
GigabitEthernet2/1	unassigned	YES	TFTP	administratively down	dow
GigabitEthernet2/2	unassigned	YES	TFTP	administratively down	dow
FastEthernet3/1	172.16.84.110	YES	TFTP	administratively down	dow

<snip>...

!--- Issue the no shut command on all interfaces that you want to bring up.

Router#**configure terminal**
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#**interface fastEthernet 3/1**
Router(config-if)#**no shutdown**
Router(config-if)#**exit**

!--- Overwrite the virtual terminal passwords. Router(config)#**line vty 0 4**
Router(config-line)#**password cisco**
Router(config-line)#**^Z**
Router#

!--- Restore the configuration register to its normal state so that it !--- no longer ignores the stored configuration file. Router#**show version**

Cisco Internetwork Operating System Software
IOS (tm) c6sup1_rp Software (c6sup1_rp-JSV-M), Version 12.1(6)E, EARLY DEPLOYME
TAC Support: <http://www.cisco.com/cgi-bin/ibld/view.pl?i=support>
Copyright (c) 1986-2001 by cisco Systems, Inc.
Compiled Sat 17-Mar-01 00:14 by eaarmas
Image text-base: 0x60020950, data-base: 0x6165E000

ROM: System Bootstrap, Version 12.0(3)XE, RELEASE SOFTWARE
BOOTFLASH: MSFC Software (C6MSFC-BOOT-M), Version 12.1(6)E, EARLY DEPLOYMENT RE)

Router uptime is 7 minutes
System returned to ROM by power-on (SP by reload)
System image file is "sup-bootflash:c6sup11-jsv-mz.121-6.E"

Cisco Catalyst 6000 (R5000) processor with 114688K/16384K bytes of memory.
Processor board ID SAD04281AF6
R5000 CPU at 200Mhz, Implementation 35, Rev 2.1, 512KB L2 Cache
Last reset from power-on

Bridging software.
X.25 software, Version 3.0.0.
SuperLAT software (copyright 1990 by Meridian Technology Corp).
TN3270 Emulation software.
24 Ethernet/IEEE 802.3 interface(s)
2 Virtual Ethernet/IEEE 802.3 interface(s)
48 FastEthernet/IEEE 802.3 interface(s)
4 Gigabit Ethernet/IEEE 802.3 interface(s)
381K bytes of non-volatile configuration memory.
4096K bytes of packet SRAM memory.

16384K bytes of Flash internal SIMM (Sector size 256K).

Configuration register is 0x2142

Router#**configure terminal**

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#**config-register 0x2102**

Router(config)#**^Z**

Router#

!--- Verify that the configuration register is changed for the next reload. Router#**show version**

Cisco Internetwork Operating System Software
IOS (tm) c6sup1_rp Software (c6sup1_rp-JSV-M), Version 12.1(6)E, EARLY DEPLOYME
TAC Support: <http://www.cisco.com/cgi-bin/ibld/view.pl?i=support>
Copyright (c) 1986-2001 by cisco Systems, Inc.
Compiled Sat 17-Mar-01 00:14 by eaarmas
Image text-base: 0x60020950, data-base: 0x6165E000

ROM: System Bootstrap, Version 12.0(3)XE, RELEASE SOFTWARE

BOOTFLASH: MSFC Software (C6MSFC-BOOT-M), Version 12.1(6)E, EARLY DEPLOYMENT RE)

Router uptime is 8 minutes

System returned to ROM by power-on (SP by reload)

System image file is "sup-bootflash:c6sup11-jsv-mz.121-6.E"

Cisco Catalyst 6000 (R5000) processor with 114688K/16384K bytes of memory.

Processor board ID SAD04281AF6

R5000 CPU at 200Mhz, Implementation 35, Rev 2.1, 512KB L2 Cache

Last reset from power-on

Bridging software.

X.25 software, Version 3.0.0.

SuperLAT software (copyright 1990 by Meridian Technology Corp).

TN3270 Emulation software.

24 Ethernet/IEEE 802.3 interface(s)

2 Virtual Ethernet/IEEE 802.3 interface(s)

48 FastEthernet/IEEE 802.3 interface(s)

4 Gigabit Ethernet/IEEE 802.3 interface(s)

381K bytes of non-volatile configuration memory.

4096K bytes of packet SRAM memory.

16384K bytes of Flash internal SIMM (Sector size 256K).

Configuration register is 0x2142 (**will be 0x2102 at next reload**)

Router#

Router#**copy running-config startup-config**

Destination filename [startup-config]? **<press enter>**

Building configuration...

[OK]

Router#

!--- Optional: If you want to test that the router !--- operates properly and that you have changed !--- the passwords, then reload and test. Router#**reload**

Proceed with reload? [confirm] **<press enter>**

[Información Relacionada](#)

- [Página de Soporte de LAN Switching](#)
- [Páginas de Soporte de Productos de LAN](#)
- [Soporte de Producto para Switches de ATM y Catalyst de LAN](#)
- [Soporte Técnico - Cisco Systems](#)