

Contenu

[Introduction](#)

[Conditions préalables](#)

[Conditions requises](#)

[Composants utilisés](#)

[Conventions](#)

[Configuration](#)

[Commandes VoIP](#)

[résumé de show voice port](#)

[résumé de show voice call](#)

[résumé de show dial-peer voice](#)

[brief de show call active voice](#)

[show voice dsp](#)

[Annexe](#)

[Informations connexes](#)

[Introduction](#)

Ce document couvre les objets équivalents MIB qui fournissent les informations contenues dans diverses commandes de vérification de la voix sur ip (VoIP). Les applications et/ou les scripts NMS peuvent potentiellement utiliser ces informations.

[Conditions préalables](#)

[Conditions requises](#)

Aucune spécification déterminée n'est requise pour ce document.

[Composants utilisés](#)

Ce document n'est pas limité aux versions de logiciel spécifiques. Cependant, on lui écrit spécifiquement pour un routeur de gamme Cisco 3600 avec une carte NM-2V.

Les informations contenues dans ce document ont été créées à partir des périphériques d'un environnement de laboratoire spécifique. Tous les périphériques utilisés dans ce document ont démarré avec une configuration effacée (par défaut). Si votre réseau est opérationnel, assurez-vous que vous comprenez l'effet potentiel de toute commande.

[Conventions](#)

Pour plus d'informations sur les conventions de documents, reportez-vous à [Conventions relatives aux conseils techniques Cisco](#).

Configuration

Cette sortie affiche une partie appropriée de la configuration que ce document l'utilise :

```
VoipRouter#show running-configurationBuilding configuration...Current configuration : 5412
bytes!version 12.3...!snmp-server community public RO!...!voice-port 2/0/0!...!dial-peer voice
2000 pots destination-pattern 2000 port 2/0/0!dial-peer voice 1000 voip destination-pattern 1000
session target ipv4:172.16.99.22!...end
```

Commandes VoIP

Ces sections affichent les objets MIB qui correspondent à la sortie de ces commandes de vérification VoIP :

- [résumé de show voice port](#) (pour la carte NM-2V seulement)
- [résumé de show voice call](#)
- [résumé de show dial-peer voice](#)
- [brief de show call active voice](#) (pour la plate-forme de Cisco 3600 seulement)
- [show voice dsp](#) (pour la carte NM-HDV seulement)

Les informations que ces la vérification VoIP commande contiennent peuvent être extraites d'[IF-MIB](#), de [CISCO-VOICE-IF-MIB](#), de [CISCO-VOICE-ANALOG-IF-MIB](#), de [CISCO-VOICE-DIAL-CONTROL-MIB](#), de [DIAL-CONTROL-MIB](#), et de [CISCO-DSP-MGMT-MIB](#).

Remarque: Dans ces exemples, le tronçon de téléphonie est indexé par 1102799 et H.323 le tronçon est indexé par 1102966.

[résumé de show voice port](#)

Remarque: Le texte en gras dans la commande **récapitulative de show voice port** est tracé les grandes lignes dans la section [équivalente d'objets MIB](#).

```
VoipRouter#show voice port summary                                     IN          OUTPORT
CH  SIG-TYPE  ADMIN OPER  STATUS      STATUS      EC===== == =====
=====                ==2/0/0(A1) -- fxs-ls(A2)  up(A3)up(A4) off-hook(A5) idle      y(A6) 2/0/1
--  fxs-ls   up    dorm  on-hook    idle       y
```

[Objets équivalents MIB](#)

```
A1 ? IF-MIB::ifDescr.37 = STRING: Foreign Exchange Station 2/0/0A2 ? CISCO-VOICE-ANALOG-IF-
MIB::cvaIfFXSCfgSignalType.37 = INTEGER: fxsLoopStart(1)A3 ? IF-MIB::ifAdminStatus.37 =
INTEGER: up(1)A4 ? IF-MIB::ifOperStatus.37 = INTEGER: up(1)A5 ? CISCO-VOICE-ANALOG-IF-
MIB::cvaIfFXSHookStatus.37 = INTEGER: offHook(2)A6 ? CISCO-VOICE-IF-
MIB::cvIfCfigEchoCancelEnable.37 = INTEGER: true(1)
```

Remarque: Aucun objet MIB ne met à jour la valeur contenue dans la partie `ch` de la commande **récapitulative de show voice port** quand la carte NM-2V est utilisée.

[résumé de show voice call](#)

Remarque: Le texte en gras dans la commande **récapitulative de show voice call** est tracé les grandes lignes dans la section [équivalente d'objets MIB](#).

```
VoipRouter#show voice call summaryPORT          CODEC      VAD  VTSP STATE          VPM
STATE=====
===== ==
===== =2/0/0(B1)
```

Objets équivalents MIB

B1 ? IF-MIB::ifDescr.37 = STRING: Foreign Exchange Station 2/0/0**B2** ? CISCO-VOICE-COMMON-DIAL-CONTROL-MIB::cvCommonDcCallActiveCoderTypeRate. 1102966.1 = INTEGER:
ietfg729r8000(25)**B3** ? CISCO-VOICE-COMMON-DIAL-CONTROL-MIB::cvCommonDcCallActiveVADEnable.
1102966.1 = INTEGER: true(1)

Remarque: Aucun objet MIB ne met à jour le fournisseur de service de téléphonie voix (VTSP) et des états VPM individuellement. CallActiveCallState d'utilisation de DIAL-CONTROL-MIB à la place.

résumé de show dial-peer voice

Remarque: Le texte en gras dans la commande récapitulative de show dial-peer voice est tracé les grandes lignes dans la section équivalente d'objets MIB.

```
VoipRouter#show dial-peer voice summarydial-peer hunt 0 AD
PRE PASSTAG TYPE MIN OPER PREFIX DEST-PATTERN FER THRU SESS-TARGET
PORT2000(C1) pots(C2) up(C3) up(C4) 9(C5) 2000(C6) 0(C7) 2/0/0(C8)1000
voip up up 1000 0 syst ipv4:172.16.99.22(C9)
```

Objets équivalents MIB

C1 ? CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCfgIfIndex.2000 = INTEGER: 90 ? DIAL-CONTROL-MIB::dialCtlPeerCfgLowerIf.2000.90 = INTEGER: 37**C2** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCfgType.2000 = INTEGER: voice(1)**C3** ? IF-MIB::ifAdminStatus.37 = INTEGER: up(1)**C4** ? IF-MIB::ifOperStatus.37 = INTEGER: up(1)**C5** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoicePeerCfgDialDigitsPrefix.90 = STRING: 9**C6** ? DIAL-CONTROL-MIB::dialCtlPeerCfgOriginateAddress.2000.90 = STRING: 2000**C7** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgPreference.90 = INTEGER: 0**C8** ? IF-MIB::ifDescr.37 = STRING: Foreign Exchange Station 2/0/0**C9** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPPeerCfgSessionTarget.91 = STRING: ipv4:172.16.99.22

Remarque: Aucun objet MIB ne met à jour la valeur contenue dans le modem TRAVERSEMENT la partie de méthode de la commande de résumé de cadran-pair d'exposition.

brief de show call active voice

Remarque: Le texte en gras dans la commande brief de show call active voice est tracé les grandes lignes dans la section équivalente d'objets MIB.

```
VoIPRouter#show call active voice brief <ID>:<start>hs.<index> +<connect> pid:<peer_id> <dir>
<addr> <state> dur hh:mm:ss tx:<packets>/<bytes> rx:<packets>/<bytes> IP <ip>:<udp>
rtt:<time>ms pl:<play>/<gap>ms lost:<lost>/<early>/<late> delay:<last>/<min>/<max>ms <codec>
MODEMPASS <method> buf:<fills>/<drains> loss <overall%> <multipkt>/<corrected> last <buf
event time>s dur:<Min>/<Max>s FR <protocol> [int dlci cid] vad:<y/n> dtmf:<y/n> seq:<y/n>
sig:<on/off> <codec> (payload size) ATM <protocol> [int vpi/vci cid] vad:<y/n> dtmf:<y/n>
seq:<y/n> sig:<on/off> <codec> (payload size) Tele <int>:tx:<tot>/<v>/<fax>ms <codec>
noise:<l> acom:<l> i/o:<l>/<l> dBm MODEMRELAY info:<rcvd>/<sent>/<resent> xid:<rcvd>/<sent>
total:<rcvd>/<sent>/<drops> Proxy <ip>:<audio udp>,<video udp>,<tcp0>,<tcp1>,<tcp2>,<tcp3>
endpt: <type>/<manf> bw:<req>/<act> codec:<audio>/<video> tx:<audio pkts>/<audio
bytes>,<video pkts>/<video bytes>,<t120 pkts>/<t120 bytes> rx:<audio pkts>/<audio
bytes>,<video pkts>/<video bytes>,<t120 pkts>/<t120 bytes> Telephony call-legs: 1SIP call-
legs: 0H323 call-legs: 1MGCP call-legs: 0Total call-legs: 211D9 : 1102799(D1)hs.1 +1324
pid:2000(D2) Answer(D3) 2000(D4) active(D5) dur 1d19h(D6) tx:7875641(D7)/157512782(D8)
rx:7875955(D9)/157519081(D10) Tele 2/0/0(D11):1: tx:157515460(D12)/157514630(D13)/0ms
g729r8(D14) noise:-56(D15) acom:5(D16) i/o:-40(D17)/-46(D18) dBm11D9 : 1102966hs.1 +1157
```

pid:1000 Originate 1000 active dur 1d19h tx:7875388/157507741 rx:7875641/157512782 IP 172.16.99.22(D19):19066(D20) rtt:6ms(D21) pl:157496940(D22)/4770ms(D23) lost:52(D24)/1(D25)/325(D26) delay:67(D27)/55(D28)/132ms(D29) g729r8Telephony call-legs: 1SIP call-legs: 0H323 call-legs: 1MGCP call-legs: 0Total call-legs: 2

Objets équivalents MIB

D1 ? CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveConnectionId.1102799.1 = Hex-STRING: 53 98 B1 3F EB B7 11 D7 80 02 AA AD C2 77 19 FCD2 ? DIAL-CONTROL-MIB::callActivePeerId.1102799.1 = INTEGER: 2000**D3** ? DIAL-CONTROL-MIB::callActiveCallOrigin.1102799.1 = INTEGER: answer(2)**D4** ? DIAL-CONTROL-MIB::callActivePeerAddress.1102799.1 = STRING: 2000**D5** ? DIAL-CONTROL-MIB::callActiveCallState.1102799.1 = INTEGER: active(4)**D6** ? DIAL-CONTROL-MIB::callActiveConnectTime.1102799.1 = Timeticks: (1104123) 3:04:01.23 ? DISMAN-EVENT-MIB::sysUpTimeInstance = Timeticks: (16590203) 1 days, 22:05:02.03**D7** ? DIAL-CONTROL-MIB::callActiveTransmitPackets.1102799.1 = Gauge32: 7875641**D8** ? DIAL-CONTROL-MIB::callActiveTransmitBytes.1102799.1 = Gauge32: 157512782**D9** ? DIAL-CONTROL-MIB::callActiveReceivePackets.1102799.1 = Gauge32: 7875955**D10** ? DIAL-CONTROL-MIB::callActiveReceiveBytes.1102799.1 = Gauge32: 157519081**D11** ? IF-MIB::ifDescr.37 = STRING: Foreign Exchange Station 2/0/0**D12** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveTxDuration.1102799.1 = Gauge32: 157515460 milliseconds**D13** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveVoiceTxDuration.1102799.1 = Gauge32: 157514630 milliseconds**D14** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveCoderTypeRate.1102799.1 = INTEGER: ietfg729r8000(25)**D15** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveNoiseLevel.1102799.1 = INTEGER: -56 dBm**D16** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveACOMLevel.1102799.1 = INTEGER: 5 dB**D17** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveInSignalLevel.1102799.1 = INTEGER: -40 dBm**D18** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveOutSignalLevel.1102799.1 = INTEGER: -46 dBm**D19** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveRemoteIPAddress.1102966.1 = IpAddress: 172.16.99.22**D20** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveRemoteUDPPort.1102966.1 = INTEGER: 19066**D21** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveRoundTripDelay.1102966.1 = Gauge32: 6 milliseconds**D22** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveOnTimeRvPayout.1102966.1 = Gauge32: 157496940 milliseconds**D23** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveGapFillWithSilence.1102966.1 = Gauge32: 1090 milliseconds ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveGapFillWithPrediction.1102966.1 = Gauge32: 3680 milliseconds ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveGapFillWithInterpolation.1102966.1 = Gauge32: 0 milliseconds**D24** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveLostPackets.1102966.1 = Gauge32: 52 packets**D25** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveEarlyPackets.1102966.1 = Gauge32: 1 packets**D26** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveLatePackets.1102966.1 = Gauge32: 325 packets**D27** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveReceiveDelay.1102966.1 = Gauge32: 67**D28** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveLoWaterPayoutDelay.1102966.1 = Gauge32: 55 milliseconds**D29** ? CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveHiWaterPayoutDelay.1102966.1 = Gauge32: 132 milliseconds

Remarque: La valeur de GapFill de la commande **brief show call active voice** est obtenue quand vous ajoutez le **cvVoIPCallActiveGapFillWithSilence**, le **cvVoIPCallActiveGapFillWithPrediction**, et le **cvVoIPCallActiveGapFillWithInterpolation** d'objets SNMP.

show voice dsp

```
VoIPRouter#show voice dsp DSP DSP DSPWARE CURR BOOT PAK
TX/RXTYPE NUM CH CODEC VERSION STATE STATE RST AI VOICEPORT TS ABORT PACK COUNT====
=====
4.1.31 IDLE idle 0 0 1/0:0 05 0 0/36 02 {medium} 4.1.31 IDLE idle 0 1/0:0 08
idle 0 1/0:0 06 0 0/0 03 {medium} 4.1.31 IDLE idle 0 1/0:0 08
0 0/0C549 010 01 {medium} 4.1.31 IDLE idle 0 0 1/0:0 09 0 0/0 03 {medium}
02 {medium} 4.1.31 IDLE idle 0 1/0:0 11 0 0/0 04 {medium} 4.1.31 IDLE
idle 0 1/0:0 12 0 0/0C549 011 01 {medium} 4.1.31 IDLE idle 0 0
1/0:0 13 0 0/0 02 {medium} 4.1.31 IDLE idle 0 1/0:0 14
```

```

0          0/0          03 {medium} 4.1.31 IDLE idle          0 1/0:0      15      0          0/0
04 {medium} 4.1.31 IDLE idle          0 1/0:0      16      0          0/0C549 012 01 {medium}
4.1.31 IDLE idle          0 0 1/0:0      17      0          0/0          02 {medium} 4.1.31 IDLE
idle          0 1/0:0      18      0          0/0          03 {medium} 4.1.31 IDLE idle          0
1/0:0      19      0          0/0          04 {medium} 4.1.31 IDLE idle          0 1/0:0      20
0          0/0C549 013 01 {medium} 4.1.31 IDLE idle          0 0 1/0:0      21      0          0/0
02 {medium} 4.1.31 IDLE idle          0 1/0:0      22      0          0/0          03 {medium}
4.1.31 IDLE idle          0 1/0:0      23      0          0/12          04 g729r8 4.1.31 busy
idle          0 1/0:0      24      0          176/56702C549 014 01 {medium} 4.1.31 IDLE idle          0 0
1/0:0      01      0          0/27          02 {medium} 4.1.31 IDLE idle          0 1/0:0      02
0          0/12          03 {medium} 4.1.31 IDLE idle          0 1/0:0      03      0          0/12
04 {medium} 4.1.31 IDLE idle          0 1/0:0      04      0          0/12

```

Voici quelques objets utiles MIB qui fournissent des informations au sujet de l'appel actif dans l'exemple de sortie de la commande de **show voice dsp** :

```

VoIPRouter#show voice dsp DSP DSP DSPWARE CURR BOOT PAK
TX/RXTYPE NUM CH CODEC VERSION STATE STATE RST AI VOICEPORT TS ABORT PACK COUNT==== ==
=====
4.1.31 IDLE idle 0 0 1/0:0 05 0 0/36 02 {medium} 4.1.31 IDLE
idle 0 1/0:0 06 0 0/0 03 {medium} 4.1.31 IDLE idle 0
1/0:0 07 0 0/0 04 {medium} 4.1.31 IDLE idle 0 1/0:0 08
0 0/0C549 010 01 {medium} 4.1.31 IDLE idle 0 0 1/0:0 09 0 0/0
02 {medium} 4.1.31 IDLE idle 0 1/0:0 10 0 0/0 03 {medium}
4.1.31 IDLE idle 0 1/0:0 11 0 0/0 04 {medium} 4.1.31 IDLE
idle 0 1/0:0 12 0 0/0C549 011 01 {medium} 4.1.31 IDLE idle 0 0
1/0:0 13 0 0/0 02 {medium} 4.1.31 IDLE idle 0 1/0:0 14
0 0/0 03 {medium} 4.1.31 IDLE idle 0 1/0:0 15 0 0/0
04 {medium} 4.1.31 IDLE idle 0 1/0:0 16 0 0/0C549 012 01 {medium}
4.1.31 IDLE idle 0 0 1/0:0 17 0 0/0 02 {medium} 4.1.31 IDLE
idle 0 1/0:0 18 0 0/0 03 {medium} 4.1.31 IDLE idle 0
1/0:0 19 0 0/0 04 {medium} 4.1.31 IDLE idle 0 1/0:0 20
0 0/0C549 013 01 {medium} 4.1.31 IDLE idle 0 0 1/0:0 21 0 0/0
02 {medium} 4.1.31 IDLE idle 0 1/0:0 22 0 0/0 03 {medium}
4.1.31 IDLE idle 0 1/0:0 23 0 0/12 04 g729r8 4.1.31 busy
idle 0 1/0:0 24 0 176/56702C549 014 01 {medium} 4.1.31 IDLE idle 0 0
1/0:0 01 0 0/27 02 {medium} 4.1.31 IDLE idle 0 1/0:0 02
0 0/12 03 {medium} 4.1.31 IDLE idle 0 1/0:0 03 0 0/12
04 {medium} 4.1.31 IDLE idle 0 1/0:0 04 0 0/12

```

Remarque: Le MIB qui contient le **dsp de Voix de l'information en démonstration** est CISCO-DSP-MGMT-MIB. Cependant, en raison de l'ID de bogue Cisco CSCeb62542 pour la carte NM-2V, des DSP sur NM-2V ne sont pas affichés dans ENTITY-MIB. Puisque cdspCardStatusTable dépend de l'entPhysicalIndex d'ENTITY-MIB, cdspCardStatusTable n'est pas rempli pour la carte NM-2V.

[Annexe](#)

Cette sortie affiche le **snmpwalk** complet du ciscoVoiceAnalogIfMIB de CISCO-VOICE-ANALOG-IF-MIB au moment des commandes de vérification VoIP affichées dans ce document :

```

snmpwalk -c public 172.16.100.20 CISCO-VOICE-ANALOG-IF-MIB:ciscoVoiceAnalogIfMIB CISCO-VOICE-ANALOG-IF-MIB::cvaIfCfgImpedance.37 = INTEGER: ohms600Real(2) CISCO-VOICE-ANALOG-IF-MIB::cvaIfCfgImpedance.38 = INTEGER: ohms600Real(2) CISCO-VOICE-ANALOG-IF-MIB::cvaIfCfgIntegratedDSP.37 = INTEGER: false(2) CISCO-VOICE-ANALOG-IF-MIB::cvaIfCfgIntegratedDSP.38 = INTEGER: false(2) CISCO-VOICE-ANALOG-IF-MIB::cvaIfStatusInfoType.37 = INTEGER: voice(2) CISCO-VOICE-ANALOG-IF-MIB::cvaIfStatusInfoType.38 = INTEGER: none(1) CISCO-VOICE-ANALOG-IF-MIB::cvaIfMaintenanceMode.37 = INTEGER: none(1) CISCO-VOICE-ANALOG-IF-MIB::cvaIfMaintenanceMode.38 = INTEGER: none(1) CISCO-VOICE-ANALOG-IF-MIB::cvaIfStatusSignalErrors.37 = Counter32: 0 CISCO-VOICE-ANALOG-IF-MIB::cvaIfStatusSignalErrors.38 = Counter32: 0 CISCO-VOICE-ANALOG-IF-MIB::cvaIfFXSCfgSignalType.37 = INTEGER: fxsLoopStart(1) CISCO-VOICE-ANALOG-IF-MIB::cvaIfFXSCfgSignalType.38 = INTEGER: fxsLoopStart(1) CISCO-VOICE-ANALOG-IF-

```

```
MIB::cvaIfFXSRingFrequency.37 = INTEGER: ringFrequency25(1) CISCO-VOICE-ANALOG-IF-
MIB::cvaIfFXSRingFrequency.38 = INTEGER: ringFrequency25(1) CISCO-VOICE-ANALOG-IF-
MIB::cvaIfFXSHookStatus.37 = INTEGER: offHook(2) CISCO-VOICE-ANALOG-IF-MIB::cvaIfFXSHookStatus.38
= INTEGER: onHook(1) CISCO-VOICE-ANALOG-IF-MIB::cvaIfFXSRingActive.37 = INTEGER: false(2) CISCO-
VOICE-ANALOG-IF-MIB::cvaIfFXSRingActive.38 = INTEGER: false(2) CISCO-VOICE-ANALOG-IF-
MIB::cvaIfFXSRingGround.37 = INTEGER: false(2) CISCO-VOICE-ANALOG-IF-MIB::cvaIfFXSRingGround.38 =
INTEGER: false(2) CISCO-VOICE-ANALOG-IF-MIB::cvaIfFXSTipGround.37 = INTEGER: false(2) CISCO-VOICE-
ANALOG-IF-MIB::cvaIfFXSTipGround.38 = INTEGER: false(2) CISCO-VOICE-ANALOG-IF-
MIB::cvaIfFXSTimingDigitDuration.37 = INTEGER: 100 milliseconds CISCO-VOICE-ANALOG-IF-
MIB::cvaIfFXSTimingDigitDuration.38 = INTEGER: 100 milliseconds CISCO-VOICE-ANALOG-IF-
MIB::cvaIfFXSTimingInterDigitDuration.37 = INTEGER: 100 milliseconds CISCO-VOICE-ANALOG-IF-
MIB::cvaIfFXSTimingInterDigitDuration.38 = INTEGER: 100 milliseconds
```

Cette sortie affiche le **snmpwalk** complet du **ciscoVoiceInterfaceMIB** de **CISCO-VOICE-IF-MIB** au moment des commandes de vérification VoIP affichées dans ce document :

```
snmpwalk -c public 172.16.100.20 CISCO-VOICE-IF-MIB:ciscoVoiceInterfaceMIB CISCO-VOICE-IF-
MIB::cvIfCfgNoiseRegEnable.37 = INTEGER: true(1) CISCO-VOICE-IF-MIB::cvIfCfgNoiseRegEnable.38 =
INTEGER: true(1) CISCO-VOICE-IF-MIB::cvIfCfgNonLinearProcEnable.37 = INTEGER: true(1) CISCO-VOICE-
IF-MIB::cvIfCfgNonLinearProcEnable.38 = INTEGER: true(1) CISCO-VOICE-IF-
MIB::cvIfCfgMusicOnHoldThreshold.37 = INTEGER: -38 dBm CISCO-VOICE-IF-
MIB::cvIfCfgMusicOnHoldThreshold.38 = INTEGER: -38 dBm CISCO-VOICE-IF-MIB::cvIfCfgInGain.37 =
INTEGER: 0 dB CISCO-VOICE-IF-MIB::cvIfCfgInGain.38 = INTEGER: 0 dB CISCO-VOICE-IF-
MIB::cvIfCfgOutAttn.37 = INTEGER: 3 dB CISCO-VOICE-IF-MIB::cvIfCfgOutAttn.38 = INTEGER: 3
dB CISCO-VOICE-IF-MIB::cvIfCfgEchoCancelEnable.37 = INTEGER: true(1) CISCO-VOICE-IF-
MIB::cvIfCfgEchoCancelEnable.38 = INTEGER: true(1) CISCO-VOICE-IF-
MIB::cvIfCfgEchoCancelCoverage.37 = INTEGER: 4 CISCO-VOICE-IF-MIB::cvIfCfgEchoCancelCoverage.38 =
INTEGER: 4 CISCO-VOICE-IF-MIB::cvIfCfgConnectionMode.37 = INTEGER: normal(1) CISCO-VOICE-IF-
MIB::cvIfCfgConnectionMode.38 = INTEGER: normal(1) CISCO-VOICE-IF-MIB::cvIfCfgConnectionNumber.37
= STRING: CISCO-VOICE-IF-MIB::cvIfCfgConnectionNumber.38 = STRING: CISCO-VOICE-IF-
MIB::cvIfCfgInitialDigitTimeOut.37 = INTEGER: 10 seconds CISCO-VOICE-IF-
MIB::cvIfCfgInitialDigitTimeOut.38 = INTEGER: 10 seconds CISCO-VOICE-IF-
MIB::cvIfCfgInterDigitTimeOut.37 = INTEGER: 10 seconds CISCO-VOICE-IF-
MIB::cvIfCfgInterDigitTimeOut.38 = INTEGER: 10 seconds CISCO-VOICE-IF-MIB::cvIfCfgRegionalTone.37
= STRING: "US" CISCO-VOICE-IF-MIB::cvIfCfgRegionalTone.38 = STRING: "US" CISCO-VOICE-IF-
MIB::cvIfCfgEntry.13.37 = INTEGER: 1 CISCO-VOICE-IF-MIB::cvIfCfgEntry.13.38 = INTEGER: 1 CISCO-
VOICE-IF-MIB::cvIfCfgEntry.14.37 = INTEGER: 1 CISCO-VOICE-IF-MIB::cvIfCfgEntry.14.38 = INTEGER: 1
```

Cette sortie affiche le **snmpwalk** complet du **ciscoVoiceDialControlMIB** de **CISCO-VOICE-DIAL-CONTROL-MIB** au moment des commandes de vérification VoIP affichées dans ce document :

```
snmpwalk -c public 172.16.100.20 CISCO-VOICE-DIAL-CONTROL-MIB:ciscoVoiceDialControlMIB CISCO-
VOICE-DIAL-CONTROL-MIB::cvGeneralPoorQoVNotificationEnable.0 = INTEGER: true(1) CISCO-VOICE-DIAL-
CONTROL-MIB::cvPeerCfgIfIndex.1000 = INTEGER: 91 CISCO-VOICE-DIAL-CONTROL-
MIB::cvPeerCfgIfIndex.2000 = INTEGER: 90 CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCfgType.1000 =
INTEGER: voip(2) CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCfgType.2000 = INTEGER: voice(1) CISCO-VOICE-
DIAL-CONTROL-MIB::cvPeerCfgRowStatus.1000 = INTEGER: active(1) CISCO-VOICE-DIAL-CONTROL-
MIB::cvPeerCfgRowStatus.2000 = INTEGER: active(1) CISCO-VOICE-DIAL-CONTROL-
MIB::cvPeerCfgEntry.5.1000 = INTEGER: 1 CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCfgEntry.5.2000 =
INTEGER: 1 CISCO-VOICE-DIAL-CONTROL-MIB::cvVoicePeerCfgSessionTarget.90 = STRING: CISCO-VOICE-
DIAL-CONTROL-MIB::cvVoicePeerCfgDialDigitsPrefix.90 = STRING: 9 CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoicePeerCfgDIDCallEnable.90 = INTEGER: false(2) CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoicePeerCfgCasGroup.90 = INTEGER: -1 CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoicePeerCfgRegisterEl64.90 = INTEGER: true(1) CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoicePeerCfgForwardDigits.90 = INTEGER: -1 CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoicePeerCfgEntry.7.90 = INTEGER: 1 CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoIPPeerCfgSessionProtocol.91 = INTEGER: cisco(2) CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoIPPeerCfgDesiredQoS.91 = INTEGER: 1 CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoIPPeerCfgMinAcceptableQoS.91 = INTEGER: 1 CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoIPPeerCfgSessionTarget.91 = STRING: ipv4:172.16.99.22 CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoIPPeerCfgCoderRate.91 = INTEGER: g729IETFr8000(16) CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoIPPeerCfgFaxRate.91 = INTEGER: voiceRate(2) CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoIPPeerCfgVADEnable.91 = INTEGER: true(1) CISCO-VOICE-DIAL-CONTROL-
MIB::cvVoIPPeerCfgExpectFactor.91 = INTEGER: 0 equipment impairment factor (eif) CISCO-VOICE-
```

DIAL-CONTROL-MIB::cvVoIPPeerCfgIcpif.91 = INTEGER: 20 equipment impairment factor (eif)CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPPeerCfgPoorQoVNotificationEnable.91 = INTEGER: false(2)CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPPeerCfgUDPChecksumEnable.91 = INTEGER: false(2)CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPPeerCfgIPPrecedence.91 = INTEGER: 0CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPPeerCfgTechPrefix.91 = STRING: CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPPeerCfgDigitRelay.91 = Hex-STRING: 00 CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPPeerCfgCoderBytes.91 = INTEGER: 20 bytesCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPPeerCfgFaxBytes.91 = INTEGER: 20 bytesCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPPeerCfgInBandSignaling.91 = INTEGER: cas(1)CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPPeerCfgEntry.23.91 = INTEGER: 1CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgIncomingDnisDigits.90 = STRING: CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgIncomingDnisDigits.91 = STRING: CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgMaxConnections.90 = INTEGER: -1 connectionsCISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgMaxConnections.91 = INTEGER: -1 connectionsCISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgApplicationName.90 = STRING: CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgApplicationName.91 = STRING: CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgPreference.90 = INTEGER: 0CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgPreference.91 = INTEGER: 0CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgHuntStop.90 = INTEGER: false(2)CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgHuntStop.91 = INTEGER: false(2)CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgEntry.6.90 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgEntry.6.91 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgEntry.7.90 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgEntry.7.91 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgEntry.8.90 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgEntry.8.91 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgEntry.9.90 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgEntry.9.91 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgEntry.10.90 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvPeerCommonCfgEntry.10.91 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveConnectionId.1102799.1 = Hex-STRING: 53 98 B1 3F EB B7 11 D7 80 02 AA AD C2 77 19 FCCISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveTxDuration.1102799.1 = Gauge32: 157515460 millisecondsCISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveVoiceTxDuration.1102799.1 = Gauge32: 157514630 millisecondsCISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveFaxTxDuration.1102799.1 = Gauge32: 0 millisecondsCISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveCoderTypeRate.1102799.1 = INTEGER: ietfg729r8000(25)CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveNoiseLevel.1102799.1 = INTEGER: -56 dBmCISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveACOMLevel.1102799.1 = INTEGER: 5 dBmCISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveOutSignalLevel.1102799.1 = INTEGER: -46 dBmCISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveInSignalLevel.1102799.1 = INTEGER: -40 dBmCISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveERLLevel.1102799.1 = INTEGER: 5 dBmCISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveSessionTarget.1102799.1 = STRING: CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveImgPageCount.1102799.1 = Gauge32: 0 pagesCISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveEntry.13.1102799.1 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveEntry.14.1102799.1 = INTEGER: 2CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveEntry.15.1102799.1 = INTEGER: 19971CISCO-VOICE-DIAL-CONTROL-MIB::cvCallActiveEntry.17.1102799.1 = INTEGER: 5CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveConnectionId.1102966.1 = Hex-STRING: 53 98 B1 3F EB B7 11 D7 80 02 AA AD C2 77 19 FCCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveRemoteIPAddress.1102966.1 = IpAddress: 172.16.99.22CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveRemoteUDPPort.1102966.1 = INTEGER: 19066CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveRoundTripDelay.1102966.1 = Gauge32: 6 millisecondsCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveSelectedQoS.1102966.1 = INTEGER: 1CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveSessionProtocol.1102966.1 = INTEGER: cisco(2)CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveSessionTarget.1102966.1 = STRING: ipv4:172.16.99.22CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveOnTimeRvPLayout.1102966.1 = Gauge32: 157496940 millisecondsCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveGapFillWithSilence.1102966.1 = Gauge32: 1090 millisecondsCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveGapFillWithPrediction.1102966.1 = Gauge32: 3680 millisecondsCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveGapFillWithInterpolation.1102966.1 = Gauge32: 0 millisecondsCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveGapFillWithRedundancy.1102966.1 = Gauge32: 0 millisecondsCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveHiWaterPayoutDelay.1102966.1 = Gauge32: 132 millisecondsCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveLoWaterPayoutDelay.1102966.1 = Gauge32: 55 millisecondsCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveReceiveDelay.1102966.1 = Gauge32: 67CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveVADEnable.1102966.1 = INTEGER: true(1)CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveCoderTypeRate.1102966.1 = INTEGER: ietfg729r8000(25)CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveLostPackets.1102966.1 = Gauge32: 52 packetsCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveEarlyPackets.1102966.1 = Gauge32: 1 packetsCISCO-VOICE-DIAL-

```
CONTROL-MIB::cvVoIPCallActiveLatePackets.1102966.1 = Gauge32: 325 packetsCISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveEntry.21.1102966.1 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveEntry.22.1102966.1 = "CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveEntry.23.1102966.1 = INTEGER: 1CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveEntry.24.1102966.1 = STRING: "172.16.99.22"CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveEntry.25.1102966.1 = INTEGER: 1720CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveEntry.26.1102966.1 = INTEGER: 1CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveEntry.27.1102966.1 = STRING: "172.16.99.22"CISCO-VOICE-DIAL-CONTROL-MIB::cvVoIPCallActiveEntry.28.1102966.1 = INTEGER: 19066
```

Cette sortie affiche le **snmpwalk** complet du **ciscoVoiceCommonDialControlMIB** de **CISCO-VOICE-DIAL-CONTROL-MIB** au moment des commandes de vérification VoIP affichées dans ce document :

```
snmpwalk -c public 172.16.100.20 CISCO-VOICE-COMMON-DIAL-CONTROL-MIB:ciscoVoiceCommonDialControlMIBCISCO-VOICE-COMMON-DIAL-CONTROL-MIB::cvCommonDcCallActiveConnectionId.1102966.1 = Hex-STRING: 53 98 B1 3F EB B7 11 D7 80 02 AA AD C2 77 19 FCCISCO-VOICE-COMMON-DIAL-CONTROL-MIB::cvCommonDcCallActiveVADEnable.1102966.1 = INTEGER: true(1)CISCO-VOICE-COMMON-DIAL-CONTROL-MIB::cvCommonDcCallActiveCoderTypeRate.1102966.1 = INTEGER: ietfg729r8000(25)CISCO-VOICE-COMMON-DIAL-CONTROL-MIB::cvCommonDcCallActiveCodecBytes.1102966.1 = INTEGER: 20CISCO-VOICE-COMMON-DIAL-CONTROL-MIB::cvCommonDcCallActiveInBandSignaling.1102966.1 = INTEGER: cas(1)CISCO-VOICE-COMMON-DIAL-CONTROL-MIB::cvCommonDcCallActiveEntry.6.1102966.1 = "CISCO-VOICE-COMMON-DIAL-CONTROL-MIB::cvCommonDcCallActiveEntry.7.1102966.1 = INTEGER: 2
```

Cette sortie affiche le **snmpwalk** complet du **dialControlMib** du **DIAL-CONTROL-MIB** au moment des commandes de vérification VoIP affichées dans ce document :

```
snmpwalk -c public 172.16.100.20 DIAL-CONTROL-MIB:dialControlMibDIAL-CONTROL-MIB::dialCtlAcceptMode.0 = INTEGER: acceptAll(2)DIAL-CONTROL-MIB::dialCtlTrapEnable.0 = INTEGER: enabled(1)DIAL-CONTROL-MIB::dialCtlPeerCfgIfType.1000.91 = INTEGER: voiceOverIp(104)DIAL-CONTROL-MIB::dialCtlPeerCfgIfType.2000.90 = INTEGER: voiceFXS(102)DIAL-CONTROL-MIB::dialCtlPeerCfgLowerIf.1000.91 = INTEGER: 0DIAL-CONTROL-MIB::dialCtlPeerCfgLowerIf.2000.90 = INTEGER: 37DIAL-CONTROL-MIB::dialCtlPeerCfgOriginateAddress.1000.91 = STRING: 1000DIAL-CONTROL-MIB::dialCtlPeerCfgOriginateAddress.2000.90 = STRING: 2000DIAL-CONTROL-MIB::dialCtlPeerCfgAnswerAddress.1000.91 = STRING: DIAL-CONTROL-MIB::dialCtlPeerCfgAnswerAddress.2000.90 = STRING: DIAL-CONTROL-MIB::dialCtlPeerCfgSubAddress.1000.91 = STRING: DIAL-CONTROL-MIB::dialCtlPeerCfgSubAddress.2000.90 = STRING: DIAL-CONTROL-MIB::dialCtlPeerCfgSpeed.1000.91 = INTEGER: 0DIAL-CONTROL-MIB::dialCtlPeerCfgSpeed.2000.90 = INTEGER: 0DIAL-CONTROL-MIB::dialCtlPeerCfgInfoType.1000.91 = INTEGER: speech(2)DIAL-CONTROL-MIB::dialCtlPeerCfgInfoType.2000.90 = INTEGER: speech(2)DIAL-CONTROL-MIB::dialCtlPeerCfgPermission.1000.91 = INTEGER: both(3)DIAL-CONTROL-MIB::dialCtlPeerCfgPermission.2000.90 = INTEGER: both(3)DIAL-CONTROL-MIB::dialCtlPeerCfgInactivityTimer.1000.91 = INTEGER: 0 secondsDIAL-CONTROL-MIB::dialCtlPeerCfgInactivityTimer.2000.90 = INTEGER: 0 secondsDIAL-CONTROL-MIB::dialCtlPeerCfgMinDuration.1000.91 = INTEGER: 0DIAL-CONTROL-MIB::dialCtlPeerCfgMinDuration.2000.90 = INTEGER: 0DIAL-CONTROL-MIB::dialCtlPeerCfgMaxDuration.1000.91 = INTEGER: 0DIAL-CONTROL-MIB::dialCtlPeerCfgMaxDuration.2000.90 = INTEGER: 0DIAL-CONTROL-MIB::dialCtlPeerCfgCarrierDelay.1000.91 = INTEGER: 0 secondsDIAL-CONTROL-MIB::dialCtlPeerCfgCarrierDelay.2000.90 = INTEGER: 0 secondsDIAL-CONTROL-MIB::dialCtlPeerCfgCallRetries.1000.91 = INTEGER: 0DIAL-CONTROL-MIB::dialCtlPeerCfgCallRetries.2000.90 = INTEGER: 0DIAL-CONTROL-MIB::dialCtlPeerCfgRetryDelay.1000.91 = INTEGER: 0 secondsDIAL-CONTROL-MIB::dialCtlPeerCfgRetryDelay.2000.90 = INTEGER: 0 secondsDIAL-CONTROL-MIB::dialCtlPeerCfgFailureDelay.1000.91 = INTEGER: 0 secondsDIAL-CONTROL-MIB::dialCtlPeerCfgFailureDelay.2000.90 = INTEGER: 0 secondsDIAL-CONTROL-MIB::dialCtlPeerCfgTrapEnable.1000.91 = INTEGER: disabled(2)DIAL-CONTROL-MIB::dialCtlPeerCfgTrapEnable.2000.90 = INTEGER: disabled(2)DIAL-CONTROL-MIB::dialCtlPeerCfgStatus.1000.91 = INTEGER: active(1)DIAL-CONTROL-MIB::dialCtlPeerCfgStatus.2000.90 = INTEGER: active(1)DIAL-CONTROL-MIB::dialCtlPeerStatsConnectTime.1000.91 = Gauge32: 0 secondsDIAL-CONTROL-MIB::dialCtlPeerStatsConnectTime.2000.90 = Gauge32: 0 secondsDIAL-CONTROL-
```


MIB::dialCtlPeerStatsChargedUnits.1000.91 = Gauge32: 0DIAL-CONTROL-
MIB::dialCtlPeerStatsChargedUnits.2000.90 = Gauge32: 0DIAL-CONTROL-
MIB::dialCtlPeerStatsSuccessCalls.1000.91 = Gauge32: 0DIAL-CONTROL-
MIB::dialCtlPeerStatsSuccessCalls.2000.90 = Gauge32: 0DIAL-CONTROL-
MIB::dialCtlPeerStatsFailCalls.1000.91 = Gauge32: 0DIAL-CONTROL-
MIB::dialCtlPeerStatsFailCalls.2000.90 = Gauge32: 0DIAL-CONTROL-
MIB::dialCtlPeerStatsAcceptCalls.1000.91 = Gauge32: 0DIAL-CONTROL-
MIB::dialCtlPeerStatsAcceptCalls.2000.90 = Gauge32: 0DIAL-CONTROL-
MIB::dialCtlPeerStatsRefuseCalls.1000.91 = Gauge32: 0DIAL-CONTROL-
MIB::dialCtlPeerStatsRefuseCalls.2000.90 = Gauge32: 0DIAL-CONTROL-
MIB::dialCtlPeerStatsLastDisconnectCause.1000.91 = "DIAL-CONTROL-
MIB::dialCtlPeerStatsLastDisconnectCause.2000.90 = "DIAL-CONTROL-
MIB::dialCtlPeerStatsLastDisconnectText.1000.91 = STRING: DIAL-CONTROL-
MIB::dialCtlPeerStatsLastDisconnectText.2000.90 = STRING: DIAL-CONTROL-
MIB::dialCtlPeerStatsLastSetupTime.1000.91 = Timeticks: (1102966) 3:03:49.66DIAL-CONTROL-
MIB::dialCtlPeerStatsLastSetupTime.2000.90 = Timeticks: (1102799) 3:03:47.99DIAL-CONTROL-
MIB::callActivePeerAddress.1102799.1 = STRING: 2000DIAL-CONTROL-
MIB::callActivePeerAddress.1102966.1 = STRING: 1000DIAL-CONTROL-
MIB::callActivePeerSubAddress.1102799.1 = STRING: DIAL-CONTROL-
MIB::callActivePeerSubAddress.1102966.1 = STRING: DIAL-CONTROL-MIB::callActivePeerId.1102799.1 =
INTEGER: 2000DIAL-CONTROL-MIB::callActivePeerId.1102966.1 = INTEGER: 1000DIAL-CONTROL-
MIB::callActivePeerIfIndex.1102799.1 = INTEGER: 90DIAL-CONTROL-
MIB::callActivePeerIfIndex.1102966.1 = INTEGER: 91DIAL-CONTROL-
MIB::callActiveLogicalIfIndex.1102799.1 = INTEGER: 37DIAL-CONTROL-
MIB::callActiveLogicalIfIndex.1102966.1 = INTEGER: 0DIAL-CONTROL-
MIB::callActiveConnectTime.1102799.1 = Timeticks: (1104123) 3:04:01.23DIAL-CONTROL-
MIB::callActiveConnectTime.1102966.1 = Timeticks: (1104123) 3:04:01.23DIAL-CONTROL-
MIB::callActiveCallState.1102799.1 = INTEGER: active(4)DIAL-CONTROL-
MIB::callActiveCallState.1102966.1 = INTEGER: active(4)DIAL-CONTROL-
MIB::callActiveCallOrigin.1102799.1 = INTEGER: answer(2)DIAL-CONTROL-
MIB::callActiveCallOrigin.1102966.1 = INTEGER: originate(1)DIAL-CONTROL-
MIB::callActiveChargedUnits.1102799.1 = Gauge32: 0DIAL-CONTROL-
MIB::callActiveChargedUnits.1102966.1 = Gauge32: 0DIAL-CONTROL-MIB::callActiveInfoType.1102799.1
= INTEGER: speech(2)DIAL-CONTROL-MIB::callActiveInfoType.1102966.1 = INTEGER: speech(2)DIAL-
CONTROL-MIB::callActiveTransmitPackets.1102799.1 = Gauge32: 7875641DIAL-CONTROL-
MIB::callActiveTransmitPackets.1102966.1 = Gauge32: 7875388DIAL-CONTROL-
MIB::callActiveTransmitBytes.1102799.1 = Gauge32: 157512782DIAL-CONTROL-
MIB::callActiveTransmitBytes.1102966.1 = Gauge32: 157507741DIAL-CONTROL-
MIB::callActiveReceivePackets.1102799.1 = Gauge32: 7875955DIAL-CONTROL-
MIB::callActiveReceivePackets.1102966.1 = Gauge32: 7875641DIAL-CONTROL-
MIB::callActiveReceiveBytes.1102799.1 = Gauge32: 157519081DIAL-CONTROL-
MIB::callActiveReceiveBytes.1102966.1 = Gauge32: 157512782DIAL-CONTROL-
MIB::callHistoryTableMaxLength.0 = INTEGER: 50DIAL-CONTROL-MIB::callHistoryRetainTimer.0 =
INTEGER: 15 minutes

[Informations connexes](#)

- [Outils MIB de Cisco IOS](#)
- [Navigateur d'objet SNMP de Cisco](#)
- [Notes en tech SNMP](#)
- [Support et documentation techniques - Cisco Systems](#)