

# Configuration d'un Cisco 6400 pour prendre en charge MUX-PPP, SNAP, et utiliser une sous-interface atm ilmi-pvc-discovery

## Contenu

[Introduction](#)

[Conditions préalables](#)

[Conditions requises](#)

[Composants utilisés](#)

[Conventions](#)

[Configurez](#)

[Configuration](#)

[Vérifiez](#)

[Dépannez](#)

[Dépannage des commandes](#)

[Informations connexes](#)

## [Introduction](#)

Ce document décrit une configuration d'échantillon pour un concentrateur d'accès universel de Cisco 6400 (UAC) ce les supports MUX-PPP et le protocole d'accès de sous-réseau (SNAP) et utilise une sous-interface d'atm ilmi-pvc-discovery.

## [Conditions préalables](#)

### [Conditions requises](#)

Aucune spécification déterminée n'est requise pour ce document.

### [Composants utilisés](#)

Ce document n'est pas limité à des versions de matériel et de logiciel spécifiques.

Les informations contenues dans ce document ont été créées à partir des périphériques d'un environnement de laboratoire spécifique. Tous les périphériques utilisés dans ce document ont démarré avec une configuration effacée (par défaut). Si votre réseau est opérationnel, assurez-vous que vous comprenez l'effet potentiel de toute commande.

### [Conventions](#)

Pour plus d'informations sur les conventions de documents, reportez-vous à [Conventions relatives aux conseils techniques Cisco](#).

## Configurez

Cette section vous fournit des informations pour configurer les fonctionnalités décrites dans ce document.

**Remarque:** Pour obtenir des informations supplémentaires sur les commandes utilisées dans ce document, utilisez l'[Outil de recherche de commande](#) ([clients enregistrés](#) seulement).

## Configuration

Ce document utilise la configuration suivante :

### **Cisco 6400 NRP1**

```
!  
version 12.0  
no service pad  
service timestamps debug datetime msec  
service timestamps log datetime msec  
no service password-encryption  
!  
hostname Access-6400-NRP1  
!  
enable password <password>  
!  
username <username> password 0 <password>  
username <username1> password 0 <password1>  
username <username2> password 0 <password2>  
!  
!  
!  
!  
redundancy  
  main-cpu  
    auto-sync standard  
  no secondary console enable  
ip subnet-zero  
ip domain-name cisco.com  
ip name-server 171.68.10.70  
!  
!  
!  
bridge irb  
!  
!  
process-max-time 200  
!  
interface Loopback1  
  ip address 10.1.1.1 255.255.255.0  
  no ip directed-broadcast  
  !  
interface ATM0/0/0  
  no ip address  
  no ip directed-broadcast  
  no atm ilmi-keepalive  
  atm ilmi-pvc-discovery subinterface
```

```

pvc 0/16 ilmi
!
!
interface ATM0/0/0.1 multipoint
  !--- For VPI starting with number 1 (example: 1/34). no
ip directed-broadcast class-int bridgel bridge-group 1 !
interface ATM0/0/0.4 multipoint !--- For VPI starting
with number 4 (example: 4/33). no ip directed-broadcast
class-int router ! interface Ethernet0/0/1 no ip address
no ip directed-broadcast ! interface Ethernet0/0/0 ip
address 171.68.186.117 255.255.255.240 no ip directed-
broadcast ! interface FastEthernet0/0/0 no ip address no
ip directed-broadcast shutdown ! interface Virtual-
Templatel ip unnumbered Loopback1 no ip directed-
broadcast peer default ip address pool mypool ppp
authentication chap ! interface BVI1 mac-address ip
address 10.10.33.1 255.255.255.0 no ip directed-
broadcast ! ip local pool mypool 10.1.1.2 10.1.1.200 ip
classless ip route 0.0.0.0 0.0.0.0 171.68.186.113 no ip
http server ! ! vc-class atm bridgel encapsulation
aal5snap ! vc-class atm router encapsulation aal5mux ppp
Virtual-Templatel tacacs-server host 171.68.201.249
tacacs-server last-resort succeed tacacs-server
optional-passwords tacacs-server extended ! bridge 1
protocol ieee bridge 1 route ip ! line con 0 transport
input none line aux 0 line vty 0 4 password xxxxxx login
local ! end

```

## Vérifiez

Cette section présente des informations que vous pouvez utiliser pour vous assurer que votre configuration fonctionne correctement.

Certaines commandes **show** sont prises en charge par l'[Output Interpreter Tool](#) (clients [enregistrés](#) uniquement), qui vous permet de voir une analyse de la sortie de la commande show.

### sortie de commande de show atm pvc

```

Access-6400-NRP1# show atm pvc
      VCD /                Peak Avg/Min Burst
Interface Name  VPI  VCI  Type  Encaps  SC  Kbps  Kbps  Cells  Sts
0/0/0          2    0   16  PVC    ILMI  UBR 155000          UP
0/0/0.1        7    1   34  PVC-D  SNAP  UBR 155000          UP
!--- Snap (bridge). !--- Subinterface 1 took VPI . 0/0/0.4 8 4 33 PVC-D MUX UBR 155000 UP !---
mux (ppp) !--- Subinterface 4 took VPI 4.

```

## Dépannez

Cette section fournit des informations que vous pouvez utiliser pour dépanner votre configuration.

### Dépannage des commandes

Certaines commandes **show** sont prises en charge par l'[Output Interpreter Tool](#) (clients [enregistrés](#) uniquement), qui vous permet de voir une analyse de la sortie de la commande show.

**Remarque:** Avant d'émettre des commandes de **débogage**, référez-vous aux [informations importantes sur des commandes de debug](#).

## Événements atmosphère de débogage

La sortie suivante affiche l'identifiant de chemin virtuel/identifiant de canal virtuel (VPI/VCI) que le processeur d'artère de noeud (NRP) apprend du processeur de commutateur de noeud (NSP).

```
Access-6400-NRP1# debug atm events
```

```
ATM events debugging is on
```

```
Shut/no Shut on main ATM0/0/0 interface
```

```
Access-6400-NRP1#
```

```
*Dec 16 15:51:43.667: ATM0/0/0 nrp_sarmgr_shutdown: state=0
*Dec 16 15:51:44.515: Resetting ATM0/0/0
*Dec 16 15:51:45.015: Resetting ATM0/0/0
*Dec 16 15:51:45.015: nrp_sarmgr_config(ATM0/0/0)
*Dec 16 15:51:45.015: nrp_sarmgr_enable(ATM0/0/0)
*Dec 16 15:51:45.215: nrp_sarmgr_enable(ATM0/0/0): restarting VCs: 0
*Dec 16 15:51:45.215: nrp_sarmgr_setup_vc(ATM0/0/0): vc:2 vpi:0 vci:16
*Dec 16 15:51:45.223: %SYS-5-CONFIG_I: Configured from console by console
*Dec 16 15:51:45.667: %LINK-3-UPDOWN: Interface ATM0/0/0, changed state to up
*Dec 16 15:51:46.667: %LINEPROTO-5-UPDOWN: Line protocol on Interface ATM0/0/0,
  changed state to up
*Dec 16 15:51:47.219: %LINK-3-UPDOWN: Interface BV11, changed state to up
*Dec 16 15:51:47.471: Reserved bw for 1/34 Available bw = 155000
*Dec 16 15:51:47.471: nrp_sarmgr_setup_vc(ATM0/0/0): vc:13 vpi:1 vci:34
*Dec 16 15:51:47.475: Reserved bw for 4/33 Available bw = 155000
*Dec 16 15:51:47.527: nrp_sarmgr_setup_vc(ATM0/0/0): vc:14 vpi:4 vci:33
*Dec 16 15:51:48.219: %LINEPROTO-5-UPDOWN: Line protocol on Interface BV11,
  changed state to up
*Dec 16 15:51:49.019: nrp_sarmgr_tearardown_vc(ATM0/0/0): vc:13 vpi:1 vci:34
*Dec 16 15:51:49.179: nrp_sarmgr_tearardown_vc(ATM0/0/0): vc:14 vpi:4 vci:33
*Dec 16 15:51:49.339: PPP-ATM(Virtual-Access1) deleting vaccess on VC 14
*Dec 16 15:51:49.351: %LANE-6-INFO: ATM0/0/0: ILMI prefix add event received
*Dec 16 15:51:49.659: Reserved bw for 1/34 Available bw = 155000
*Dec 16 15:51:49.659: nrp_sarmgr_setup_vc(ATM0/0/0): vc:15 vpi:1 vci:34
*Dec 16 15:51:49.659: Reserved bw for 4/33 Available bw = 155000
*Dec 16 15:51:49.715: nrp_sarmgr_setup_vc(ATM0/0/0): vc:16 vpi:4 vci:33
*Dec 16 15:51:55.419: %LINK-3-UPDOWN: Interface Virtual-Access1, changed state to up
```

```
Access-6400-NRP1#
```

## Sortie de débogage de PPP pour Cisco 675 en mode de Routage IP

```
Access-6400-NRP1# debug atm events
```

```
ATM events debugging is on
```

```
Shut/no Shut on main ATM0/0/0 interface
```

```
Access-6400-NRP1#
```

```
*Dec 16 15:51:43.667: ATM0/0/0 nrp_sarmgr_shutdown: state=0
*Dec 16 15:51:44.515: Resetting ATM0/0/0
*Dec 16 15:51:45.015: Resetting ATM0/0/0
*Dec 16 15:51:45.015: nrp_sarmgr_config(ATM0/0/0)
*Dec 16 15:51:45.015: nrp_sarmgr_enable(ATM0/0/0)
*Dec 16 15:51:45.215: nrp_sarmgr_enable(ATM0/0/0): restarting VCs: 0
*Dec 16 15:51:45.215: nrp_sarmgr_setup_vc(ATM0/0/0): vc:2 vpi:0 vci:16
*Dec 16 15:51:45.223: %SYS-5-CONFIG_I: Configured from console by console
*Dec 16 15:51:45.667: %LINK-3-UPDOWN: Interface ATM0/0/0, changed state to up
*Dec 16 15:51:46.667: %LINEPROTO-5-UPDOWN: Line protocol on Interface ATM0/0/0,
  changed state to up
*Dec 16 15:51:47.219: %LINK-3-UPDOWN: Interface BV11, changed state to up
*Dec 16 15:51:47.471: Reserved bw for 1/34 Available bw = 155000
*Dec 16 15:51:47.471: nrp_sarmgr_setup_vc(ATM0/0/0): vc:13 vpi:1 vci:34
*Dec 16 15:51:47.475: Reserved bw for 4/33 Available bw = 155000
*Dec 16 15:51:47.527: nrp_sarmgr_setup_vc(ATM0/0/0): vc:14 vpi:4 vci:33
*Dec 16 15:51:48.219: %LINEPROTO-5-UPDOWN: Line protocol on Interface BV11,
```

```

changed state to up
*Dec 16 15:51:49.019: nrp_sarmgr_tearardown_vc(ATM0/0/0): vc:13 vpi:1 vci:34
*Dec 16 15:51:49.179: nrp_sarmgr_tearardown_vc(ATM0/0/0): vc:14 vpi:4 vci:33
*Dec 16 15:51:49.339: PPP-ATM(Virtual-Access1) deleting vaccess on VC 14
*Dec 16 15:51:49.351: %LANE-6-INFO: ATM0/0/0: ILMI prefix add event received
*Dec 16 15:51:49.659: Reserved bw for 1/34 Available bw = 155000
*Dec 16 15:51:49.659: nrp_sarmgr_setup_vc(ATM0/0/0): vc:15 vpi:1 vci:34
*Dec 16 15:51:49.659: Reserved bw for 4/33 Available bw = 155000
*Dec 16 15:51:49.715: nrp_sarmgr_setup_vc(ATM0/0/0): vc:16 vpi:4 vci:33
*Dec 16 15:51:55.419: %LINK-3-UPDOWN: Interface Virtual-Access1, changed state to up
Access-6400-NRP1#

```

## Sortie de la commande show

```
Access-6400-NRP1# show user
```

Line	User	Host(s)	Idle	Location
* 0	con 0	idle	00:00:00	
Vil		Virtual PPP (ATM)	00:06:45	
Interface	User	Mode	Idle	Peer Address

```
Access-6400-NRP1# show interface atm 0/0/0 accounting
```

```
ATM0/0/0
```

Protocol	Pkts In	Chars In	Pkts Out	Chars Out
Trans. Bridge	0	0	3	222
Spanning Tree	0	0	1384	65048
PPP over ATM	358	6646	605	11657

```
Access-6400-NRP1# show interface atm 0/0/0
```

```

ATM0/0/0 is up, line protocol is up
Hardware is ATM-SAR
MTU 4470 bytes, sub MTU 4470, BW 156250 Kbit, DLY 80 usec,
  reliability 255/255, txload 1/255, rxload 1/255
Encapsulation ATM, loopback not supported
Keepalive not supported
Encapsulation(s): AAL5, PVC mode
2047 maximum active VCs, 3 current VCCs
VC idle disconnect time: 300 seconds
Last input 00:09:37, output 00:00:00, output hang never
Last clearing of "show interface" counters never
Queueing strategy: fifo
Output queue 0/40, 0 drops; input queue 0/75, 0 drops
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
  1307 packets input, 57832 bytes, 0 no buffer
  Received 0 broadcasts, 0 runts, 0 giants, 0 throttles
  0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
  2876 packets output, 123055 bytes, 0 underruns
  0 output errors, 0 collisions, 3 interface resets
  0 output buffer failures, 0 output buffers swapped out

```

```
Access-6400-NRP1#
```

```
Access-6400-NRP1#
```

```
Access-6400-NRP1#
```

```
Access-6400-NRP1# show interface atm 0/0/0.1
```

```

ATM0/0/0.1 is up, line protocol is up
Hardware is ATM-SAR
MTU 4470 bytes, BW 156250 Kbit, DLY 80 usec,
  reliability 255/255, txload 1/255, rxload 1/255
Encapsulation ATM
0 packets input, 0 bytes
1392 packets output, 59937 bytes

```

0 OAM cells input, 0 OAM cells output

Access-6400-NRP1# **show interface atm 0/0/0.4**

ATM0/0/0.4 is up, line protocol is up  
Hardware is ATM-SAR  
MTU 4470 bytes, BW 156250 Kbit, DLY 80 usec,  
reliability 255/255, txload 1/255, rxload 1/255  
Encapsulation ATM  
705 packets input, 11705 bytes  
615 packets output, 9415 bytes  
0 OAM cells input, 0 OAM cells output

Access-6400-NRP1# **show atm vc 15**

ATM0/0/0.1: VCD: 15, VPI: 1, VCI: 34  
UBR, PeakRate: 155000  
AAL5-LLC/SNAP, etype:0x0, Flags: 0xC20, VCmode: 0x0  
OAM frequency: 0 second(s)  
InARP frequency: 15 minutes(s)  
InPkts: 0, OutPkts: 321, InBytes: 0, OutBytes: 13803  
InPRoc: 0, OutPRoc: 321, Broadcasts: 0  
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0  
OAM cells received: 0  
OAM cells sent: 0  
Status: UP  
Access-6400-NRP1#

Access-6400-NRP1# **show atm vc 16**

ATM0/0/0.4: VCD: 16, VPI: 4, VCI: 33  
UBR, PeakRate: 155000  
AAL5-MUX, etype:0x9, Flags: 0xC23, VCmode: 0x0  
OAM frequency: 0 second(s)  
InARP DISABLED  
InPkts: 6, OutPkts: 143, InBytes: 48, OutBytes: 2420  
InPRoc: 3, OutPRoc: 143  
InFast: 0, OutFast: 0, InAS: 3, OutAS: 0  
OAM cells received: 0  
OAM cells sent: 0  
Status: UP  
PPP: Virtual-Access1 from Virtual-Templat1  
Access-6400-NRP1#

Access-6400-NRP1# **show interface virtual-access 1**

Virtual-Access1 is up, line protocol is down  
Hardware is Virtual Access interface  
Interface is unnumbered. Using address of Loopback1 (10.1.1.1)  
MTU 1500 bytes, BW 100000 Kbit, DLY 100000 usec,  
reliability 255/255, txload 1/255, rxload 1/255  
Encapsulation PPP, loopback not set  
Keepalive set (10 sec)  
DTR is pulsed for 5 seconds on reset  
LCP REQsent  
Closed: IPCP  
Bound to ATM0/0/0.4 VCD: 16, VPI: 4, VCI: 33  
Cloned from virtual-template: 1  
Last input 00:12:07, output never, output hang never  
Last clearing of "show interface" counters 00:12:18  
Queueing strategy: fifo > Output queue 0/40, 0 drops; input queue 0/75, 0 drops  
5 minute input rate 0 bits/sec, 0 packets/sec  
5 minute output rate 0 bits/sec, 0 packets/sec  
3 packets input, 18 bytes, 0 no buffer

```
Received 0 broadcasts, 0 runts, 0 giants, 0 throttles  
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort  
158 packets output, 2675 bytes, 0 underruns  
0 output errors, 0 collisions, 0 interface resets  
0 output buffer failures, 0 output buffers swapped out  
0 carrier transitions  
Access-6400-NRP1#
```

## [Informations connexes](#)

- [Soutien technique DSL](#)
- [Assistance sur les produits](#)
- [Support technique - Cisco Systems](#)