

配置 Cisco 827 路由器，以实现 NAT 并作为 PPPoE 客户端

目录

[简介](#)

[先决条件](#)

[要求](#)

[使用的组件](#)

[规则](#)

[配置](#)

[网络图](#)

[配置](#)

[验证](#)

[故障排除](#)

[调试PPPoE客户端](#)

[调试PPPoE服务器](#)

[相关信息](#)

简介

在Cisco IOS软件版本12.1(3)XG，PPP over Ethernet (PPPoE)客户端特性为Cisco 827路由器介绍。此功能允许PPPoE功能被移动到路由器。多台PC可以在Cisco 827后安装。在他们的流量发送给PPPoE会话前，可以加密，过滤，等等。并且，网络地址转换(NAT)能运行。

本文显示配置在Cisco 827路由器的ATM接口(DSL 接口) 上的一个PPPoE客户端。此配置在Cisco 1700路由器可能也使用与非对称数字用户线(ADSL)广域网接口卡。

Cisco 6400节点路由处理器(NRP)的配置也可用在作为带有ATM接口的聚集器的路由器上。

先决条件

要求

本文档没有任何特定的要求。

使用的组件

本文档不限于特定的软件和硬件版本。

规则

有关文档规则的详细信息，请参阅 [Cisco 技术提示规则](#)。

配置

本部分提供用于配置本文档所述功能的信息。

注意：要查找有关本文档中所使用的命令的详细信息，请使用[命令查找工具](#)（[仅限注册用户](#)）。

网络图

本文档使用以下网络设置：

配置

本文档使用以下配置：

- [Cisco 827路由器](#)
- [Cisco 6400 NRP](#)

PPPoE在Cisco 827路由器配置用虚拟专用拨号网络(VPDN)命令。确保您首先配置这些命令。

注意：关于如何更改最大传输单元(MTU)的大小的信息，参考[在PPPoE拨入连通性的故障排除MTU大小](#)。

Cisco 827路由器

```
!  
vpdn enable  
no vpdn logging!--- This is the default. ! vpdn-group  
pppoe request-dialin !--- This is the PPPoE client that  
requests to establish a session !--- with the  
aggregation unit (6400 NRP). protocol pppoe ! !--- This  
is the Internal Ethernet network. ! interface Ethernet0  
ip address 10.92.1.182 255.255.255.0 ip nat inside !---  
The DSL interface. ! interface ATM0 no ip address no atm  
ilmi-keepalive bundle-enable dsl operating-mode auto  
hold-queue 224 in !--- All defaults. !--- PPPoE runs on  
top of AAL5SNAP. However, the !--- encaps aal5snap  
command is not used. ! interface ATM0.1 point-to-point  
pvc 1/1 pppoe-client dial-pool-number 1 !--- pvc 1/1 is  
an example value that must be changed !--- in order to  
match the value used by the ISP. ! !--- The PPPoE client  
code ties into a dialer interface upon !--- which a  
virtual-access interface is cloned. ! interface Dialer1  
ip address negotiated ip mtu 1492 !--- Ethernet MTU is  
1500 by default -- 1492 + PPPoE headers = 1500 ip nat  
outside encapsulation ppp dialer pool 1 !--- Ties to ATM  
interface. ppp authentication chap callin ppp chap  
hostname <username> ppp chap password <password> ! !---  
Note: The ISP instructs you about the !--- type of  
authentication to use. !--- In order to change from PPP  
CHAP to PPP PAP, replace !--- ppp authentication chap  
callin !--- ppp chap hostname <username> !--- ppp chap  
password <password> !--- with ppp authentication pap  
callin !--- ppp pap sent-username <username> password  
<password> !--- For NAT, overload on the Dialer1  
interface !--- and add a default route out since dialer
```

```
IP address can change. ip nat inside source list 1
interface Dialer1 overload ip classless ip route 0.0.0.0
0.0.0.0 dialer1 no ip http server ! access-list 1 permit
10.92.1.0 0.0.0.255 !--- For NAT. !
```

Cisco 6400 NRP

```
*** local ppp user !--- Or, use AAA. username <username>
password <password> !--- Begin with the VPDN commands.
!--- Notice that the PPPoE is bound here to !--- a
virtual-template instead of on the ATM interface. !---
You cannot (at this time) use more than one !---
virtual-template (or VPDN group) for PPPoE that begins
!--- with the VPDN commands. vpdn enable no vpdn logging
! vpdn-group pppoe accept-dialin !--- PPPoE server mode.
protocol pppoe virtual-template 1 ! ! interface ATM0/0/0
no ip address no atm ilmi-keepalive hold-queue 500 in !-
-- The binding to the virtual-template !--- interface is
configured in the VPDN group. ! interface ATM0/0/0.182
point-to-point pvc 1/82 encapsulation aal5snap !---
Needs the command on the server side. protocol pppoe ! !
!--- Virtual-template is used instead of dialer
interface. ! interface Virtual-Templat1 ip unnumbered
Loopback10 ip mtu 1492 peer default ip address pool
ippool ppp authentication chap ! ! interface Loopback10
ip address 8.8.8.1 255.255.255.0 ! ip local pool ippool
9.9.9.1 9.9.9.5
```

验证

当前没有可用于此配置的验证过程。

故障排除

本部分提供的信息可用于对配置进行故障排除。

[命令输出解释程序工具](#) ([仅限注册用户](#)) 支持某些 **show** 命令，使用此工具可以查看对 show 命令输出的分析。

注意： 在发出 **debug** 命令之前，请参阅[有关 debug 命令的重要信息](#)。

调试PPPoE客户端

为了调试Cisco 827路由器或Cisco 6400 NRP的PPPoE客户端，您必须考虑协议栈。您能开始在底部排除故障。

- 4. [PPP 层](#)
- 3. [以太网层](#)
- 2. [ATM 层](#)
- 1. [DSL 物理层](#)

1. [DSL 物理层](#)

确保线路是上和培训。

```
show interface atm0 ATM0 is up, line protocol is up Hardware is PQUICC_SAR (with Alcatel ADSL
Module) show dsl interface atm0 !--- Look for "Showtime" in the first few lines. ATU-R (DS) ATU-
C (US) Modem Status: Showtime (DMTDSL_SHOWTIME)
```

2. ATM层

如果ATM接口是UP，请使用**debug atm packets**命令发现任何是否自ISP进来。

注意：您看不到输出数据包用此命令由于方式数据包处理。

您需要发现输出类似于此，与同一个，SAP，CTL，并且显示该流入的ATM信息包的OUI字段是AAL5SNAP。

```
debug atm packet 03:21:32: ATM0(I): VCD:0x2 VPI:0x1 VCI:0x1 Type:0x0 SAP:AAAA CTL:03 OUI:0080C2
TYPE:0007 Length:0x30 03:21:32: 0000 0050 7359 35B7 0001 96A4 84AC 8864 1100 0001 000E C021 09AB
000C 0235 03:21:32: 279F 0000 0000 03:21:32:
```

3. 以太网层

完整以太网帧在AAL5SNAP数据包。**debug ethernet packet**命令。然而，您需要执行一些VPDN调试为了发现PPPoE帧。

作为参考，实际是PPPoE帧的以太网帧包含二种以太网类型中的一种。

- 0x8863以太网类型= PPPoE控制信息包(处理PPPoE会话)
- 0x8864以太网类型= PPPOE信息包(包含PPP数据包)

一重要提示是有PPPoE的两会话。是VPDN L2TP类型会话和PPP会话的PPPoE会话。所以，为了设立PPPoE，您有一个PPPoE会话建立阶段和一个PPP会话建立阶段。

终端通常介入一个PPP终止阶段和一个PPPoE终止阶段。

PPPoE建立阶段包括PPPoE客户端和服务端(MAC地址)的识别和会话ID的分配。在这完成后，正常PPP建立出现正如其他PPP连接。

为了调试，使用VPDN PPPoE调试帮助您确定PPPoE连接阶段是否是成功的。

```
#debug vpdn pppoe-events 06:17:58: Sending PADI: vc=1/1 !--- A broadcast Ethernet frame (in this
case encapsulated in ATM) !--- that requests a PPPoE server, "Are there any PPPoE servers out
there?" 06:18:00: PPPOE: we've got our pado and the pado timer went off !--- This is a unicast
reply from a PPPoE server !--- (very similar to a DHCP offer). 06:18:00: OUT PADR from PPPoE
tunnel !--- This is a unicast reply that accepts the offer. 06:18:00: IN PADS from PPPoE tunnel
!--- This is a confirmation and the establishment completes.
```

PPP建立在其他PPP开始开始正如。在PPPoE会话建立后，请使用**show vpdn**命令为了得到状态。

```
#show vpdn %No active L2TP tunnels %No active L2F tunnels PPPoE Tunnel and Session Information
Total tunnels 1 sessions 1 PPPoE Tunnel Information Session count: 1 PPPoE Session Information
SID RemMAC LocMAC Intf VASt OIntf VC 1 0050.7359.35b7 0001.96a4.84ac Vi1 UP AT0 1 1
```

使用**show vpdn session all**命令，您能获得信息包计数信息。

```
show vpdn session all %No active L2TP tunnels %No active L2F tunnels PPPoE Session Information
Total tunnels 1 sessions 1 session id: 1 local MAC address: 0001.96a4.84ac, remote MAC address:
0050.7359.35b7 virtual access interface: Vi1, outgoing interface: AT0, vc: 1/1 1656 packets
sent, 1655 received, 24516 bytes sent, 24486 received
```

其它调试命令：

- debug vpdn pppoe-data
- debug pppoe-errors
- debug pppoe-packets

PPP 层

建立PPPoE会话之后，PPP调试与其他PPP建立模式相同。

使用同样debug ppp negotiation和debug ppp authentication指令。以下是示例输出。

注意：在此示例，主机名是"client1"，并且远程Cisco 6400 NRP的名称是"nrp-b"。

```
06:36:03: Vi1 PPP: Treating connection as a callout
06:36:03: Vi1 PPP: Phase is ESTABLISHING, Active Open [0 sess, 1 load]
06:36:03: Vi1 PPP: No remote authentication for call-out
06:36:03: Vi1 LCP: O CONFREQ [Closed] id 1 len 10
06:36:03: Vi1 LCP:   MagicNumber 0x03013D43 (0x050603013D43)
06:36:03: Vi1 LCP: I CONFACK [REQsent] id 1 len 10
06:36:03: Vi1 LCP:   MagicNumber 0x03013D43 (0x050603013D43)
06:36:05: Vi1 LCP: I CONFREQ [ACKrcvd] id 2 len 15
06:36:05: Vi1 LCP:   AuthProto CHAP (0x0305C22305)
06:36:05: Vi1 LCP:   MagicNumber 0x65E315E5 (0x050665E315E5)
06:36:05: Vi1 LCP: O CONFACK [ACKrcvd] id 2 len 15
06:36:05: Vi1 LCP:   AuthProto CHAP (0x0305C22305)
06:36:05: Vi1 LCP:   MagicNumber 0x65E315E5 (0x050665E315E5)
06:36:05: Vi1 LCP: State is Open
06:36:05: Vi1 PPP: Phase is AUTHENTICATING, by the peer [0 sess, 1 load]
06:36:05: Vi1 CHAP: I CHALLENGE id 9 len 26 from "nrp-b"
06:36:05: Vi1 CHAP: Using alternate hostname client1
06:36:05: Vi1 CHAP: Username nrp-b not found
06:36:05: Vi1 CHAP: Using default password
06:36:05: Vi1 CHAP: O RESPONSE id 9 len 28 from "client1"
06:36:05: Vi1 CHAP: I SUCCESS id 9 len 4
06:36:05: Vi1 PPP: Phase is FORWARDING [0 sess, 1 load]
06:36:05: Vi1 PPP: Phase is AUTHENTICATING [0 sess, 1 load]
06:36:05: Vi1 PPP: Phase is UP [0 sess, 1 load]
06:36:05: Vi1 IPCP: O CONFREQ [Closed] id 1 len 10
06:36:05: Vi1 IPCP:   Address 0.0.0.0 (0x030600000000)
06:36:05: Vi1 CDPCP: O CONFREQ [Closed] id 1 len 4
06:36:05: Vi1 IPCP: I CONFREQ [REQsent] id 1 len 10
06:36:05: Vi1 IPCP:   Address 8.8.8.1 (0x030608080801)
06:36:05: Vi1 IPCP:   Address 8.8.8.1 (0x030608080801)
06:36:05: Vi1 IPCP:   Address 9.9.9.2 (0x030609090902)
06:36:05: Vi1 IPCP: O CONFREQ [ACKsent] id 2 len 10
06:36:05: Vi1 IPCP:   Address 9.9.9.2 (0x030609090902)
06:36:05: Vi1 LCP: I PROTREJ [Open] id 3 len 10 protocol CDPCP (0x820701010004)
06:36:05: Vi1 CDPCP: State is Closed
06:36:05: Vi1 IPCP: I CONFACK [ACKsent] id 2 len 10
06:36:05: Vi1 IPCP:   Address 9.9.9.2 (0x030609090902)
06:36:05: Vi1 IPCP: State is Open
06:36:05: Di1 IPCP: Install negotiated IP interface address 9.9.9.2
06:36:05: Di1 IPCP: Install route to 8.8.8.1
06:36:06: %LINEPROTO-5-UPDOWN: Line protocol on Interface Virtual-Access1,
changed state to up
```

调试PPPoE服务器

为了调试Cisco 6400 (PPPoE服务器)，请使用用于Cisco 827路由器的同一个自上而上的过程(客户端)。区别在DSL的物理层，这里您需要检查DSL接入复用器(DSLAM)。

- 4. [PPP 层](#)
- 3. [以太网层](#)
- 2. [ATM 层](#)
- 1. [DSL 物理层](#)

1. [DSL 物理层](#)

为了检查DSL物理层，您需要发现在DSLAM的DSL统计信息。对于Cisco DSLAMs，请使用**show dsl interface**命令。

2. [ATM 层](#)

在Cisco 6400端，您也能使用**debug atm packet**命令，为一个特定永久虚拟电路(PVC)启用Cisco 6400。

```
debug atm packet interface atm 0/0/0.182 vc 1/82
```

您需要发现输出类似于此，与同一个，SAP，CTL，并且显示该流入的ATM信息包的OUI字段是AAL5SNAP。

```
4d04h: ATM0/0/0.182(I):
VCD:0x3 VPI:0x1 VCI:0x52 Type:0x900 SAP:AAAA CTL:03 OUI:0080C2 TYPE:0007 Length:0x30 4d04h: 0000
0001 96A4 84AC 0050 7359 35B7 8864 1100 0001 000E C021 0A2E 000C 65E3 4d04h: 15E5 0000 0000
```

注意：您看不到输出数据包用此命令由于方式数据包处理。

3. [以太网层](#)

在Cisco 827路由器使用的相同的VPDN show命令和debug可以在Cisco 6400 NRP上使用，以查看PPPoE的建立。

```
#debug vpdn pppoe-events 4d04h: IN PADI from PPPoE tunnel 4d04h: OUT PADO from PPPoE tunnel
4d04h: IN PADR from PPPoE tunnel 4d04h: PPPoE: Create session 4d04h: PPPoE: VPN session created.
4d04h: OUT PADS from PPPoE tunnel #show vpdn %No active L2TP tunnels %No active L2F tunnels PPPoE
Tunnel and Session Information Total tunnels 1 sessions 1 PPPoE Tunnel Information Session
count: 1 PPPoE Session Information SID RemMAC LocMAC Intf VASt OIntf VC 1 0001.96a4.84ac
0050.7359.35b7 Vi4 UP AT0/0/0 1 82 nrp-b#show vpdn session all %No active L2TP tunnels %No
active L2F tunnels PPPoE Session Information Total tunnels 1 sessions 1 session id: 1 local MAC
address: 0050.7359.35b7, remote MAC address: 0001.96a4.84ac virtual access interface: Vi4,
outgoing interface: AT0/0/0, vc: 1/82 30 packets sent, 28 received, 422 bytes sent, 395 received
其它调试命令：
```

- debug vpdn pppoe-data
- debug pppoe-errors
- debug pppoe-packets

4. [PPP 层](#)

这是对应于从Cisco 827路由器的更早的调试从Cisco 6400 NRP的PPP debug输出。

```
debug ppp negotiation and debug ppp authentication 4d04h: Vi2 PPP: Treating connection as a
dedicated line 4d04h: Vi2 PPP: Phase is ESTABLISHING, Active Open [0 sess, 1 load] 4d04h: Vi2
```

LCP: O CONFREQ [Closed] id 1 len 15 4d04h: Vi2 LCP: AuthProto CHAP (0x0305C22305) 4d04h: Vi2 LCP: MagicNumber 0x65F62814 (0x050665F62814) 4d04h: Vi2 LCP: I CONFREQ [REQsent] id 1 len 10 4d04h: Vi2 LCP: MagicNumber 0x03144FF9 (0x050603144FF9) 4d04h: Vi2 LCP: O CONFACK [REQsent] id 1 len 10 4d04h: Vi2 LCP: MagicNumber 0x03144FF9 (0x050603144FF9) 4d04h: Vi3 LCP: I ECHOREQ [Open] id 60 len 8 magic 0xA60C0000 4d04h: Vi3 LCP: O ECHOREP [Open] id 60 len 8 magic 0x51A0BEF6 4d04h: Vi2 LCP: TIMEOUT: State ACKsent 4d04h: Vi2 LCP: O CONFREQ [ACKsent] id 2 len 15 4d04h: Vi2 LCP: AuthProto CHAP (0x0305C22305) 4d04h: Vi2 LCP: MagicNumber 0x65F62814 (0x050665F62814) 4d04h: Vi2 LCP: I CONFACK [ACKsent] id 2 len 15 4d04h: Vi2 LCP: AuthProto CHAP (0x0305C22305) 4d04h: Vi2 LCP: MagicNumber 0x65F62814 (0x050665F62814) 4d04h: Vi2 LCP: State is Open 4d04h: Vi2 PPP: Phase is AUTHENTICATING, by this end [0 sess, 1 load] 4d04h: Vi2 CHAP: O CHALLENGE id 10 len 26 from "nrp-b" 4d04h: Vi2 CHAP: I RESPONSE id 10 len 28 from "client1" 4d04h: Vi2 PPP: Phase is FORWARDING [0 sess, 1 load] 4d04h: Vi2 PPP: Phase is AUTHENTICATING [0 sess, 1 load] 4d04h: Vi2 CHAP: O SUCCESS id 10 len 4 4d04h: Vi2 PPP: Phase is UP [0 sess, 1 load] 4d04h: Vi2 IPCP: O CONFREQ [Closed] id 1 len 10 4d04h: Vi2 IPCP: Address 8.8.8.1 (0x030608080801) 4d04h: Vi2 IPCP: I CONFREQ [REQsent] id 1 len 10 4d04h: Vi2 IPCP: Address 0.0.0.0 (0x030600000000) 4d04h: Vi2 IPCP: Pool returned 9.9.9.2 4d04h: Vi2 IPCP: O CONFNAK [REQsent] id 1 len 10 4d04h: Vi2 IPCP: Address 9.9.9.2 (0x030609090902) 4d04h: Vi2 CDPCP: I CONFREQ [Not negotiated] id 1 len 4 4d04h: Vi2 LCP: O PROTREJ [Open] id 3 len 10 protocol CDPCP (0x820701010004) 4d04h: Vi2 IPCP: I CONFACK [REQsent] id 1 len 10 4d04h: Vi2 IPCP: Address 8.8.8.1 (0x030608080801) 4d04h: Vi2 IPCP: I CONFREQ [ACKrcvd] id 2 len 10 4d04h: Vi2 IPCP: Address 9.9.9.2 (0x030609090902) 4d04h: Vi2 IPCP: O CONFACK [ACKrcvd] id 2 len 10 4d04h: Vi2 IPCP: Address 9.9.9.2 (0x030609090902) 4d04h: Vi2 IPCP: State is Open 4d04h: Vi2 IPCP: Install route to 9.9.9.2 4d04h: %LINEPROTO-5-UPDOWN: Line protocol on Interface Virtual-Access2, changed state to up

相关信息

- [Cisco DSL技术支持信息](#)
- [思科800系列路由器产品支持信息](#)
- [技术支持 - Cisco Systems](#)