

Send comments to nx5000-docfeedback@cisco.com



CHAPTER 8

Fibre Channel Commands

This chapter describes the Cisco NX-OS Fibre Channel, virtual Fibre Channel, and Fibre Channel over Ethernet (FCoE) commands available on Cisco Nexus 5000 Series switches.

Send comments to nx5000-docfeedback@cisco.com

cfs distribute

To enable or disable Cisco Fabric Services (CFS) distribution on the switch, use the **cfs distribute** command. To disable this feature, use the **no** form of this command.

cfs distribute

no cfs distribute

Syntax Description This command has no arguments or keywords.

Command Default CFS distribution is enabled.

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines By default, CFS is in the distribute mode. In the distribute mode, fabric-wide distribution is enabled. Applications can distribute configuration data to all CFS-capable switches in the fabric where the application exists. This is the normal mode of operation.

If you disable CFS distribution by entering the **no cfs distribute** command, the following events occur:

- The CFS commands continue to operate. However, CFS and the applications using CFS on the switch are isolated from the rest of the fabric even though there is physical connectivity.
- All CFS operations are restricted to the isolated switch.
- CFS operations (for example, lock, commit, and abort) initiated at other switches do not have any effect at the isolated switch.
- CFS distribution is disabled over both Fibre Channel and IP.

Examples This example shows how to disable CFS distribution:

```
switch(config)# no cfs distribute
```

This example shows how to reenab CFS distribution:

```
switch(config)# cfs distribute
```

Related Commands	Command	Description
	show cfs status	Displays whether CFS distribution is enabled or disabled.

Send comments to nx5000-docfeedback@cisco.com

cfs ipv4 distribute

To enable Cisco Fabric Services (CFS) distribution over IPv4 for applications that want to use this feature, use the **cfs ipv4** command. To disable this feature, use the **no** form of this command.

cfs ipv4 distribute

no cfs ipv4 distribute

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	CFS distribution is enabled. CFS over IP is disabled.
------------------------	---

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	<p>All CFS over IP enabled switches with similar multicast addresses form one CFS over IP fabric. CFS protocol-specific distributions, such as the keepalive mechanism for detecting network topology changes, use the IP multicast address to send and receive information.</p> <p>Observe the following guidelines when using this command:</p> <ul style="list-style-type: none">• If a switch is reachable over both IP and Fibre Channel, application data will be distributed over Fibre Channel.• You can select either an IPv4 or IPv6 distribution when CFS is enabled over IP.• Both IPv4 and IPv6 distribution cannot be enabled on the same switch.• A switch that has IPv4 distribution enabled cannot detect a switch that IPv6 distribution enabled. The switches operate as if they are in two different fabrics even though they are connected to each other.
-------------------------	---

Examples	This example shows how to disable CFS IPv4 distribution:
-----------------	--

```
switch(config)# no cfs ipv4 distribute
This will prevent CFS from distributing over IPv4 network.
Are you sure? (y/n) [n]
```

This example shows how to reenable CFS IPv4 distribution:

```
switch(config)# cfs ipv4 distribute
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	cfs ipv4 mcast-address	Configures an IPv4 multicast address for Cisco Fabric Services (CFS) distribution over IPv4.
	show cfs status	Displays whether CFS distribution is enabled or disabled.

Send comments to nx5000-docfeedback@cisco.com

cfs ipv4 mcast-address

To configure an IPv4 multicast address for Cisco Fabric Services (CFS) distribution over IPv4, use the **cfs ipv4 mcast-address** command. To disable this feature, use the **no** form of this command.

cfs ipv4 mcast-address *ipv4-address*

no cfs ipv4 mcast-address *ipv4-address*

Syntax Description

<i>ipv4-address</i>	IPv4 multicast address for CFS distribution over IPv4. The range of valid IPv4 addresses is 239.255.0.0 through 239.255.255.255 and 239.192.0.0 through 239.251.251.251.
---------------------	--

Command Default

Multicast address: 239.255.70.83.

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

Before using this command, enable CFS distribution over IPv4 by using the **cfs ipv4 distribute** command.

All CFS over IP-enabled switches with similar multicast addresses form one CFS over IP fabric. CFS protocol-specific distributions, such as the keepalive mechanism for detecting network topology changes, use the IP multicast address to send and receive information.

CFS distributions for application data use directed unicast.

You can configure a value for a CFS over IP multicast address. The default IPv4 multicast address is 239.255.70.83.

Examples

This example shows how to configure an IP multicast address for CFS over IPv4:

```
switch(config)# cfs ipv4 mcast-address 239.255.1.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP ?
Are you sure? (y/n) [n] y
```

This example shows how to revert to the default IPv4 multicast address for CFS distribution over IPv4:

```
switch(config)# no cfs ipv4 mcast-address 10.1.10.100
Distribution over this IP type will be affected
Change multicast address for CFS-IP ?
Are you sure? (y/n) [n] y
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	cfs ipv4 distribute	Enables or disables Cisco Fabric Services (CFS) distribution over IPv4.
	show cfs status	Displays whether CFS distribution is enabled or disabled.

Send comments to nx5000-docfeedback@cisco.com

cfs ipv6 distribute

To enable Cisco Fabric Services (CFS) distribution over IPv6 for applications using CFS, use the **cfs ipv6 distribute** command. To disable this feature, use the **no** form of this command.

cfs ipv6 distribute

no cfs ipv6 distribute

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	CFS distribution is enabled. CFS over IPv4 is disabled.
------------------------	---

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	All CFS over IP-enabled switches with similar multicast addresses form one CFS over IP fabric. CFS protocol-specific distributions, such as the keepalive mechanism for detecting network topology changes, use the IP multicast address to send and receive information.
	Observe the following guidelines when using this command: <ul style="list-style-type: none">• If a switch is reachable over both IP and Fibre Channel, application data will be distributed over Fibre Channel.• You can select either an IPv4 or IPv6 distribution when CFS is enabled over IP.• Both IPv4 and IPv6 distribution cannot be enabled on the same switch.• A switch that has IPv4 distribution enabled cannot detect a switch that IPv6 distribution enabled. The switches operate as if they are in two different fabrics even though they are connected to each other.

Examples	This example shows how to disable CFS IPv6 distribution:
-----------------	--

```
switch(config)# no cfs ipv6 distribute
This will prevent CFS from distributing over IPv6 network.
Are you sure? (y/n) [n]
```

This example shows how to reenab CFS IPv6 distribution:

```
switch(config)# cfs ipv6 distribute
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	cfs ipv6 mcast-address	Configures an IPv6 multicast address for Cisco Fabric Services (CFS) distribution over IPv6.
	show cfs status	Displays whether CFS distribution is enabled or disabled.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

cfs ipv6 mcast-address

To configure an IPv6 multicast address for Cisco Fabric Services (CFS) distribution over IPv6, use the **cfs ipv6 mcast-address** command. To disable this feature, use the **no** form of this command.

cfs ipv6 mcast-address *ipv6-address*

no cfs ipv6 mcast-address *ipv6-address*

Syntax Description

<i>ipv6-address</i>	IPv6 multicast address or CFS distribution over IPv6. The IPv6 Admin scope range is [ff15::/16, ff18::/16].
---------------------	---

Command Default

Multicast address: ff15::efff:4653

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

Before using this command, enable CFS distribution over IPv6 by using the **cfs ipv6 distribute** command.

All CFS over IP-enabled switches with similar multicast addresses form one CFS over IP fabric. CFS protocol-specific distributions, such as the keepalive mechanism for detecting network topology changes, use the IP multicast address to send and receive information. CFS distributions for application data use directed unicast.

You can configure a CFS over IP multicast address value for IPv6. The default IPv6 multicast address is ff15::efff:4653. Examples of the IPv6 Admin scope range are ff15::0000:0000 to ff15::ffff:ffff and ff18::0000:0000 to ff18::ffff:ffff.

Examples

This example shows how to configure an IP multicast address for CFS over IPv6:

```
switch(config)# cfs ipv6 mcast-address ff13::e244:4754
Distribution over this IP type will be affected
Change multicast address for CFS-IP ?
Are you sure? (y/n) [n] y
```

This example shows how to revert to the default IPv6 multicast address for CFS distribution over IPv6:

```
switch(config)# no cfs ipv6 mcast-address ff13::e244:4754
Distribution over this IP type will be affected
Change multicast address for CFS-IP ?
Are you sure? (y/n) [n] y
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	cfs ipv6 distribute	Enables or disables Cisco Fabric Services (CFS) distribution over IPv6.
	show cfs status	Displays whether CFS distribution is enabled or disabled.

Send comments to nx5000-docfeedback@cisco.com

cfs region

To create a region that restricts the scope of application distribution to the selected switches, use the **cfs region** command. To disable this feature, use the **no** form of this command.

cfs region *region-id*

no cfs region *region-id*

Syntax Description

<i>region-id</i>	Region identifier. The range is from 1 to 255. A total of 200 regions are supported.
------------------	--

Command Default

The default region identifier is 0.

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

An application can only be a part of one region on a given switch. By creating the region ID and assigning it to an application, the application distribution is restricted to switches with a similar region ID.

Cisco Fabric Services (CFS) regions provide the ability to create distribution islands within the application scope. Currently, the regions are supported only for physical scope applications. In the absence of any region configuration, the application will be a part of the default region. The default region is region ID 0.

Examples

This example shows how to create a region ID:

```
switch(config)# cfs region 1
```

This example shows how to assign an application to a region:

```
switch(config)# cfs region 1
switch(config-cfs-region)# ntp
```

This example shows how to remove an application assigned to a region:

```
switch(config)# cfs region 1
switch(config-cfs-region)# no ntp
```

Related Commands

Command	Description
show cfs regions	Displays all configured applications with peers.

Send comments to nx5000-docfeedback@cisco.com

cfs staggered-merge

To enable Cisco Fabric Series (CFS) to merge the data from multiple Virtual SANs (VSANs), use the **cfs staggered-merge** command. To disable this feature, use the **no** form of this command.

cfs staggered-merge enable

no cfs staggered-merge enable

Syntax Description	enable	Enables the CFS staggered-merge option.
---------------------------	---------------	---

Command Default	Staggered merge is disabled.
------------------------	------------------------------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to enable CFS staggered merge: switch(config)# cfs staggered-merge enable
-----------------	--

Related Commands	Command	Description
	show cfs status	Displays whether staggered merge is enabled.

Send comments to nx5000-docfeedback@cisco.com

clear device-alias

To clear device alias information, use the **clear device-alias** command.

clear device-alias { **database** | **session** | **statistics** }

Syntax Description	database	Clears the device alias database.
	session	Clears session information.
	statistics	Clears device alias statistics.

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to clear the device alias session: <pre>switch# clear device-alias session</pre>
----------	--

Related Commands	Command	Description
	show device-alias	Displays device alias database information.

Send comments to nx5000-docfeedback@cisco.com

clear fcdomain

To clear the entire list of configured hosts, use the **clear fcdomain** command.

clear fcdomain session vsan *vsan-id*

Syntax Description	session	Clears session information.
	vsan <i>vsan-id</i>	Clears Fibre Channel domains for a specified VSAN ranging from 1 to 4093.

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	This command clears only the list of configured hosts. Existing connections are not terminated.
------------------	---

Examples	This example shows how to clear the entire list of configured hosts for remote capture: switch# clear fcdomain
----------	--

Related Commands	Command	Description
	show fcdomain	Displays the list of hosts configured for a remote capture.

Send comments to nx5000-docfeedback@cisco.com

clear fcflow stats

To clear Fibre Channel flow statistics, use the **clear fcflow stats** command.

clear fcflow stats [**aggregated**] **index** *flow-index*

Syntax Description	aggregated	(Optional) Clears the Fibre Channel flow aggregated statistics.
	index	Clears the Fibre Channel flow counters for a specified flow index.
	<i>flow-index</i>	Flow index number.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to clear aggregated Fibre Channel flow statistics for flow index 1:
	<pre>switch(config)# clear fcflow stats aggregated index 1</pre>

Related Commands	Command	Description
	show fcflow	Displays the fcflow statistics.

Send comments to nx5000-docfeedback@cisco.com

clear fcns statistics

To clear the name server statistics, use the **clear fcns statistics** command.

clear fcns statistics vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Clears the FCS statistics for a specified VSAN ranging from 1 to 4093.	
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Examples	<p>This example shows how to clear the name server statistics:</p> <pre>switch# clear fcns statistics vsan 1</pre>	
Related Commands	Command	Description
	show fcns statistics	Displays the name server statistics.

Send comments to nx5000-docfeedback@cisco.com

clear fcsn log

To clear the Fibre Channel Signal Modeling (FCSM) log, use the **clear fcsn log** command.

clear fcsn log

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to clear the FSCM log: switch# clear fcsn log
-----------------	--

Related Commands	Command	Description
	show fcs	Displays the fabric configuration server information.

Send comments to nx5000-docfeedback@cisco.com

clear fcs statistics

To clear the fabric configuration server statistics, use the **clear fcs statistics** command.

clear fcs statistics vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Clears the FCS statistics for a specified VSAN ranging from 1 to 4093.	
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Examples	<p>This example shows how to clear the fabric configuration server statistics for VSAN 10:</p> <pre>switch# clear fcs statistics vsan 10</pre>	
Related Commands	Command	Description
	show fcs statistics	Displays the fabric configuration server statistics information.

Send comments to nx5000-docfeedback@cisco.com

clear fctimer session

To clear fctimer Cisco Fabric Services (CFS) session configuration and locks, use the **clear fctimer session** command.

clear fctimer session

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	<p>This example shows how to clear an fctimer session:</p> <pre>switch# clear fctimer session</pre>
-----------------	---

Related Commands	Command	Description
	show fctimer	Displays fctimer information.

Send comments to nx5000-docfeedback@cisco.com

clear fspf counters

To clear the Fabric Shortest Path First (FSPF) statistics, use the **clear fspf counters** command.

clear fspf counters vsan *vsan-id* [**interface** *type*]

Syntax Description	vsan	Indicates that the counters are to be cleared for a VSAN.
	<i>vsan-id</i>	VSAN ID. The range is from 1 to 4093.
	interface <i>type</i>	(Optional) Specifies that the counters are to be cleared for an interface. The interface types are fc (Fibre Channel) and san-port-channel (SAN port channel).
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Usage Guidelines	If the interface is not specified, then all of the counters of a VSAN are cleared. If the interface is specified, then the counters of the specific interface are cleared.	
Examples	This example shows how to clear the FSPF statistics on VSAN 1:	
	switch# clear fspf counters vsan 1	
	This example shows how to clear the FSPF statistics in VSAN 1 for the specified Fibre Channel interface:	
	switch# clear fspf counters vsan 1 interface fc 3/2	
Related Commands	Command	Description
	show fspf	Displays global FSPF information for a specific VSAN.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

clear fc-port-security

To clear the port security information on the switch, use the **clear fc-port-security** command.

```
clear fc-port-security {database auto-learn {interface fc slot/port | san-port-channel port} |
session | statistics} vsan vsan-id
```

Syntax Description

database	Clears the port security active configuration database.
auto-learn	Clears the automatically learned entries for a specified interface or VSAN.
interface fc slot/port	Clears entries for the specified Fibre Channel interface.
san-port-channel port	Clears entries for a specified SAN port channel. The range is from 1 to 128.
session	Clears the port security CFS configuration session and locks.
statistics	Clears the port security counters.
vsan vsan-id	Clears entries for a specified VSAN ID. The range is from 1 to 4093.

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.
4.2(1)N1(1)	The clear fc-port-security command was added.
Note	On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.2(1)N1(1), this command was known as the clear port-security command.

Usage Guidelines

The active database is read-only and the **clear fc-port-security database** command can be used when resolving conflicts.

Examples

This example shows how to clear all existing statistics from the port security database for a specified VSAN:


```
switch# clear fc-port-security statistics vsan 1
```

This example shows how to clear the learned entries in the active database for a specified interface within a VSAN:

```
switch# clear fc-port-security database auto-learn interface fc2/1 vsan 1
```

This example shows how to clear the learned entries in the active database up to for the entire VSAN:

```
switch# clear fc-port-security database auto-learn vsan 1
```

 clear fc-port-security

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	show fc-port-security	Displays the configured port security information.

Send comments to nx5000-docfeedback@cisco.com

clear rlir

To clear Registered Link Incident Report (RLIR) information, use the **clear rlir** command.

clear rlir {**history** | **recent** {**interface fc** *slot/port* | **portnumber** *port*} | **statistics vsan** *vsan-id*}

Syntax Description		
history		Clears RLIR incident link history.
recent		Clears recent link incidents.
interface fc <i>slot/port</i>		Clears entries for the specified interface.
portnumber <i>port</i>		Displays the port number for the link incidents.
statistics		Clears the RLIR statistics.
vsan <i>vsan-id</i>		Clears the RLIR statistics for a Virtual SAN (VSAN). The ID of the VSAN is from 1 to 4093.

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to clear the RLIR statistics for VSAN 1:

```
switch# clear rlir statistics vsan 1
```

Related Commands	Command	Description
	show rlir	Displays RLIR information.

Send comments to nx5000-docfeedback@cisco.com

clear rscn session

To clear a Registered State Change Notification (RSCN) session for a specified Virtual SAN (VSAN), use the **clear rscn session** command.

clear rscn session vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i>	Specifies a VSAN where the RSCN session should be cleared. The ID of the VSAN is from 1 to 4093.
--------------------	----------------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	<p>This example shows how to clear an RSCN session on VSAN 1:</p> <pre>switch# clear rscn session vsan 1</pre>
----------	---

Related Commands	Command	Description
	rscn	Configures an RSCN.
	show rscn	Displays RSCN information.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

clear rscn statistics

To clear the registered state change notification statistics for a specified Virtual SAN (VSAN), use the **clear rscn statistics** command.

clear rscn statistics vsan *vsan-id*

Syntax Description

vsan	Clears the RSCN statistics for a VSAN.
<i>vsan-id</i>	ID of the VSAN is from 1 to 4093.

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Examples

This example shows how to clear the RSCN statistics for VSAN 1:

```
switch# clear rscn statistics vsan 1
```

Related Commands

Command	Description
show rscn	Displays RSCN information.

Send comments to nx5000-docfeedback@cisco.com

clear zone

To clear all configured information in the zone server for a specified Virtual SAN (VSAN), use the **clear zone** command.

clear zone { **database** | **lock** | **statistics** } **vsan** *vsan-id*

Syntax Description

database	Clears zone server database information.
lock	Clears a zone server database lock.
statistics	Clears zone server statistics.
vsan	Clears zone information for a VSAN.
<i>vsan-id</i>	ID of the VSAN. The range is from 1 to 4093.

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

After entering a **clear zone database** command, you must explicitly enter the **copy running-config startup-config** command to ensure that the running configuration is used when you next start the switch.

When you enter the **clear zone lock** command from a remote switch, only the lock on that remote switch is cleared. When you enter the **clear zone lock** command from the switch where the lock originated, all locks in the VSAN are cleared. The recommended method to clear a session lock on a switch where the lock originated is by entering the **no zone commit vsan** command.

Examples

This example shows how to clear all configured information in the zone server for VSAN 1:

```
switch# clear zone database vsan 1
```

Related Commands

Command	Description
show zone	Displays zone information for any configured interface.

Send comments to nx5000-docfeedback@cisco.com

device-alias abort

To discard a Distributed Device Alias Services (device alias) Cisco Fabric Services (CFS) distribution session in progress, use the **device-alias abort** command.

device-alias abort

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 4.0	This command was introduced.

Examples	<p>This example shows how to discard a device alias CFS distribution session in progress:</p> <pre>switch(config)# device-alias abort</pre>
-----------------	--

Related Commands	Command	Description
	device-alias database	Configures and activates the device alias database.
	device-alias distribute	Enables CFS distribution for device aliases.
	show device-alias	Displays device alias information.

Send comments to nx5000-docfeedback@cisco.com

device-alias commit

To apply the pending configuration pertaining to the Distributed Device Alias Services (device alias) Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **device-alias commit** command.

device-alias commit

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration mode

Command History	Release	Modification
	Release 4.0	This command was introduced.

Examples This example shows how to commit pending changes to the active Dynamic Port VSAN Membership (DPVM) database:

```
switch(config)# device-alias commit
```

Related Commands	Command	Description
	device-alias database	Configures and activates the device alias database.
	device-alias distribute	Enables CFS distribution for device aliases.
	show device-alias	Displays device alias information.

Send comments to nx5000-docfeedback@cisco.com

device-alias database

To initiate a Distributed Device Alias Services (device alias) session and configure the device alias database, use the **device-alias database** command. To deactivate the device alias database, use the **no** form of this command.

device-alias database

no device-alias database

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Deactivated
------------------------	-------------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 4.0	This command was introduced.

Usage Guidelines	The device-alias database command starts a device alias session that locks all the databases on all the switches in this fabrics. When you exit device alias database configuration mode, the device alias session ends and the locks are released.
-------------------------	--

You can only perform all modifications in the temporary device alias database. To make the changes permanent, use the device-alias commit command.

Examples	This example shows how to activate a device alias session and enter device alias database configuration mode:
-----------------	---

<pre>switch(config)# device-alias database switch(config-device-alias-db)#</pre>

Related Commands	Command	Description
	device-alias commit	Commits changes from the temporary device alias database to the active device alias database.
	show device-alias	Displays device alias database information.

Send comments to nx5000-docfeedback@cisco.com

device-alias distribute

To enable Cisco Fabric Services (CFS) distribution for Distributed Device Alias Services (device alias), use the **device-alias distribute** command. To disable this feature, use the **no** form of this command.

device-alias distribute

no device-alias distribute

Syntax Description This command has no arguments or keywords.

Command Default Enabled

Command Modes Global configuration mode

Release	Modification
Release 4.0	This command was introduced.

Usage Guidelines Use the **device-alias commit** command to apply pending changes to the CFS distribution session.

Examples This example shows how to enable distribution for device alias information:

```
switch(config)# device-alias distribute
```

Command	Description
device-alias commit	Commits changes to the active device alias database.
device-alias database	Configures and activates the device alias database.
show device-alias	Displays device alias information.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

device-alias import fcalias

To import device alias database information from another Virtual SAN (VSAN), use the **device-alias import fcalias** command. To revert to the default configuration or factory defaults, use the **no** form of this command.

device-alias import fcalias vsan *vsan-id*

no device-alias import fcalias vsan *vsan-id*

Syntax Description

vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is from 1 to 4093.
----------------------------	---

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
Release 4.0	This command was introduced.

Usage Guidelines

You can import legacy device name configurations using this feature without losing data, if they satisfy the following restrictions:

- Each fcalias has only one member.
- The member type is supported by the device name implementation.

If any name conflict exists, the fcalias are not imported. The device name database is completely independent from the VSAN dependent fcalias database.

When the import operation is complete, the modified global fcalias table can distribute to all other switches in the physical fabric using the **device-alias distribute** command so that new definitions are available everywhere.

Examples

This example shows how to import device alias information:

```
switch(config)# device-alias import fcalias vsan 10
```

Related Commands

Command	Description
device-alias database	Configures and activates the device alias database.
device-alias distribute	Distributes fcalias database changes to the fabric.
show device-alias	Displays device alias database information.

Send comments to nx5000-docfeedback@cisco.com

device-alias mode

To configure device alias enhanced mode, use the **device-alias mode** command. To remove device alias enhanced mode, use the **no** form of this command.

device-alias mode enhanced

no device-alias mode enhanced

Syntax Description	enhanced	Specifies enhanced mode.
--------------------	----------	--------------------------

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	Release 4.0	This command was introduced.

Examples	<p>This example shows how to configure the device alias enhanced mode:</p> <pre>switch(config)# device-alias mode enhanced</pre>
----------	---

Related Commands	Command	Description
	device-alias database	Enters device alias database configuration mode.
	show device-alias	Displays device alias database information.

Send comments to nx5000-docfeedback@cisco.com

device-alias name

To configure device names in the device alias database, use the **device-alias name** command. To remove device names from the device alias database, use the **no** form of this command.

device-alias name *device-name* **pwwn** *pwwn-id*

no device-alias name *device-name*

Syntax Description	<i>device-name</i>	Device name. The name can be a maximum of 64 characters.
	pwwn <i>pwwn-id</i>	Specifies the pWWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal number.

Command Default	None
-----------------	------

Command Modes	Device alias database configuration mode
---------------	--

Command History	Release	Modification
	Release 4.0	This command was introduced.

Examples	This example shows how to configure a device name alias entry in the device name database:
	<pre>switch(config)# device-alias database switch(config-device-alias-db)# device-alias name Device1 pwwn 21:00:00:20:37:6f:db:bb</pre>

Related Commands	Command	Description
	device-alias database	Enters device alias database configuration mode.
	show device-alias	Displays device alias database information.

Send comments to nx5000-docfeedback@cisco.com

device-alias rename

To configure device names in the device alias database, use the **device-alias rename** command. To remove device names from the device alias database, use the **no** form of this command.

device-alias rename *device-name1 device-name2*

no device-alias rename *device-name*

Syntax Description	<i>device-name1</i>	Current device name.
	<i>device-name2</i>	New device name. The maximum length is 64 characters.

Command Default	None
-----------------	------

Command Modes	Device alias database configuration mode
---------------	--

Command History	Release	Modification
	Release 4.0	This command was introduced.

Examples This example shows how to configure a device name alias entry in the device name database:

```
switch(config)# device-alias database
switch(config-device-alias-db)# device-alias rename Device1 Device2
```

Related Commands	Command	Description
	device-alias database	Enters device alias database configuration mode.
	show device-alias	Displays device alias database information.

Send comments to nx5000-docfeedback@cisco.com

discover custom-list

To selectively initiate discovery for specified domain IDs in a Virtual SAN (VSAN), use the **discover custom-list** command.

discover custom-list {**add** | **delete**} **vsan** *vsan-id* **domain** *domain-id*

Syntax Description

add	Adds a targets to the customized list.
delete	Deletes a target from the customized list.
vsan <i>vsan-id</i>	Discovers SCSI targets for the specified VSAN ID. The range is from 1 to 4093.
domain <i>domain-id</i>	Discovers SCSI targets for the specified domain ID. The range is from 1 to 239.

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Examples

This example shows how to selectively initiate the discovery for the specified VSAN and domain ID:

```
switch# discover custom-list add vsan 1 domain 2
```

This example shows how to delete the specified VSAN and domain ID from the customized list:

```
switch# discover custom-list delete vsan 1 domain 2
```

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

discover scsi-target

To discover SCSI targets on local storage to the switch or remote storage across the fabric, use the **discover scsi-target** command.

```
discover scsi-target { custom-list | local | remote | vsan vsan-id fcid fc-id } os { aix | all | hpux | linux | solaris | windows } [lun | target]
```

Syntax Description		
custom-list		Discovers SCSI targets from the customized list.
local		Discovers local SCSI targets.
remote		Discovers remote SCSI targets.
vsan <i>vsan-id</i>		Discovers SCSI targets for the specified Virtual SAN (VSAN) ID. The range is from 1 to 4093.
fcid <i>fc-id</i>		Discovers SCSI targets for the specified FCID. The format is <i>0xhhhhhhh</i> , where <i>h</i> is a hexadecimal digit.
os		Discovers the specified operating system.
aix		Discovers the AIX operating system
all		Discovers all operating systems
hpux		Discovers the HPUX operating system
linux		Discovers the Linux operating system
solaris		Discovers the Solaris operating system
windows		Discovers the Windows operating system
lun		(Optional) Discovers SCSI targets and Logical Unit Numbers (LUNs).
target		(Optional) Discovers SCSI targets.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples

This example shows how to discover local targets assigned to all OSs:

```
switch# discover scsi-target local os all
discovery started
```

This example shows how to discover remote targets assigned to the Windows OS:

```
switch# discover scsi-target remote os windows
discovery started
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to discover SCSI targets for the specified VSAN (1) and FCID (0x9c03d6):

```
switch# discover scsi-target vsan 1 fcid 0x9c03d6 os aix
discover scsi-target vsan 1 fcid 0x9c03d6
VSAN:      1 FCID: 0x9c03d6 PWWN: 00:00:00:00:00:00:00:00
PRLI RSP: 0x01 SPARM: 0x0012...
```

This example begins discovering targets from a customized list assigned to the Linux operating system:

```
switch# discover scsi-target custom-list os linux
discovery started
```

Send comments to nx5000-docfeedback@cisco.com

fabric profile

To utilize a preset quality of service (QoS) setting, use the **fabric profile** command. To restore the default, use the **no** form of this command.

fabric profile {reliable-multicast | unicast-optimized}

no fabric profile

Syntax Description	reliable-multicast	Optimizes the QoS parameters in the fabric to ensure reliable delivery of multicast traffic.
	unicast-optimized	Optimizes the QoS parameters in the fabric for unicast traffic.
Command Default	Unicast-optimized	
Command Modes	Global configuration mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Examples	<p>This example shows how to set the fabric to ensure reliable delivery of multicast traffic:</p> <pre>switch(config)# fabric profile reliable-multicast</pre> <p>This example shows how to set the fabric profile to the default value:</p> <pre>switch(config)# no fabric profile</pre>	
Related Commands	Command	Description
	show fabric profile	Displays the current setting of the fabric.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fabric-binding activate

To activate fabric binding in a Virtual SAN (VSAN), use the **fabric-binding activate** command. To disable this feature, use the **no** form of this command.

fabric-binding activate vsan *vsan-id* [**force**]

no fabric-binding activate vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i>	Specifies the VSAN. The ID of the VSAN is from 1 to 4093.
	force	(Optional) Forces fabric binding activation.
Command Default	Disabled	
Command Modes	Global configuration mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Examples	This example shows how to activate the fabric binding database for the specified VSAN:	
	<pre>switch(config)# fabric-binding activate vsan 1</pre>	
	This example shows how to deactivate the fabric binding database for the specified VSAN:	
	<pre>switch(config)# no fabric-binding activate vsan 10</pre>	
	This example shows how to forcefully activate the fabric binding database for the specified VSAN:	
	<pre>switch(config)# fabric-binding activate vsan 3 force</pre>	
	This example shows how to revert to the previously configured state or to the factory default (if no state is configured):	
	<pre>switch(config)# no fabric-binding activate vsan 1 force</pre>	
Related Commands	Command	Description
	fabric-binding database	Configures a fabric-binding database.
	fabric-binding enable	Enables fabric-binding.

Send comments to nx5000-docfeedback@cisco.com

fabric-binding database copy

To copy from the active fabric binding database to the configuration fabric binding database, use the **fabric-binding database copy** command.

fabric-binding database copy vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Specifies the Virtual SAN (VSAN). The ID of the VSAN is from 1 to 4093.	
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Usage Guidelines	<p>Fabric binding is configured on a per-VSAN basis and can be implemented in both FICON VSANs and Fibre Channel VSANs.</p> <p>If the configured database is empty, this command is not accepted.</p>	
Examples	<p>This example shows how to copy from the active database to the configuration database in VSAN 1:</p> <pre>switch# fabric-binding database copy vsan 1</pre>	
Related Commands	Command	Description
	fabric-binding diff	Provides the differences between the fabric-binding databases.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fabric-binding database diff

To view the differences between the active database and the configuration database in a Virtual SAN (VSAN), use the **fabric-binding database diff** command.

fabric-binding database diff { **active** | **config** } **vsan** *vsan-id*

Syntax Description	active	Provides information about the differences in the active database relating to the configuration database.
	config	Provides information about information on the differences in the configuration database relating to the active database.
	vsan <i>vsan-id</i>	Specifies the VSAN. The ID of the VSAN is from 1 to 4093.

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	Fabric binding is configured on a per-VSAN basis and can be implemented in both FICON VSANs and Fibre Channel VSANs.
------------------	--

Examples	This example shows how to display the differences between the active database and the configuration database in VSAN 1:
----------	---

```
switch# fabric-binding database diff active vsan 1
```

This example shows how to display information about the differences between the configuration database and the active database:

```
switch# fabric-binding database diff config vsan 1
```

Related Commands	Command	Description
	fabric-binding copy	Copies from the active to the configuration fabric binding database.

Send comments to nx5000-docfeedback@cisco.com

fabric-binding database vsan

To configure a user-specified fabric binding list in a Virtual SAN (VSAN), use the **fabric-binding database vsan** command. To disable the fabric binding, use the **no** form of this command.

fabric-binding database vsan *vsan-id*
swwn *switch-wwn* **domain** *domain-id*

fabric-binding database vsan *vsan-id*
no swwn *switch-wwn* **domain** *domain-id*

no fabric-binding database vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i>	Specifies the VSAN. The ID of the VSAN is from 1 to 4093.
	swwn <i>switch-wwn</i>	Configures the switch WWN in dotted hexadecimal format.
	domain <i>domain-id</i>	Specifies the specified domain ID. The domain ID is a number from 1 to 239.

Command Default None

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

Fabric binding is configured on a per-VSAN basis. In a Fibre Channel VSAN, only the switch world wide name (sWWN) is required; the domain ID is optional.

A user-specified fabric binding list contains a list of switch WWNs (sWWNs) within a fabric. If an sWWN attempts to join the fabric and that sWWN is not on the list, or the sWWN is using a domain ID that differs from the one specified in the allowed list, the ISL between the switch and the fabric is automatically isolated in that VSAN and the switch is denied entry into the fabric.

Examples

This example shows how to enter the fabric binding database mode and adds the sWWN and domain ID of a switch to the configured database list:

```
switch(config)# fabric-binding database vsan 5
switch(config-fabric-binding)# swwn 21:00:05:30:23:11:11:11 domain 102
```

This example shows how to delete a fabric binding database for the specified VSAN:

```
switch(config)# no fabric-binding database vsan 10
```

This example shows how to delete the sWWN and domain ID of a switch from the configured database list:

```
switch(config)# fabric-binding database vsan 5
```

Send comments to nx5000-docfeedback@cisco.com

```
switch(config-fabric-binding)# no swwn 21:00:15:30:23:1a:11:03 domain 101
```

Related Commands

Command	Description
fabric-binding activate	Activates fabric binding.
fabric-binding enable	Enables fabric binding.

Send comments to nx5000-docfeedback@cisco.com

fabric-binding enable

To enable fabric binding in a Virtual SAN (VSAN), use the **fabric-binding enable** command. To disable fabric binding, use the **no** form of this command.

fabric-binding enable

no fabric-binding enable

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Disabled
------------------------	----------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	<p>Fabric binding is configured on a per-VSAN basis.</p> <p>The fabric binding feature must be enabled in each switch in the fabric that participates in the fabric binding.</p>
-------------------------	--

Examples	<p>This example shows how to enable fabric binding on that switch:</p> <pre>switch(config)# fabric-binding enable</pre> <p>This example shows how to disable fabric binding on that switch:</p> <pre>switch(config)# no fabric-binding enable</pre>
-----------------	---

Related Commands	Command	Description
	fabric-binding activate	Activates fabric binding.
	fabric-binding database	Configures a fabric-binding database.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fc-port-security

To configure port security features and reject intrusion attempts, use the **fc-port-security** command. To negate the command or revert to the factory defaults, use the **no** form of this command.

fc-port-security { **activate vsan** *vsan-id* [**force** | **no-auto-learn**] | **auto-learn vsan** *vsan-id* | **database vsan** *vsan-id* }

no fc-port-security { **activate vsan** *vsan-id* [**force** | **no-auto-learn**] | **auto-learn vsan** *vsan-id* | **database vsan** *vsan-id* }

Syntax Description		
activate		Activates a port security database for the specified VSAN and automatically enables auto-learning.
vsan <i>vsan-id</i>		Specifies the Virtual SAN (VSAN) ID. The range is from 1 to 4093.
force		(Optional) Forces the database activation.
no-auto-learn		(Optional) Disables the auto-learning feature for the port security database.
auto-learn		Enables auto-learning for the specified VSAN.
database		Enters the port security database configuration mode for the specified VSAN.

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The fc-port-security command was added.
	Note	On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.2(1)N1(1), this command was known as the port-security command.

Usage Guidelines

When you activate the port security feature, the **auto-learn** option is also automatically enabled. You can choose to activate the fc-port-security feature and disable auto-learning by using the **fc-port-security activate vsan number no-auto-learn** command. In this case, you need to manually populate the port security database by individually securing each port.

If the **auto-learn** option is enabled on a VSAN, you cannot activate the database for that VSAN without the **force** option.

Send comments to nx5000-docfeedback@cisco.com

Examples

This example shows how to activate the port security database for the specified VSAN and automatically enable auto-learning:

```
switch(config)# fc-port-security activate vsan 1
```

This example shows how to deactivate the port security database for the specified VSAN and automatically disable auto-learning:

```
switch(config)# no fc-port-security activate vsan 1
```

This example shows how to disable the auto-learning feature for the port security database in VSAN 1:

```
switch(config)# fc-port-security activate vsan 1 no-auto-learn
```

This example shows how to enable auto-learning so the switch can learn about any device that is allowed to access VSAN 1. These devices are logged in the port security active database.

```
switch(config)# fc-port-security auto-learn vsan 1
```

This example shows how to disable auto-learning and stops the switch from learning about new devices accessing the switch:

```
switch(config)# no fc-port-security auto-learn vsan 1
```

This example shows how to enter the port security database mode for the specified VSAN:

```
switch(config)# fc-port-security database vsan 1  
switch(config-fc-port-security)#
```

This example shows how to force the VSAN 1 port security database to activate even if there are conflicts:

```
switch(config)# fc-port-security activate vsan 1 force
```

Related Commands

Command	Description
show fc-port-security database	Displays configured port security information.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fc-port-security abort

To discard the port security Cisco Fabric Services (CFS) distribution session in progress, use the **fc-port-security abort** command.

fc-port-security abort vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Specifies the VSAN ID. The range is from 1 to 4093.
--------------------	--

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The fc-port-security abort command was added.
	Note	On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.2(1)N1(1), this command was known as the port-security abort command.

Examples	This example shows how to discard a port security CFS distribution session in progress:
	<pre>switch(config)# fc-port-security abort vsan 33</pre>

Related Commands	Command	Description
	fc-port-security distribute	Enables CFS distribution for port security.
	show fc-port-security	Displays port security information.

Send comments to nx5000-docfeedback@cisco.com

fc-port-security commit

To apply the pending configuration pertaining to the port security Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **fc-port-security commit** command.

fc-port-security commit vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is from 1 to 4093.
---------------------------	----------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The fc-port-security commit command was added.
	Note	On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.2(1)N1(1), this command was known as the port-security commit command.

Examples	This example shows how to commit changes to the active port security configuration:
	<pre>switch(config)# fc-port-security commit vsan 13</pre>

Related Commands	Command	Description
	fc-port-security distribute	Enables CFS distribution for port security.
	show fc-port-security	Displays port security information.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fc-port-security database

To copy the port security database or to view the difference within the port security database, use the **fc-port-security database** command.

fc-port-security database { **copy** | **diff** { **active** | **config** } } **vsan** *vsan-id*

Syntax Description		
copy		Copies the active database to the configuration database.
diff		Provides the difference between the active and configuration port security database.
active		Writes the active database to the configuration database.
config		Writes the configuration database to the active database.
vsan <i>vsan-id</i>		Specifies the VSAN ID. The ranges is from 1 to 4093.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The fc-port-security database command was added.
		Note On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.2(1)N1(1), this command was known as the port-security database command.

Usage Guidelines If the active database is empty, the fc-port-security database is empty. Use the **fc-port-security database diff active** command to resolve conflicts.

Examples

This example shows how to copy the active database to the configured database:

```
switch# fc-port-security database copy vsan 1
```

This example shows how to provide the differences between the active database and the configuration database:

```
switch# fc-port-security database diff active vsan 1
```

This example shows how to provide information on the differences between the configuration database and the active database:

```
switch# fc-port-security database diff config vsan 1
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	fc-port-security database	Copies and provides information on the differences within the port security database.
	show fc-port-security database	Displays configured port security information.

Send comments to nx5000-docfeedback@cisco.com

fc-port-security distribute

To enable Cisco Fabric Services (CFS) distribution for port security, use the **fc-port-security distribute** command. To disable this feature, use the **no** form of this command.

fc-port-security distribute

no fc-port-security distribute

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The fc-port-security distribute command was added.
	Note	On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.2(1)N1(1), this command was known as the port-security distribute command.

Usage Guidelines Before distributing the Fibre Channel timer changes to the fabric, the temporary changes to the configuration must be committed to the active configuration by using the **fc-port-security commit** command.

Examples This example shows how to distribute the port security configuration to the fabric:

```
switch(config)# fc-port-security distribute
```

Related Commands	Command	Description
	fc-port-security commit	Commits the port security configuration changes to the active configuration.
	show fc-port-security	Displays port security information.

Send comments to nx5000-docfeedback@cisco.com

fcalias clone

To clone a Fibre Channel alias, use the **fcalias clone** command.

fcalias clone *origFcalias-Name* *cloneFcalias-Name* **vsan** *vsan-id*

Syntax Description	<i>origFcalias-Name</i>	Fibre Channel alias. The name can be a maximum of 64 characters.
	<i>cloneFcalias-Name</i>	
	vsan	Specifies the clone Fibre Channel alias for a Virtual SAN (VSAN).
	<i>vsan-id</i>	VSAN ID. The range is from 1 to 4093.

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	To disable a Fibre Channel alias, use the no form of the fcalias name command.
-------------------------	--

Examples	This example shows how to clone a fcalias called origAlias to cloneAlias on VSAN 45: switch(config)# fcalias clone origAlias cloneAlias vsan 45
-----------------	---

Related Commands	Command	Description
	show fcalias	Displays the member name information in a Fibre Channel alias (fcalias).

Send comments to nx5000-docfeedback@cisco.com

fcalias name

To configure a Fibre Channel alias, use the **fcalias name** command. To disable a Fibre Channel alias, use the **no** form of this command.

fcalias name *alias-name* **vsan** *vsan-id*

no fcalias name *alias-name* **vsan** *vsan-id*

Syntax Description	<i>alias-name</i>	Name of the fcalias. The name can a maximum of 64 characters.
	vsan	Specifies the fcalias for a Virtual SAN (VSAN).
	<i>vsan-id</i>	VSAN ID. The range is from 1 to 4093.

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	To include multiple members in any alias, use the FCID, fWWN, or pWWN values.
------------------	---

Examples	This example shows how to configure an fcalias called AliasSample on VSAN 3: switch(config)# fcalias name AliasSample vsan 3 switch(config-fcalias)#
----------	---

Related Commands	Command	Description
	member (fcalias configuration mode)	Configures alias members for a specified zone.

Send comments to nx5000-docfeedback@cisco.com

fcalias rename

To rename a Fibre Channel alias (fcalias), use the **fcalias rename** command. To revert to the defaults, use the **no** form of this command.

fcalias rename *current-name new-name vsan vsan-id*

no fcalias rename *current-name new-name vsan vsan-id*

Syntax Description	<i>current-name</i>	Current fcalias name. The name can be a maximum of 64 characters.
	<i>new-name</i>	New fcalias name. The name can be a maximum of 64 characters.
	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is from 1 to 4093.

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 4.0	This command was introduced.

Examples	This example shows how to rename an fcalias:
	<code>switch(config)# fcalias rename oldalias newalias vsan 10</code>

Related Commands	Command	Description
	fcalias name	Configures fcalias names.
	show fcalias	Displays fcalias information.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fcdomain

To configure the Fibre Channel domain feature, use the **fcdomain** command. To disable the Fibre Channel domain, use the **no** form of this command.

fcdomain { **allowed** *domain* **vsan** *vsan-id* | **auto-reconfigure** **vsan** *vsan-id* | **contiguous-allocation** **vsan** *vsan-id* | **domain** *id* { **preferred** | **static** } **vsan** *vsan-id* | **fabric-name** *name* **vsan** *vsan-id* | **fcid** { **database** | **persistent** **vsan** *vsan-id* } | **optimize fast-restart** **vsan** *vsan-id* | **priority** *value* **vsan** *vsan-id* | **restart** [**disruptive**] **vsan** *vsan-id* | **vsan** *vsan-id* }

no fcdomain { **allowed** *domain* **vsan** *vsan-id* | **auto-reconfigure** **vsan** *vsan-id* | **contiguous-allocation** **vsan** *vsan-id* | **domain** *id* { **preferred** | **static** } **vsan** *vsan-id* | **fabric-name** *name* **vsan** *vsan-id* | **fcid** { **database** | **persistent** **vsan** *vsan-id* } | **optimize fast-restart** **vsan** *vsan-id* | **priority** *value* **vsan** *vsan-id* | **restart** [**disruptive**] **vsan** *vsan-id* | **vsan** *vsan-id* }

Syntax Description	
allowed <i>domain</i>	Configures the allowed domain ID list ranging from 1 to 239.
vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is from 1 to 4093.
auto-reconfigure	Configures autoreconfigure.
contiguous-allocation	Configures contiguous allocation.
domain <i>id</i>	Configures the domain ID and its type. The range is from 0 to 239.
preferred	Configures the domain ID as preferred. By default, the local switch accepts the domain ID assigned by the principal switch and the assigned domain ID becomes the runtime domain ID.
static	Configures the domain ID as static. The assigned domain ID is discarded, all local interfaces are isolated, and the local switch assigns itself the configured domain ID, which becomes the runtime domain ID.
fabric-name <i>name</i>	Specifies the fabric name. The name format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> .
fcid	Configures Fibre Channel domain persistent FC IDs.
database	Enters persistent FC IDs mode.
persistent	Enables or disables Fibre Channel domain persistent FC IDs.
optimize fast-restart	Enables a domain manager fast restart on a specified VSAN.
priority <i>value</i>	Specifies the Fibre Channel domain priority. The range is from 1 to 254.
restart	Starts a disruptive or nondisruptive reconfiguration.
disruptive	(Optional) Forces the disruptive fabric reconfiguration.

Command Default Enabled

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Send comments to nx5000-docfeedback@cisco.com

Usage Guidelines

You can use this command to select the principal switch, configure domain ID distribution, reconfigure the fabric, and allocate FC IDs.

We recommend using the **optimize fast-restart** option on most fabrics, especially those with a large number of logical ports (3200 or more), where a logical port is an instance of a physical port in a VSAN.

Examples

This example shows how to configure a preferred domain ID for VSAN 87:

```
switch(config)# fcdomain domain 3 preferred vsan 87
```

This example shows how to specify the disruptive fabric reconfiguration for VSAN 1:

```
switch(config)# fcdomain restart disruptive vsan 1
```

This example shows how to enable the domain manager fast restart for VSANs 7 through 10:

```
switch(config)# fcdomain optimize fast-restart vsan 7 - 10
```

This example shows how to configure the fabric world wide name (fWWN) for VSAN 3:

```
switch(config)# fcdomain fabric-name 20:1:ac:16:5e:0:21:01 vsan 3
```

Related Commands

Command	Description
show fcdomain	Displays global information about the Fibre Channel domain configurations.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fcdomain abort vsan

To flush cached data without committing the cached data and release the lock, use the **fcdomain abort vsan** command. To disable the flushing of cached data, use the **no** form of this command.

fcdomain abort vsan *vsan-id*

no fcdomain abort vsan *vsan-id*

Syntax Description	<i>vsan-id</i>	Virtual SAN (VSAN) ID. The range is from 1 to 4093.
--------------------	----------------	---

Command Default	Enabled
-----------------	---------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to flush cached data: switch(config)# fcdomain abort vsan 10
----------	---

Related Commands	Command	Description
	fcdomain	Configures Fibre Channel domain features.
	fcdomain commit vsan	Commits cached data and releases the lock.
	show fcdomain	Displays global information about the Fibre Channel domain configurations.

Send comments to nx5000-docfeedback@cisco.com

fcdomain commit vsan

To commit cached data and release the lock, use the **fcdomain commit vsan** command. To release the lock without committing the cached data, use the **no** form of this command.

fcdomain commit vsan *vsan-id*

no fcdomain commit vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Specifies a VSAN ID. The range is from 1 to 4093.
---------------------------	--

Command Default	Enabled
------------------------	---------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to commit cached data:
	switch(config)# fcdomain commit vsan 10

Related Commands	Command	Description
	fcdomain	Configures Fibre Channel domain features.
	fcdomain abort vsan	Flushes cached data without committing and releases the lock.
	show fcdomain	Displays global information about the Fibre Channel domain configurations.

Send comments to nx5000-docfeedback@cisco.com

fcdomain distribute

To enable fabric distribution using Cisco Fabric Services (CFS), use the **fcdomain distribute** command. To disable fabric distribution using CFS, use the **no** form of this command.

fcdomain distribute

no fcdomain distribute

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Disabled
------------------------	----------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to enable the fabric distribution using CFS:
-----------------	---

```
switch(config)# fcdomain distribute
```

This example shows how to disable the fabric distribution using CFS:
--

```
switch(config)# no fcdomain distribute
```

Related Commands	Command	Description
	fcdomain	Configures Fibre Channel domain features.
	show fcdomain	Displays global information about the Fibre Channel domain configurations.

Send comments to nx5000-docfeedback@cisco.com

fcdomain rcf-reject

To enable the reconfigure fabric (RCF) rejection flag for a Fibre Channel interface, use the **fcdomain rcf-reject** command. To disable this feature, use the **no** form of this command.

fcdomain rcf-reject vsan *vsan-id*

no fcdomain rcf-reject vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Specifies a Virtual SAN (VSAN) ID. The range is from 1 to 4093.	
Command Default	Enabled	
Command Modes	Interface configuration mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Usage Guidelines	Use this option to configure the RCF reject option for the selected Fibre Channel or virtual Fibre Channel interface.	
Examples	This example shows how to configure the FCIP RCF reject fcdomain feature on a virtual Fibre Channel interface:	
	<pre>switch(config)# interface vfc 3 switch(config-if)# fcdomain rcf-reject vsan 1</pre>	
Related Commands	Command	Description
	show fcdomain	Displays global information about the Fibre Channel domain configurations.
	show interface fc	Displays an interface configuration for a specified Fibre Channel interface.

Send comments to nx5000-docfeedback@cisco.com

fcdroplateny

To configure the network and switch Fibre Channel drop latency time, use the **fcdroplateny** command. To disable the Fibre Channel latency time, use the **no** form of this command.

fcdroplateny {**network** *milliseconds* [**vsan** *vsan-id*] | **switch** *milliseconds*}

no fcdroplateny {**network** *milliseconds* [**vsan** *vsan-id*] | **switch** *milliseconds*}

Syntax Description	network <i>milliseconds</i>	Specifies network latency. The range is from 500 to 60000.
	vsan <i>vsan-id</i>	(Optional) Specifies a Virtual SAN (VSAN) ID. The range is from 1 to 4093.
	switch <i>milliseconds</i>	Specifies switch latency. The range is from 0 to 60000 milliseconds.

Command Default	2000 millisecond network latency
	500 millisecond switch latency

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to configure the network latency to 5000 milliseconds:

```
switch(config)# fcdroplateny network 5000
```

This example shows how to revert to the default switch latency:

```
switch(config)# no fcdroplateny switch 4000
```

Related Commands	Command	Description
	show fcdroplateny	Displays the configured Fibre Channel drop latency parameters.

Send comments to nx5000-docfeedback@cisco.com

fcflow stats

To configure fcflow statistics, use the **fcflow stats** command. To disable the counter, use the **no** form of this command.

fcflow stats { **aggregated index** *flow-number* **vsan** *vsan-id* | **index** *flow-number* *destination-fcid* *source-fcid* *netmask* **vsan** *vsan-id* }

no fcflow stats { **aggregated index** *flow-number* | **index** *flow-number* }

Syntax Description

aggregated	Configures aggregated fcflow statistics.
index <i>flow-number</i>	Specifies a flow index. The range is from 1 to 2147483647.
vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is from 1 to 4093.
<i>destination-fcid</i>	Destination FCID in hexadecimal format.
<i>source-fcid</i>	Source FCID in hexadecimal format.
<i>netmask</i>	Mask for the source and destination FCID (restricted to 6 hexadecimal characters ranging from 0xff0000 to 0xffffffff).

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

If you enable flow counters, you can enable a maximum of 1024 entries for aggregate flow and flow statistics. Be sure to assign an unused flow index for each new flow. The number space for the flow index is shared between the aggregate flow statistics and the flow statistics.

Examples

This example shows how to enable the aggregated flow counter:

```
switch(config)# fcflow stats aggregated index 1005 vsan 1
```

This example shows how to disable the aggregated flow counter:

```
switch(config)# no fcflow stats aggregated index 1005
```

This example shows how to enable the flow counter for a specific flow:

```
switch(config)# fcflow stats index 1 0x145601 0x5601 0xffffffff vsan 1
```

This example shows how to disable the flow counter for index 1001:

```
switch(config)# no fcflow stats index 1001
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands

Command	Description
show fcflow stats	Displays the configured Fibre Channel drop latency parameters.

Send comments to nx5000-docfeedback@cisco.com

fcid-allocation

To manually add a FCID to the default area company ID list, use the **fcid-allocation** command. To remove a FCID from the default area company ID list, use the **no** form of this command.

fcid-allocation area company-id *company-id*

no fcid-allocation area company-id *company-id*

Syntax Description	area	Modifies the auto area list of company IDs.
	company-id	Configures the company IDs.
	<i>company-id</i>	

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	Fibre Channel standards require a unique FCID to be allocated to an N port attached to a Fx port in any switch. To conserve the number of FCIDs used, Cisco Nexus 5000 Series switches use a special allocation scheme.
	Some Host Bust Adaptors (HBAs) do not discover targets that have FC IDs with the same domain and area. The switch software maintains a list of tested company IDs that do not exhibit this behavior. These HBAs were allocated with single FC IDs, and for others a full area was allocated.
	To allow further scalability for switches with numerous ports, the switch software maintains a list of HBAs that exhibit this behavior. Each HBA is identified by its company ID (also known as an Organizational Unique Identifier, or OUI) used in the pWWN during a fabric login. A full area is allocated to the N ports with company IDs that are listed and for the others, a single FC ID is allocated. Regardless of the type (whole area or single) of FC ID allocated, the FC ID entries remain persistent.

Examples	This example shows how to add a new company ID to the default area company ID list:
----------	---

```
switch(config)# fcid allocation area company-id 0x003223
```


Send comments to nx5000-docfeedback@cisco.com

fcinterop fcid-allocation

To allocate FCIDs on the switch, use the **fcinterop fcid-allocation** command. To disable FCIDs on the switch, use the **no** form of this command.

fcinterop fcid-allocation { auto | flat | none }

no fcinterop fcid-allocation { auto | flat | none }

Syntax Description

auto	Assigns a single FCID to compatible HBAs.
flat	Assign a single FCID.
none	Assigns an FCID range.

Command Default

The default is automatic allocation of FCIDs.

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

This command defines how the switch assigns FCIDs.

Examples

This example shows how to set the FCID allocation to flat:

```
switch(config)# fcinterop fcid-allocation flat
```

Related Commands

Command	Description
show flogi database	Displays the fabric login (FLOGI) table.

Send comments to nx5000-docfeedback@cisco.com

fcns no-auto-poll

To enable or disable automatic polling in the name server database, use the **fcns no-auto-poll** command.

fcns no-auto-poll [**vsan** *vsan-id*] | [**wwn** *wwn-id*]

no fcns no-auto-poll [**vsan** *vsan-id*] | [**wwn** *wwn-id*]

Syntax Description	vsan <i>vsan-id</i>	(Optional) Specifies a Virtual SAN (VSAN) ID. The range is from 1 to 4093.
	wwn <i>wwn-id</i>	(Optional) Specifies the port WWN, with the format <i>hh:hh:hh:hh:hh:hh:hh:hh</i> .
Command Default	None	
Command Modes	Global configuration mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Examples	<p>This example shows how to disable automatic polling for VSAN 2:</p> <pre>switch(config)# fcns no-auto-poll vsan 2</pre>	
Related Commands	Command	Description
	show fcns	Displays the name server database and statistical information for a specified VSAN or for all VSANs.

Send comments to nx5000-docfeedback@cisco.com

fcns proxy-port

To register a name server proxy, use the **fcns proxy-port** command.

fcns proxy-port *wwn-id* **vsan** *vsan-id*

no fcns proxy-port *wwn-id* **vsan** *vsan-id*

Syntax Description	<i>wwn-id</i>	Port WWN, with the format <i>hh:hh:hh:hh:hh:hh:hh:hh</i> .
	vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is from 1 to 4093.

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	<p>One name server can be configured to proxy another name server, and the name server information can be displayed using the CLI. The name server can be viewed using the CLI or the Cisco Fabric Manager.</p> <p>All name server registration requests come from the same port whose parameter is registered or changed. If it does not, then the request is rejected.</p>
------------------	--

Examples	<p>This example shows how to configure a proxy port for VSAN 2:</p> <pre>switch(config)# fcns proxy-port 21:00:00:e0:8b:00:26:d vsan 2</pre>
----------	--

Related Commands	Command	Description
	show fcns	Displays the name server database and statistical information for a specified VSAN or for all VSANs.

Send comments to nx5000-docfeedback@cisco.com

fcns reject-duplicate-pwwn vsan

To reject duplicate Fibre Channel name server (FCNS) proxies on a Virtual SAN (VSAN), use the **fcns reject-duplicate-pwwn vsan** command.

fcns reject-duplicate-pwwn vsan *vsan-id*

no fcns reject-duplicate-pwwn vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Specifies a VSAN ID. The range is from 1 to 4093.	
Command Default	Disabled	
Command Modes	Global configuration mode	
Command History	Release	Modification
	Release 4.0	This command was introduced.
Examples	<p>This example shows how to reject duplicate FCNS pWWNs for VSAN 2:</p> <pre>switch(config)# fcns reject-duplicate-pwwn vsan 2</pre>	
Related Commands	Command	Description
	show fcns	Displays the name server database and statistical information for a specified VSAN or for all VSANs.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fcoe fcf-priority

To configure the FCoE Initialization Protocol (FIP) priority value advertised by the Fibre Channel Forwarder (FCF) to FCoE nodes (ENodes), use the **fcoe fcf-priority** command. To revert to the default FCF priority value, use the **no** form of this command.

fcoe fcf-priority *value*

no fcoe fcf-priority *value*

Syntax Description	valueFCF priority value. The range is from 0 to 255, and the default is 128.	
Command Default	128	
Command Modes	Global configuration mode Interface vFC mode	
Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.
Usage Guidelines	Before you use this command, you must enable FCoE on the switch by using the feature fcoe command. The Cisco Nexus 5000 Series switch advertises its priority. The priority is used by the converged network adapters (CNAs) in the fabric to determine the best switch to connect to.	
Examples	This example shows how to configure the FCF priority on the switch: switch(config)# fcoe fcf-priority 50 switch(config)#	
Related Commands	Command	Description
	fcoe fcmap	Configures the FCoE MAC address prefix (FC-Map) value.
	fcoe fka-adv-period	Configures the time interval at which FIP keep alive (FKA) messages are transmitted to the MAC address of the ENode.
	feature fcoe	Enables FCoE on the switch.
	show fcoe	Displays the FCoE parameters, such as FC-Map, default FCF priority value, and FKA advertisement period.

Send comments to nx5000-docfeedback@cisco.com

fcoe fcmmap

To configure the FCoE MAC address prefix (FC-Map) used to associate the FCoE node (ENode), use the **fcoe fcmmap** command. To restore the default global FC-Map value of 0xefc00, use the **no** form of this command.

fcoe fcmmap *value*

no fcoe fcmmap *value*

Syntax Description	<i>value</i>	FC-Map value. The range is from 0xefc00 to 0xefcff, and the default is 0xefc00.
---------------------------	--------------	---

Command Default	0xefc00
------------------------	---------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

Usage Guidelines	<p>Before you use this command, you must enable FCoE on the switch by using the feature fcoe command.</p> <p>You can prevent data corruption due to cross-fabric talk by configuring an FC-Map, which identifies the Fibre Channel fabric for this Cisco Nexus 5000 Series switch. When the FC-Map is configured, the switch discards the MAC addresses that are not part of the current fabric.</p> <p>This command requires a license.</p>
-------------------------	---

Examples	This example shows how to configure the FC-Map value on the switch:
-----------------	---

```
switch(config)# fcoe fcmmap 0xefc10
switch(config)#
```

Related Commands	Command	Description
	fcoe fcf-priority	Configures the FCoE Initialization Protocol (FIP) priority value.
	fcoe fka-adv-period	Configures the time interval at which FIP keep alive (FKA) messages are transmitted to the MAC address of the ENode.
	feature fcoe	Enables FCoE on the switch.
	show fcoe	Displays the FCoE parameters, such as an FC-Map, default FCF priority value, and FKA advertisement period.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fcoe fka-adv-period

To configure the time interval at which FIP keep alive (FKA) messages are transmitted to the MAC address of the FCoE node (ENode), use the **fcoe fka-adv-period** command. To revert to the default value of 128 seconds, use the **no** form of this command.

fcoe fka-adv-period *value*

no fcoe fka-adv-period *value*

Syntax Description

<i>value</i>	FKA advertisement period (in seconds). The range is from 4 to 60 seconds, and the default is 8.
--------------	---

Command Default

8 seconds

Command Modes

Global configuration mode

Command History

Release	Modification
4.2(1)N1(1)	This command was introduced.

Usage Guidelines

Before you use this command, FCoE must be enabled on the switch, using the **feature fcoe** command.

Examples

This example shows how to configure the FKA advertisement period for the switch to 5 seconds:

```
switch(config)# fcoe fka-adv-period 5
switch(config)#
```

Related Commands

Command	Description
fcoe fcf-priority	Configures the FCoE Initialization Protocol (FIP) priority value.
fcoe fcmap	Configures the FCoE MAC address prefix (FC-Map) used to associate the FCoE node (ENode).
feature fcoe	Enables FCoE on the switch.
show fcoe	Displays the FCoE parameters, such as an FC-Map, default FCF priority value, and FKA advertisement period.
show fcoe database	Displays the FCoE database information.

Send comments to nx5000-docfeedback@cisco.com

fcoe vsan

To map a Virtual SAN (VSAN) to a VLAN that carries Fibre Channel over Ethernet (FCoE) traffic, use the **fcoe vsan** command. To remove the mapping, use the **no** form of this command.

fcoe [**vsan** *vsan_ID*]

no fcoe [**vsan** *vsan_ID*]

Syntax Description	<i>vsan_ID</i>	VSAN ID. The range is from 1 to 4094.
---------------------------	----------------	---------------------------------------

Command Default	None
------------------------	------

Command Modes	Vlan configuration mode.
----------------------	--------------------------

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

Usage Guidelines	<p>Before you map the FCoE VLAN to the VSAN, make sure that you create a VSAN using the vsan command in the Vsan database configuration mode.</p> <p>You should use an FCoE VLAN only for FCoE. Do not use the default VLAN, VLAN1, as an FCoE VLAN. FCoE is not supported on private VLANs.</p> <p>When you map a FCoE VLAN to a VSAN, ensure that the VSAN is not mapped to any other FCoE VLAN. If you map a FCoE VLAN to a VSAN that is already mapped to another FCoE VLAN, the following error appears:</p> <pre>vlan 30:another FCOE VLAN mapping exists using the requested VSAN</pre> <p>If you do not specify a VSAN number, a mapping is created from the FCoE VLAN in use to the VSAN with the same number.</p>
-------------------------	--

Examples	<p>This example shows how to map a FCoE VLAN to a VSAN:</p> <pre>switch(config)# vlan 30 switch(config-vlan)# fcoe vsan 337 switch(config-vlan)#</pre>
-----------------	--

Related Commands	Command	Description
	show vsan	Displays the configuration information of VSANs.
	show vlan fcoe	Displays the FCoE VLAN to VSAN mappings.

Send comments to nx5000-docfeedback@cisco.com

Command	Description
show vsan membership	Displays VSAN membership information.
vsan	Configures the VSAN information or membership.
vsan database	Enters the VSAN database mode.

Send comments to nx5000-docfeedback@cisco.com

fcping

To ping an N port, use the **fcping** command.

fcping {**device-alias** *aliasname* | **fcid** {*fc-port* | *domain-controller-id*} | **pwwn** *pwwn-id*} **vsan** *vsan-id* [**count** *number* [**timeout** *value* [**usr-priority** *priority*]]]

Syntax Description

device-alias <i>aliasname</i>	Specifies the device alias name. The name can be a maximum of 64 characters.
fcid	Specifies the FCID of the destination N port.
<i>fc-port</i>	FCID port, with the format <i>0xhhhhhh</i> .
<i>domain-controller-id</i>	Controller ID to connect to the destination switch.
pwwn <i>pwwn-id</i>	Specifies the port WWN of the destination N port, with the format <i>hh:hh:hh:hh:hh:hh:hh:hh</i> .
vsan <i>vsan-id</i>	Specifies the VSAN ID of the destination N port. The range is from 1 to 4093.
count <i>number</i>	(Optional) Specifies the number of frames to send. A value of 0 sends forever. The range is from 0 to 2147483647.
timeout <i>value</i>	(Optional) Specifies the timeout value in seconds. The range is from 1 to 10, and the default period to wait is 5 seconds.
usr-priority <i>priority</i>	(Optional) Specifies the priority the frame receives in the switch fabric. The range is from 0 to 1.

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

To obtain the domain controller ID, concatenate the domain ID with FFFC. For example, if the domain ID is 0xda(218), the concatenated ID is 0xfffcda.

Examples

This example shows how to configure an fcping operation for the FCID of the destination. By default, five frames are sent.

```
switch# fcping fcid 0xd70000 vsan 1
```

This example shows how to configure the number of frames to be sent using the count option. The range is from 0 through 2147483647. A value of 0 will ping forever.

```
switch# fcping fcid 0xd70000 vsan 1 count 10
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to configure the timeout value:

```
switch# fcping fcid 0xd500b4 vsan 1 timeout 10
```

This example shows how to display the fcping operation using the device alias of the specified destination:

```
switch# fcping device-alias x vsan 1
```

Send comments to nx5000-docfeedback@cisco.com

fcroute

To configure Fibre Channel routes and to activate policy routing, use the **fcroute** command. To remove a configuration or revert to factory defaults, use the **no** form of this command.

fcroute {*fcid* [*network-mask*] **interface** {**fc** *slot/port* | **san-port-channel** *port* | **vfc** *vfc-id*} **domain** *domain-id* {**metric** *number* | **remote** | **vsan** *vsan-id*}}

no fcroute {*fcid* *network-mask* **interface** {**fc** *slot/port* | **san-port-channel** *port* | **vfc** *vfc-id*} **domain** *domain-id* {**metric** *number* | **remote** | **vsan** *vsan-id*}}

Syntax Description	
<i>fcid</i>	FC ID. The format is 0xhhhhhh.
<i>network-mask</i>	(Optional) Network mask of the FC ID. The format is 0x0 to 0xffffffff.
interface	Specifies an interface.
fc <i>slot/port</i>	Specifies a Fibre Channel interface and its slot number and port number.
san-port-channel <i>port</i>	Specifies a SAN port channel interface.
vfc <i>vfc-id</i>	Specifies a virtual Fibre Channel interface.
domain <i>domain-id</i>	Specifies the route for the domain of the next hop switch. The range is from 1 to 239.
metric <i>number</i>	Specifies the cost of the route. The range is from 1 to 65535. Default cost is 10.
remote	Configures the static route for a destination switch remotely connected.
vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is from 1 to 4093.

Command Default None

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines Use this command to assign forwarding information to the switch and to activate a preferred path route map.

Examples This example shows how to specify the Fibre Channel interface and the route for the domain of the next hop switch for VSAN 2:

```
switch(config)# fcroute 0x111211 interface fc3/1 domain 3 vsan 2
```

This example shows how to specify the SAN port channel interface and the route for the domain of the next hop switch for VSAN 4:

Send comments to nx5000-docfeedback@cisco.com

```
switch(config)# fcroute 0x111211 interface san-port-channel 1 domain 3 vsan 4
```

This example shows how to specify the Fibre Channel interface, the route for the domain of the next hop switch, and the cost of the route for VSAN 1:

```
switch(config)# fcroute 0x031211 interface fc1/1 domain 3 metric 1 vsan 1
```

This example shows how to specify the Fibre Channel interface, the route for the domain of the next hop switch, the cost of the route, and configures the static route for a destination switch remotely connected for VSAN 3:

```
switch(config)# fcroute 0x111112 interface fc3/1 domain 3 metric 3 remote vsan 3
```

Related Commands

Command	Description
show fcroute	Displays Fibre Channel routes.
fcroute-map	Specifies a preferred path Fibre Channel route map.
show fcroute-map	Displays the preferred path route map configuration and status.
fcroute policy fcroute-map	Activates the preferred path Fibre Channel route map.

Send comments to nx5000-docfeedback@cisco.com

fcs plat-check-global

To enable Fabric Configuration Server (FCS) platform and node-name checking fabric wide, use the **fcs plat-check-global** command. To disable this feature, use the **no** form of this command.

fcs plat-check-global vsan *vsan-id*

no fcs plat-check-global vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Specifies the VSAN ID for platform checking, which is from 1 to 4096.	
Command Default	None	
Command Modes	Global configuration mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Examples	<p>This example shows how to enable FCS platform and node-name checking fabric wide:</p> <pre>switch(config)# fcs plat-check-global vsan 2</pre>	
Related Commands	Command	Description
	show fcs	Displays fabric configuration server information.

Send comments to nx5000-docfeedback@cisco.com

fcs register

To register Fabric Configuration Server (FCS) attributes, use the **fcs register** command. To disable this feature, use the **no** form of this command.

fcs register

no fcs register

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	<p>This example shows how to register FCS attributes:</p> <pre>switch(config)# fcs register</pre>
-----------------	--

Related Commands	Command	Description
	show fcs	Displays fabric configuration server information.

Send comments to nx5000-docfeedback@cisco.com

fcs virtual-device-add

To include a virtual device in a query about zone information from an FCS, use the **fcs virtual-device-add** command. To remove a virtual device, use the **no** form of this command.

fcs virtual-device-add [**vsan-ranges** *vsan-ids*]

no fcs virtual-device-add [**vsan-ranges** *vsan-ids*]

Syntax Description	vsan-ranges <i>vsan-ids</i> (Optional) Specifies one or multiple ranges of VSANs. The range is from 1 to 4093.	
Command Default	Disabled	
Command Modes	Global configuration mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Usage Guidelines	VSAN ranges are entered as <i>vsan-ids-vsan-ids</i> . When you specify more than one range, separate each range with a comma. If no range is specified, the command applies to all VSANs.	
Examples	This example shows how to add to one range of VSANs:	
	switch(config)# fcs virtual-device-add vsan-ranges 2-4	
Examples	This example shows how to add to more than one range of VSANs:	
	switch(config)# fcs virtual-device-add vsan-ranges 2-4,5-8	
Related Commands	Command	Description
	show fcs	Displays fabric configuration server information.

Send comments to nx5000-docfeedback@cisco.com

fcsp

To configure a Fibre Channel Security Protocol (FC-SP) authentication mode for a specific interface in a FC-SP-enabled switch, use the **fcsp** command. To disable an FC-SP on the interface, use the **no** form of this command.

fcsp { **auto-active** | **auto-passive** | **on** | **off** } [*timeout-period*]

no fcsp

Syntax Description

auto-active	Configures the auto-active mode to authenticate the specified interface.
auto-passive	Configures the auto-passive mode to authenticate the specified interface.
on	Configures the on mode to authenticate the specified interface.
off	Configures the off mode to authenticate the specified interface.
<i>timeout-period</i>	(Optional) Time out period to reauthenticate the interface. The time ranges from 0 (default—no authentication is performed) to 100,000 minutes.

Command Default

Auto-passive mode

Command Modes

Interface configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

To use this command, FC-SP must be enabled using the **feature fcsp** command.

Examples

This example shows how to turn on the authentication mode for Fibre Channel interface in port 1 of slot 2:

```
switch(config)# interface fc 2/1
switch(config-if)# fcsp on
switch(config-if)#
```

This example shows how to revert to the factory default of auto-passive for the selected interface:

```
switch(config-if)# no fcsp
```

This example shows how to change the selected interface to initiate FC-SP authentication but does not permit reauthentication:

```
switch(config-if)# fcsp auto-active 0
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	feature fcsp	Enables FC-SP.
	show interface	Displays an interface configuration for a specified interface.

Send comments to nx5000-docfeedback@cisco.com

fcsp dhchap

To configure DHCHAP options in a switch, use the **fcsp dhchap** command. To revert to the factory defaults, use the **no** form of this command.

```
fcsp dhchap { devicename switch-wwn password [0 | 7] password |  
               dhgroup [0] [1][2][3][4] | hash [md5 | sha1] | password [0 | 7] password [wwn wwn-id]}  
  
no fcsp dhchap { devicename switch-wwn password [0 | 7] password |  
                 dhgroup [0 | 1 | 2 | 3 | 4] | hash [md5] [sha1] | password [0 | 7] password [wwn-id]}
```

Syntax Description		
devicename		Configures a password of another device in the fabric.
<i>switch-wwn</i>		WWN of the device being configured.
password		Configures a DHCHAP password for the local switch.
0		(Optional) Specifies a clear text password.
7		(Optional) Specifies a password in encrypted text.
dhgroup		Configures a DHCHAP Diffie-Hellman group priority list.
0		(Optional) Specifies Null DH—no exchange is performed (default).
1 2 3 4		(Optional) Specifies one or more of the groups specified by the standards.
hash		Configures a DHCHAP hash algorithm priority list in order of preference.
md5		(Optional) Specifies the MD5 hash algorithm.
sha1		(Optional) Specifies the SHA-1 hash algorithm.
wwn <i>wwn-id</i>		(Optional) Specifies the WWN ID with the format hh:hh:hh:hh:hh:hh:hh:hh.

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

You can only see the **fcsp dhchap** command if you enter the **feature fcsp** command.

Using SHA-1 as the hash algorithm may prevent RADIUS or TACACS+ usage.

If you change the DH group configuration, make sure that you change it globally for all switches in the fabric.

Examples This example shows how to enable FC-SP:

```
switch(config)# # feature fcsp
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to configure the use of only the SHA-1 hash algorithm:

```
switch(config)# fcsp dhchap hash sha1
```

This example shows how to configure the use of only the MD-5 hash algorithm:

```
switch(config)# fcsp dhchap hash md5
```

This example shows how to define the use of the default hash algorithm priority list of MD-5 followed by SHA-1 for DHCHAP authentication:

```
switch(config)# fcsp dhchap hash md5 sha1
```

This example shows how to revert to the factory default priority list of the MD-5 hash algorithm followed by the SHA-1 hash algorithm:

```
switch(config)# no fcsp dhchap hash sha1
```

This example shows how to prioritize the use of DH group 2, 3, and 4 in the configured order:

```
switch(config)# fcsp dhchap dhgroup 2 3 4
```

This example shows how to configure a clear text password for the local switch:

```
switch(config)# fcsp dhchap password 0 mypassword
```

This example shows how to configure a clear text password for the local switch to be used for the device with the specified WWN:

```
switch(config)# fcsp dhchap password 0 mypassword 30:11:bb:cc:dd:33:11:22
```

This example shows how to configure a password entered in an encrypted format for the local switch:

```
switch(config)# fcsp dhchap password 7 sfsfdf
```

Related Commands

Command	Description
feature fcsp	Enables FC-SP.
show fcsp	Displays configured FC-SP information.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fcsp reauthenticate

To reauthenticate a Fibre Channel or virtual Fibre Channel interface, use the **fcsp reauthenticate** command. To revert to the factory defaults, use the **no** form of this command.

fcsp reauthenticate interface {**fc slot/port** | **vfc vfc-id**}

no fcsp reauthenticate interface {**fc slot/port** | **vfc vfc-id**}

Syntax Description	interface	Specifies the interface on which to perform the reauthentication.
	interface fc slot/port	Specifies the Fibre Channel interface by the slot number and port number.
	vfc vfc-id	Specifies the virtual Fibre Channel interface by the virtual interface group number and virtual interface ID.

Command Default	30 seconds
-----------------	------------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to configure the Fibre Channel Security Protocol (FC-SP) reauthentication on a virtual Fibre Channel interface:

```
switch# fcsp reauthenticate vfc 1
```

Related Commands	Command	Description
	feature fcsp	Enables FC-SP.
	show fcsp	Displays configured FC-SP information.

Send comments to nx5000-docfeedback@cisco.com

fcsp timeout

To configure the timeout value for a Fibre Channel Security Protocol (FC-SP) message, use the **fcsp timeout** command. To revert to the factory defaults, use the **no** form of this command.

fcsp timeout *timeout-period*

no fcsp timeout *timeout-period*

Syntax Description	<i>timeout-period</i> Timeout period. The time range is from 20 to 100 seconds.							
Command Default	30 seconds							
Command Modes	Global configuration mode							
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>4.0(0)N1(1a)</td><td>This command was introduced.</td></tr></table>		Release	Modification	4.0(0)N1(1a)	This command was introduced.		
Release	Modification							
4.0(0)N1(1a)	This command was introduced.							
Usage Guidelines	You can only see the fcsp timeout command if you enable FC-SP by using the feature fcsp command.							
Examples	This example shows how to configure the FCSP timeout value: switch(config)# feature fcsp switch(config)# fcsp timeout 60							
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>feature fcsp</td><td>Enables FC-SP.</td></tr><tr><td>show fcsp</td><td>Displays configured FC-SP information.</td></tr></table>		Command	Description	feature fcsp	Enables FC-SP.	show fcsp	Displays configured FC-SP information.
Command	Description							
feature fcsp	Enables FC-SP.							
show fcsp	Displays configured FC-SP information.							

Send comments to nx5000-docfeedback@cisco.com

fctimer

To change the default Fibre Channel timers, use the **fctimer** command. To revert to the default values, use the **no** form of this command.

```
fctimer {d_s_tov milliseconds | e_d_tov milliseconds | r_a_tov milliseconds} [vsan vsan-id]
```

```
no fctimer {d_s_tov milliseconds | e_d_tov milliseconds | r_a_tov milliseconds} [vsan vsan-id]
```

Syntax Description	
d_s_tov <i>milliseconds</i>	Specifies the distributed services timeout value (DS_TOV). The range is from 5000 to 100000 milliseconds.
e_d_tov <i>milliseconds</i>	Specifies the error detect timeout value (ED_TOV). The range is from 1000 to 100000 milliseconds, with a default of 2000.
r_a_tov <i>milliseconds</i>	Specifies the resolution allocation timeout value (RA_TOV). The range is from 5000 to 100000 milliseconds with a default of 10000.
vsan <i>vsan-id</i>	(Optional) Specifies the VSAN ID. The range is from 1 to 4096.

Command Default

The Fibre Channel timers have the following default values:

- 30 seconds for DS_TOV.
- 2 seconds for ED_TOV.
- 10 seconds for RA_TOV.

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

The Cisco, Brocade, and McData FC Error Detect (ED_TOV) and Resource Allocation (RA_TOV) timers default to the same values. They can be changed if needed. In accordance with the FC-SW2 standard, these values must be the same on each switch in the fabric.

Use the **vsan** option to configure different TOV values for specific VSANs.

Examples

This example shows how to change the default Fibre Channel timers:

```
switch(config)# fctimer e_d_tov 5000
switch(config)# fctimer r_a_tov 7000
```

Related Commands

Command	Description
show fctimer	Displays the configured Fibre Channel timer values.

Send comments to nx5000-docfeedback@cisco.com

fctimer abort

To discard a Fibre Channel timer (fctimer) Cisco Fabric Services (CFS) distribution session in progress, use the **fctimer abort** command.

fctimer abort

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 4.0	This command was introduced.

Examples	<p>This example shows how to discard a CFS distribution session in progress:</p> <pre>switch(config)# fctimer abort</pre>
-----------------	--

Related Commands	Command	Description
	fctimer distribute	Enables CFS distribution for the fctimer.
	show fctimer	Displays fctimer information.

Send comments to nx5000-docfeedback@cisco.com

fctimer commit

To apply the pending configuration pertaining to the Fibre Channel timer (fctimer) Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **fctimer commit** command.

fctimer commit

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 4.0	This command was introduced.

Examples	<p>This example shows how to commit changes to the active Fibre Channel timer configuration:</p> <pre>switch(config)# fctimer commit</pre>
-----------------	--

Related Commands	Command	Description
	fctimer distribute	Enables CFS distribution for the fctimer.
	show fctimer	Displays fctimer information.

Send comments to nx5000-docfeedback@cisco.com

fctimer distribute

To enable Cisco Fabric Services (CFS) distribution for the Fibre Channel timer (fctimer), use the **fctimer distribute** command. To disable this feature, use the **no** form of this command.

fctimer distribute

no fctimer distribute

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration mode

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines Before distributing the Fibre Channel timer changes to the fabric, the temporary changes to the configuration must be committed to the active configuration using the **fctimer commit** command.

Examples This example shows how to change the default Fibre Channel timer:

```
switch(config)# fctimer distribute
```

Command	Description
fctimer commit	Commits the Fibre Channel timer configuration changes to the active configuration.
show fctimer	Displays fctimer information.

Send comments to nx5000-docfeedback@cisco.com

fctrace

To trace the route to an N port, use the **fctrace** command.

fctrace { **device-alias** *aliasname* | **fcid** *fcid* | **pwwn** *pwwn-id* } **vsan** *vsan-id* [**timeout** *seconds*]

Syntax Description	
device-alias <i>aliasname</i>	Specifies the device alias name. The name can be a maximum of 64 characters.
fcid <i>fcid</i>	Specifies the FCID of the destination N port, with the format 0xhhhhhh .
pwwn <i>pwwn-id</i>	Specifies the PWWN of the destination N port, with the format hh:hh:hh:hh:hh:hh:hh:hh .
vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is from 1 to 4093.
timeout <i>seconds</i>	(Optional) Specifies the the timeout value. The range is from 1 to 10.

Command Default By default, the period to wait before timing out is 5 seconds.

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to trace a route to the specified FCID in VSAN 1:

```
switch# fctrace fcid 0x660000 vsan 1
```

This example shows how to trace a route to the specified device alias in VSAN 1:

```
switch# fctrace device-alias x vsan 1
```

Send comments to nx5000-docfeedback@cisco.com

fdmi suppress-updates

To suppress Fabric-Device Management Interface (FDMI) updates, use the **fdmi suppress-updates** command.

fdmi suppress-updates vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Specifies a VSAN ID. The range is from 1 to 4093.				
Command Default	By default, FDMI updates are not suppressed.				
Command Modes	Global configuration mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>4.0(0)N1(1a)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	4.0(0)N1(1a)	This command was introduced.
Release	Modification				
4.0(0)N1(1a)	This command was introduced.				
Examples	<p>This example shows how to suppress the FDMI updates in VSAN 1:</p> <pre>switch# fdmi suppress-updates vsan 1</pre>				

Send comments to nx5000-docfeedback@cisco.com

feature fc-port-security

To enable port security, use the **feature fc-port-security** command. To disable port security, use the **no** form of this command.

feature fc-port-security

no feature fc-port-security

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Disabled
------------------------	----------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The feature fc-port-security command was added.
		Note On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.2(1)N1(1), this command was known as the port-security enable command.

Usage Guidelines	Entering the feature fc-port-security command enables the other commands that are used to configure FC port security.
-------------------------	--

Examples	<p>This example shows how to enable port security:</p> <pre>switch(config)# feature fc-port-security</pre> <p>This example shows how to disable port security:</p> <pre>switch(config)# no feature fc-port-security</pre>
-----------------	---

Related Commands	Command	Description
	show fc-port-security	Displays port security information.

Send comments to nx5000-docfeedback@cisco.com

feature fcsp

To enable the Fibre Channel Security Protocol (FC-SP) in a switch, use the **feature fcsp** command. To disable FC-SP, use the **no** form of this command.

feature fcsp

no feature fcsp

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The feature fcsp command has been added.
	Note	On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.2(1)N1(1), this command was known as the fcsp enable command.

Usage Guidelines Additional FC-SP commands are available when the FC-SP feature is enabled.

Examples This example shows how to enable FC-SP:

```
switch(config)# feature fcsp
```

Related Commands	Command	Description
	show fcsp	Displays configured FC-SP information.

Send comments to nx5000-docfeedback@cisco.com

feature npiv

To enable N Port Identifier Virtualization (NPIV) for all Virtual SANs (VSANs) on a switch, use the **feature npiv** command. To disable NPIV, use the **no** form of this command.

feature npiv

no feature npiv

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Disabled
------------------------	----------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.1(3)N1(1)	The feature npiv command was added.
	Note	On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.1(3)N1(1), this command was known as the npiv enable command.

Usage Guidelines	<p>NPIV provides a means to assign multiple port IDs to a single N port. This feature allows multiple applications on the N port to use different identifiers and allows access control, zoning, and port security to be implemented at the application level.</p> <p>You must globally enable NPIV for all VSANs on the switch to allow the NPIV-enabled applications to use multiple N port identifiers.</p>
-------------------------	--

Examples	<p>This example shows how to enable NPIV for all VSANs on the switch:</p> <pre>switch(config)# feature npiv</pre> <p>This example shows how to disable NPIV for all VSANs on the switch:</p> <pre>switch(config)# no feature npiv</pre>
-----------------	---

Related Commands	Command	Description
	show interface	Displays interface configurations.

Send comments to nx5000-docfeedback@cisco.com

feature npv

To enable N Port Virtualization (NPV) mode, use the **feature npv** command. To disable this feature, use the **no** form of this command.

feature npv

no feature npv

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.1(3)N1(1)	The feature npv command has been added.
	Note	On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.2(1)N1(1), this command was known as the npv enable command.

Usage Guidelines When NPV mode is enabled, switch configuration related to interfaces is erased and the switch is rebooted. The switch restarts in NPV mode. Configuration and verification commands for NPV are available only when NPV is enabled on the switch. When you disable NPV mode, all related configurations are automatically erased and the switch is rebooted.

Examples This example shows how to enable NPV mode:

```
switch(config)# feature npv
```

Related Commands	Command	Description
	show npv status	Displays the NPV current status.

Send comments to nx5000-docfeedback@cisco.com

feature port-track

To enable port tracking for indirect errors, use the **feature port-track** command. To disable this feature, use the **no** form of this command.

feature port-track

no feature port-track

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.1(3)N1(1)	The feature port-track command has been added.
	Note	On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 4.2(1)N1(1), this command was known as the port-track enable command.

Usage Guidelines The software brings the linked port down when the tracked port goes down. When the tracked port recovers from the failure and comes back up again, the tracked port is also brought up automatically (unless otherwise configured).

Examples This example shows how to enable port tracking:

```
switch(config)# feature port-track
```

This example shows how to disable port tracking:

```
switch(config)# no feature port-track
```

Related Commands	Command	Description
	show interface fc	Displays configuration and status information for a specified Fibre Channel interface.
	show interface san-port-channel	Displays configuration and status information for a specified SAN port channel interface.

Send comments to nx5000-docfeedback@cisco.com

fspf config

To configure an Fabric Shortest Path First (FSPF) feature for an entire Virtual SAN (VSAN), use the **fspf config** command. To delete an FSPF configuration for the entire VSAN, use the **no** form of this command.

```
fspf config vsan vsan-id
  min-ls-arrival ls-arrival-time
  min-ls-interval ls-interval-time
  region region-id
  spf {hold-time spf-holdtime | static}
```

```
  no min-ls-arrival
  no min-ls-interval
  no region
  no spf {hold-time | static}
```

```
no fspf config vsan vsan-id
```

Syntax Description

vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is from 1 to 4093.
min-ls-arrival <i>ls-arrival-time</i>	Specifies the minimum time before a new link state update for a domain will be accepted by the switch. <i>ls-arrival-time</i> is an integer that specifies time in milliseconds. The range is from 0 to 65535.
min-ls-interval <i>ls-interval-time</i>	Specifies the minimum time before a new link state update for a domain will be generated by the switch. <i>ls-interval-time</i> is an integer that specifies time in milliseconds. The range is from 0 to 65535.
region <i>region-id</i>	Specifies the autonomous region to which the switch belongs. The backbone region has <i>region-id</i> =0. <i>region-id</i> is an unsigned integer value ranging from 0 to 255.
spf	Specifies parameters related to the shortest path first (SPF) route computation.
hold-time <i>spf-holdtime</i>	Specifies the time between two consecutive SPF computations. If the time is small, then routing will react faster to changes but CPU usage will be more. <i>spf-holdtime</i> is an integer that specifies time in milliseconds. The range is from 0 to 65535.
static	Forces static SPF computation.

Command Default

In FSPF configuration mode, the default is dynamic SPF computation.

If configuring the *spf hold-time*, the default value for FSPF is 0.

If configuring the *min-ls-arrival*, the default value for FSPF is 1000 milliseconds.

If configuring the *min-ls-interval*, the default value for FSPF is 5000 milliseconds.

Command Modes

Global configuration mode

Send comments to nx5000-docfeedback@cisco.com

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

The **fspf config** command enters FSPF configuration mode for the specified Virtual SAN (VSAN). In FSPF configuration mode, the commands configure FSPF for this VSAN.

Examples

This example shows how to configure a static SPF computation in VSAN 1 and delete the FSPF configuration in VSAN 3:

```
switch(config)# fspf config vsan 1
switch(fspf-config)# spf static
switch(fspf-config)# exit
switch(config)# no fspf config vsan 3
switch(config)#
```

Related Commands

Command	Description
show fspf interface	Displays information for each selected interface.
fspf enable	Enables FSPF routing protocol in the specified VSAN.
fspf cost	Configures the cost for the selected interface in the specified VSAN.
fspf hello-interval	Specifies the hello message interval to verify the health of a link in the VSAN.
fspf passive	Disables the FSPF protocol for the specified interface in the specified VSAN.
fspf retransmit	Specifies the retransmit time interval for unacknowledged link state updates in the specified VSAN.

Send comments to nx5000-docfeedback@cisco.com

fspf cost

To configure Fabric Shortest Path First (FSPF) link cost for an Fibre Channel over IP (FCIP) interface, use the **fspf cost** command. To revert to the default value, use the **no** form of this command.

fspf cost *link-cost* **vsan** *vsan-id*

no fspf cost *link-cost* **vsan** *vsan-id*

Syntax Description	<i>link-cost</i>	FSPF link cost in seconds. The range is from 1 to 65535.
	vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is from 1 to 4093.

Command Default	1000 seconds for 1 Gigabits per second interfaces
	500 seconds for 2 Gigabits per second interfaces

Command Modes	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	This command is not applicable to virtual Fibre Channel interfaces.
	FSPF tracks the state of links on all switches in the fabric, associates a cost with each link in its database, and then chooses the path with a minimal cost. The cost associated with an interface can be changed using the fspf cost command to implement the FSPF route selection.

Examples	This example shows how to configure the FSPF link cost on an FCIP interface:
-----------------	--

```
switch(config)# interface fc 2/1
switch(config-if)# fspf cost 5000 vsan 1
```

Related Commands	Command	Description
	show fspf interface	Displays information for each selected interface.
	show interface fc	Displays an interface configuration for a specified Fibre Channel interface.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fspf dead-interval

To set the maximum interval for which a hello message must be received before the neighbor is considered lost, use the **fspf dead-interval** command. To revert to the default value, use the **no** form of this command.

fspf dead-interval *seconds vsan vsan-id*

no fspf dead-interval *seconds vsan vsan-id*

Syntax Description	<i>seconds</i>	FSPF dead interval in seconds. The range is from 2 to 65535.
	vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is from 1 to 4093.

Command Default	80 seconds
------------------------	------------

Command Modes	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	This command is not applicable to virtual Fibre Channel interfaces. This value must be the same in the ports at both ends of the ISL.
-------------------------	---



Caution

An error is reported at the command prompt if the configured dead time interval is less than the hello time interval.

Examples	This example shows how to configure the maximum interval of 400 seconds for a hello message before the neighbor is considered lost:
-----------------	---

```
switch(config)# interface fc 2/1
switch(config-if)# fspf dead-interval 4000 vsan 1
```

Related Commands	Command	Description
	show fspf interface	Displays information for each selected interface.
	show interface fc	Displays an interface configuration for a specified Fibre Channel interface.

Send comments to nx5000-docfeedback@cisco.com

fspf enable

To enable Fabric Shortest Path First (FSPF) for a Virtual SAN (VSAN), use the **fspf enable** command. To disable FSPF routing protocols, use the **no** form of this command.

fspf enable vsan *vsan-id*

no fspf enable vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Specifies a VSAN ID. The range is from 1 to 4093.	
Command Default	Enabled	
Command Modes	Global configuration mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Usage Guidelines	This command configures FSPF on VSANs globally.	
Examples	This example shows how to enable a FSPF in VSAN 5 and disable FSPF in VSAN 7:	
	<pre>switch(config)# fspf enable vsan 5 switch(config)# no fspf enable vsan 7</pre>	
Related Commands	Command	Description
	fspf config vsan	Configures FSPF features for a VSAN.
	show fspf interface	Displays information for each selected interface.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fspf hello-interval

To verify the health of the link, use the **fspf hello-interval** command. To revert to the default value, use the **no** form of this command.

fspf hello-interval *seconds vsan vsan-id*

no fspf hello-interval *seconds vsan vsan-id*

Syntax Description	hello-interval <i>seconds</i>	Specifies the FSPF hello interval in seconds. The range is from 2 to 65535.
	vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is from 1 to 4093.
Command Default	20 seconds	
Command Modes	Interface configuration mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Usage Guidelines	<p>This command is not applicable to virtual Fibre Channel interfaces.</p> <p>This command configures FSPF for the specified Fibre Channel interface. This value must be the same in the ports at both ends of the ISL.</p>	
Examples	<p>This example shows how to configure a hello interval of 3 seconds on VSAN 1:</p> <pre>switch(config)# interface fc 2/1 switch(config-if)# fspf hello-interval 3 vsan 1</pre>	
Related Commands	Command	Description
	show fspf interface	Displays information for each selected interface.

Send comments to nx5000-docfeedback@cisco.com

fspf passive

To disable the Fabric Shortest Path First (FSPF) protocol for selected interfaces, use the **fspf passive** command. To revert to the default state, use the **no** form of this command.

fspf passive vsan *vsan-id*

no fspf passive vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Specifies a VSAN ID. The range is from 1 to 4093.	
Command Default	FSPF is enabled	
Command Modes	Interface configuration mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Usage Guidelines	<p>This command is not applicable to virtual Fibre Channel interfaces.</p> <p>By default, FSPF is enabled on all E ports and TE ports. FSPF can be disabled by setting the interface as passive using the fspf passive command. FSPF must be enabled on the ports at both ends of the ISL for the protocol to operate correctly.</p>	
Examples	<p>This example shows how to disable the FSPF protocol for the selected interface on VSAN 1:</p> <pre>switch(config)# interface fc 2/1 switch(config-if)# fspf passive vsan 1</pre>	
Related Commands	Command	Description
	show fspf interface	Displays information for each selected interface.
	show interface fc	Displays an interface configuration for a specified FCIP interface.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

fspf retransmit-interval

To specify the time after which an unacknowledged link state update should be transmitted on the interface, use the **fspf retransmit-interval** command. To revert to the default value, use the **no** form of this command.

fspf retransmit-interval *seconds* **vsan** *vsan-id*

no fspf retransmit-interval *seconds* **vsan** *vsan-id*

Syntax Description	<i>seconds</i>	FSPF retransmit interval in seconds. The range is from 1 to 65535.
	vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is from 1 to 4093.

Command Default	5 seconds
------------------------	-----------

Command Modes	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	This command is not applicable to virtual Fibre Channel interfaces. This value must be the same in the ports at both ends of the ISL.
-------------------------	---

Examples	<p>This example shows how to specify a retransmit interval of 6 seconds after which an unacknowledged link state update should be transmitted on the interface for VSAN 1:</p> <pre>switch(config)# interface fc 2/1 switch(config-if)# fspf retransmit-interval 6 vsan 1</pre>
-----------------	---

Related Commands	Command	Description
	show fspf interface	Displays information for each selected interface.
	show interface fc	Displays an interface configuration for a specified FCIP interface.

Send comments to nx5000-docfeedback@cisco.com

in-order-guarantee

To enable in-order delivery, use the **in-order-guarantee** command. To disable in-order delivery, use the **no** form of this command.

in-order-guarantee [**vsan** *vsan-id*]

no in-order-guarantee [**vsan** *vsan-id*] [,] [-]

Syntax Description

vsan <i>vsan-id</i>	(Optional) Specifies a VSAN ID. The range is from 1 to 4093.
[,] [-]	(Optional) Allows you to enter multiple VSANs separated by commas, or a range of VSANs separated by a dash.

Command Default

Disabled

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

In-order delivery of data frames guarantees frame delivery to a destination in the same order that they were sent by the originator.

Examples

This example shows how to enable in-order delivery for the entire switch:

```
switch(config) # in-order-guarantee
```

This example shows how to disable in-order delivery for the entire switch:

```
switch(config) # no in-order-guarantee
```

This example shows how to enable in-order delivery for a specific VSAN:

```
switch(config) # in-order-guarantee vsan 3452
```

This example shows how to disable in-order delivery for a specific VSAN:

```
switch(config) # no in-order-guarantee vsan 101
```

Related Commands

Command	Description
show	Displays the in-order-guarantee status.
in-order-guarantee	

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

interface fc

To configure a Fibre Channel interface on a Cisco Nexus 5000 Series switch, use the **interface fc** command. To revert to defaults, use the **no** form of this command.

```
interface fc slot/port
  channel-group {group-id [force] | auto}
  fcdomain rcf-reject vsan vsan-id
  fcsp {auto-active | auto-passive | on | off} [timeout-period]
  fspf {cost link-cost vsan vsan-id | dead-interval seconds vsan vsan-id | hello-interval seconds
        vsan vsan-id | passive vsan vsan-id | retransmit-interval seconds vsan vsan-id}
  switchport

no interface fc slot/port
  no channel-group {group-id [force] | auto}
  no fcdomain rcf-reject vsan vsan-id
  no fcsp {auto-active | auto-passive | on | off}
  no fspf {cost link-cost vsan vsan-id | dead-interval seconds vsan vsan-id | hello-interval
          seconds vsan vsan-id | passive vsan vsan-id | retransmit-interval seconds vsan vsan-id}
  switchport
```

Syntax Description

<i>slot/port</i>	Slot number and port number of the interface.
channel-group	Adds to or removes from a port channel.
<i>group-id</i>	Port channel group number from 1 to 128.
force	(Optional) Forcefully adds a port.
auto	Enables autocreation of port channels.
fcdomain	Enters the interface mode.
rcf-reject	Configures the rcf-reject flag.
vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is from 1 to 4093.
fcsp	Configures Fibre Channel Security Protocol (FC-SP) parameters for a specific interface.
auto-active	Configures the auto-active mode to authenticate the specified interface.
auto-passive	Configures the auto-passive mode to authenticate the specified interface.
on	Configures the on mode to authenticate the specified interface.
off	Configures the off mode to authenticate the specified interface.
<i>timeout-period</i>	(Optional) Timeout period to reauthenticate the interface. The time ranges from 0 (default—no authentication is performed) to 100,000 minutes.
fspf	Configures the FSPF parameters.
cost <i>link-cost</i>	Configures the FSPF link cost. The range is from 1 to 65535.
dead-interval <i>seconds</i>	Configures the FSPF dead interval in seconds. The range is from 2 to 65535.
hello-interval <i>seconds</i>	Configures the FSPF hello-interval. The range is from 1 to 65535.
passive	Enables or disables FSPF on the interface.
retransmit-interval <i>seconds</i>	Configures the FSPF retransmit interface in seconds. The range is from 1 to 65535.
switchport	Configures switchport parameters.

Send comments to nx5000-docfeedback@cisco.com

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines You can specify a range of interfaces by entering a command with the following example format:

```
interface fc 1/1 - 5 , fc 2/5 - 7
```

See the *Cisco Nexus 5000 Series Switch CLI Software Configuration Guide* for information on port number allocation.

Use the **no shutdown** command to enable the interface.

The **interface fc** command enters interface configuration mode, which includes five commands (each with a no form). These five commands can only be used in the interface configuration mode.

The **channel-group auto** command enables autocreation of port channels. If autocreation of port channels is enabled for an interface, you must first disable this configuration before downgrading to earlier software versions or before configuring the interface in a manually configured channel group.

Examples This example shows how to configure ports 1 to 4 in Fibre Channel interface 3:

```
switch(config)# interface fc 3/1 - 4
```

This example shows how to enable the Fibre Channel interface in port 1 of slot 3:

```
switch(config)# interface fc 3/1
switch(config-if)# no shutdown
```

Related Commands	Command	Description
	show interface	Displays an interface configuration for a specified interface.
	shutdown	Disables and enables an interface.

Send comments to nx5000-docfeedback@cisco.com

interface san-port-channel

To configure a SAN port channel interface on a Cisco Nexus 5000 Series switch, use the **interface san-port-channel** command. To revert to the defaults, use the **no** form of this command.

```
interface san-port-channel port { description line | shutdown [force] | switchport { mode { E | auto } | speed { 1000 | 2000 | 4000 | auto } | trunk { allowed vsan { vsan-id | add vsan-id | all } | mode { auto | on | off } } }
```

```
no interface san-port-channel port { no description | no shutdown | no switchport { no mode | no speed | no trunk { allowed vsan { vsan-id | add vsan-id | all } | mode } } }
```

Syntax Description

<i>port</i>	Port number.
description <i>line</i>	Specifies a description for the interface.
shutdown	Specifies that the interface state be changed to administrative down.
force	(Optional) Forces the interface state to administrative down.
switchport	Enters configuration parameters for the SAN port channel.
mode	Configures receive BB_credit for the specific port mode.
E	Configures E port mode.
auto	Configures autosense mode.
speed	Configures the port speed.
1000	Configures 1000-Mbps speed.
2000	Configures 2000-Mbps speed.
4000	Configures 4000-Mbps speed.
auto	Configures autosense speed.
trunk	Configures trunking parameters on the interface.
allowed	Specifies the allowed list for interface(s).
vsan	Configures the VSAN range.
<i>vsan-id</i>	VSAN ID. The range is from 1 to 4093.
add	Adds the VSAN ID to the range of allowed VSAN list.
all	Adds all the VSANs to allowed VSAN list.
mode	Configures the trunking mode.
off	Disables the trunking mode.
on	Enables the trunking mode.

Command Default

Disabled

Command Modes

Global configuration mode

Send comments to nx5000-docfeedback@cisco.com

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

The **interface san-port-channel** command enters interface configuration mode, which includes six commands (each with a **no** form). These commands can only be used in the interface configuration mode. Use the **no shutdown** command to enable the interface.

Examples

This example shows how to configure SAN port channel interface 3:

```
switch(config)# interface san-port-channel 3
```

Related Commands

Command	Description
show interface	Displays an interface configuration for a specified interface.
shutdown	Disables and enables an interface.

Send comments to nx5000-docfeedback@cisco.com

interface vfc

To configure a virtual Fibre Channel interface on a Cisco Nexus 5000 Series switch, use the **interface vfc** command. To revert to defaults, use the **no** form of this command.

```
interface vfc vfc-id { bind interface ethernet slot/port | description line | shutdown [force] |  
  switchport mode F}
```

```
no interface vfc vfc-id { no bind interface ethernet slot/port | no description | no shutdown | no  
  switchport mode}
```

Syntax Description	
<i>vfc-id</i>	Virtual interface ID. The range is from 1 to 8192.
bind interface ethernet	Specifies that the virtual Fibre Channel interface be bound to specified Ethernet interface.
<i>slot/port</i>	Ethernet interface slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
description <i>line</i>	Enters a line of text to describe the interface.
shutdown	Specifies that the interface state be changed to administrative down.
force	(Optional) Specifies that the interface state be forcefully changed to administrative down.
switchport mode F	Specifies the mode of the virtual Fibre Channel interface.

Command Default	Disabled
------------------------	----------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	You can specify a range of interfaces by entering a command with the following example format:
-------------------------	--

```
interface vfc 1 - 3 , vfc 5 - 7
```

Use the **no shutdown** command to enable the interface.

Examples	This example shows how to enter interface configuration mode for virtual Fibre Channel interface 3: switch(config)# interface vfc 3
-----------------	---

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	show interface	Displays an interface configuration for a specified interface.
	shutdown	Disables and enables an interface.

Send comments to nx5000-docfeedback@cisco.com

lldp

To configure the Link Layer Discovery Protocol (LLDP) global options, use the **lldp** command. To remove the LLDP settings, use the **no** form of this command.

lldp { **holdtime** *seconds* | **reinit** *seconds* | **timer** *seconds* }

no lldp { **holdtime** | **reinit** | **timer** }

Syntax Description	holdtime <i>seconds</i>	Specifies the hold time (in seconds) to set the length of time that a device should save LLDP information received before discarding it. The range is from 10 to 255, and the default is 120 seconds.
	reinit <i>seconds</i>	Specifies the length of time (in seconds) to wait before performing LLDP initialization on any interface. The range is from 1 to 10 seconds, and the default is 2 seconds.
	timer <i>seconds</i>	Specifies the rate (in seconds) at which LLDP packets are sent. The range is from 5 to 254 seconds, and the default is 30 seconds.

Command Default	Holdtime: 120 seconds. Reinit: 2 seconds. Timer: 30 seconds.
-----------------	--

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	Before you use this command, you must enable LLDP on the switch. The LLDP settings include the length of time before discarding LLDP information received from peers, the length of time to wait before performing LLDP initialization on any interface, and the rate at which LLDP packets are sent.
------------------	--

Examples	This example shows how to configure the global LLDP holdtime to 200 seconds: switch(config)# lldp holdtime 200 switch(config)#
----------	---

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	feature lldp	Enables or disables LLDP on the switch.
	lldp (Interface)	Configures the LLDP feature on an interface.
	show lldp	Displays LLDP configuration information.

Send comments to nx5000-docfeedback@cisco.com

lldp (interface)

To enable the reception, or transmission, of Link Layer Discovery Protocol (LLDP) packets on an interface, use the **lldp** command. To disable the reception or transmission of LLDP packets, use the **no** form of this command.

lldp {receive | transmit}

no lldp {receive | transmit}

Syntax Description

receive	Specifies that the interface receive LLDP packets.
transmit	Specifies that the interface transmit LLDP packets.

Command Default

None

Command Modes

Interface configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

Before you use this command, you must enable LLDP on the switch.

Examples

This example shows how to set an interface to transmit LLDP packets:

```
switch(config)# interface ethernet 2/1
switch(config-if)# lldp transmit
switch(config-if)#
```

Related Commands

Comand	Description
feature lldp	Enables or disables LLDP on the switch.
show interface	Displays configuration information about interfaces.

Send comments to nx5000-docfeedback@cisco.com

logging abort

To discard the logging Cisco Fabric Services (CFS) distribution session in progress, use the **logging abort** command.

logging abort

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to discard the logging CFS distribution session in progress:

```
switch(config)# logging abort
```

Related Commands	Command	Description
	show logging	Displays logging information.

Send comments to nx5000-docfeedback@cisco.com

logging commit

To apply the pending configuration pertaining to the logging Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **logging commit** command.

logging commit

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to commit changes to the active logging configuration:

```
switch(config)# logging commit
```

Related Commands	Command	Description
	show logging	Displays logging information.

Send comments to nx5000-docfeedback@cisco.com

logging distribute

To enable Cisco Fabric Services (CFS) distribution for logging, use the **logging distribute** command. To disable this feature, use the **no** form of this command.

logging distribute

no logging distribute

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines Before distributing the Fibre Channel timer changes to the fabric, the temporary changes to the configuration must be committed to the active configuration using the **logging commit** command.

Examples This example shows how to change the distribute logging configuration changes:

```
switch(config)# logging distribute
```

Related Commands	Command	Description
	logging commit	Commits the logging configuration changes to the active configuration.
	show logging	Displays logging information.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

member (fcalias configuration mode)

To add a member name to a Fibre Channel alias on a Virtual SAN (VSAN), use the **member** command. To remove a member name from a Fibre Channel alias, use the **no** form of this command.

```
member { device-alias aliasname | domain-id domain-id port-number port-number | fcid fc-id |
fwwn fwwn-id | interface fc slot/port [domain-id domain-id | swwn swwn-id] | pwwn pwwn-id
| symbolic-nodename nodename }
```

```
no member { device-alias aliasname | domain-id domain-id port-number port-number | fcid fc-id |
fwwn fwwn-id | interface fc slot/port [domain-id domain-id | swwn swwn-id] | pwwn pwwn-id
| symbolic-nodename nodename }
```

Syntax Description	
device-alias <i>aliasname</i>	Specifies the member device alias. The name can be a maximum of 64 characters.
domain-id <i>domain-id</i>	Specifies the member domain ID. The range is from 1 to 239.
port-number <i>port-number</i>	Specifies a port number in the range of 0 to 255.
fcid <i>fc-id</i>	Specifies the member FC ID. The format is <i>0xhhhhhh</i> , where <i>h</i> is a hexadecimal digit.
fwwn <i>fwwn-id</i>	Specifies the member fWWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal digit.
interface fc <i>slot/port</i>	Specifies the member interface ID and its slot number and port number.
swwn <i>swwn-id</i>	(Optional) Specifies the member sWWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal digit.
pwwn <i>pwwn-id</i>	Specifies the member pWWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal digit.
symbolic-nodename <i>nodename</i>	Specifies the member symbolic node name. The maximum length is 255 characters.

Command Default	None
------------------------	------

Command Modes	Fcalias configuration mode
----------------------	----------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples

This example shows how to add a member to an alias called samplealias:

```
switch(config)# fcalias name samplealias
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to define a Fibre Channel interface for the member:

```
switch(config-fcalias)# member interface fc3/1
```

This example shows how to delete the specified member:

```
switch(config-fcalias)# no member interface fc3/1
```

Related Commands

Command	Description
fcalias name	Configures an alias.
show fcalias	Displays the member name information in an alias.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

member (zone configuration mode)

To add a member name to a Fibre Channel zone, use the **member** command. To remove a member name from a zone, use the **no** form of this command.

member { **device-alias** *aliasname* | **domain-id** *domain-id* **port-number** *port* | **fcalias** *alias-name* | **fcid** *fc-id* | **fwwn** *fwwn-id* | **interface fc** *slot/port* [**domain-id** *domain-id* | **swwn** *swwn-id*] | **pwwn** *pwwn-id* [**lun** *lun-id*] | **symbolic-nodename** *nodename* }

no member { **device-alias** *aliasname* | **domain-id** *domain-id* **port-number** *port* | **fcid** *fc-id* | **fwwn** *fwwn-id* | **interface fc** *slot/port* [**domain-id** *domain-id* | **swwn** *swwn-id*] | **pwwn** *pwwn-id* [**lun** *lun-id*] | **symbolic-nodename** *nodename* }

Syntax Description	
device-alias <i>aliasname</i>	Specifies the member device alias. The name can be a maximum of 64 characters.
domain-id <i>domain-id</i>	Specifies the member domain ID. The range is from 1 to 239.
port-number <i>port</i>	Specifies the member port number. The range is from 0 to 255.
fcalias <i>alias-name</i>	Specifies a Fibre Channel alias name. The name can be a maximum of 64 characters.
fcid <i>fc-id</i>	Specifies the member FC ID. The format is <i>0xhhhhh</i> , where <i>h</i> is a hexadecimal digit.
fwwn <i>fwwn-id</i>	Specifies the member fWWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal digit.
interface fc <i>slot/port</i>	Specifies the member interface ID and its slot number and port number.
swwn <i>swwn-id</i>	(Optional) Specifies the member sWWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal digit.
pwwn <i>pwwn-id</i>	Specifies the member pWWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal digit.
lun <i>lun-id</i>	(Optional) Specifies the member Logical Unit Number (LUN) ID. The format is <i>0xhhh[:hhh[:hhh[:hhh]]]</i> , where <i>h</i> is a hexadecimal digit.
symbolic-nodename <i>nodename</i>	Specifies the member symbolic node name. The name can be a maximum of 255 characters.

Command Default None

Command Modes Zone set zone configuration mode and zoneset-zone configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines Create a zone set zone member only if you need to add member to a zone from the zone set prompt.

Send comments to nx5000-docfeedback@cisco.com

Examples

This example shows how to add a member to a zone called zs1 on VSAN 1:

```
switch(config)# zone name zs1 vsan 1
switch(config-zone)# member fcid 0x111112
```

This example shows how to add a zone to a zone set called Zoneset1 on VSAN 1:

```
switch(config)# zoneset name ZoneSet1 vsan 1
switch(config-zoneset-zone)# member fcid 0x111112
```

This example shows how to assign a Fibre Channel interface member into a zone:

```
switch(config)# zoneset name ZoneSet1 vsan 1
switch(config-zoneset-zone)# member interface fc 3/1
```

This example shows how to delete the specified device from a zone:

```
switch(config-zoneset-zone)# no member interface fc 3/1
```

Related Commands

Command	Description
zoneset (configuration mode)	Specifies a name for a zone set.
zone name (zone set configuration mode)	Configures a zone in a zone set.
show zoneset	Displays zone set information.

Send comments to nx5000-docfeedback@cisco.com

member (zoneset configuration mode)

To configure zone set members, use the **member** command. To remove a zone set member, use the **no** form of this command.

member *member-name*

no member *member-name*

Syntax Description	<i>member-name</i>	Member name. The name can be a maximum of 64 characters.
--------------------	--------------------	--

Command Default	None
-----------------	------

Command Modes	Zone set configuration mode
---------------	-----------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	<p>This example shows how to add a member zone to a zone set:</p> <pre>switch(config)# zoneset name Zoneset1 vsan 10 switch(config-zoneset)# member ZoneA</pre>
----------	---

Related Commands	Command	Description
	show zone	Displays zone information.
	zoneset name	Creates a zone set.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

npv auto-load-balance disruptive

To enable N Port Virtualization (NPV) disruptive load balancing, use the **npv auto-load-balance disruptive** command. To disable this feature, use the **no** form of this command.

npv auto-load-balance disruptive

no npv auto-load-balance disruptive

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(2a)	This command was introduced.

Usage Guidelines	Disruptive load balancing can be configured only in NPV mode.
	When disruptive load balancing is enabled, NPV redistributes the server interfaces across all available NP uplinks when a new NP uplink becomes operational. To move a server interface from one NP uplink to another NP uplink, NPV forces reinitialization of the server interface so that the server performs a new login to the core switch. This action causes traffic disruption on the attached end devices.
	To avoid disruption of server traffic, enable this feature only after adding a new NP uplink, and then disable it again after the server interfaces have been redistributed.

Examples	This example shows how to enable disruptive load-balancing:
-----------------	---

```
switch(config)# npv auto-load-balance disruptive
```

Related Commands	Command	Description
	feature npv	Enables NPV mode.
	show npv status	Displays the NPV current status.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

npv traffic-map

To configure an N Port Virtualization (NPV) traffic map, use the **npv traffic-map** command. To disable this feature, use the **no** form of this command.

npv traffic-map server-interface { **fc slot/port** | **vfc vfc-id** } **external-interface fc slot/port**

no npv traffic-map server-interface { **fc slot/port** | **vfc vfc-id** } **external-interface fc slot/port**

Syntax Description		
server-interface		Specifies the server interface or a range of server interfaces.
fc slot/port		Specifies the slot number and port number for a native Fibre Channel interface.
vfc vfc-id		Specifies a virtual Fibre Channel interface.
external-interface		Specifies the NP/TNP uplink interface or a range of NP/TNP uplink interfaces that can be selected by the server interface.

Command Default No traffic map. The switch uses automatic uplink selection to select an NP uplink for the server interface.

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(2a)	This command was introduced.

Usage Guidelines This command is only available when the switch is operating in NPV mode.
NPV traffic maps can be configured only in NPV mode.

Examples This example shows how to create a mapping between server interface vfc1 and NP uplink fc 3/1:

```
switch(config)# npv traffic-map server-interface vfc 1 external-interface fc 3/1
```

Related Commands	Command	Description
	feature npv	Enables NPV mode.
	show npv status	Displays the NPV current status.

Send comments to nx5000-docfeedback@cisco.com

port-track force-shut

To force a shutdown of a tracked port, use the **port-track force-shut** command. To reenable the port tracking, use the **no** form of this command.

port-track force-shut

no port-track force-shut

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	Use the port-track force-shut command to keep the linked port down, even though the tracked port comes back up. You must explicitly bring the port up when required by using the no port-track force-shut command.
-------------------------	--

Examples	This example shows how to force the shutdown of an interface and the interfaces that it is tracking:
-----------------	--

```
switch(config)# interface fc 2/2
switch(config-if)# no port-track force-shut
```

Related Commands	Command	Description
	feature port-track	Enables port tracking.
	show interface fc	Displays configuration and status information for a specified Fibre Channel interface.
	show interface san-port-channel	Displays configuration and status information for a specified SAN port channel interface.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

port-track interface

To enable port tracking for specific interfaces, use the **port-track interface** command. To disable this feature, use the **no** form of this command.

port-track interface { *fc slot/port* | *san-port-channel port* } [*vsan vsan-id*]

no port-track interface { *fc slot/port* | *san-port-channel port* } [*vsan vsan-id*]

Syntax Description

fc slot/port	Specifies a Fibre Channel interface.
san-port-channel port	Specifies a SAN port channel interface. The range is from 1 to 128.
vsan vsan-id	(Optional) Specifies a VSAN ID. The range is from 1 to 4093.

Command Default

None

Command Modes

Interface configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

When the port that an interface is tracking goes down, the interface also goes down. When the tracked port comes back up, the linked interface also comes back up. Use the **port-track force-shut** command to keep the linked interface down.

Examples

This example shows how to enable port tracking for specific interfaces:

```
switch(config)# interface fc 2/3
switch(config-if)# port-track interface san-port-channel 2
```

Related Commands

Command	Description
feature port-track	Enables port tracking.
port-track force-shut	Forcefully shuts an interface for port tracking.
show interface fc	Displays configuration and status information for a specified Fibre Channel interface.
show interface san-port-channel	Displays configuration and status information for a specified SAN port channel interface.

Send comments to nx5000-docfeedback@cisco.com

purge fcdomain fcid

To purge persistent FCIDs, use the **purge fcdomain fcid** command.

purge fcdomain fcid vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i>	Indicates that FCIDs are to be purged for a VSAN ID. The range is from 1 to 4093.
--------------------	----------------------------	---

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples This example shows how to purge all dynamic, unused FCIDs in VSAN 4:

```
switch# purge fcdomain fcid vsan 4
```

This example shows how to purge all dynamic, unused FCIDs in VSANs 4, 5, and 6:

```
switch# purge fcdomain fcid vsan 4-6
```


Send comments to nx5000-docfeedback@cisco.com

rlir preferred-cond fcid

To specify a preferred host to receive Registered Link Incident Report (RLIR) frames, use the **rlir preferred-cond fcid** command. To remove a preferred host, use the **no** form of this command.

rlir preferred-cond fcid *fc-id* **vsan** *vsan-id*

no rlir preferred-cond fcid *fc-id* **vsan** *vsan-id*

Syntax Description	fcid <i>fc-id</i>	Specifies the FC ID. The format is 0xhhhhh .
	vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is from 1 to 4093.

Command Default	By default, the switch sends RLIR frames to one of the hosts in the Virtual SAN (VSAN) with the register function set to “conditionally receive” if no hosts have the register function set to “always receive.”
------------------------	--

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	The switch sends RLIR frames to the preferred host only if it meets the following conditions:
	<ul style="list-style-type: none">• No host in the VSAN is registered for RLIR with the registration function set to “always receive.” If one or more hosts in the VSAN are registered as “always receive,” then RLIR sends only to these hosts and not to the configured preferred host.• The preferred host is registered with the registration function set to “conditionally receive.” If all registered hosts have the registration function set to “conditionally receive,” then the preferred host receives the RLIR frames.

You can specify only one RLIR preferred host per VSAN.

Examples	This example shows how to specify the FCID 0x654321 as the RLIR preferred host for VSAN 2:
-----------------	--

```
switch(config)# rlir preferred-cond fcid 0x654321 vsan 2
```

This example shows how to remove the FCID 0x654321 as the RLIR preferred host for VSAN 2:

```
switch(config)# no rlir preferred-cond fcid 0x654321 vsan 2
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	show rlir	Displays information about RLIR, Link Incident Record Registration (LIRR), and Distribute Registered Link Incident Record (DRLIR) frames.
	clear rlir	Clears the RLIRs.
	debug rlir	Enables RLIR debugging.

Send comments to nx5000-docfeedback@cisco.com

rscn

To configure a registered state change notification (RSCN), which is a Fibre Channel service that informs N ports about changes in the fabric, use the **rscn** command.

rscn { **multi-pid** | **suppress domain-swrscn** } **vsan** *vsan-id*

Syntax Description	multi-pid	Sends RSCNs in multiple port ID (multi-PID) format.
	suppress domain-swrscn	Suppresses transmission of domain format SW-RCSNs.
	vsan <i>vsan-id</i>	Configures VSAN information or membership. The ID of the VSAN is from 1 to 4093.

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to configure RSCNs in multi-PID format:
	<pre>switch(config)# rscn multi-pid vsan 1</pre>

Related Commands	Command	Description
	show rscn src-table	Displays the state change registration table.
	show rscn statistics	Displays RSCN statistics.

Send comments to nx5000-docfeedback@cisco.com

rscn abort

To cancel a Registered State Change Notification (RSCN) configuration on a Virtual SAN (VSAN), use the **rscn abort** command. To reverse the cancellation, use the **no** form of this command.

rscn abort vsan *vsan-id*

no rscn abort vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i>	Specifies a VSAN where the RSCN configuration should be canceled. The ID of the VSAN is from 1 to 4093.
---------------------------	----------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to cancel an RSCN configuration on VSAN 1:
	switch(config)# rscn abort vsan 1

Related Commands	Command	Description
	rscn commit	Commits a pending RSCN configuration on a specified VSAN.
	rscn distribute	Enables the distribution of an RSCN configuration.
	rscn event-tov	Configures an RSCN event timeout.
	clear rscn session vsan	Clears the RSCN session for a specified VSAN.
	show rscn	Displays RSCN configuration information.

Send comments to nx5000-docfeedback@cisco.com

rscn commit

To apply a pending Registered State Change Notification (RSCN) configuration, use the **rscn commit** command. To discard a pending RSCN configuration, use the **no** form of this command.

rscn commit vsan *vsan-id*

no rscn commit vsan *vsan-id*

Syntax Description

vsan <i>vsan-id</i>	Specifies a VSAN where the RSCN configuration should be committed. The ID of the VSAN is from 1 to 4093.
----------------------------	--

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

If you commit the changes made to the active database, the configuration is committed to all the switches in the fabric. On a successful commit, the configuration change is applied throughout the fabric and the lock is released.

Examples

This example shows how to commit an RSCN configuration on VSAN 1:

```
switch(config)# rscn commit vsan 1
```

Related Commands

Command	Description
rscn abort	Cancels a pending RSCN configuration on a specified VSAN.
rscn distribute	Enables the distribution of an RSCN configuration.
rscn event-tov	Configures an RSCN event timeout.
clear rscn session	Clears the RSCN session for a specified VSAN.
show rscn	Displays RSCN configuration information.

Send comments to nx5000-docfeedback@cisco.com

rscn distribute

To enable distribution of a Registered State Change Notification (RSCN) configuration, use the **rscn distribute** command. To disable the distribution, use the **no** form of this command.

rscn distribute

no rscn distribute

Syntax Description This command has no arguments or keywords.

Command Default RSCN timer distribution is disabled.

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines The RSCN timer configuration must be the same on all switches in the Virtual SAN (VSAN). Cisco Fabric Service (CFS) automatically distributes the RSCN timer configuration to all switches in a fabric. Only the RSCN timer configuration is distributed.

Examples This example shows how to enable the distribution of an RSCN configuration:

```
switch(config)# rscn distribute
```

Related Commands	Command	Description
	rscn abort	Cancels a pending RSCN configuration on a specified VSAN.
	rscn commit	Applies a pending RSCN configuration.
	rscn event-tov	Configures an RSCN event timeout.
	clear rscn session	Clears the RSCN session for a specified VSAN.
	show rscn	Displays RSCN configuration information.

Send comments to nx5000-docfeedback@cisco.com

rscn event-tov

To configure an event timeout value for a Registered State Change Notification (RSCN) on a specified Virtual SAN (VSAN), use the **rscn event-tov** command. To cancel the event timeout value and restore the default value, use the **no** form of this command.

rscn event-tov *timeout* **vsan** *vsan-id*

no rscn event-tov *timeout* **vsan** *vsan-id*

Syntax Description

<i>timeout</i>	Event timeout value in milliseconds. The range is from 0 to 2000.
vsan <i>vsan-id</i>	Specifies a VSAN where the RSCN event timer should be used. The ID of the VSAN is from 1 to 4093.

Command Default

The default timeout values are 2000 milliseconds for Fibre Channel VSANs.

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

Before changing the timeout value, you must enable RSCN configuration distribution using the **rscn distribute** command.

The RSCN timer is registered with Cisco Fabric Services (CFS) during initialization and switchover.

Examples

This example shows how to configure an RSCN event timeout value on VSAN 1:

```
switch(config)# rscn event-tov 20 vsan 1
```

Related Commands

Command	Description
rscn abort	Cancels a pending RSCN configuration on a specified VSAN.
rscn commit	Applies a pending RSCN configuration.
rscn distribute	Enables distribution of an RSCN configuration.
clear rscn session	Clears the RSCN session for a specified VSAN.
show rscn	Displays RSCN configuration information.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

san-port-channel persistent

To convert an autocreated SAN port channel to a persistent SAN port channel, use the **san-port-channel persistent** command.

san-port-channel *port-channel-id* **persistent**

Syntax Description	<i>port-channel-id</i>	Port channel ID. The range is from 1 to 128.
	persistent	Converts the autocreated SAN port channel to a persistent SAN port channel

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	This command is not reversible. A user-created channel group cannot be converted to an autocreated channel group. When the san-port-channel persistent command is applied to an autocreated channel group, the channel group number does not change and the properties of the member ports change to those of a user-created channel group. The channel mode remains active.
-------------------------	---

Examples	<p>This example shows how to change the properties of an autocreated channel group to a persistent channel group:</p> <pre>switch# san-port-channel 10 persistent</pre>
-----------------	--

Related Commands	Command	Description
	san-port-channel protocol	Enables the SAN port channel protocol.
	show interface port-channel	Displays SAN port channel interface information.
	show port-channel	Displays SAN port channel information.

Send comments to nx5000-docfeedback@cisco.com

scsi-target

To configure SCSI target discovery, use the **scsi-target** command. To remove SCSI target discovery, use the **no** form of this command.

scsi-target { **auto-poll** [vsan vsan-id] | **discovery** | **ns-poll** [vsan vsan-id] | **on-demand** [vsan vsan-id] }

no scsi-target { **auto-poll** [vsan vsan-id] | **discovery** | **ns-poll** [vsan vsan-id] | **on-demand** [vsan vsan-id] }

Syntax Description	auto-poll	Configures SCSI target auto-polling globally or per VSAN.
	vsan vsan-id	(Optional) Specifies a VSAN ID. The range is from 1 to 4093.
	discovery	Configures SCSI target discovery.
	ns-poll	Configures SCSI target name-server polling globally or per VSAN.
	on-demand	Configures SCSI targets on-demand globally or per VSAN.

Command Default SCSI target discovery for each option is enabled.

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines Automatic global SCSI target discovery is on by default. Discovery can also be triggered for specific VSANs using on-demand, name server polling, or auto-polling options. All options are on by default. Use the **no scsi-target discovery** command to turn off all discovery options. You can also turn off specific options by using the **no** form of this command.

Examples This example shows how to configure a SCSI target auto-polling discovery for VSAN 1:

```
switch(config)# scsi-target auto-poll vsan 1
```

This example shows how to remove the SCSI target auto-polling discovery for VSAN 1:

```
switch(config)# no scsi-target auto-poll vsan 1
```

This example shows how to configure a SCSI target discovery:

```
switch(config)# scsi-target discovery
```

This example shows how to configure a SCSI target ns-polling discovery for VSAN 1:

```
switch(config)# scsi-target ns-poll vsan 1
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to remove a SCSI target ns-polling discovery for VSAN 1:

```
switch(config)# no scsi-target ns-poll vsan 1
```

This example shows how to configure a SCSI target on-demand discovery for VSAN 1:

```
switch(config)# scsi-target on-demand vsan 1
```

This example shows how to remove a SCSI target on-demand discovery for VSAN 1:

```
switch(config)# no scsi-target on-demand vsan 1
```

Related Commands

Command	Description
discover scsi-target	Discovers SCSI targets on local storage to the switch or remote storage across the fabric.
show scsi-target	Displays information about existing SCSI target configurations.

Send comments to nx5000-docfeedback@cisco.com

shutdown lan (FCoE)

To shut down the Ethernet traffic on a Fibre Channel over Ethernet (FCoE) link, use the **shutdown lan** command. To restore Ethernet traffic, use the **no** form of this command.

shutdown lan

no shutdown lan

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Not shut down.
------------------------	----------------

Command Modes	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	Use this command to shut down Ethernet traffic on the interface. If the interface is part of an FCoE VLAN, the shutdown has no impact on the FCoE traffic.
-------------------------	--

Examples	This example shows how to shut down an Ethernet interface on an FCoE link:
-----------------	--

```
switch(config)# interface ethernet 2/1
switch(config-if)# shutdown lan
switch(config-if)#
```

This example shows how to restore traffic on an interface after you have shut down, or disabled, the interface:

```
switch(config)# interface ethernet 2/1
switch(config-if)# no shutdown lan
switch(config-if)#
```

Related Commands	Command	Description
	fcoe	Configures FCoE parameters.

Send comments to nx5000-docfeedback@cisco.com

switchport

To configure a switch port parameter on a Fibre Channel or virtual Fibre Channel interface, use the **switchport** command. To discard the configuration, use the **no** form of this command.

Fibre Channel Interface:

switchport

```
{fcrxbbscredit {credit [mode E | F] | default | } |
mode {F | NP | SD} |
speed {1000 | 2000 | 4000 | 8000 | auto [max 2000]} |
trunk {allowed vsan [{add} vsan-id | all] | mode {auto | off | on}}}
```

```
no switchport {fcrxbbscredit | mode | speed | trunk {allowed vsan [{add} vsan-id | all] | mode}}
```

Virtual Fibre Channel Interface:

switchport mode F

Syntax	Description
fcrxbbscredit	Configures receive BB_credit for the port.
<i>credit</i>	Receive BB_credit. The range is from 1 to 255.
mode	Configures receive BB_credit for the specific port mode.
E	Configures receive BB_credit for E or TE port mode.
F	Configures receive BB_credit for F port mode.
default	Configures default receive BB_credits depending on the port mode and capabilities.
mode	Configures the port mode.
F	Configures F port mode.
NP	Configures N port proxy mode. NP mode is valid only when the switch is operating in NPV mode.
SD	Configures SD port mode.
speed	Configures the port speed.
1000	Configures 1000-Mbps speed.
2000	Configures 2000-Mbps speed.
4000	Configures 4000-Mbps speed.
8000	Configures 8000-Mbps speed.
auto	Configures autosense speed.
max 2000	(Optional) Configures 2 Gbps as the maximum bandwidth reserved in auto mode for 24-port and 48-port 4-Gbps switching module interfaces.
trunk	Configures trunking parameters on the interface.
allowed	Specifies the allowed list for interface(s).
vsan	Configures the VSAN range.
add	(Optional) Adds the VSAN ID to the range of allowed VSAN list
<i>vsan-id</i>	VSAN ID. The range is from 1 to 4093.
all	Adds all the VSANs to the allowed VSAN list.

Send comments to nx5000-docfeedback@cisco.com

mode	Configures the trunking mode.
auto	Configures automatic trunking mode.
off	Disables the trunking mode.
on	Enables the trunking mode.

Command Default

The EISL encapsulation is disabled.

The default receive data buffer size is 2112 bytes.

The port mode is auto.

The speed is auto.

The maximum auto speed is 2000.

The trunk mode is on.

Command Modes

Interface configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

You can specify a range of interfaces by entering a command with the following example format:

```
interface fc 1/1 - 5 , fc 2/5 - 7
```

The port speed on an interface determines the amount of shared resources available to the ports in the port group. Port group resources are reserved even though the bandwidth is not used. For example, if an interface is configured for autosensing (**auto**), then 4 Gbps of bandwidth is reserved even though the maximum operating speed is 2 Gbps. For the same interface, if autosensing with a maximum speed of 2 Gbps (**auto max 2000**) is configured, then only 2 Gbps of bandwidth is reserved and the unused 2 Gbps is shared with the other interface in the port group.

When configuring port modes, observe the following guidelines:

- Auto port mode and E port mode cannot be configured in shared rate mode.
- Shared to dedicated ports should be configured in this order: speed, port mode, credit.
- Dedicated to shared ports should be configured in this order: credit, port mode, speed.

For a virtual Fibre Channel interface, you can set the port mode to F. The remaining switch port parameters are not configurable.

Examples

This example shows how to configure the switch port parameters for a Fibre Channel interface:

```
switch(config)# interface fc 2/3  
switch(config-if)# switchport description techdocsSample
```

Send comments to nx5000-docfeedback@cisco.com

```
switch(config-if)# switchport mode E
switch(config-if)# switchport trunk mode auto
switch(config-if)# switchport trunk allowed vsan all
switch(config-if)# switchport trunk allowed vsan 3
switch(config-if)# switchport trunk allowed vsan add 2
switch(config-if)# switchport fcrxbcredit 20
```

This example shows how to configure the mode of a virtual Fibre Channel interface:

```
switch(config)# interface vfc 2
switch(config-if)# switchport mode F
```

Related Commands

Command	Description
fcxrbcredit extended enable	Enables extended BB_credits on the switch.
show interface	Displays an interface configuration for a specified interface.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

switchport ignore bit-errors

To prevent the detection of bit error threshold events from disabling the interface on Fibre Channel interfaces, use the **switchport ignore bit-errors** command. To revert to the default, use the **no** form of this command.

switchport ignore bit-errors

no switchport ignore bit-errors

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	The bit error rate threshold is used by the switch to detect an increased error rate before performance degradation seriously affects traffic.
-------------------------	--

Bit errors can occur for the following reasons:

- Faulty or bad cable
- Faulty or bad SFP
- SFP is specified to operate at 1 Gbps but is used at 2 Gbps
- Short haul cable is used for long haul or long haul cable is used for short haul
- Momentary sync loss
- Loose cable connection at one or both ends
- Improper SFP connection at one or both ends

A bit error rate threshold is detected when 15 error bursts occur in a 5-minute period. By default, the switch disables the interface when the threshold is reached. You can enter a **shutdown/no shutdown** command sequence to reenable the interface.

Regardless of the setting of the **switchport ignore bit-errors** command, the switch generates a syslog message when bit error threshold events are detected.

Examples	This example shows how to prevent the detection of bit error events from disabling the interface:
-----------------	---

```
switch(config)# interface fc2/1
switch(config-if)# switchport ignore bit-errors
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to allow the detection of bit error events from disabling the interface:

```
switch(config)# interface fc2/1
switch(config-if)# no switchport ignore bit-errors
```

Related Commands

Command	Description
show interface	Displays interface information.

Send comments to nx5000-docfeedback@cisco.com

system default switchport

To configure port attributes for Fibre Channel interfaces, use the **system default switchport** command. To disable port attributes, use the **no** form of this command.

system default switchport {shutdown | trunk mode {auto | off | on}}

no system default switchport {shutdown | trunk mode {auto | off | on}}

Syntax Description	shutdown	Disables or enables switch ports by default.
	trunk	Configures the trunking parameters as a default.
	mode	Configures the trunking mode.
	auto	Enables autosense trunking.
	off	Disables trunking.
	on	Enables trunking.

Command Default	Enabled
------------------------	---------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

Attributes configured using this command are applied globally to all future switch port configurations, even if you do not individually specify them at that time.

This command changes the configuration of the following ports to administrative mode F:

- All ports that are down.
- All F ports that are up, whose operational mode is F, and whose administrative mode is not F.

This command does not affect non-F ports that are up; however, if non-F ports are down, this command changes the administrative mode of those ports.

Examples

This example shows how to configure a port shutdown:

```
switch(config)# system default switchport shutdown
```

This example shows how to configure the trunk mode:

```
switch(config)# system default switchport trunk mode auto
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	show system default switchport	Displays default values for switch port attributes.
	show interface brief	Displays Fibre Channel port modes.

Send comments to nx5000-docfeedback@cisco.com

system default zone default-zone permit

To configure default values for a zone, use the **system default zone default-zone permit** command. To revert to the defaults, use the **no** form of this command.

system default zone default-zone permit

no system default zone default-zone permit

Syntax Description This command has no arguments or keywords.

Command Default No default values for zones.

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines This command defines the default values for the default zone for all Virtual SANs (VSANs). The default values are used when you initially create a VSAN and it becomes active. If you do not want to use the default values, use the **zone default-zone permit vsan** command to define the operational values for the default zone.

The **system default zone default-zone permit** command should only be used with VSANs that have not yet been created; it has no effect on existing VSANs.

Because VSAN 1 is the default VSAN and is always present, this command has no effect on it.

Examples This example shows how to set the default zone to use the default values:

```
switch(config)# system default zone default-zone permit
```

This example shows how to restore the default setting:

```
switch(config)# no system default zone default-zone permit
```

Related Commands	Command	Description
	zone default-zone permit vsan	Defines whether a default zone (nodes not assigned a created zone) permits or denies access to all in the default zone.
	show system default zone	Displays default values for the default zone.

Send comments to nx5000-docfeedback@cisco.com

system default zone distribute full

To configure default values for distribution to a zone set, use the **system default zone distribute full** command. To revert to the defaults, use the **no** form of this command.

system default zone distribute full

no system default zone distribute full

Syntax Description This command has no arguments or keywords.

Command Default Distribution to active zone sets only.

Command Modes Global configuration mode

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines This command distributes the default values for the default zone to all Virtual SANs (VSANs). The default values are used when you initially create a VSAN and it becomes active. If you do not want to use the default values, use the **zoneset distribute full vsan** command to distribute the operational values for the default zone.

The **system default zone distribute full** command should only be used with VSANs that have not yet been created; it has no effect on existing VSANs.

Because VSAN 1 is the default VSAN and is always present, this command has no effect on it.

Examples This example shows how to distribute the default values to the full zone set:

```
switch(config)# system default zone distribute full
```

This example shows how to distribute the default values to the active zone set only:

```
switch(config)# no system default zone distribute full
```

Command	Description
zoneset distribute full vsan	Distributes the operational values for the default zone to all zone sets.
show system default zone	Displays default values for the default zone.

Send comments to nx5000-docfeedback@cisco.com

trunk protocol enable

To configure the trunking protocol for Fibre Channel interfaces, use the **trunk protocol enable** command. To disable this feature, use the **no** form of this command.

trunk protocol enable

no trunk protocol enable

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Enabled
------------------------	---------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	If the trunking protocol is disabled on a switch, no port on that switch can apply new trunk configurations. Existing trunk configurations are not affected, and the TE port continues to function in trunking mode, but only supports traffic in Virtual SANs (VSANs) that it negotiated previously (when the trunking protocol was enabled). Also, other switches that are directly connected to this switch are similarly affected on the connected interfaces. In some cases, you may need to merge traffic from different port VSANs across a nontrunking ISL. Before you merge traffic, you need to disable the trunking protocol.
-------------------------	--

Examples	This example shows how to disable the trunk protocol feature:
-----------------	---

```
switch(config)# no trunk protocol enable
```

This example shows how to enable the trunk protocol feature:

```
switch(config)# trunk protocol enable
```

Related Commands	Command	Description
	show trunk protocol	Displays the trunk protocol status.

Send comments to nx5000-docfeedback@cisco.com

vsan

To create multiple fabrics sharing the same physical infrastructure, assign ports to Virtual SANs (VSANs), turn on or off interop mode, load balance either per originator exchange or by source-destination ID, and VSAN membership, use the **vsan** command. To remove a configuration, use the **no** form of this command.

vsan *vsan-id*

```
[interface {fc slot/port | san-port-channel port | vfc vfc-id} |
interop [mode] [loadbalancing {src-dst-id | src-dst-ox-id}] |
loadbalancing {src-dst-id | src-dst-ox-id} |
name name [interop [mode] [loadbalancing {src-dst-id | src-dst-ox-id}] | loadbalancing
{src-dst-id | src-dst-ox-id}] | suspend [interop [mode] [loadbalancing {src-dst-id |
src-dst-ox-id}] | loadbalancing {src-dst-id | src-dst-ox-id}] |
suspend [interop [mode] [loadbalancing {src-dst-id | src-dst-ox-id}] | loadbalancing
{src-dst-id | src-dst-ox-id}]]
```

no vsan *vsan-id*

```
[interop [mode] [loadbalancing {src-dst-id | src-dst-ox-id}] |
loadbalancing {src-dst-id | src-dst-ox-id} |
name name [interop [mode] [loadbalancing {src-dst-id | src-dst-ox-id}] | loadbalancing
{src-dst-id | src-dst-ox-id}] | suspend [interop [mode] [loadbalancing {src-dst-id |
src-dst-ox-id}] | loadbalancing {src-dst-id | src-dst-ox-id}] |
suspend [interop [mode] [loadbalancing {src-dst-id | src-dst-ox-id}] | loadbalancing
{src-dst-id | src-dst-ox-id}]]
```

Syntax Description

vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is from 1 to 4094.
interface <i>fc slot/port</i>	(Optional) Specifies the Fibre Channel interface by slot and port number on the switch.
san-port-channel <i>port</i>	Configures the SAN port channel interface specified by the SAN port channel number.
vfc <i>vfc-id</i>	Specifies the virtual Fibre Channel interface.
interop	(Optional) Turns on interoperability mode.
<i>mode</i>	(Optional) Interop mode. The range is from 1 to 4.
loadbalancing	(Optional) Configures the load balancing scheme.
src-dst-id	Sets src-id/dst-id for load-balancing.
src-dst-ox-id	Sets ox-id/src-id/dst-id for load balancing (default).
name <i>name</i>	Assigns a name to the VSAN. The name can be a maximum of 32 characters.
suspend	Suspends the VSAN.

Command Default

None

Command Modes

VSAN database configuration mode

Send comments to nx5000-docfeedback@cisco.com

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The VSAN ID range is increased to 4094.

Usage Guidelines

To use this command, change to the VSAN database mode.

The interface range must be in ascending order and nonoverlapping. You can specify a range using a hyphen and several interfaces using commas:

- The interface range format for a Fibre Channel interface range is fcslot/port - port , fcslot/port , fcslot/port:

For example, **show int fc2/1 - 3 , fc2/4 , fc3/2**

- The format for a SAN port channel is san-port-channel portchannel-number.subinterface-number:

For example, **show int san-port-channel 5.1**

There are four interop modes:

- Interop mode 1 — Standards based interop mode that requires all other vendors in the fabric to be in interop mode.
- Interop mode 2 — Brocade native mode (Core PID 0).
- Interop mode 3 — Brocade native mode (Core PID 1).
- Interop mode 4 — McData native mode. Before you configure Interop mode 4 (or remove the configuration), you must suspend the VSAN. You should unsuspend the VSAN only after you configure a VSAN-dependent switch WWN with the McData OUI [08:00:88].

The **no** form of the **vsan vsan-id interface** command is not supported. To remove a VSAN membership of an interface (for example, interface fc1/8 from VSAN 7), you must assign the interface to another VSAN. The best practice is to assign the interface back to the default VSAN (VSAN 1).

Examples

This example shows how to create multiple fabrics sharing the same physical infrastructure and how to assign ports to VSANs:

```
switch(config)# vsan database
switch-config-vsan-db# vsan 2
switch(config-vsan-db)# vsan 2 name TechDoc
switch(config-vsan-db)# vsan 2 loadbalancing src-dst-id
switch(config-vsan-db)# vsan 2 loadbalancing src-dst-ox-id
switch(config-vsan-db)# vsan 2 suspend
switch(config-vsan-db)# no vsan 2 suspend
switch(config-vsan-db)# end
```

This example shows how to suspend a VSAN and enable Interop mode 4:

```
switch(config)# vsan database
switch(config-vsan-db)# vsan 100 suspend
switch(config-vsan-db)# vsan 100 interop 4
switch(config-vsan-db)# exit
```

This example shows how to configure a VSAN to create a FCOE-VLAN to VSAN mapping:

```
switch(config)# vsan database
switch(config-vsan-db)# vsan 377
switch(config-vsan-db)# exit
```

Send comments to nx5000-docfeedback@cisco.com

```
switch(config)# vlan 30
switch(config-vlan)# fcoe vsan 337
switch(config-vlan)#
```

This example shows how to remove interface fc2/1 from VSAN 7:

```
switch(config)# vsan database
switch(config-vsan-db)# vsan 1 interface fc2/1
switch(config-vsan-db)#
```

Related Commands

Command	Description
show vsan	Displays the configuration information of VSANs.
show vlan fcoe	Displays the FCoE VLAN to VSAN mappings.
show vsan membership	Displays VSAN membership information.
wwn vsan	Configures a WWN for a suspended VSAN that has interop mode 4 enabled.

Send comments to nx5000-docfeedback@cisco.com

vsan database

To enter Virtual SAN (VSAN) database mode to configure VSAN information and membership, use the **vsan database** command.

vsan database

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	To exit from the VSAN database configuration mode, use the exit command.
-------------------------	---

Examples	This example shows how to enter the VSAN database configuration mode:
-----------------	---

```
switch(config)# vsan database  
switch(config-vsan-db)# exit  
switch(config)#
```

Related Commands	Command	Description
	show vsan	Displays the configuration information of VSANs.
	show vlan fcoe	Displays the FCoE VLAN to VSAN mappings.
	show vsan membership	Displays VSAN membership information.
	vsan	Configures VSAN information or membership.

Send comments to nx5000-docfeedback@cisco.com

wwn secondary-mac

To allocate a secondary MAC address to a SAN node, use the **wwn secondary-mac** command.

wwn secondary-mac *wwn-id range address-range*

Syntax Description	<i>wwn-id</i>	Secondary MAC address with the format <i>hh:hh:hh:hh:hh:hh</i> .
	range <i>address-range</i>	Specifies the range for the specified WWN. The only valid value is 64.

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	This command cannot be undone.
	Changes to the worldwide names are only performed as required. They should not be changed on a daily basis. These changes should be made by an administrator or individual who is completely familiar with switch operations.
	For more information, see the <i>Cisco Nexus 5000 Series Switch CLI Software Configuration Guide</i> .

Examples	This example shows how to allocate a secondary range of MAC addresses:
	<code>switch(config)# wwn secondary-mac 00:99:55:77:55:55 range 64</code>

Send comments to nx5000-docfeedback@cisco.com

wwn vsan

To configure a WWN for a suspended Virtual SAN (VSAN) that has interop mode 4 enabled, use the **wwn vsan** command. To discard the configuration, use the **no** form of this command.

wwn vsan *vsan-id* **vsan-wwn** *wwn*

no wwn vsan *vsan-id* **vsan-wwn** *wwn*

Syntax Description	<i>vsan-id</i>	VSAN ID. The range is from 1 to 4093.
	vsan-wwn <i>wwn</i>	Specifies the WWN for the VSAN. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> .
Command Default	None	
Command Modes	Global configuration mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Usage Guidelines	<p>This command can succeed only if the following conditions are satisfied:</p> <ul style="list-style-type: none"> • The VSAN must be suspended. • The VSAN must have interop mode 4 enabled before you can specify the switch WWN for it. • The switch WWN must be unique throughout the entire fabric. • The configured switch WWN must have McData OUI [08:00:88]. 	
Examples	<p>This example shows how to assign a WWN to a VSAN:</p> <pre>switch(config)# wwn vsan 100 vsan-wwn 20:64:08:00:88:0d:5f:81 switch(config)# vsan database switch(config-vsan-db)# vsan 100 suspend switch(config-vsan-db)# exit switch(config)# wwn vsan 100 vsan-wwn 20:64:08:00:88:0d:5f:81</pre>	
Related Commands	Command	Description
	vsan database	Creates multiple fabrics sharing the same physical infrastructure, assigns ports to a VSAN, turns on or off interop mode, load balances either per originator exchange or source-destination ID, and creates VSAN membership.

Send comments to nx5000-docfeedback@cisco.com

zone clone

To clone a zone name, use the **zone clone** command.

zone clone *current-zone-name new-zone-name vsan vsan-id*

Syntax Description	<i>current-zone-name</i>	Zone attribute group name. The name can be a maximum of 64 characters.
	<i>new-zone-name</i>	
	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is from 1 to 4093.

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	Use the no form of the zone name (configuration mode) command to delete the zone name.
-------------------------	--

Examples	This example shows how to create a clone of the original zone group called origZone into the clone zone group cloneZone on VSAN 45:
	<pre>switch(config)# zone clone origZone cloneZone vsan 45</pre>

Related Commands	Command	Description
	show zone	Displays zone information.

Send comments to nx5000-docfeedback@cisco.com

zone commit

To commit zoning changes to a Virtual SAN (VSAN), use the **zone commit** command. To negate the command, use the **no** form of this command.

zone commit vsan *vsan-id* [**force**]

no zone commit vsan *vsan-id* [**force**]

Syntax Description	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is from 1 to 4093.
	force	(Optional) Forces the commit.
Command Default	None	
Command Modes	Global configuration mode	
Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
Usage Guidelines	Use the no form of the zone commit command to clear a session lock on a switch where the lock originated.	
Examples	This example shows how to commit zoning changes to VSAN 200: switch(config)# zone commit vsan 200	
Related Commands	Command	Description
	show zone	Displays zone information.

Send comments to nx5000-docfeedback@cisco.com

zone compact

To compact a zone database in a Virtual SAN (VSAN), use the **zone compact** command.

zone compact vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is from 1 to 4093.
---------------------------	----------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	8000 zones are supported in a Cisco Nexus 5000 Series switch.
	If you attempt to merge VSANs, the merge will fail if more than 2000 zones are present in a VSAN and the neighboring VSAN cannot support more than 2000 zones.
	Activation will fail if more than 2000 zones are present in the VSAN and one or more switches in the fabric cannot support more than 2000 zones.

Examples	This example shows how to compact a zone database in VSAN 1:
	<pre>switch(oongif)# zone compact vsan 1</pre>

Related Commands	Command	Description
	show zone	Displays zone information.
	show zone analysis	Displays detailed analysis and statistical information about the zoning database.

Send comments to nx5000-docfeedback@cisco.com

zone copy

To copy the active zone set to the full zone set, use the **zone copy** command. To negate the command or revert to the factory defaults, use the **no** form of this command.

zone copy active-zoneset full-zoneset [**include-auto-zones**] **vsan** *vsan-id*

zone copy vsan *vsan-id* **active-zoneset** { **bootflash:** | **ftp:** | **full-zoneset** | **scp:** | **sftp:** | **tftp:** | **volatile:** }

no zone copy

Syntax Description

active-zoneset	Copies from the active zone set.
full-zoneset	Copies the active zone set to the full-zone set.
include-auto-zones	(Optional)
vsan <i>vsan-id</i>	Configures to copy the active zone set on a VSAN to the full zone set. The ID of the VSAN is from 1 to 4093.
bootflash:	Copies the active zone set to a location in the bootflash: directory.
ftp:	Copies the active zone set to a remote location using the File Transfer Protocol (FTP) protocol.
scp:	Copies the active zone set to a remote location using the SCP protocol.
sftp:	Copies the active zone set to a remote location using the SFTP protocol.
tftp:	Copies the active zone set to a remote location using the TFTP protocol.
volatile:	Copies the active zone set to a location in the volatile: directory.

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Examples

This example shows how to copy the active zone set to the full zone set:

```
switch# zone copy active-zoneset full-zoneset vsan 1
```

This example shows how to copy the active zone set in VSAN 3 to a remote location using SCP:

```
switch# zone copy vsan 3 active-zoneset scp://guest@myserver/tmp/active_zoneset.txt
```

■ zone copy

Send comments to nx5000-docfeedback@cisco.com

Related Commands	Command	Description
	show zone	Displays zone information.

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

zone default-zone

To define whether a default zone (assigned to nodes not assigned to a created zone) permits or denies access to all nodes in the default zone, use the **zone default-zone** command. To negate the command or revert to the factory defaults, use the **no** form of this command.

zone default-zone permit vsan *vsan-id*

no zone default-zone permit vsan *vsan-id*

Syntax Description

permit	Permits access to all nodes in the default zone.
vsan <i>vsan-id</i>	Sets default zoning behavior for the specified Virtual SAN (VSAN). The ID of the VSAN is from 1 to 4093.

Command Default

All default zones are permitted access.

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

Use the **zone default-zone permit vsan** command to define the operational values for the default zone in a VSAN. This command applies to existing VSANs; it has no effect on VSANs that have not yet been created.

Use the **system default zone default-zone permit** command to use the default values defined for the default zone for all VSANs. The default values are used when you initially create a VSAN and it becomes active.

Examples

This example shows how to permit the default zoning in VSAN 2:

```
switch(config)# zone default-zone permit vsan 2
```

Related Commands

Command	Description
system default zone default-zone permit	Configures default values for a zone.
show zone	Displays zone information.

Send comments to nx5000-docfeedback@cisco.com

zone merge-control restrict vsan

To restrict zone database merging, use the **zone merge-control restrict vsan** command. To disable this feature, use the **no** form of this command.

zone merge-control restrict vsan *vsan-id*

no zone merge-control restrict vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i> Specifies the VSAN ID. The range is from 1 to 4093.	
Command Default	Disabled	
Command Modes	Global configuration mode	
Command History	Release	Modification
	Release 4.0	This command was introduced.
Usage Guidelines	If merge control is set to restricted and the two databases are not identical, the merge fails and Inter-Switch Links (ISLs) between the switches become isolated.	
Examples	This example shows how to set the zone merge control for VSAN 10 to restricted:	
	<pre>switch(config)# zone merge-control restrict vsan 10</pre>	
Related Commands	Command	Description
	show zone	Displays zone information.

Send comments to nx5000-docfeedback@cisco.com

zone mode enhanced

To enable enhanced zoning for a Virtual SAN (VSAN), use the **zone mode enhanced** command. To disable this feature, use the **no** form of this command.

zone mode enhanced vsan *vsan-id*

no zone mode enhanced vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is from 1 to 4093.
--------------------	----------------------------	---

Command Default	Disabled
-----------------	----------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	<p>Before using the zone mode enhanced command, verify that all switches in the fabric are capable of working in enhanced zoning mode. If one or more switches are not capable of working in enhanced zoning mode, the request to enable enhanced zoning mode is rejected.</p> <p>When the zone mode enhanced vsan command completes successfully, the software automatically starts a session, distributes the zoning database using the enhanced zoning data structures, applies the configuration changes, and sends a release change authorization (RCA) to all switches in the fabric. All switches in the fabric then enable enhanced zoning mode.</p>
------------------	--

Examples	<p>This example shows how to enable enhanced zoning mode:</p> <pre>switch(config)# zone mode enhanced vsan 10</pre>
----------	--

Related Commands	Command	Description
	show zone	Displays zone information.

Send comments to nx5000-docfeedback@cisco.com

zone name (configuration mode)

To create a zone, use the **zone name** command. To negate the command or revert to the factory defaults, use the **no** form of this command.

zone name *zone-name* **vsan** *vsan-id*
member

zone name *zone-name* **vsan** *vsan-id*
no member

no zone name *zone-name* **vsan** *vsan-id*

Syntax Description	<i>zone-name</i>	Name of the zone. The name can be a maximum of 64 characters.
	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is from 1 to 4093.

Command Default None

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines Zones are assigned to zone sets. Zone sets are then activated from one switch and propagate across the fabric to all switches. Zones allow security by permitting and denying access between nodes (hosts and storage). **zone name** commands are entered from the configuration mode. Configure a zone for a VSAN from the config-zone mode.

Use the **show wwn switch** command to retrieve the switch world wide name (sWWN). If you do not provide an sWWN, the software automatically uses the local sWWN.

Examples This example shows how to configure attributes for the specified zone (Zone1) based on the member type (pWWN, fabric pWWN, FCID, or Fibre Channel alias) and value specified:

```
switch(config)# zone name Zone1 vsan 10
switch(config-zone)# member device-alias device1
```

This example shows how to configure the members for the specified zone (Zone2) based on the member type (pWWN, fabric pWWN, FCID, or Fibre Channel alias) and value specified:

```
switch(config)# zone name Zone2 vsan 10
switch(config-zone)# member fcalias Payroll
switch(config-zone)# member domain-id 2 portnumber 23
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands

Command	Description
show zone	Displays zone information.
zone rename	Renames zones.
zone-attribute-group name	Configures zone attribute groups.

Send comments to nx5000-docfeedback@cisco.com

zone name (zone set configuration mode)

To configure a zone in a zone set, use the **zone name** command. To delete the zone from the zone set, use the **no zone name** form of this command.

zone name *zone-name*

no zone name *zone-name*

Syntax Description	<i>zone-name</i> Name of the zone. The name can be a maximum of 64 characters.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Zone set configuration mode
----------------------	-----------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples

This example shows how to configure a zone in a zone set:

```
switch(config)# zoneset name Sample vsan 1
switch(config-zoneset)# zone name MyZone
```

This example shows how to delete a zone from a zone set:

```
switch(config-zoneset)# no zone name Zone2
switch(config-zoneset)#
```

Related Commands	Command	Description
	show zoneset	Displays zone set information.
	zone name (configuration mode)	Configure zones.
	zoneset	Configures zone set attributes.

Send comments to nx5000-docfeedback@cisco.com

zone rename

To rename a zone, use the **zone rename** command.

zone rename *current-name new-name vsan vsan-id*

Syntax Description	<i>current-name</i>	Current fcalias name. The name can be a maximum of 64 characters.
	<i>new-name</i>	New fcalias name. The name can be a maximum of 64 characters.
	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is from 1 to 4093.

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to rename a zone:
	switch# zone rename ZoneA ZoneB vsan 10

Related Commands	Command	Description
	show zone	Displays zone information.
	zone name	Creates and configures zones.

Send comments to nx5000-docfeedback@cisco.com

zoneset (configuration mode)

To group zones under one zone set, use the **zoneset** command. To negate the command or revert to the factory defaults, use the **no** form of this command.

zoneset { **activate** [**name** *zoneset-name*] **vsan** *vsan-id* | **clone** *zoneset-currentName* *zoneset-cloneName* **vsan** *vsan-id* | **distribute full vsan** *vsan-id* **name** *zoneset-name* **vsan** *vsan-id* | **rename** *current-name* *new-name* **vsan** *vsan-id* }

no zoneset { **activate** [**name** *zoneset-name*] **vsan** *vsan-id* | **clone** *zoneset-currentName* *zoneset-cloneName* **vsan** *vsan-id* | **distribute full vsan** *vsan-id* **name** *zoneset-name* **vsan** *vsan-id* | **rename** *current-name* *new-name* **vsan** *vsan-id* }

Syntax Description	
activate	Activates a zone set
name <i>zoneset-name</i>	(Optional) Specifies a name for a zone set. The name can be a maximum of 64 characters.
vsan <i>vsan-id</i>	Activates a zone set on the specified Virtual SAN (VSAN). The range is from 1 to 4093.
clone <i>zoneset-currentName</i> <i>zoneset-cloneName</i>	Clones a zone set from the current name to a new name. The name can be a maximum of 64 characters.
distribute full	Enables zone set propagation.
rename	Renames a zone set.
<i>current-name</i>	Current fcalias name.
<i>new-name</i>	New fcalias name.

Command Default None

Command Modes Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines Zones are activated by activating the parent zone set.

The **zoneset distribute full vsan** command distributes the operational values for the default zone to all zone sets in a VSAN. If you do not want to distribute the operation values, use the **system default zone distribute full** command to distribute the default values. The default values are used when you initially create a VSAN and it becomes active.

The **zoneset distribute full vsan** command applies to existing VSANs; it has no effect on VSANs that have not yet been created.

Send comments to nx5000-docfeedback@cisco.com

Examples

This example shows how to activate a zone set called zSet1 in VSAN 333:

```
switch(config)# zoneset activate name zSet1 vsan 333
```

This example shows how to clone a zone set called zSet1 into a new zoneset called zSetClone in VSAN 45:

```
switch(config)# zoneset clone existing zSet1 zSetClone vsan 45
```

This example shows how to distribute the operational values for the default zone to all zone sets in VSAN 22:

```
switch(config)# zoneset distribute full vsan 22
```

Related Commands

Command	Description
system default zone distribute full	Configures default values for distribution to a zone set
show zoneset	Displays zone set information.

Send comments to nx5000-docfeedback@cisco.com

zoneset (EXEC mode)

To merge zone set databases, use the **zoneset** command.

```
zoneset { distribute | export | import interface { fc slot/port | san-port-channel port-number } }
vsan vsan-id
```

Syntax Description		
distribute		Distributes the full zone set in the fabric.
export		Exports the zone set database to the adjacent switch on the specified Virtual SAN (VSAN). The active zone set in this switch becomes the activated zone set of the merged SAN.
import		Imports the zone set database to the adjacent switch on the specified interface. The active zone set in the adjacent switch becomes the activated zone set of the merged SAN.
interface		Configures the interface.
fc <i>slot/port</i>		Configures a Fibre Channel interface for the specified slot number and port number.
san-port-channel <i>port-number</i>		Specifies a SAN port channel interface.
vsan <i>vsan-id</i>		Merges the zone set database of a VSAN on the specified interface. The ID of the VSAN is from 1 to 4093.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines You can also enter the **zoneset import** and the **zoneset export** commands for a range of VSANs. The **zoneset distribute vsan vsan-id** command is supported in interop 2 and interop 3 modes, and not in interop 1 mode.

Examples This example shows how to import the zone set database from the adjacent switch connected through the VSAN 2 interface:

```
switch# zoneset import interface fc2/3 vsan 2
```

This example shows how to export the zone set database to the adjacent switch connected through VSAN 5:

```
switch# zoneset export vsan 5
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to distribute the zone set in VSAN 333:

```
switch# zoneset distribute vsan 333
```

Related Commands	Command	Description
	show zone status vsan	Displays the distribution status for the specified VSAN.
	show zoneset	Displays zone set information.

Send comments to nx5000-docfeedback@cisco.com