

Send comments to nx5000-docfeedback@cisco.com



CHAPTER 1

Basic System Commands

This chapter describes the basic Cisco NX-OS system commands available on Cisco Nexus 5000 Series switches. These commands allow you to navigate and control the switch.

Send comments to nx5000-docfeedback@cisco.com

banner motd

To configure the message-of-the-day (MOTD) banner that displays when the user logs in to a Cisco Nexus 5000 Series switch, use the **banner motd** command. To revert to the default, use the **no** form of this command.

banner motd *delimiter message delimiter*

no banner motd

Syntax Description

| | |
|------------------|--|
| <i>delimiter</i> | Delimiter character that indicates the start and end of the message and is not a character that you use in the message. Do not use " or % as a delimiting character. White space characters will not work. |
| <i>message</i> | Message text. The text is alphanumeric, case sensitive, and can contain special characters. It cannot contain the delimiter character you have chosen. The text has a maximum length of 80 characters and a maximum of 40 lines. |

Command Default

“Nexus 5000 Switch” is the default MOTD string.

Command Modes

Interface configuration mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

To create a multiple-line MOTD banner, press **Enter** before typing the delimiting character to start a new line. You can enter up to 40 lines of text.

Examples

This example shows how to configure a single-line MOTD banner:

```
switch(config)# banner motd #Unauthorized access to this device is prohibited!#
```

This example shows how to configure a multiple-line MOTD banner:

```
switch(config)# banner motd #Welcome Authorized Users Unauthorized access prohibited!#
```

This example shows how to revert to the default MOTD banner:

```
switch(config)# no banner motd
```

Related Commands

| Command | Description |
|-------------------------|---------------------------|
| show banner motd | Displays the MOTD banner. |

Send comments to nx5000-docfeedback@cisco.com

boot

To configure the boot variable for the Cisco Nexus 5000 Series kickstart or system software image, use the **boot** command. To clear the boot variable, use the **no** form of this command.

boot {**kickstart** | **system**} [**bootflash:**] [*//server/*] [*directory*] *filename*

no boot {**kickstart** | **system**}

Syntax Description

| | |
|-------------------|---|
| kickstart | Configures the kickstart image. |
| system | Configures the system image. |
| bootflash: | (Optional) Specifies the name of the bootflash file system. |
| <i>//server/</i> | (Optional) Name of the server. Valid values are <i>///</i> , <i>//module-1/</i> , <i>//sup-1/</i> , <i>//sup-active/</i> , or <i>//sup-local/</i> . The double slash (<i>//</i>) is required. |
| <i>directory</i> | (Optional) Name of a directory. The directory name is case sensitive. |
| <i>filename</i> | Name of the kickstart or system image file. The filename is case sensitive. |



Note

There can be no spaces in the *bootflash://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

Command Default

None

Command Modes

Global configuration mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

The Cisco NX-OS software uses the boot variable for loading images when booting up. You must copy the correct image to the switch before you reload.

Examples

This example shows how to configure the system boot variable:

```
switch(config)# boot system bootflash:n5000.bin
```

This example shows how to configure the kickstart boot variable:

```
switch(config)# boot kickstart bootflash:n5000-kickstart.bin
```

This example shows how to clear the system boot variable:

```
switch(config)# no boot system
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to clear the kickstart boot variable:

```
switch(config)# no boot kickstart
```

Related Commands

| Command | Description |
|------------------|---|
| copy | Copies files. |
| show boot | Displays boot variable configuration information. |

Send comments to nx5000-docfeedback@cisco.com

cd

To change the current working directory in the device file system, use the **cd** command.

cd [*filesystem:*] [*//server/*] *directory*

| | | |
|---------------------------|--------------------|---|
| Syntax Description | <i>filesystem:</i> | (Optional) Name of the file system. Valid values are bootflash or volatile . |
| | <i>//server/</i> | (Optional) Name of the server. Valid values are <i>///</i> , <i>//module-1/</i> , <i>//sup-1/</i> , <i>//sup-active/</i> , or <i>//sup-local/</i> . The double slash (<i>//</i>) is required. |
| | <i>directory</i> | Name of the destination directory. The directory name is case sensitive. |



Note

There can be no spaces in the *filesystem://server/directory* string. Individual elements of this string are separated by colons (*:*) and slashes (*/*).

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | Use the pwd command to verify the current working directory. |
|-------------------------|---|

| | |
|-----------------|--|
| Examples | This example shows how to change the current working directory on the current file system: |
|-----------------|--|

```
switch# cd my-scripts
```

This example shows how to change the current working directory to another file system:

```
switch# cd volatile:
```

| | | |
|-------------------------|----------------|--|
| Related Commands | Command | Description |
| | pwd | Displays the current working directory name. |

Send comments to nx5000-docfeedback@cisco.com

clear cli history

To clear the command history, use the **clear cli history** command.

clear cli history

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | Use the show cli history command to display the history of the commands that you entered at the command-line interface (CLI). |
|-------------------------|--|

| | |
|-----------------|---|
| Examples | <p>This example shows how to clear the command history:</p> <pre>switch# clear cli history</pre> |
|-----------------|---|

| | | |
|-------------------------|-------------------------|-------------------------------|
| Related Commands | Command | Description |
| | show cli history | Displays the command history. |

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

clear cores

To clear the core files, use the **clear cores** command.

clear cores

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | Use the show system cores command to display information about the core files. |
|-------------------------|---|

| | |
|-----------------|--|
| Examples | This example shows how to clear the core file: |
|-----------------|--|

```
switch# clear cores
```

| Related Commands | Command | Description |
|-------------------------|--------------------------|-------------------------------|
| | show system cores | Displays the core filename. |
| | system cores | Configures the core filename. |

Send comments to nx5000-docfeedback@cisco.com

clear debug-logfile

To clear the contents of the debug log file, use the **clear debug-logfile** command.

clear debug-logfile *filename*

| | | |
|---------------------------|-----------------|--------------------------------------|
| Syntax Description | <i>filename</i> | Name of the debug log file to clear. |
|---------------------------|-----------------|--------------------------------------|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|--|
| Examples | <p>This example shows how to clear the debug log file:</p> <pre>switch# clear debug-logfile syslogd_debugs</pre> |
|-----------------|--|

| Related Commands | Command | Description |
|-------------------------|---------------------------|--|
| | debug logfile | Configures a debug log file. |
| | debug logging | Enables debug logging. |
| | show debug logfile | Displays the contents of the debug log file. |

Send comments to nx5000-docfeedback@cisco.com

clear install failure-reason

To clear the reason for software installation failures, use the **clear install failure-reason** command.

clear install failure-reason

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|---|
| Examples | <p>This example shows how to clear the reason for software installation failures:</p> <pre>switch# clear install failure-reason</pre> |
|-----------------|---|

| Related Commands | Command | Description |
|-------------------------|-------------------------|--|
| | show install all | Displays status information for the software installation. |

Send comments to nx5000-docfeedback@cisco.com

clear license

To uninstall a license, use the **clear license** command.

clear license *filename*

| | | |
|---------------------------|--|---|
| Syntax Description | <i>filename</i> | Name of the license file to be uninstalled. |
| Command Default | None | |
| Command Modes | EXEC mode | |
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| Examples | <p>This example shows how to clear a specific license:</p> <pre>switch# clear license fm.lic</pre> | |
| Related Commands | Command | Description |
| | show license | Displays license information. |

Send comments to nx5000-docfeedback@cisco.com

clear user

To log out a particular user, use the **clear user** command.

clear user *username*

| | | |
|--------------------|---|--|
| Syntax Description | <i>username</i> Name of the user to be logged out. | |
| Command Default | None | |
| Command Modes | EXEC mode | |
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| Examples | This example shows how to log out a specific user: switch# clear user admin | |
| Related Commands | Command | Description |
| | show users | Displays the users currently logged on the switch. |

Send comments to nx5000-docfeedback@cisco.com

cli var name

To define a command-line interface (CLI) variable for a terminal session, use the **cli var name** command. To remove the CLI variable, use the **no** form of this command.

cli var name *variable-name variable-text*

no cli var name *variable-name*

| | | |
|---------------------------|----------------------|---|
| Syntax Description | <i>variable-name</i> | Name of the variable. The name is alphanumeric, case sensitive, and has a maximum of 31 characters. |
| | <i>variable-text</i> | Variable text. The text is alphanumeric, can contain spaces, and has a maximum of 200 characters. |

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines You can reference a CLI variable using the following syntax:

`$(variable-name)`

Instances where you can use variables include the following:

- Command scripts
- Filenames

You cannot reference a variable in the definition of another variable.

The Cisco NX-OS software provides a predefined variable, **TIMESTAMP**, that you can use to insert the time of day. You cannot change or remove the **TIMESTAMP** CLI variable.

You cannot change the definition of a CLI variable. You must remove the variable and then create it again with the new definition.

Examples This example shows how to define a CLI variable:

```
switch# cli var name testvar interface ethernet 1/3
```

This example shows how to reference a CLI variable:

```
switch# show $(testvar)
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to reference the TIMESTAMP variable:

```
switch# copy running-config > bootflash:run-config-$(TIMESTAMP).cnfg
```

This example shows how to remove a CLI variable:

```
switch# cli no var name testvar
```

Related Commands

| Command | Description |
|---------------------------|-----------------------------|
| run-script | Runs command scripts. |
| show cli variables | Displays the CLI variables. |

Send comments to nx5000-docfeedback@cisco.com

clock set

To manually set the clock on a Cisco Nexus 5000 Series switch, use the **clock set** command.

clock set *time day month year*

| | | |
|---------------------------|--------------|---|
| Syntax Description | <i>time</i> | Time of day. The format is <i>HH:MM:SS</i> . |
| | <i>day</i> | Day of the month. The range is from 1 to 31. |
| | <i>month</i> | Month of the year. The values are January, February, March, April, May, June, July, August, September, October, November, and December . |
| | <i>year</i> | Year. The range is from 2000 to 2030. |

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | Use this command when you cannot synchronize the switch with an outside clock source, such as an NTP server. |
|-------------------------|--|

| | |
|-----------------|---|
| Examples | This example shows how to manually configure the clock: |
|-----------------|---|

```
switch# clock set 12:00:00 04 July 2008
```

| | | |
|-------------------------|----------------|--------------------------|
| Related Commands | Command | Description |
| | show clock | Displays the clock time. |

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

clock summer-time

To configure the summer-time (daylight saving time) offset, use the **clock summer-time** command. To revert to the default, use the **no** form of this command.

clock summer-time *zone-name start-week start-day start-month start-time end-week end-day end-month end-time offset-minutes*

no clock summer-time

Syntax Description

| | |
|-----------------------|---|
| <i>zone-name</i> | Time zone string. The time zone string is a three-character string. |
| <i>start-week</i> | Week of the month to start the summer-time offset. The range is from 1 to 5. |
| <i>start-day</i> | Day of the month to start the summer-time offset. Valid values are Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, or Sunday . |
| <i>start-month</i> | Month to start the summer-time offset. Valid values are January, February, March, April, May, June, July, August, September, October, November, and December . |
| <i>start-time</i> | Time to start the summer-time offset. The format is <i>HH:MM</i> . |
| <i>end-week</i> | Week of the month to end the summer-time offset. The range is from 1 to 5. |
| <i>end-day</i> | Day of the month to end the summer-time offset. Valid values are Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, or Sunday . |
| <i>end-month</i> | Month to end the summer-time offset. Valid values are January, February, March, April, May, June, July, August, September, October, November, and December . |
| <i>end-time</i> | Time to end the summer-time offset. The format is <i>HH:MM</i> . |
| <i>offset-minutes</i> | Number of minutes to offset the clock. The range is from 1 to 1440. |

Command Default

None

Command Modes

Interface configuration mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Examples

This example shows how to configure the offset for summer-time or daylight saving time:

```
switch(config)# clock summer-time PDT 1 Sunday March 02:00 5 Sunday November 02:00 60
```

This example shows how to revert to the default offset for summer-time:

```
switch(config)# no clock summer-time
```

Send comments to nx5000-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|------------|--|
| | show clock | Displays the clock summer-time offset configuration. |

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

clock timezone

To configure the time zone offset from Coordinated Universal Time (UTC), use the **clock timezone** command. To revert to the default, use the **no** form of this command.

clock timezone *zone-name offset-hours offset-minutes*

no clock timezone

| | | |
|---------------------------|-----------------------|--|
| Syntax Description | <i>zone-name</i> | Zone name. The name is a 3-character string for the time zone acronym (for example, PST or EST). |
| | <i>offset-hours</i> | Number of hours offset from UTC. The range is from -23 to 23. |
| | <i>offset-minutes</i> | Number of minutes offset from UTC. The range is from 0 to 59. |

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|------------------------------|
| Command Modes | Interface configuration mode |
|----------------------|------------------------------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | Use this command to offset the device clock from UTC. |
|-------------------------|---|

| | |
|-----------------|--|
| Examples | This example shows how to configure the time zone offset from UTC: switch(config)# clock timezone PST -8 0 |
| | This example shows how to revert the time zone offset to the default: switch# no clock timezone |

| | | |
|-------------------------|-------------------|--------------------------|
| Related Commands | Command | Description |
| | show clock | Displays the clock time. |

Send comments to nx5000-docfeedback@cisco.com

configure session

To create or modify a configuration session, use the **configure session** command.

configure session *name*

| Syntax Description | <i>name</i> | Name of the session. The name is a case-sensitive alphanumeric string up to 63 characters. |
|--------------------|-------------|--|
|--------------------|-------------|--|

| Command Default | None |
|-----------------|------|
|-----------------|------|

| Command Modes | EXEC mode |
|---------------|-----------|
|---------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(1a)N1(1) | This command was introduced. |

Examples This example shows how to create a configuration session:

```
switch# configure session MySession
switch(config-s)#
```

| Related Commands | Command | Description |
|------------------|-----------------------------------|--|
| | show configuration session | Displays information about the configuration sessions. |

Send comments to nx5000-docfeedback@cisco.com

configure terminal

To enter configuration mode, use the **configure terminal** command.

configure terminal

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | <p>Use this command to enter configuration mode. Commands in this mode are written to the running configuration file as soon as you enter them (using the Enter key/Carriage Return).</p> <p>After you enter the configure terminal command, the system prompt changes from switch# to switch(config)#, indicating that the router is in configuration mode. To leave configuration mode and return to EXEC mode, type end or press Ctrl-Z.</p> <p>To view the changes to the configuration that you have made, use the show running-config command.</p> |
|-------------------------|--|

| | |
|-----------------|---|
| Examples | This example shows how to enter configuration mode: |
|-----------------|---|

```
switch# configure terminal
switch(config)#
```

| | | |
|-------------------------|---|---|
| Related Commands | Command | Description |
| | copy running-config startup-config | Saves the running configuration as the startup configuration file. |
| | end | Ends your configuration session by exiting to EXEC mode. |
| | exit (global) | Exits from the current configuration mode to the next highest configuration mode. |
| | show running-config | Displays the current running configuration. |

Send comments to nx5000-docfeedback@cisco.com

copy

To copy any file from a source to a destination, use the **copy** command.

copy *source-url destination-url*

Syntax Description

| | |
|------------------------|--|
| <i>source-url</i> | Location URL (or variable) of the source file or directory to be copied. The source can be either local or remote, depending upon whether the file is being downloaded or uploaded. For more information, see the “Usage Guidelines” section. |
| <i>destination-url</i> | Destination URL (or variable) of the copied file or directory. The destination can be either local or remote, depending upon whether the file is being downloaded or uploaded. For more information, see the “Usage Guidelines” section. |

Command Default

The default name for the destination file is the source filename.

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

The **copy** command allows you to copy a file (such as a system image or configuration file) from one location to another location. The source and destination for the file is specified using a Cisco NX-OS file system URL, which allows you to specify a local or remote file location. The file system being used (such as a local memory source or a remote server) determines the syntax used in the command.

You can enter on the command line all necessary source- and destination-URL information and the username to use, or you can enter the **copy** command and have the CLI prompt you for any missing information.

The entire copying process may take several minutes, depending on the network conditions and the size of the file, and differs from protocol to protocol and from network to network.

The colon character (:) is required after the file system URL prefix keywords (such as **bootflash**).

In the URL syntax for **ftp:**, **scp:**, **sftp:**, and **tftp:**, the server is either an IPv4 address or a hostname.

Format of Source and Destination URL

The format of the source and destination URLs varies according to the file or directory location. You can enter either a command-line interface (CLI) variable for a directory or a filename that follows the Cisco NX-OS file system syntax (*filesystem:[/directory][/filename]*).

The following tables list URL prefix keywords by the file system type. If you do not specify a URL prefix keyword, the router looks for a file in the current directory.

Send comments to nx5000-docfeedback@cisco.com

Table 1-1 lists URL prefix keywords for local writable storage file systems. Table 1-2 lists the URL prefix keywords for remote file systems. Table 1-3 lists the URL prefix keywords for nonwritable file systems.

Table 1-1 URL Prefix Keywords for Local Writable Storage File Systems

| Keyword | Source or Destination |
|--------------------------------------|---|
| bootflash: <i>[//server/]</i> | Source or destination URL for boot flash memory. The <i>server</i> argument value is module-1 , sup-1 , sup-active , or sup-local . |
| volatile: <i>[//server/]</i> | Source or destination URL of the default internal file system. Any files or directories stored in this file system will be erased when the switch reboots. The <i>server</i> argument value is module-1 , sup-1 , sup-active , or sup-local . |

Table 1-2 URL Prefix Keywords for Remote File Systems

| Keyword | Source or Destination |
|--------------|--|
| ftp: | Source or destination URL for a FTP network server. The syntax for this alias is as follows: ftp: <i>[//server][/path]/filename</i> |
| scp: | Source or destination URL for a network server that supports Secure Shell (SSH) and accepts copies of files using the secure copy protocol (scp). The syntax for this alias is as follows: scp: <i>[//[username@]server][/path]/filename</i> |
| sftp: | Source or destination URL for an SSH FTP (SFTP) network server. The syntax for this alias is as follows: sftp: <i>[//[username@]server][/path]/filename</i> |
| tftp: | Source or destination URL for a TFTP network server. The syntax for this alias is as follows: tftp: <i>[//server[:port]][/path]/filename</i> |

Table 1-3 URL Prefix Keywords for Special File Systems

| Keyword | Source or Destination |
|------------------|--|
| core: | Local memory for core files. You can copy core files from the core file system. |
| debug: | Local memory for debug files. You can copy core files from the debug file system. |
| log: | Local memory for log files. You can copy log files from the log file system. |
| modflash: | External memory for mod files. You can copy mod files from modflash file system. |
| system: | Local system memory. You can copy the running configuration to or from the system file system. The system file system is optional when referencing the running-config file in a command. |
| volatile: | Local volatile memory. You can copy files to or from the volatile file system. All files in the volatile memory are lost when the physical device reloads. |

Send comments to nx5000-docfeedback@cisco.com

This section contains usage guidelines for the following topics:

- [Copying Files from a Server to Bootflash Memory, page 1-22](#)
- [Copying a Configuration File from a Server to the Running Configuration, page 1-22](#)
- [Copying a Configuration File from a Server to the Startup Configuration, page 1-22](#)
- [Copying the Running or Startup Configuration on a Server, page 1-22](#)

Copying Files from a Server to Bootflash Memory

Use the **copy *source-url* bootflash:** command (for example, **copy tftp:*source-url* bootflash:**) to copy an image from a server to the local bootflash memory.

Copying a Configuration File from a Server to the Running Configuration

Use the **copy {ftp: | scp: | sftp: | tftp:} *source-url* running-config** command to download a configuration file from a network server to the running configuration of the device. The configuration is added to the running configuration as if the commands were typed in the CLI. The resulting configuration file is a combination of the previous running configuration and the downloaded configuration file. The downloaded configuration file has precedence over the previous running configuration.

You can copy either a host configuration file or a network configuration file. Accept the default value of *host* to copy and load a host configuration file containing commands that apply to one network server in particular. Enter *network* to copy and load a network configuration file that contains commands that apply to all network servers on a network.

Copying a Configuration File from a Server to the Startup Configuration

Use the **copy {ftp: | scp: | sftp: | tftp:} *source-url* startup-config** command to copy a configuration file from a network server to the router startup configuration. These commands replace the startup configuration file with the copied configuration file.

Copying the Running or Startup Configuration on a Server

Use the **copy running-config {ftp: | scp: | sftp: | tftp:} *destination-url*** command to copy the current configuration file to a network server that uses FTP, scp, SFTP, or TFTP. Use the **copy startup-config {ftp: | scp: | sftp: | tftp:} *destination-url*** command to copy the startup configuration file to a network server.

You can use the copied configuration file copy as a backup.

Examples

This example shows how to copy a file within the same directory:

```
switch# copy file1 file2
```

This example shows how to copy a file to another directory:

```
switch# copy file1 my-scripts/file2
```

This example shows how to copy a file to another file system:

```
switch# copy file1 bootflash:
```

This example shows how to copy a file to another supervisor module:

```
switch# copy file1 bootflash://sup-1/file1.bak
```

This example shows how to copy a file from a remote server:

Send comments to nx5000-docfeedback@cisco.com

```
switch# copy scp://192.168.1.1/image-file.bin bootflash:image-file.bin
```

Related Commands

| Command | Description |
|---------------|---|
| cd | Changes the current working directory. |
| delete | Delete a file or directory. |
| dir | Displays the directory contents. |
| move | Moves a file. |
| pwd | Displays the name of the current working directory. |

Send comments to nx5000-docfeedback@cisco.com

copy running-config startup-config

To save the running configuration to the startup configuration file so that all current configuration details are available after a reboot, use the **copy running-config startup-config** command.

copy running-config startup-config

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | To view the changes to the configuration that you have made, use the show startup-config command. |
|-------------------------|--|



Note

Once you enter the **copy running-config startup-config** command, the running and the startup copies of the configuration are identical.

| | |
|-----------------|---|
| Examples | <p>This example shows how to save the running configuration to the startup configuration:</p> <pre>switch# copy running-config startup-config</pre> |
|-----------------|---|

| | | |
|-------------------------|----------------------------|---|
| Related Commands | Command | Description |
| | show running-config | Displays the currently running configuration. |
| | show startup-config | Displays the startup configuration file. |

Send comments to nx5000-docfeedback@cisco.com

databits

To configure the number of data bits in a character for the terminal port, use the **databits** command. To revert to the default, use the **no** form of this command.

databits *bits*

no databits *bits*

| | | |
|---------------------------|---|--|
| Syntax Description | <i>bits</i> Number of data bits in a character. The range is from 5 to 8. | |
| Command Default | 8 bits | |
| Command Modes | Terminal line configuration mode | |
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| Usage Guidelines | You can configure the console port only from a session on the console port. | |
| Examples | This example shows how to configure the number of data bits for the console port: switch# configure terminal switch(config)# line console switch(config-console)# databits 7 | |
| | This example shows how to revert to the default number of data bits for the console port: switch# configure terminal switch(config)# line console switch(config-console)# no databits 7 | |
| Related Commands | Command | Description |
| | show line | Displays information about the console port configuration. |

Send comments to nx5000-docfeedback@cisco.com

debug logfile

To direct the output of the **debug** commands to a specified file, use the **debug logfile** command. To revert to the default, use the **no** form of this command.

debug logfile *filename* [*size bytes*]

no debug logfile *filename* [*size bytes*]

| | | |
|---------------------------|-------------------|---|
| Syntax Description | <i>filename</i> | Name of the file for debug command output. The filename is alphanumeric, case sensitive, and has a maximum of 64 characters. |
| | <i>size bytes</i> | (Optional) Specifies the size of the log file in bytes. The range is from 4096 to 4194304. |

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | The Cisco NX-OS software creates the logfile in the log: file system root directory. Use the dir log: command to display the log files. |
|-------------------------|--|

| | |
|-----------------|---|
| Examples | This example shows how to specify a debug log file: |
|-----------------|---|

```
switch# debug logfile debug_log
```

This example shows how to revert to the default debug log file:

```
switch# no debug logfile debug_log
```

| Related Commands | Command | Description |
|-------------------------|---------------------------|---------------------------------------|
| | dir | Displays the contents of a directory. |
| | show debug logfile | Displays the debug logfile contents. |

Send comments to nx5000-docfeedback@cisco.com

debug logging

To enable **debug** command output logging, use the **debug logging** command. To disable debug logging, use the **no** form of this command.

debug logging

no debug logging

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|----------|
| Command Default | Disabled |
|------------------------|----------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|---|
| Examples | This example shows how to enable the output logging for the debug command: |
|-----------------|---|

switch# **debug logging**

| |
|--|
| This example shows how to disable the output logging for the debug command: |
|--|

switch# **no debug logging**

| Related Commands | Command | Description |
|-------------------------|----------------------|--|
| | debug logfile | Configures the log file for the debug command output. |

Send comments to nx5000-docfeedback@cisco.com

delete

To delete a file or directory, use the **delete** command.

delete [*filesystem:*] [*//server/*] [*directory*] *filename*

Syntax Description

| | |
|--------------------|--|
| <i>filesystem:</i> | (Optional) Name of the file system. Valid values are bootflash , debug , log , modflash , or volatile . |
| <i>//server/</i> | (Optional) Name of the server. Valid values are // , //module-1/ , //sup-1/ , //sup-active/ , or //sup-local/ . The double slash (//) is required. |
| <i>directory</i> | (Optional) Name of a directory. The directory name is case sensitive. |
| <i>filename</i> | Name of the file to delete. The filename is case sensitive. |



Note

There can be no spaces in the *filesystem://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

Command Default

None

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

Use the **dir** command to locate the file you that want to delete.

The **delete** command will delete a directory and its contents. Exercise caution when using this command to delete directories.

Examples

This example shows how to delete a file:

```
switch# delete bootflash:old_config.cfg
```

This example shows how to delete a directory:

```
switch# delete my_dir
This is a directory. Do you want to continue (y/n)? [y] y
```

Send comments to nx5000-docfeedback@cisco.com

Related Commands

| Command | Description |
|-------------|--|
| dir | Displays the contents of a directory. |
| save | Saves the configuration session to a file. |

Send comments to nx5000-docfeedback@cisco.com

dir

To display the contents of a directory, use the **dir** command.

dir [*filesystem:*] [*//server/*] [*directory*]

Syntax Description

| | |
|--------------------|---|
| <i>filesystem:</i> | (Optional) Name of the file system. Valid values are bootflash , debug , log , modflash , or volatile . |
| <i>//server/</i> | (Optional) Name of the server. Valid values are <i>///</i> , <i>//module-1/</i> , <i>//sup-1/</i> , <i>//sup-active/</i> , or <i>//sup-local/</i> . The double slash (<i>//</i>) is required. |
| <i>directory</i> | (Optional) Name of a directory. The directory name is case sensitive. |



Note

There can be no spaces in the *filesystem://server/directory* string. Individual elements of this string are separated by colons (*:*) and slashes (*/*).

Command Default

Displays the contents of the current working directory.

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

The **dir** command displays a listing of the files in the specified directory. For each file, it lists the size of the file in bytes, the last modified time of the file, and the filename of the file. This command then displays the usage statistics for the file system.

Use the **pwd** command to verify the current working directory.

Use the **cd** command to change the current working directory.

Examples

This example shows how to display the contents of the root directory in bootflash:

```
switch# dir bootflash:
```

This example shows how to display the contents of the current working directory:

```
switch# dir
```

Send comments to nx5000-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|---------------|---|
| | cd | Changes the current working directory. |
| | delete | Deletes a file or directory. |
| | pwd | Displays the name of the current working directory. |
| | rmdir | Deletes a directory. |

Send comments to nx5000-docfeedback@cisco.com

echo

To display a text string on the terminal, use the **echo** command.

echo [*text*]

| | | |
|---------------------------|-------------|---|
| Syntax Description | <i>text</i> | (Optional) Text string to display. The text string is alphanumeric, case sensitive, can contain spaces, and has a maximum length of 200 characters. The text string can also contain references to CLI variables. |
|---------------------------|-------------|---|

| | |
|------------------------|------------|
| Command Default | Blank line |
|------------------------|------------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | You can use this command in a command script to display status information or prompts while the script is running. |
|-------------------------|--|

| | |
|-----------------|---|
| Examples | This example shows how to display a blank line at the command prompt: |
|-----------------|---|

```
switch# echo
```

This example shows how to display a line of text at the command prompt:

```
switch# echo Script run at $(TIMESTAMP).
```

| Related Commands | Command | Description |
|-------------------------|---------------------------|-----------------------------|
| | run-script | Runs command scripts. |
| | show cli variables | Displays the CLI variables. |

Send comments to nx5000-docfeedback@cisco.com

end

To end the current configuration session and return to EXEC mode, use the **end** command.

end

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|---------------------------|
| Command Modes | Global configuration mode |
|----------------------|---------------------------|

| Command History | Release | Modification |
|------------------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | This command returns you to EXEC mode regardless of which configuration mode you are in. Use this command when you are done configuring the system and you want to return to EXEC mode to perform verification steps. |
|-------------------------|---|

| | |
|-----------------|---|
| Examples | This example shows how the end command is used to exit from interface configuration mode and return to EXEC mode. A show command is used to verify the configuration. |
|-----------------|---|

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# switchport host
switch(config-if)# end
switch# show interface ethernet 1/1
```

| Related Commands | Command | Description |
|-------------------------|----------------------|---|
| | exit (EXEC) | Terminates the active terminal session by logging off the router. |
| | exit (global) | Exits from the current configuration mode. |

Send comments to nx5000-docfeedback@cisco.com

exec-timeout

To configure the inactive session timeout on the console port or the virtual terminal, use the **exec-timeout** command. To revert to the default, use the **no** form of this command.

exec-timeout *minutes*

no exec-timeout

| | | |
|---------------------------|----------------|--|
| Syntax Description | <i>minutes</i> | Number of minutes. The range is from 0 to 525600. A setting of 0 minutes disables the timeout. |
|---------------------------|----------------|--|

| | |
|------------------------|----------------------|
| Command Default | Timeout is disabled. |
|------------------------|----------------------|

| | |
|----------------------|----------------------------------|
| Command Modes | Terminal line configuration mode |
|----------------------|----------------------------------|

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | You can configure the console port only from a session on the console port. |
|-------------------------|---|

Examples This example shows how to configure the inactive session timeout for the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# exec-timeout 30
```

This example shows how to revert to the default inactive session timeout for the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# no exec-timeout
```

This example shows how to configure the inactive session timeout for the virtual terminal:

```
switch# configure terminal
switch(config)# line vty
switch(config-line)# exec-timeout 30
```

This example shows how to revert to the default inactive session timeout for the virtual terminal:

```
switch# configure terminal
switch(config)# line vty
switch(config-line)# no exec-timeout
```

Send comments to nx5000-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|----------------------------|---|
| | line console | Enters the console terminal configuration mode. |
| | line vty | Enters the virtual terminal configuration mode. |
| | show running-config | Displays the running configuration. |

Send comments to nx5000-docfeedback@cisco.com

exit (EXEC)

To close an active terminal session by logging off the switch, use the **exit** command.

exit

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|--|
| Examples | <p>This example shows how the exit (global) command is used to move from configuration mode to EXEC mode and the exit (EXEC) command is used to log off (exit the active session):</p> |
|-----------------|--|

```
switch(config)# exit
switch# exit
```

| | | |
|-------------------------|----------------------|---|
| Related Commands | Command | Description |
| | end | Ends your configuration session by exiting to EXEC mode. |
| | exit (global) | Exits from the current configuration mode to the next highest configuration mode. |

Send comments to nx5000-docfeedback@cisco.com

exit (global)

To exit any configuration mode to the next highest mode in the CLI mode hierarchy, use the **exit** command in any configuration mode.

exit

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-------------------------|
| Command Modes | All configuration modes |
|----------------------|-------------------------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | Use the exit command in configuration mode to return to EXEC mode. Use the exit command in interface, VLAN, or zone configuration mode to return to configuration mode. At the highest level, EXEC mode, the exit command will exit the EXEC mode and disconnect from the switch (see the description of the exit (EXEC) command for details). |
|-------------------------|---|

| | |
|-----------------|--|
| Examples | <p>This example shows how to exit from the interface configuration mode and to return to the configuration mode:</p> <pre>switch(config-if) # exit switch(config) #</pre> |
|-----------------|--|

| Related Commands | Command | Description |
|------------------|--------------------|---|
| | end | Ends your configuration session by exiting to privileged EXEC mode. |
| | exit (EXEC) | Terminates the active terminal session by logging off the router. |

Send comments to nx5000-docfeedback@cisco.com

feature fcoe

To enable virtual and native Fibre Channel interfaces after installing the FC_FEATURES_PKG license, use the **feature fcoe** command. To disable Fibre Channel interfaces and return the FC_FEATURES_PKG license to the license manager software, use the **no** form of this command.

feature fcoe

no feature fcoe

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|----------|
| Command Default | Disabled |
|------------------------|----------|

| | |
|----------------------|---------------------------|
| Command Modes | Global configuration mode |
|----------------------|---------------------------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | You must save the configuration, and then reboot the switch to enable or disable the FCoE feature. |
|-------------------------|--|

| | |
|-----------------|--|
| Examples | This example shows how to enable FCoE on the switch: |
|-----------------|--|

```
switch(config)# feature fcoe
```

| | | |
|-------------------------|---------------------|--|
| Related Commands | Command | Description |
| | fcoe | Configures FCoE parameters. |
| | show feature | Displays whether or not FCoE is enabled on the switch. |

Send comments to nx5000-docfeedback@cisco.com

feature fex

To enable Fabric Extender (FEX) features on the switch, use the **feature fex** command. To disable FEX, use the **no** form of this command.

feature fex

no feature fex

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|---------------------------|
| Command Modes | Global configuration mode |
|----------------------|---------------------------|

| Command History | Release | Modification |
|------------------------|--------------|------------------------------|
| | 4.0(1a)N2(1) | This command was introduced. |

| | |
|-----------------|---|
| Examples | This example shows how to enable FEX features on the switch: |
| | <pre>switch(config)# feature fex switch(config)#</pre> |

| Related Commands | Command | Description |
|-------------------------|---------------------|--|
| | fex | Creates a Fabric Extender and enters fabric extender configuration mode. |
| | show feature | Displays the features enabled or disabled on the switch. |

Send comments to nx5000-docfeedback@cisco.com

feature interface-vlan

To enable the creation of VLAN interfaces, use the **feature interface-vlan** command. To disable the VLAN interface feature, use the **no** form of this command.

feature interface-vlan

no feature interface-vlan

Syntax Description This command has no arguments or keywords.

Command Default VLAN interfaces are disabled.

Command Modes Global configuration mode

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines You must use the **feature interface-vlan** command before you can create VLAN interfaces.

Examples This example shows how to enable the interface VLAN feature on the switch:

```
switch(config)# feature interface-vlan
```

| Related Commands | Command | Description |
|------------------|-----------------------|--|
| | interface vlan | Creates a VLAN interface. |
| | show feature | Displays whether or not VLAN interface is enabled on the switch. |

Send comments to nx5000-docfeedback@cisco.com

feature lacp

To enable Link Aggregation Control Protocol (LACP), which bundles a number of physical ports together to form a single logical channel, use the **feature lacp** command. To disable LACP on the switch, use the **no** form of this command.

feature lacp

no feature lacp

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|-------------------|
| Command Default | LACP is disabled. |
|------------------------|-------------------|

| | |
|----------------------|---------------------------|
| Command Modes | Global configuration mode |
|----------------------|---------------------------|

| Command History | Release | Modification |
|------------------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | You must remove all the LACP configuration parameters from all EtherChannels on the switch before you can disable LACP. |
| | Even after you enable LACP globally, you do not have to run LACP on all EtherChannels on the switch. You enable LACP on each channel mode using the channel-group mode command. |

| | |
|-----------------|--|
| Examples | This example shows how to enable LACP EtherChannels on the switch: |
| | <pre>switch(config)# feature lacp</pre> |

| Related Commands | Command | Description |
|-------------------------|---------------------|--|
| | show lacp | Displays information on LACP. |
| | show feature | Displays whether or not LACP is enabled on the switch. |

Send comments to nx5000-docfeedback@cisco.com

feature lldp

The Link Layer Discovery Protocol (LLDP), which is a neighbor discovery protocol that is used for network devices to advertise information about themselves to other devices on the network, is enabled on the switch by default.

| | |
|------------------------|---------|
| Command Default | Enabled |
|------------------------|---------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

You cannot enable or disable LLDP on a Cisco Nexus 5000 Series switch. LLDP is enabled on the switch by default. However, the **feature lldp** command shows as part of the running configuration on the switch.

The Cisco Discovery Protocol (CDP) is a device discovery protocol that runs over Layer 2 (the data link layer) on all Cisco-manufactured devices (routers, bridges, access servers, and switches). CDP allows network management applications to automatically discover and learn about other Cisco devices connected to the network.

To support non-Cisco devices and to allow for interoperability between other devices, the switch supports the Link Layer Discovery Protocol (LLDP). LLDP is a neighbor discovery protocol that is used for network devices to advertise information about themselves to other devices on the network. This protocol runs over the data-link layer, which allows two systems running different network layer protocols to learn about each other.

Examples

This example shows how to enable LLDP on the switch:

```
switch(config)# feature lldp
switch(config)#
```

This example shows how to disable LLDP on the switch:

```
switch(config)# no feature lldp
switch(config)#
```

| | | |
|-------------------------|-------------------------|--|
| Related Commands | Command | Description |
| | lldp | Configures the global LLDP options on the switch. |
| | lldp (Interface) | Configures the LLDP feature on an interface. |
| | show feature | Displays whether or not LLDP is enabled on the switch. |

Send comments to nx5000-docfeedback@cisco.com

feature private-vlan

To enable private VLANs, use the **feature private-vlan** command. To return to the default settings, use the **no** form of this command.

feature private-vlan

no feature private-vlan

Syntax Description This command has no arguments or keywords.

Command Default Private VLANs are disabled.

Command Modes Global configuration mode

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines The private VLAN commands are not available until you enable the private VLAN feature. You cannot disable the private VLANs if there are operational ports on the switch that are in private VLAN mode.



Note

A private VLAN-isolated port on a Cisco Nexus 5000 Series switch running the current release of Cisco NX-OS does not support IEEE 802.1Q encapsulation and cannot be used as a trunk port.

Examples This example shows how to enable private VLAN functionality on the switch:

```
switch(config)# feature private-vlan
```

| Related Commands | Command | Description |
|------------------|-------------------------------|--|
| | private-vlan | Configures a VLAN as either a community, isolated, or primary private VLAN. |
| | show vlan private-vlan | Displays information on private VLANs. If the feature is not enabled, this command is not available. |
| | show feature | Displays whether or not private VLAN is enabled on the switch. |

Send comments to nx5000-docfeedback@cisco.com

feature tacacs+

To enable TACACS+, use the **feature tacacs+** command. To disable TACACS+, use the **no** form of this command.

feature tacacs+

no feature tacacs+

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration mode

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines You must use the **feature tacacs+** command before you configure TACACS+.



Note

When you disable TACACS+, the Cisco NX-OS software removes the TACACS+ configuration.

Examples This example shows how to enable TACACS+:

```
switch(config)# feature tacacs+
```

This example shows how to disable TACACS+:

```
switch(config)# no feature tacacs+
```

| Related Commands | Command | Description |
|------------------|---------------------|---|
| | show tacacs+ | Displays TACACS+ information. |
| | show feature | Displays whether or not TACACS+ is enabled on the switch. |

Send comments to nx5000-docfeedback@cisco.com

feature uddl

To enable the Cisco-proprietary Unidirectional Link Detection (UDLD) protocol, which allows ports that are connected through fiber optics or copper Ethernet cables to monitor the physical configuration of the cables and detect when a unidirectional link exists, use the **feature uddl** command. To disable UDLD on the switch, use the **no** form of this command.

feature uddl

no feature uddl

Syntax Description

This command has no arguments or keywords.

Command Default

UDLD is disabled.

Command Modes

Global configuration mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(1a)N1(1) | This command was introduced. |

Examples

This example shows how to enable UDLD on the switch:

```
switch(config)# feature uddl
```

Related Commands

| Command | Description |
|---------------------|--|
| show uddl | Displays the administrative and operational UDLD status. |
| show feature | Displays whether or not UDLD is enabled on the switch. |

Send comments to nx5000-docfeedback@cisco.com

feature vpc

To enable virtual port channel (vPC), which allows links that are physically connected to two different Cisco Nexus 5000 Series devices to appear as a single port channel to a third device, use the **feature vpc** command. To disable vPC on the switch, use the **no** form of this command.

feature vpc

no feature vpc

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|----------|
| Command Default | Disabled |
|------------------------|----------|

| | |
|----------------------|---------------------------|
| Command Modes | Global configuration mode |
|----------------------|---------------------------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.1(3)N1(1) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | In a vPC configuration, the third device can be a Cisco Nexus 2000 Series Fabric Extender or a switch, server, or any other networking device. |
|-------------------------|--|

| | |
|-----------------|--|
| Examples | <p>This example shows how to enable vPC on the switch:</p> <pre>switch(config)# feature vpc</pre> |
|-----------------|--|

| | | |
|-------------------------|---------------------|---|
| Related Commands | Command | Description |
| | show vpc | Displays the vPC configuration status. |
| | show feature | Displays whether or not vPC is enabled on the switch. |

Send comments to nx5000-docfeedback@cisco.com

find

To find filenames beginning with a character string, use the **find** command.

find *filename-prefix*

| | | |
|---------------------------|---|---|
| Syntax Description | <i>filename-prefix</i> | First part or all of a filename. The filename prefix is case sensitive. |
| Command Default | None | |
| Command Modes | EXEC mode | |
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| Usage Guidelines | The find command searches all subdirectories under the current working directory. You can use the cd and pwd commands to navigate to the starting directory. | |
| Examples | This example shows how to display filenames beginning with “n5000”: switch# find n5000 | |
| Related Commands | Command | Description |
| | cd | Changes the current working directory. |
| | pwd | Displays the name of the current working directory. |

Send comments to nx5000-docfeedback@cisco.com

format

To format the bootflash device, which erases its contents and restores it to its factory-shipped state, use the **format** command.

format bootflash:

| | | |
|---------------------------|--|---|
| Syntax Description | bootflash: | Specifies the name of the bootflash file system. |
| Command Default | None | |
| Command Modes | EXEC mode | |
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| Examples | <p>This example shows how to format the bootflash device:</p> <pre>switch# format bootflash:</pre> | |
| Related Commands | Command | Description |
| | cd | Changes the current working directory. |
| | dir | Displays the directory contents. |
| | pwd | Displays the name of the current working directory. |

Send comments to nx5000-docfeedback@cisco.com

gunzip

To uncompress a compressed file, use the **gunzip** command.

gunzip [*filesystem:*] [*//server/*] [*directory*] *filename*

Syntax Description

| | |
|--------------------|--|
| <i>filesystem:</i> | (Optional) Name of the file system. Valid values are bootflash , modflash , or volatile . |
| <i>//server/</i> | (Optional) Name of the server. Valid values are <i>///</i> , //module-1/ , //sup-1/ , //sup-active/ , or //sup-local/ . The double slash (//) is required. |
| <i>directory</i> | (Optional) Name of a directory. The directory name is case sensitive. |
| <i>filename</i> | Name of the file to uncompress. The filename is case sensitive. |



Note

There can be no spaces in the *filesystem://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

Command Default

None

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

The compressed filename must have the .gz extension.

The Cisco NX-OS software uses Lempel-Ziv 1977 (LZ77) coding for compression.

Examples

This example shows how to uncompress a compressed file:

```
switch# gunzip run_cfg.cfg.gz
```

Related Commands

| Command | Description |
|-------------|----------------------------------|
| dir | Displays the directory contents. |
| gzip | Compresses a file. |

Send comments to nx5000-docfeedback@cisco.com

gzip

To compress a file, use the **gzip** command.

gzip [*filesystem:*] [*//server/*] [*directory*] *filename*

Syntax Description

| | |
|--------------------|--|
| <i>filesystem:</i> | (Optional) Name of the file system. Valid values are bootflash , modflash , or volatile . |
| <i>//server/</i> | (Optional) Name of the server. Valid values are <i>///</i> , //module-1/ , //sup-1/ , //sup-active/ , or //sup-local/ . The double slash (//) is required. |
| <i>directory</i> | (Optional) Name of a directory. The directory name is case sensitive. |
| <i>filename</i> | Name of the file to compress. The filename is case sensitive. |



Note

There can be no spaces in the *filesystem://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

Command Default

None

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

After you run this command, the named file is replaced with a compressed file that has the .gz extension added to its filename.

The Cisco NX-OS software uses Lempel-Ziv 1977 (LZ77) coding for compression.

Examples

This example shows how to compress a file:

```
switch# gzip run_cfg.cfg
```

Related Commands

| Command | Description |
|---------------|----------------------------------|
| dir | Displays the directory contents. |
| gunzip | Uncompresses a compressed file. |

Send comments to nx5000-docfeedback@cisco.com

hostname

To configure the hostname for the switch, use the **hostname** command. To revert to the default, use the **no** form of this command.

hostname *name*

no hostname

Syntax Description

| | |
|-------------|---|
| <i>name</i> | Hostname for the switch. The name is alphanumeric, case sensitive, can contain special characters, and can have a maximum of 32 characters. |
|-------------|---|

Command Default

“switch” is the default hostname.

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

The Cisco NX-OS software uses the hostname in command-line interface (CLI) prompts and in default configuration filenames.

The **hostname** command performs the same function as the **switchname** command.

Examples

This example shows how to configure the hostname for a Cisco Nexus 5000 Series switch:

```
switch# configure terminal
switch(config)# hostname Engineering2
Engineering2(config)#
```

This example shows how to revert to the default hostname:

```
Engineering2# configure terminal
Engineering2(config)# no hostname
switch(config)#
```

Related Commands

| Command | Description |
|------------------------|---------------------------------|
| show hostname | Displays the switch hostname. |
| show switchname | Displays the switch hostname. |
| switchname | Configures the switch hostname. |

Send comments to nx5000-docfeedback@cisco.com

install all

To install the kickstart and system images on a Cisco Nexus 5000 Series switch, use the **install all** command.

install all [**kickstart** *kickstart-url*] [**system** *system-url*]

Syntax Description

| | |
|----------------------|---|
| kickstart | (Optional) Specifies the kickstart image file. |
| <i>kickstart-url</i> | Full address of the kickstart image file. The name is case sensitive. |
| system | (Optional) Specifies the system image file. |
| <i>system-url</i> | Full address of the system image file. The name is case sensitive. |

Command Default

If you do not enter any parameters, the boot variable values are used.

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

The format of the kickstart and system URLs varies according to the file system, directory, and file location.

The following tables list URL prefix keywords by the file system type. If you do not specify a URL prefix keyword, the router looks for a file in the current directory.

[Table 1-4](#) lists URL prefix keywords for local writable storage file systems. [Table 1-5](#) lists the URL prefix keywords for remote file systems. For remote file systems, if it is not otherwise specified, the path is the default for the user on the remote server.

Table 1-4 URL Prefix Keywords for Local Writable Storage File Systems

| Keyword | Source or Destination |
|--|--|
| bootflash: [<i>//server/</i>] | Source URL for boot flash memory. The <i>server</i> argument value is module-1 , sup-1 , sup-active , or sup-local . |
| modflash: [<i>//server/</i>] | Source URL of an external flash file system. The <i>server</i> argument value is module-1 , sup-1 , sup-active , or sup-local . |
| volatile: [<i>//server/</i>] | Source URL of the default internal file system. Any files or directories stored in this file system are erased when the switch reboots. The <i>server</i> argument value is module-1 , sup-1 , sup-active , or sup-local . |

Send comments to nx5000-docfeedback@cisco.com

Table 1-5 URL Prefix Keywords for Remote File Systems

| Keyword | Source or Destination |
|--------------|---|
| ftp: | Source URL for a FTP network server. The syntax for this alias is as follows: ftp:[//server][/path]/filename |
| scp: | Source URL for a network server that supports Secure Shell (SSH) and uses the secure copy protocol (scp). The syntax is as follows: scp:[//[username@]server][/path]/filename |
| sftp: | Source URL for an SSH FTP (SFTP) network server. The syntax is as follows: sftp:[//[username@]server][/path]/filename |
| tftp: | Source URL for a TFTP network server. The syntax is as follows: tftp:[//server[:port]][/path]/filename |

If you do not enter the information about the server or username when downloading and installing the image files from a remote server, you are prompted for the information.

This command sets the kickstart and system boot variables and copies the image files to the redundant supervisor module.

The **install all** command upgrades the switch software and also upgrades the Fabric Extender software of all attached chassis. The Fabric Extender remains online passing traffic while the software is copied. Once the software images have successfully been installed, the parent switch and the Fabric Extender chassis are rebooted automatically to maintain the software version compatibility between the parent switch and the Fabric Extender.

You can use the **install all** command to downgrade the Cisco NX-OS software on the switch. To determine if the downgrade software is compatible with the current configuration on the switch, use the **show incompatibility system** command and resolve any configuration incompatibilities.

Examples

This example shows how to install the Cisco NX-OS software from the bootflash: directory:

```
switch# install all kickstart bootflash:nx-os_kick.bin system bootflash:nx-os_sys.bin
```

This example shows how to install the Cisco NX-OS software using the values configured in the kickstart and system boot variables:

```
switch# configure terminal
switch(config)# boot kickstart bootflash:nx-os_kick.bin
switch(config)# boot system bootflash:nx-os_sys.bin
switch(config)# exit
switch# copy running-config startup-config
switch# install all
```

This example shows how to install the Cisco NX-OS software from an SCP server:

```
switch# install all kickstart scp://adminuser@192.168.1.1/nx-os_kick.bin system
bootflash:scp://adminuser@192.168.1.1/nx-os_sys.bin
```

Send comments to nx5000-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|------------------------------------|--|
| | reload | Reloads the device with new Cisco NX-OS software. |
| | show incompatibility system | Displays configuration incompatibilities between Cisco NX-OS system software images. |
| | show version | Displays information about the software version. |

Send comments to nx5000-docfeedback@cisco.com

install license

To install a license, use the **install license** command.

install license [*filesystem:*] [*//server/*] [*directory*] *src-filename* [*target-filename*]

Syntax Description

| | |
|------------------------|--|
| <i>filesystem:</i> | (Optional) Name of the file system. Valid values are bootflash or volatile . |
| <i>//server/</i> | (Optional) Name of the server. Valid values are <i>///</i> , //module-1/ , //sup-1/ , //sup-active/ , or //sup-local/ . The double slash (//) is required. |
| <i>directory</i> | (Optional) Name of a directory. The directory name is case sensitive. |
| <i>src-filename</i> | Name of the source license file. |
| <i>target-filename</i> | (Optional) Name of the target license file. |



Note

There can be no spaces in the *filesystem://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

Command Default

All licenses for the Cisco Nexus 5000 Series switches are factory installed. Manual installation is not required.

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

If a target filename is provided after the source location, the license file is installed with that name. Otherwise, the filename in the source URL is used. This command also verifies the license file before installing it.

Examples

This example shows how to install a file named license-file that resides in the bootflash: directory:

```
switch# install license bootflash:license-file
```

Related Commands

| Command | Description |
|-----------------------------|---|
| show license | Displays license information. |
| show license host-id | Displays the serial number of the chassis to use for licensing. |
| show license usage | Displays license usage information. |

Send comments to nx5000-docfeedback@cisco.com

line console

To specify the console port and enter console port configuration mode, use the **line console** command.

line console

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Interface configuration mode

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines You can configure the console line only from a console port session.

Examples This example shows how to enter console port configuration mode:

```
switch# configure terminal
switch(config)# line console
switch(config-console)#
```

| Related Commands | Command | Description |
|------------------|---------------------|---|
| | databits | Configures the number of data bits in a character for a port. |
| | exec-timeout | Configures the inactive terminal timeout for a port. |
| | modem | Configures the modem settings for a port. |
| | parity | Configures the parity settings for a port. |
| | show line | Displays information about the console port configuration. |
| | speed | Configures the transmit and receive speed for a port. |
| | stopbits | Configures the stop bits for a port. |

Send comments to nx5000-docfeedback@cisco.com

line vty

To specify the virtual terminal and enter line configuration mode, use the **line vty** command.

line vty

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|------------------------------|
| Command Modes | Interface configuration mode |
|----------------------|------------------------------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|--|
| Examples | This example shows how to enter console port configuration mode: |
|-----------------|--|

```
switch# configure terminal
switch(config)# line vty
switch(config-line)#
```

| | | |
|-------------------------|----------------------|--|
| Related Commands | Command | Description |
| | exec-timeout | Configures the inactive terminal timeout for a port. |
| | session-limit | Configures the maximum number of the concurrent virtual terminal sessions. |
| | show line | Displays information about the console port configuration. |

Send comments to nx5000-docfeedback@cisco.com

modem in

To enable the modem connection on the console port, use the **modem in** command. To disable the modem connection, use the **no** form of this command.

modem in

no modem in

Syntax Description This command has no arguments or keywords.

Command Default Timeout is disabled.

Command Modes Terminal line configuration mode

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines You can configure the console port only from a session on the console port.

Examples This example shows how to enable a modem connection on the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# modem in
```

This example shows how to disable a modem connection on the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# no modem in
```

| Command | Description |
|---------------------|--|
| line console | Enters console port configuration mode. |
| show line | Displays information about the console port configuration. |

Send comments to nx5000-docfeedback@cisco.com

modem init-string

To download the initialization string to a modem connected to the console port, use the **modem init-string** command. To revert to the default, use the **no** form of this command.

modem init-string {default | user-input}

no modem init-string

| Syntax Description | default | Downloads the default initialization string. |
|--------------------|------------|---|
| | user-input | Downloads the user-input initialization string. |

| | |
|-----------------|--|
| Command Default | The default initialization string is ATE0Q1&D2&C1S0=1\015. |
|-----------------|--|

| | |
|---------------|----------------------------------|
| Command Modes | Terminal line configuration mode |
|---------------|----------------------------------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|------------------|---|
| Usage Guidelines | <p>You can configure the console port only from a session on the console port.</p> <p>The default initialization string ATE0Q1&D2&C1S0=1\015 is defined as follows:</p> |
|------------------|---|

- AT—Attention
- E0 (required)—No echo
- Q1—Result code on
- &D2—Normal data terminal ready (DTR) option
- &C1—Enable tracking the state of the data carrier
- S0=1—Pick up after one ring
- \015 (required)—Carriage return in octal

Use the **modem set-string** command to configure the user-input initialization string.

| | |
|----------|---|
| Examples | <p>This example shows how to download the default initialization string to the modem connected to the console port:</p> |
|----------|---|

```
switch# configure terminal
switch(config)# line console
switch(config-console)# modem init-string default
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to download the user-input initialization string to the modem connected to the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# modem init-string user-input
```

This example shows how to remove the initialization string to the modem connected to the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# no modem init-string
```

Related Commands

| Command | Description |
|-------------------------|--|
| line console | Enters console port configuration mode. |
| modem set-string | Configures the user-input initialization string for a modem. |
| show line | Displays information about the console port configuration. |

Send comments to nx5000-docfeedback@cisco.com

modem set-string user-input

To configure the user-input initialization string to download to a modem connected to the console port, use the **modem set-string user-input** command. To revert to the default, use the **no** form of this command.

modem set-string user-input *string*

no modem set-string

| | | |
|---------------------------|---------------|---|
| Syntax Description | <i>string</i> | User-input string. This string is alphanumeric and case sensitive, can contain special characters, and has a maximum of 100 characters. |
|---------------------------|---------------|---|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|----------------------------------|
| Command Modes | Terminal line configuration mode |
|----------------------|----------------------------------|

| Command History | Release | Modification |
|------------------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | You can configure the console port only from a session on the console port. |
|-------------------------|---|

| | |
|-----------------|---|
| Examples | This example shows how to configure the user-input initialization string for the modem connected to the console port: |
|-----------------|---|

```
switch# configure terminal
switch(config)# line console
switch(config-console)# modem set-string user-input ATE0Q1&D2&C1S0=3\015
```

This example shows how to revert to the default user-input initialization string for the modem connected to the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# no modem set-string
```

| Related Commands | Command | Description |
|-------------------------|--------------------------|--|
| | line console | Enters console port configuration mode. |
| | modem init-string | Downloads the user-input initialization string to a modem. |
| | show line | Displays information about the console port configuration. |

Send comments to nx5000-docfeedback@cisco.com

move

To move a file from one directory to another, use the **move** command.

```
move {[filesystem:] [/server/] [directory] source-filename} [filesystem:] [/server/] [directory]
[destination-filename]
```

Syntax Description

| | |
|-----------------------------|---|
| <i>filesystem:</i> | (Optional) Name of the file system. Valid values are bootflash , debug , modflash , or volatile . |
| <i>/server/</i> | (Optional) Name of the server. Valid values are <i>///</i> , <i>//module-1/</i> , <i>//sup-1/</i> , <i>//sup-active/</i> , or <i>//sup-local/</i> . The double slash (<i>//</i>) is required. |
| <i>directory</i> | (Optional) Name of a directory. The directory name is case sensitive. |
| <i>source-filename</i> | Name of the file to move. The filename is case sensitive. |
| <i>destination-filename</i> | (Optional) Name of the destination file. The filename is alphanumeric, case sensitive, and has a maximum of 64 characters. |

Command Default

The default filename for the destination file is the same as the source file.

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

You can make a copy of a file by using the **copy** command.



Tip

You can rename a file by moving it within the same directory.

Examples

This example shows how to move a file to another directory:

```
switch# move file1 my_files/file2
```

This example shows how to move a file to another file system:

```
switch# move file1 volatile:
```

This example shows how to move a file to another supervisor module:

```
switch# move file1 bootflash://sup-1/file1.bak
```

Send comments to nx5000-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|---------------|---|
| | cd | Changes the current working directory. |
| | copy | Makes a copy of a file. |
| | delete | Deletes a file or directory. |
| | dir | Displays the directory contents. |
| | pwd | Displays the name of the current working directory. |

Send comments to nx5000-docfeedback@cisco.com

parity

To configure the parity for the console port, use the **parity** command. To revert to the default, use the **no** form of this command.

parity { **even** | **none** | **odd** }

no parity { **even** | **none** | **odd** }

Syntax Description

| | |
|-------------|------------------------|
| even | Specifies even parity. |
| none | Specifies no parity. |
| odd | Specifies odd parity. |

Command Default

The **none** keyword is the default.

Command Modes

Terminal line configuration mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

You can configure the console port only from a session on the console port.

Examples

This example shows how to configure the parity for the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# parity even
```

This example shows how to revert to the default parity for the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# no parity even
```

Related Commands

| Command | Description |
|------------------|--|
| show line | Displays information about the console port configuration. |

Send comments to nx5000-docfeedback@cisco.com

ping

To determine the network connectivity to another network device, use the **ping** command.

```
ping {dest-address | hostname} [count {number | unlimited}] [df-bit] [interval seconds]
[packet-size bytes] [source src-address] [timeout seconds] [vrf {vrf-name | default |
management}]
```

| Syntax Description | |
|----------------------------------|---|
| <i>dest-address</i> | IPv4 address of the destination device. The format is <i>A.B.C.D</i> . |
| <i>hostname</i> | Hostname of the destination device. The hostname is case sensitive. |
| count | (Optional) Specifies the number of transmissions to send. |
| <i>number</i> | Number of pings. The range is from 1 to 655350. The default is 5. |
| unlimited | Allows an unlimited number of pings. |
| df-bit | (Optional) Enables the do-not-fragment bit in the IPv4 header. The default is disabled. |
| interval <i>seconds</i> | (Optional) Specifies the interval in seconds between transmissions. The range is from 0 to 60. The default is 1 second. |
| packet-size <i>bytes</i> | (Optional) Specifies the packet size in bytes to transmit. The range is from 1 to 65468. The default is 56 bytes. |
| source <i>src-address</i> | (Optional) Specifies the source IPv4 address to use. The format is <i>A.B.C.D</i> . The default is the IPv4 address for the management interface of the device. |
| timeout <i>seconds</i> | (Optional) Specifies the nonresponse timeout interval in seconds. The range is from 1 to 60. The default is 2 seconds. |
| vrf <i>vrf-name</i> | (Optional) Specifies the virtual routing and forwarding (VRF) to use. The name is case sensitive. |
| default | (Optional) Specifies the default VRF. |
| management | (Optional) Specifies the management VRF. |

Command Default For the default values, see the “Syntax Description” section for this command.

Command Modes EXEC mode

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to determine connectivity to another network device:

```
switch# ping 192.168.2.246
```

Send comments to nx5000-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|-------------------|--|
| | ping6 | Determines connectivity to another device using IPv6 addressing. |
| | traceroute | Displays the routes that packets take when traveling to an IP address. |

Send comments to nx5000-docfeedback@cisco.com

ping6

To determine the network connectivity to another device using IPv6 addressing, use the **ping6** command.

```
ping6 { dest-address | hostname } [count { number | unlimited }] [interface intf-id] [interval
seconds] [packet-size bytes] [source address] [timeout seconds] [vrf { vrf-name | default |
management }]
```

| Syntax Description | |
|---------------------------------|--|
| <i>dest-address</i> | Destination IPv6 address. The format is <i>A:B::C:D</i> . |
| <i>hostname</i> | Hostname of destination device. The hostname is case sensitive. |
| count | (Optional) Specifies the number of transmissions to send. |
| <i>number</i> | Number of pings. The range is from 1 to 655350. The default is 5. |
| unlimited | Allows an unlimited number of pings. |
| interface <i>intf-id</i> | (Optional) Specifies the interface to send the IPv6 packet. The valid interface types are Ethernet, loopback, EtherChannel, and VLAN. |
| interval <i>seconds</i> | (Optional) Specifies the interval in seconds between transmissions. The range is from 0 to 60. The default is 1 second. |
| packet-size <i>bytes</i> | (Optional) Specifies the packet size in bytes to transmit. The range is from 1 to 65468. |
| source <i>address</i> | (Optional) Specifies the source IPv6 address to use. The format is <i>A:B::C:D</i> . The default is the IPv6 address for the management interface of the device. |
| timeout <i>seconds</i> | (Optional) Specifies the nonresponse timeout interval in seconds. The range is from 1 to 60. The default is 2 seconds. |
| vrf <i>vrf-name</i> | (Optional) Specifies the virtual routing and forwarding (VRF) to use. The name is case sensitive. |
| default | (Optional) Specifies the default VRF. |
| management | (Optional) Specifies the management VRF. |

Command Default For the default values, see the “Syntax Description” section for this command.

Command Modes EXEC mode

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(1a)N1(1) | This command was introduced. |

Examples This example shows how to determine connectivity to another device using IPv6 addressing:

```
switch# ping6 2001:0DB8::200C:417A vrf management
```

Send comments to nx5000-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|--------------------|--|
| | ping | Determines connectivity to another device using IPv4 addressing. |
| | traceroute6 | Displays the routes that packets take when traveling to an IPv6 address. |

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

reload

To reload the switch and all attached Fabric Extender chassis or a specific Fabric Extender, use the **reload** command.

reload {**all** | **fex chassis_ID**}

| | | |
|---------------------------|-----------------------|---|
| Syntax Description | all | Reboots the entire Cisco Nexus 5000 Series switch and all attached Fabric Extender chassis. |
| | fex chassis_ID | Reboots a specific Fabric Extender chassis. The chassis ID is from 100 to 199. |

Command Default Reloads the Cisco Nexus 5000 Series switch.

Command Modes EXEC mode

| | | |
|------------------------|----------------|--|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| | 4.0(1a)N2(1) | Support for the Cisco Nexus 2000 Series Fabric Extender was added. |

Usage Guidelines The **reload** command disrupts traffic on the switch and Fabric Extender.



Note

The **reload** command does not save the running configuration. Use the **copy running-config startup-config** command to save the current configuration on the device.

Examples

This example shows how to reload the Cisco Nexus 5000 Series switch:

```
switch# copy running-config startup-config
switch# reload
This command will reboot the system. (y/n)? [n] y
```

This example shows how to reload a Fabric Extender:

```
switch# reload fex 101
WARNING: This command will reboot FEX 101
Do you want to continue? (y/n) [n] y
```

Send comments to nx5000-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|---|--|
| | copy running-config startup-config | Copies the current running configuration to the startup configuration. |
| | show version | Displays information about the software version. |

Send comments to nx5000-docfeedback@cisco.com

rmdir

To remove a directory, use the **rmdir** command.

rmdir [*filesystem:* [*//server/*]] *directory*

| | | |
|---------------------------|--------------------|--|
| Syntax Description | <i>filesystem:</i> | (Optional) Name of the file system. Valid values are bootflash , modflash , or volatile . |
| | <i>//server/</i> | (Optional) Name of the server. Valid values are <i>///</i> , //module-1/ , //sup-1/ , //sup-active/ , or //sup-local/ . The double slash (//) is required. |
| | <i>directory</i> | Name of a directory to delete. The directory name is case sensitive. |



Note

There can be no spaces in the *filesystem://server/directory* string. Individual elements of this string are separated by colons (:) and slashes (/).

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|---|
| Examples | This example shows how to remove a directory: |
|-----------------|---|

```
switch# rmdir my_files
```

| | | |
|-------------------------|----------------|---|
| Related Commands | Command | Description |
| | cd | Changes the current working directory. |
| | delete | Deletes a file or directory. |
| | dir | Displays the directory contents. |
| | pwd | Displays the name of the current working directory. |

Send comments to nx5000-docfeedback@cisco.com

run-script

To run a command script file at the command-line interface (CLI), use the **run-script** command.

run-script [*filesystem://module/*][*directory/*]*filename*

Syntax Description

| | |
|--------------------|--|
| <i>filesystem:</i> | (Optional) Name of a file system. The name is case sensitive. |
| <i>//module/</i> | (Optional) Identifier for a supervisor module. Valid values are sup-active , sup-local , sup-remote , or sup-standby . The identifiers are case sensitive. |
| <i>directory/</i> | (Optional) Name of a directory. The name is case sensitive. |
| <i>filename</i> | Name of the command file. The name is case sensitive. |



Note

There can be no spaces in the *filesystem://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

Command Default

None

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

You must create the command file on a remote device and download it to the Cisco Nexus 5000 Series switch using the **copy** command.

Examples

This example shows how to run a command script file:

```
switch# run-script script-file
```

Related Commands

| Command | Description |
|--------------|--|
| cd | Changes the current working directory. |
| copy | Copies files. |
| dir | Displays the directory contents. |
| echo | Displays a test string on the terminal. |
| pwd | Displays the name of the current working directory. |
| sleep | Causes the CLI to pause for a defined number of seconds. |

Send comments to nx5000-docfeedback@cisco.com

save

To save the current configuration session to a file, use the **save** command.

save *location*

| Syntax Description | <i>location</i> | Location of the file. The location can be in bootflash or volatile. The file name can be any alphanumeric string up to 63 characters. |
|--------------------|-----------------|---|
|--------------------|-----------------|---|

| Command Default | None |
|-----------------|------|
|-----------------|------|

| Command Modes | Session configuration mode |
|---------------|----------------------------|
|---------------|----------------------------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(1a)N1(1) | This command was introduced. |

Examples This example shows how to save a configuration session to a file in bootflash:

```
switch# configure session MySession  
switch(config-s)# save bootflash:sessions/MySession
```

| Related Commands | Command | Description |
|------------------|--------------------------|--|
| | configure session | Creates or modifies a configuration session. |
| | delete | Deletes a file from a location. |

Send comments to nx5000-docfeedback@cisco.com

send

To send a message to the active user sessions, use the **send** command.

send [*session line*] *text*

Syntax Description

| | |
|---------------------|---|
| session line | (Optional) Specifies a user session. |
| text | Text string. The text string can be up to 80 alphanumeric characters and is case sensitive. |

Command Default

Sends a message to all active user sessions.

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

You can use the **show users** command to display information about the active user sessions.

Examples

This example shows how to send a message to all active user sessions on the switch:

```
switch# send The system will reload in 15 minutes!
The system will reload in 15 minutes!
```

This example shows how to send a message to a specific user session:

```
switch# send session pts/0 You must log off the switch.
```

Related Commands

| Command | Description |
|-------------------|--|
| show users | Displays the active user sessions on the switch. |

Send comments to nx5000-docfeedback@cisco.com

setup

To enter the basic device setup dialog, use the **setup** command.

setup [**ficon**]

| | | |
|---------------------------|---|-------------------------------------|
| Syntax Description | ficon (Optional) Runs the basic ficon setup command facility. | |
| Command Default | None | |
| Command Modes | EXEC mode | |
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| Usage Guidelines | The setup script uses the factory-default values, not the values that you have configured. You can exit the dialog at any point by pressing Ctrl-C . | |
| Examples | This example shows how to enter the basic device setup script: switch# setup | |
| Related Commands | Command | Description |
| | show running-config | Displays the running configuration. |

Send comments to nx5000-docfeedback@cisco.com

session-limit

To configure the maximum number of the concurrent virtual terminal sessions on a device, use the **session-limit** command. To revert to the default, use the **no** form of this command.

session-limit *sessions*

no session-limit *sessions*

| | | |
|---------------------------|---|---|
| Syntax Description | <i>sessions</i> Maximum number of sessions. The range is from 1 to 64. | |
| Command Default | 32 sessions | |
| Command Modes | Terminal line configuration mode | |
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| Examples | <p>This example shows how to configure the maximum number of concurrent virtual terminal sessions:</p> <pre>switch# configure terminal switch(config)# line vty switch(config-line)# session-limit 48</pre> | |
| | <p>This example shows how to revert to the default maximum number of concurrent virtual terminal sessions:</p> <pre>switch# configure terminal switch(config)# line vty switch(config-line)# no session-limit 48</pre> | |
| Related Commands | Command | Description |
| | line vty | Enters the virtual terminal configuration mode. |
| | show running-config | Displays the running configuration. |

Send comments to nx5000-docfeedback@cisco.com

show banner motd

To display the message-of-the-day (MOTD) banner, use the **show banner motd** command.

show banner motd

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|--|
| Examples | This example shows how to display the MOTD banner: |
|-----------------|--|

| |
|--|
| <pre>switch# show banner motd Unauthorized access is prohibited!</pre> |
|--|

| | | |
|-------------------------|--------------------|-----------------------------|
| Related Commands | Command | Description |
| | banner motd | Configures the MOTD banner. |

Send comments to nx5000-docfeedback@cisco.com

show boot

To display the boot variable configuration, use the **show boot** command.

show boot [**variables**]

| Syntax Description | variables (Optional) Displays a list of boot variables. | | | | |
|---------------------------|---|---------|--------------|--------------|---|
| Command Default | Displays all configured boot variables. | | | | |
| Command Modes | EXEC mode | | | | |
| Command History | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>4.0(0)N1(1a)</td><td>This command was introduced.</td></tr> </table> | Release | Modification | 4.0(0)N1(1a) | This command was introduced. |
| Release | Modification | | | | |
| 4.0(0)N1(1a) | This command was introduced. | | | | |
| Examples | <p>This example shows how to display all configured boot variables:</p> <pre>switch# show boot</pre> <p>This example shows how to display the list of boot variable names:</p> <pre>switch# show boot variables</pre> | | | | |
| Related Commands | <table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td>boot</td><td>Configures the boot variable for the kickstart or system image.</td></tr> </table> | Command | Description | boot | Configures the boot variable for the kickstart or system image. |
| Command | Description | | | | |
| boot | Configures the boot variable for the kickstart or system image. | | | | |

Send comments to nx5000-docfeedback@cisco.com

show cli alias

To display the command alias configuration, use the **show cli alias** command.

show cli alias [**name** *alias-name*]

| Syntax Description | name <i>alias-name</i> (Optional) Specifies the name of a command alias. The alias name is not case sensitive. |
|--------------------|---|
|--------------------|---|

| Command Default | Displays all configured command alias variables. |
|-----------------|--|
|-----------------|--|

| Command Modes | EXEC mode |
|---------------|-----------|
|---------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to display all configured command aliases:

```
switch# show cli alias
```

This example shows how to display a specific command alias:

```
switch# show cli alias name ethint
```

| Related Commands | Command | Description |
|------------------|-----------------------|-----------------------------|
| | cli alias name | Configures command aliases. |

Send comments to nx5000-docfeedback@cisco.com

show cli history

To display the command history, use the **show cli history** command.

show cli history [*lines*] [**unformatted**]

| | | |
|---------------------------|--------------------|---|
| Syntax Description | <i>lines</i> | (Optional) Last number of lines from the end of the command history. |
| | unformatted | (Optional) Displays the commands without line numbers or time stamps. |

| | |
|------------------------|--|
| Command Default | Displays the entire formatted history. |
|------------------------|--|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to display all of the command history:

```
switch# show cli history
```

This example shows how to display the last 10 lines of the command history:

```
switch# show cli history 10
```

This example shows how to display unformatted command history:

```
switch# show cli history unformatted
```

| | | |
|-------------------------|--------------------------|-----------------------------|
| Related Commands | Command | Description |
| | clear cli history | Clears the command history. |

Send comments to nx5000-docfeedback@cisco.com

show cli variables

To display the configuration of the command-line interface (CLI) variables, use the **show cli variables** command.

show cli variables

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|---|
| Examples | This example shows how to display the CLI variables: switch# show cli variables |
|-----------------|---|

| | | |
|-------------------------|----------------|---------------------------|
| Related Commands | Command | Description |
| | cli var name | Configures CLI variables. |

Send comments to nx5000-docfeedback@cisco.com

show clock

To display the current date and time, use the **show clock** command.

show clock [detail]

| | | |
|---------------------------|---|---|
| Syntax Description | detail (Optional) Displays the summer-time (daylight saving time) offset configuration. | |
| Command Default | None | |
| Command Modes | EXEC mode | |
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| Examples | This example shows how to display the current clock setting: <pre>switch# show clock</pre> | |
| | This example shows how to display the current clock setting and the summer-time (daylight saving time) configuration: <pre>switch# show clock detail</pre> | |
| Related Commands | Command | Description |
| | clock set | Sets the clock time. |
| | clock summer-time | Configures the summer-time (daylight saving time) offset. |

Send comments to nx5000-docfeedback@cisco.com

show configuration session

To display information about configuration sessions, use the **show configuration session** command.

show configuration session [*session-name* | **status** | **summary**]

| | | |
|---------------------------|---------------------|---|
| Syntax Description | <i>session-name</i> | (Optional) Configuration session name. The name can be a maximum of 64 alphanumeric characters. |
| | status | (Optional) Displays the status of the configuration session. |
| | summary | (Optional) Displays summary information of the active configuration sessions. |

Command Default None

Command Modes EXEC mode

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1) | This command was introduced. |

Examples This example shows how to display information about a specific configuration session:

```
switch# show configuration session mySession1
config session name mySession1
0001 ip access-list myACL
0002 permit icmp any any
0003 statistics per-entry
switch#
```


This example shows how to display the status of the active configuration session:

```
switch# show configuration session status
=====
Session Name       : mySession1
Last Action        : Validate
Last Action Status : Success
Last Action Reason  : -NA-
Last Action Timestamp : 19:03:49 UTC Sep 06 2009
=====

switch#
```

This example shows how to display the summary information of the active configuration sessions:

```
switch# show configuration session summary
Session Manager Database:
-----
Name                Session Owner          Creation Time
-----
mySession1          root                    18:09:03 UTC Sep 06 2009
```

 show configuration session

Send comments to nx5000-docfeedback@cisco.com

```
Number of active configuration sessions = 1
switch#
```

Related Commands

| Command | Description |
|--------------------------|----------------------------------|
| configure session | Creates a configuration session. |

Send comments to nx5000-docfeedback@cisco.com

show copyright

To display the Cisco NX-OS software copyright information, use the **show copyright** command.

show copyright

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|--|
| Examples | This example shows how to display the Cisco NX-OS copyright information: |
|-----------------|--|

```
switch# show copyright
Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2010, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained in this software are
owned by other third parties and used and distributed under
license. Certain components of this software are licensed under
the GNU General Public License (GPL) version 2.0 or the GNU
Lesser General Public License (LGPL) Version 2.1. A copy of each
such license is available at
http://www.opensource.org/licenses/gpl-2.0.php and
http://www.opensource.org/licenses/lgpl-2.1.php
switch#
```

Send comments to nx5000-docfeedback@cisco.com

show debug logfile

To display the contents of the debug logfile, use the **show debug logfile** command.

show debug logfile *filename*

| | | |
|---------------------------|--|--------------------------------|
| Syntax Description | <i>filename</i> | Name of the debug log file. |
| Command Default | None | |
| Command Modes | EXEC mode | |
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| Usage Guidelines | The log files are located in the log: file system. | |
| Examples | This example shows how to display the contents of a debug log file: switch# show debug logfile dmesg | |
| Related Commands | Command | Description |
| | debug logfile | Configures the debug log file. |

Send comments to nx5000-docfeedback@cisco.com

show environment

To display information about the hardware environment status, use the **show environment** command.

show environment [**fan** | **power** | **temperature**]

| | | |
|---------------------------|--------------------|--|
| Syntax Description | fan | (Optional) Displays information about the fan environment. |
| | power | (Optional) Displays information about the power capacity and distribution. |
| | temperature | (Optional) Displays information about the temperature environment. |

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to display information about the hardware environment:

```
switch# show environment
```

Fan:

| Fan | Model | Hw | Status |
|-----------|---------------|----|---------|
| Chassis-1 | N5K-C5020-FAN | -- | ok |
| Chassis-2 | -- | -- | absent |
| Chassis-3 | N5K-C5020-FAN | -- | ok |
| Chassis-4 | N5K-C5020-FAN | -- | ok |
| Chassis-5 | N5K-C5020-FAN | -- | ok |
| PS-1 | N5K-PAC-1200W | -- | failure |
| PS-2 | N5K-PAC-1200W | -- | ok |

Temperature

| Module | Sensor | MajorThresh (Celsius) | MinorThres (Celsius) | CurTemp (Celsius) | Status |
|--------|----------|--------------------------|-------------------------|----------------------|--------|
| 1 | Outlet-1 | 60 | 50 | 41 | ok |
| 1 | Outlet-2 | 60 | 50 | 44 | ok |
| 1 | Outlet-3 | 60 | 50 | 36 | ok |
| 1 | Outlet-4 | 60 | 50 | 39 | ok |
| 1 | Intake-1 | 50 | 40 | 26 | ok |
| 1 | Intake-2 | 50 | 40 | 25 | ok |
| 1 | Intake-3 | 50 | 40 | 25 | ok |
| 1 | Intake-4 | 50 | 40 | 25 | ok |
| 1 | PS-1 | 60 | 50 | 20 | ok |
| 1 | PS-2 | 60 | 50 | 27 | ok |

■ show environment

Send comments to nx5000-docfeedback@cisco.com

```

3      Outlet-1   60      50      30      ok
2      Outlet-1   60      50      32      ok

```

Power Supply:
Voltage: 12 Volts

```

-----
PS  Model                Power      Power      Status
      (Watts)      (Amp)
-----
1  --                    --        --        fail/shutdown
2  N5K-PAC-1200W         1200.00    100.00    ok

```

```

Mod Model                Power      Power      Power      Power      Status
      Requested Requested Allocated Allocated
      (Watts)      (Amp)      (Watts)      (Amp)
-----
--
1  N5K-C5020P-BF-SUP      625.20    52.10      625.20    52.10    powered-
up
2  N5K-M1600              54.00     4.50      54.00     4.50    powered-
up
3  N5K-M1008              9.96      0.83      9.96      0.83    powered-
up

```

Power Usage Summary:

```

-----
Power Supply redundancy mode:      Redundant
Power Supply redundancy operational mode: Non-redundant

```

Total Power Capacity 1200.00 W

Power reserved for Supervisor(s) 625.20 W

Power currently used by Modules 63.96 W

```

-----
Total Power Available      510.84 W
-----

```

switch#

This example shows how to display information about the power environment:

switch# **show environment power**

Power Supply:
Voltage: 12 Volts

```

-----
PS  Model                Power      Power      Status
      (Watts)      (Amp)
-----
1  --                    --        --        fail/shutdown
2  N5K-PAC-1200W         1200.00    100.00    ok

```

```

Mod Model                Power      Power      Power      Power      Status
      Requested Requested Allocated Allocated
      (Watts)      (Amp)      (Watts)      (Amp)
-----
--
1  N5K-C5020P-BF-SUP      625.20    52.10      625.20    52.10    powered-
up

```


Send comments to nx5000-docfeedback@cisco.com

| | | | | | | |
|----|-----------|-------|------|-------|------|----------|
| 2 | N5K-M1600 | 54.00 | 4.50 | 54.00 | 4.50 | powered- |
| up | | | | | | |
| 3 | N5K-M1008 | 9.96 | 0.83 | 9.96 | 0.83 | powered- |
| up | | | | | | |

Power Usage Summary:

| | |
|---|---------------|
| Power Supply redundancy mode: | Redundant |
| Power Supply redundancy operational mode: | Non-redundant |

| | |
|----------------------|-----------|
| Total Power Capacity | 1200.00 W |
|----------------------|-----------|

| | |
|----------------------------------|----------|
| Power reserved for Supervisor(s) | 625.20 W |
|----------------------------------|----------|

| | |
|---------------------------------|---------|
| Power currently used by Modules | 63.96 W |
|---------------------------------|---------|

| | |
|-----------------------|----------|
| Total Power Available | 510.84 W |
|-----------------------|----------|

switch#

Send comments to nx5000-docfeedback@cisco.com

show feature

To display the status of features on a switch, use the **show feature** command.

show feature

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to display the state of all features on a switch:

```
switch# show feature
Feature Name      Instance  State
-----
cimserver         1        disabled
fabric-binding    1        disabled
fc-port-security  1        disabled
fcoe              1        enabled
fcsp              1        disabled
fex               1        enabled
fport-channel-trunk 1        disabled
http-server       1        enabled
interface-vlan    1        enabled
lACP              1        enabled
lldp              1        enabled
npiv              1        disabled
npv               1        disabled
port_track        1        disabled
private-vlan      1        disabled
sshServer         1        enabled
tacacs            1        enabled
telnetServer      1        enabled
udld              1        enabled
vpc               1        enabled
vtp               1        disabled
switch#
```

| Related Commands | Command | Description |
|------------------|----------------|--|
| | feature | Enables or disables a feature on the switch. |

Send comments to nx5000-docfeedback@cisco.com

show file

To display the contents of a file on the local memory, use the **show file** command.

show file [*filesystem:*] [*//server/*] [*directory*] *filename*

| Syntax Description | <i>filesystem:</i> | (Optional) Name of the file system. Valid values are bootflash , modflash , or volatile . |
|--------------------|--------------------|--|
| | <i>//server/</i> | (Optional) Name of the server. Valid values are <i>///</i> , //module-1/ , //sup-1/ , //sup-active/ , or //sup-local/ . The double slash (//) is required. |
| | <i>directory</i> | (Optional) Name of a directory. The directory name is case sensitive. |
| | <i>filename</i> | Name of the file to delete. The filename is case sensitive. |



Note

There can be no spaces in the *filesystem://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

| Command Default | None |
|-----------------|------|
|-----------------|------|

| Command Modes | EXEC mode |
|---------------|-----------|
|---------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Examples

This example shows how to display the contents of a file:

```
switch# show file ent-mod.lic
```

If the file that you want to display is a directory, the command will return an error message:

```
switch# show file bootflash:///routing-sw
/bin/showfile: /bootflash/routing-sw: Is a directory
```

| Related Commands | Command | Description |
|------------------|------------|---|
| | cd | Changes the current working directory. |
| | dir | Displays the directory contents. |
| | pwd | Displays the name of the current working directory. |

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

show hardware internal

To display information about the physical device hardware, use the **show hardware internal** command.

show hardware internal

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|---|
| Examples | <p>This example shows how to display information about the physical device hardware:</p> <pre>switch# show hardware internal</pre> |
|-----------------|---|

| | | |
|-------------------------|-----------------------|--|
| Related Commands | Command | Description |
| | show inventory | Displays hardware inventory information. |
| | show module | Displays information about the modules. |

Send comments to nx5000-docfeedback@cisco.com

show hostname

To display the hostname for the switch, use the **show hostname** command.

show hostname

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | The show switchname command also displays the switch hostname. |
|-------------------------|---|

| | |
|-----------------|--|
| Examples | This example shows how to display the hostname for the switch: |
|-----------------|--|

```
switch# show hostname
switch
switch#
```

| | | |
|-------------------------|----------------------------|---|
| Related Commands | Command | Description |
| | hostname | Configures the hostname for the switch. |
| | show switchname | Displays the hostname. |
| | switchname | Configures the hostname for the switch. |

Send comments to nx5000-docfeedback@cisco.com

show incompatibility system

To display the configuration incompatibilities between the running system image and an earlier system image prior to downgrading the Cisco NX-OS software, use the **show incompatibility system** command.

show incompatibility system {*filesystem*: //server/ [*directory*] *filename*}

| Syntax Description | | |
|---------------------|--|---|
| <i>filesystem</i> : | | Name of the file system. Valid values are bootflash or volatile . |
| //server/ | | Name of the server. Valid values are ///, // module-1 /, // sup-1 /, // sup-active /, or // sup-local /. The double slash (//) is required. |
| <i>directory</i> | | (Optional) Name of a directory. The directory name is case sensitive. |
| <i>filename</i> | | Name of the file to compare with the loaded software image. The filename is case sensitive. |



Note

There can be no spaces in the *filesystem://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Examples

This example shows how to display the configuration incompatibilities:

```
switch# show incompatibility system bootflash://sup-local/old_image.bin
```

| Related Commands | Command | Description |
|------------------|---------------------|---|
| | install all | Installs the kickstart and system images. |
| | reload | Reloads the device with the new Cisco NX-OS software. |
| | show version | Displays information about the software version. |

Send comments to nx5000-docfeedback@cisco.com

show install all

To display information related to the operation of the **install all** command, use the **show install all** command.

show install all { failure-reason | impact [kickstart | system] | status }

| Syntax Description | failure-reason | Displays the software installation failure reason. |
|--------------------|-----------------------|--|
| | impact | Displays the impact of installing the images referred to in the boot variables. |
| | kickstart | (Optional) Displays the impact of installing the kickstart image referred to in the kickstart boot variable. |
| | system | (Optional) Displays the impact of installing the system image referred to in the kickstart boot variable. |
| | status | Displays the status of the software installation process. |

| Command Default | None |
|-----------------|------|
|-----------------|------|

| Command Modes | EXEC mode |
|---------------|-----------|
|---------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Examples

This example shows how to display the installation failure reason:

```
switch# show install all failure-reason
No install all failure-reason
switch#
```

This example shows how to display the impact of installing new images:

```
switch# show install all impact
```

This example shows how to display the status of the software installation process:

```
switch# show install all status
There is an on-going installation...
Enter Ctrl-C to go back to the prompt.

switch#
```

| Related Commands | Command | Description |
|------------------|--------------------|---|
| | install all | Installs the software on the physical device. |
| | show boot | Displays the boot variable configuration. |

Send comments to nx5000-docfeedback@cisco.com

show inventory

To display the physical inventory information for the switch hardware, use the **show inventory** command.

show inventory [**fex chassis_ID**]

| Syntax Description | fex chassis_ID | (Optional) Specifies the Fabric Extender chassis ID. The chassis ID is from 100 to 199. |
|--------------------|-----------------------|---|
|--------------------|-----------------------|---|

| Command Default | Displays all hardware inventory information. |
|-----------------|--|
|-----------------|--|

| Command Modes | EXEC mode |
|---------------|-----------|
|---------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|---|
| | 4.0(0)N1(1a) | This command was introduced. |
| | 4.0(1a)N2(1) | This command was modified to provide Fabric Extender support. |

| Examples | This example shows how to display the switch hardware inventory information: |
|----------|--|
|----------|--|

```
switch# show inventory
NAME: "Chassis", DESCR: "Nexus5020 Chassis"
PID: N5K-C5020P-BF      , VID: V04 , SN: SSI13390FZT

NAME: "Module 1", DESCR: "40x10GE/Supervisor"
PID: N5K-C5020P-BF      , VID: V04 , SN: JAF1344BHNK

NAME: "Module 2", DESCR: "6x10GE Ethernet Module"
PID: N5K-M1600          , VID: V01 , SN: JAB1228018M

NAME: "Module 3", DESCR: "8x1/2/4G FC Module"
PID: N5K-M1008          , VID: V01 , SN: JAB1231020C

NAME: "Fan 1", DESCR: "Chassis fan module"
PID: N5K-C5020-FAN      , VID: N/A , SN: N/A

NAME: "Fan 3", DESCR: "Chassis fan module"
PID: N5K-C5020-FAN      , VID: N/A , SN: N/A

NAME: "Fan 4", DESCR: "Chassis fan module"
PID: N5K-C5020-FAN      , VID: N/A , SN: N/A

NAME: "Fan 5", DESCR: "Chassis fan module"
PID: N5K-C5020-FAN      , VID: N/A , SN: N/A

NAME: "Power supply 1", DESCR: "AC power supply"
PID: N5K-PAC-1200W      , VID: V01 , SN: DTM134200L5

NAME: "Power supply 2", DESCR: "AC power supply"
PID: N5K-PAC-1200W      , VID: V01 , SN: DTM134200L4
```


Send comments to nx5000-docfeedback@cisco.com

```

NAME: "FEX 100 CHASSIS", DESCR: "N2K-C2148T-1GE CHASSIS"
PID: N2K-C2148T-1GE , VID: V01 , SN: FOX1252GQJR

NAME: "FEX 100 Module 1", DESCR: "Fabric Extender Module: 48x1GE, 4X10GE Supervisor"
PID: N2K-C2148T-1GE , VID: V01 , SN: JAF1302ABDP

NAME: "FEX 100 Fan 1", DESCR: "Fabric Extender Fan module"
PID: N2K-C2148-FAN , VID: N/A , SN: N/A

NAME: "FEX 100 Power Supply 1", DESCR: "Fabric Extender AC power supply"
PID: N2K-PAC-200W , VID: V01 , SN: PAC12493LQX

NAME: "FEX 100 Power Supply 2", DESCR: "Fabric Extender AC power supply"
--More--
switch#

```

This example shows how to display the hardware inventory information for an attached Fabric Extender:

```

switch# show inventory fex 101
NAME: "FEX 100 CHASSIS", DESCR: "N2K-C2148T-1GE CHASSIS"
PID: N2K-C2148T-1GE , VID: V01 , SN: FOX1252GQJR

NAME: "FEX 100 Module 1", DESCR: "Fabric Extender Module: 48x1GE, 4X10GE Supervisor"
PID: N2K-C2148T-1GE , VID: V01 , SN: JAF1302ABDP

NAME: "FEX 100 Fan 1", DESCR: "Fabric Extender Fan module"
PID: N2K-C2148-FAN , VID: N/A , SN: N/A

NAME: "FEX 100 Power Supply 1", DESCR: "Fabric Extender AC power supply"
PID: N2K-PAC-200W , VID: V01 , SN: PAC12493LQX

NAME: "FEX 100 Power Supply 2", DESCR: "Fabric Extender AC power supply"
PID: N5K-PAC-200W , VID: 00V0 , SN: PAC12423L1Q

switch#

```

Related Commands

| Command | Description |
|-------------------------------|---|
| show hardware internal | Displays information about the physical hardware. |
| show module | Displays information about the modules. |

Send comments to nx5000-docfeedback@cisco.com

show license

To display license information, use the **show license** command.

show license [**brief** | **file** *filename*]

| | | |
|---------------------------|-----------------------------|--|
| Syntax Description | brief | (Optional) Displays a list of license files installed on a device. |
| | file <i>filename</i> | (Optional) Displays information for a specific license file. |

| | |
|------------------------|--|
| Command Default | Displays information about the installed licenses. |
|------------------------|--|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

Examples

This example shows how to display a specific license installed on the switch:

```
switch# show license file fc5020.lic
```

This example shows how to display a list of license files installed on a device:

```
switch# show license brief
fcoelicense.lic
switch#
```

This example shows how to display all licenses installed on a device:

```
switch# show license
fcoelicense.lic:
SERVER this_host ANY
VENDOR cisco
INCREMENT ENTERPRISE_PKG cisco 1.0 permanent uncounted \
    VENDOR_STRING=<LIC_SOURCE>MDS_SWIFT</LIC_SOURCE><SKU>N5020-SSK9=</SKU> \
    HOSTID=VDH=SSI13390FZT \
    NOTICE="<LicFileID>20100611101827012</LicFileID><LicLineID>1</LicLineID>
\
    <PAK></PAK>" SIGN=877DB4A06E0C
INCREMENT FC_FEATURES_PKG cisco 1.0 permanent uncounted \
    VENDOR_STRING=<LIC_SOURCE>MDS_SWIFT</LIC_SOURCE><SKU>N5020-SSK9=</SKU> \
    HOSTID=VDH=SSI13390FZT \
    NOTICE="<LicFileID>20100611101827012</LicFileID><LicLineID>2</LicLineID>
\
    <PAK></PAK>" SIGN=A075D610878C

switch#
```

Send comments to nx5000-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|-----------------------------|---|
| | install license | Installs a license. |
| | show license host-id | Displays the serial number of the chassis to use for licensing. |
| | show license usage | Displays license usage information. |

Send comments to nx5000-docfeedback@cisco.com

show license host-id

To display the serial number (host ID) of the switch chassis to use for licensing, use the **show license host-id** command.

show license host-id

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | The serial number is the entire string that appears after the colon (:) as shown in the example. |
|-------------------------|--|

| | |
|-----------------|--|
| Examples | This example shows how to display the host ID, required to request node-locked licenses: |
|-----------------|--|

```
switch# show license host-id
License hostid: VDH=FLC12300568
switch#
```

| | | |
|-------------------------|---------------------------|-------------------------------------|
| Related Commands | Command | Description |
| | install license | Installs a license. |
| | show license | Displays license information. |
| | show license usage | Displays license usage information. |

Send comments to nx5000-docfeedback@cisco.com

show license usage

To display license usage information, use the **show license usage** command.

show license usage [*PACKAGE*]

| | |
|---------------------------|---|
| Syntax Description | <i>PACKAGE</i> (Optional) List of licensed features in use for the specified license package. |
|---------------------------|---|

| | |
|------------------------|--|
| Command Default | Displays license usage for the switch. |
|------------------------|--|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to display information about the current license usage:

```
switch# show license usage
Feature                               Ins   Lic   Status Expiry Date Comments
                                Count
-----
FM_SERVER_PKG                        No    -    Unused              -
ENTERPRISE_PKG                       Yes   -    Unused Never        -
FC_FEATURES_PKG                      Yes   -    In use Never        -
-----
```

Table 1-6 describes the columns used in the **show license usage** command output.

Table 1-6 *show license usage Columns*

| Column | Description |
|-----------|---|
| Feature | Name of the license package. |
| Ins | License installation status. “No” indicates that the license is not installed and “Yes” indicates that the license is installed. |
| Lic Count | License count. “-” indicates that the count is not used for this license package. A number in this field indicates that number of current usages of the license by features. This field is not supported. |
| Status | License status. “Unused” indicates that no features that require the license are enabled. “In use” indicates that one or more features are using the license. |

Send comments to nx5000-docfeedback@cisco.com

Table 1-6 *show license usage Columns (continued)*

| Column | Description |
|-------------|---|
| Expiry Date | License expiry date. The field is blank if the license is not installed. If the license is installed, the field displays “Never” to indicate that the license has no time limit or displays the date of expiry for the license. |
| Comments | Additional information. “Grace” with a time period remaining in days (“D”) and hours (:H”) indicates that the grace license is in use and “license missing” indicates that an error has occurred. |

This example shows how to display a list of features in use for a specific license:

```
switch# show license usage FC_FEATURES_PKG
Application
-----
PFM
-----
switch#
```

Related Commands

| Command | Description |
|-----------------------------|---|
| install license | Installs a license. |
| show license | Displays license information. |
| show license host-id | Displays the serial number of the chassis to use for licensing. |

Send comments to nx5000-docfeedback@cisco.com

show line

To display terminal port configuration information, use the **show line** command.

show line [**console** [**user-input-string**]]

| Syntax Description | console | (Optional) Displays only information about the console port configuration. |
|--------------------|-------------------|--|
| | user-input-string | (Optional) Displays the user-input initialization string. |

| Command Default | Displays information about the terminal port configuration. |
|-----------------|---|
|-----------------|---|

| Command Modes | EXEC mode |
|---------------|-----------|
|---------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|---|
| | 4.0(0)N1(1a) | This command was introduced. |
| | 4.1(3)N1(1) | The show line console user-input-string was added. |

Examples This example shows how to display information about the terminal port configuration information:

```
switch# show line
line Console:
  Speed:          115200 baud
  Databits:       8 bits per byte
  Stopbits:       2 bit(s)
  Parity:         none
  Modem In: Disable
  Modem Init-String -
    default : ATE0Q1&D2&C1S0=1\015

line Aux:
  Speed:          9600 baud
  Databits:       8 bits per byte
  Stopbits:       1 bit(s)
  Parity:         none
  Modem In: Disable
  Modem Init-String -
    default : ATE0Q1&D2&C1S0=1\015
  Hardware Flowcontrol: ON

switch#
```

This example shows how to display only the information about the console port configuration:

```
switch# show line console
line Console:
  Speed:          115200 baud
  Databits:       8 bits per byte
  Stopbits:       2 bit(s)
  Parity:         none
  Modem In: Disable
```

Send comments to nx5000-docfeedback@cisco.com

```
Modem Init-String -  
  default : ATE0Q1&D2&C1S0=1\015
```

```
switch#
```

This example shows how to display the user-input initialization string for a modem:

```
switch# show line console user-input-string  
Console's user-input string is ATE0Q1&D2&C1S0=3\015  
switch#
```

Related Commands

| Command | Description |
|---------------------|---|
| line console | Enters the console port configuration mode. |

Send comments to nx5000-docfeedback@cisco.com

show module

To display module information, use the **show module** command.

show module [*module-number* | **fex** [*chassis_ID* | **all**]]

| | | |
|---------------------------|----------------------|---|
| Syntax Description | <i>module-number</i> | (Optional) Number of the module. The valid range is from 1 to 3. |
| | fex | (Optional) Displays information about the attached Fabric Extender units. |
| | <i>chassis_ID</i> | (Optional) Fabric Extender chassis ID. The chassis ID is from 100 to 199. |
| | all | (Optional) Displays information about all the attached Fabric Extender units. |

Command Default Displays module information for all modules in the switch chassis.

Command Modes EXEC mode

| | | |
|------------------------|----------------|---|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| | 4.0(1a)N2(1) | This command was modified to provide Fabric Extender support. |

Examples This example shows how to display information for all modules in the chassis:

```
switch# show module
Mod Ports  Module-Type                Model                Status
---  ---
1      40      40x10GE/Supervisor         N5K-C5020P-BF-SUP   active *
2       6      6x10GE Ethernet Module     N5K-M1600            ok
3       8      8x1/2/4G FC Module         N5K-M1008            ok

Mod  Sw                Hw      World-Wide-Name(s) (WWN)
---  ---
1    4.2(1)N2(1)      1.3     --
2    4.2(1)N2(1)      0.100   --
3    4.2(1)N2(1)      0.200   20:81:00:0d:ec:e7:df:40 to 20:88:00:0d:ec:e7:df:40

Mod  MAC-Address(es)                Serial-Num
---  ---
1    000d.ece7.df48 to 000d.ece7.df6f  JAF1344BHNK
2    000d.ece7.df70 to 000d.ece7.df77  JAB1228018M
3    000d.ece7.df78 to 000d.ece7.df7f  JAB1231020C
switch#
```

This example shows how to display information for a specific module:

```
switch# show module 2
Mod Ports  Module-Type                Model                Status
---  ---
2       6      6x10GE Ethernet Module     N5K-M1600            ok

Mod  Sw                Hw      World-Wide-Name(s) (WWN)
---  ---
```

Send comments to nx5000-docfeedback@cisco.com

```

-----
2      4.2(1)N2(1)      0.100  --

Mod   MAC-Address(es)                               Serial-Num
-----
2      000d.ece7.df70 to 000d.ece7.df77              JAB1228018M
switch#

```

This example shows how to display information about an attached Fabric Extender:

```

switch# show module fex 100

FEX Mod Ports Card Type                               Model                Status.
-----
100 1   48      Fabric Extender 48x1GE Module          N2K-C2148T-1GE       present

FEX Mod Sw              Hw              World-Wide-Name(s) (WWN)
-----
100 1   4.2(1)N2(1)        1.0            --

FEX Mod   MAC-Address(es)                               Serial-Num
-----
100 1      000d.ecb1.ef00 to 000d.ecb1.ef2f              JAF1302ABDP
switch#

```

This example shows how to display information about all attached Fabric Extender units:

```

switch# show module fex all

FEX Mod Ports Card Type                               Model                Status.
-----
100 1   48      Fabric Extender 48x1GE Module          N2K-C2148T-1GE       present
150 1   48      Fabric Extender 48x1GE + 4x10G Mod N2K-C2248TP-1GE       present
151 1   48      Fabric Extender 48x1GE + 4x10G Mod N2K-C2248TP-1GE       present
170 1   32      Fabric Extender 32x10G BaseT + 8x1 0      present
171 1   32      Fabric Extender 32x10G BaseT + 8x1 0      present
198 1   32      Fabric Extender 32x10GE + 8x10G Mo N2K-C2232PP-10GE       present
199 1   32      Fabric Extender 32x10GE + 8x10G Mo N2K-C2232PP-10GE       present

FEX Mod Sw              Hw              World-Wide-Name(s) (WWN)
-----
100 1   4.2(1)N2(1)        1.0            --
150 1   4.2(1)N2(1)        3.4            --
151 1   4.2(1)N2(1)        3.2            --
170 1   4.2(1)N2(1)        1.0            --
171 1   4.2(1)N2(1)        1.0            --
198 1   4.2(1)N2(1)        3.4            --
199 1   4.2(1)N2(1)        3.5            --

FEX Mod   MAC-Address(es)                               Serial-Num
-----
100 1      000d.ecb1.ef00 to 000d.ecb1.ef2f              JAF1302ABDP
150 1      000d.ecfc.a140 to 000d.ecfc.a16f              JAF1407AARL
151 1      000d.ecf4.f916 to 000d.ecf4.f945              JAF1352AHAL
170 1      68ef.bd62.1080 to 68ef.bd62.109f              JAF1417BTEM
171 1      68ef.bd62.1680 to 68ef.bd62.169f              JAF1421DMEA
198 1      000d.ecf7.d4a3 to 000d.ecf7.d4c2              JAF1352AQCH
199 1      68ef.bd61.d8c0 to 68ef.bd61.d8df              JAF1409ATAM
switch#

```

Send comments to nx5000-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|-------------------------------|---|
| | show hardware internal | Displays information about the physical hardware. |
| | show inventory | Displays hardware inventory information. |

Send comments to nx5000-docfeedback@cisco.com

show processes

To display the process information for the switch, use the **show processes** command.

show processes [**vdc vdc-number**]

| Syntax Description | vdc vdc-number | (Optional) Displays process information for a specific virtual device context (VDC). There is only one VDC on a Cisco Nexus 5000 Series switch. |
|--------------------|-----------------------|---|
|--------------------|-----------------------|---|

| Command Default | Displays information for all processes running on the switch. |
|-----------------|---|
|-----------------|---|

| Command Modes | EXEC mode |
|---------------|-----------|
|---------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to display the process information for a device:

```
switch# show processes
```

| PID | State | PC | Start_cnt | TTY | Process |
|------|-------|----------|-----------|-----|----------------|
| 1 | S | b7f9e468 | 1 | - | init |
| 2 | S | 0 | 1 | - | ksoftirqd/0 |
| 3 | S | 0 | 1 | - | desched/0 |
| 4 | S | 0 | 1 | - | events/0 |
| 5 | S | 0 | 1 | - | khelper |
| 10 | S | 0 | 1 | - | kthread |
| 18 | S | 0 | 1 | - | kacpid |
| 169 | S | 0 | 1 | - | kblockd/0 |
| 182 | S | 0 | 1 | - | khubd |
| 247 | S | 0 | 1 | - | pdflush |
| 248 | S | 0 | 1 | - | pdflush |
| 249 | S | 0 | 1 | - | kswapd0 |
| 250 | S | 0 | 1 | - | aio/0 |
| 251 | S | 0 | 1 | - | SerrLogKthread |
| 809 | S | 0 | 1 | - | kide/0 |
| 812 | S | 0 | 1 | - | ata/0 |
| 817 | S | 0 | 1 | - | mtddbld |
| 845 | S | 0 | 1 | - | scsi_ah_0 |
| 846 | S | 0 | 1 | - | usb-storage |
| 1362 | S | 0 | 1 | - | kjournald |
| 1370 | S | 0 | 1 | - | kjournald |
| 2127 | S | 0 | 1 | - | jffs2_gcd_mtd2 |
| 2184 | S | 0 | 1 | - | kjournald |
| 2644 | S | b7f8718e | 1 | - | portmap |
| 2653 | S | 0 | 1 | - | nfsd |
| 2654 | S | 0 | 1 | - | nfsd |
| 2655 | S | 0 | 1 | - | nfsd |
| 2656 | S | 0 | 1 | - | nfsd |

Send comments to nx5000-docfeedback@cisco.com

```

2657      S      0      1      -  nfsd
2658      S      0      1      -  nfsd
2659      S      0      1      -  nfsd
2660      S      0      1      -  nfsd
2661      S      0      1      -  lockd
2662      S      0      1      -  rpciod
2667      S  b7f89468    1      -  rpc.mountd
2673      S  b7f89468    1      -  rpc.statd
2700      S  b7df3468    1      -  sysmgr
3344      S      0      1      -  mping-thread
3511      S      0      1      -  insmod
3892      S  b7f4b468    1      -  xinetd
3893      S  b7f89468    1      -  tftpd
--More--
switch#

```

Related Commands

| Command | Description |
|------------------------------|---|
| show processes cpu | Displays the CPU utilization information for processes. |
| show processes log | Displays the contents of the process log. |
| show processes memory | Displays the memory allocation information for processes. |

Send comments to nx5000-docfeedback@cisco.com

show processes cpu

To display the CPU utilization information for processes on the device, use the **show processes cpu** command.

show processes cpu

Syntax Description This command has no arguments or keywords.

Command Default Displays information for all processes in the local device.

Command Modes EXEC mode

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to display the CPU utilization information for the processes:

```
switch# show processes cpu
```

| PID | Runtime(ms) | Invoked | uSecs | 1Sec | Process |
|------|-------------|---------|-------|-------|----------------|
| ---- | ----- | ----- | ----- | ----- | ----- |
| 1 | 1802 | 22973 | 78 | 0.0% | init |
| 2 | 440 | 44555 | 9 | 0.0% | ksoftirqd/0 |
| 3 | 79 | 17021 | 4 | 0.0% | desched/0 |
| 4 | 2097 | 92976 | 22 | 0.0% | events/0 |
| 5 | 71 | 3224 | 22 | 0.0% | khelper |
| 10 | 0 | 18 | 20 | 0.0% | kthread |
| 18 | 0 | 2 | 2 | 0.0% | kacpid |
| 169 | 5 | 669 | 8 | 0.0% | kblockd/0 |
| 182 | 121 | 42 | 2885 | 0.0% | khubd |
| 247 | 0 | 2 | 1 | 0.0% | pdflush |
| 248 | 326 | 20427 | 15 | 0.0% | pdflush |
| 249 | 0 | 1 | 4 | 0.0% | kswapd0 |
| 250 | 0 | 2 | 1 | 0.0% | aio/0 |
| 251 | 0 | 1 | 1 | 0.0% | SerrLogKthread |
| 809 | 0 | 2 | 1 | 0.0% | kide/0 |
| 812 | 0 | 2 | 1 | 0.0% | ata/0 |
| 817 | 0 | 1 | 3 | 0.0% | mtddblockd |
| 845 | 0 | 1 | 6 | 0.0% | scsi_eh_0 |
| 846 | 132 | 36789 | 3 | 0.0% | usb-storage |
| 1362 | 0 | 1 | 8 | 0.0% | kjournald |
| 1370 | 0 | 1 | 5 | 0.0% | kjournald |
| 2127 | 367 | 56 | 6560 | 0.0% | jffs2_gcd_mtd2 |
| 2184 | 20 | 743 | 27 | 0.0% | kjournald |
| 2644 | 0 | 21 | 38 | 0.0% | portmap |
| 2653 | 0 | 42 | 14 | 0.0% | nfsd |
| 2654 | 0 | 30 | 2 | 0.0% | nfsd |
| 2655 | 0 | 30 | 2 | 0.0% | nfsd |
| 2656 | 0 | 30 | 2 | 0.0% | nfsd |
| 2657 | 0 | 30 | 2 | 0.0% | nfsd |

Send comments to nx5000-docfeedback@cisco.com

```

2658          0          30          2      0.0%  nfsd
2659          0          32          4      0.0%  nfsd
2660          0          32          3      0.0%  nfsd
2661          0           2         33      0.0%  lockd
2662          0           1          6      0.0%  rpciod
2667          0           1         71      0.0%  rpc.mountd
2673          2           5         571     0.0%  rpc.statd
2700         152        251559          0      0.0%  sysmgr
3344          0           1          22      0.0%  mping-thread
3511        1825        10196         179     0.0%  insmod
3892          12           3        4105     0.0%  xinetd
3893          3           4          843     0.0%  tftpd
--More--
switch#

```

Related Commands

| Command | Description |
|------------------------------|---|
| show processes | Displays the process information for the switch. |
| show processes log | Displays the contents of the process log. |
| show processes memory | Displays the memory allocation information for processes. |

Send comments to nx5000-docfeedback@cisco.com

show processes log

To display the contents of the process log, use the **show processes log** command.

show processes log [**details** | **pid** *process-id*]

| | | |
|---------------------------|------------------------------|---|
| Syntax Description | details | (Optional) Displays detailed information from the process log. |
| | pid <i>process-id</i> | (Optional) Displays detailed information from the process log for a specific process. The process ID range is from 1 to 2147483647. |

| | |
|------------------------|---|
| Command Default | Displays summary information for all processes on the device. |
|------------------------|---|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to display summary information from the process log:

```
switch# show processes log
Process          PID      Normal-exit  Stack  Core  Log-create-time
-----
afm               2948             N      Y      N  Fri Dec  4 00:36:19 2009
afm               2997             N      Y      N  Tue Dec 15 04:09:57 2009
afm               3871             N      N      N  Sat Mar 20 18:22:14 2010
afm               3875             N      N      N  Fri Mar 26 08:45:06 2010
afm               3877             N      Y      N  Mon Mar 22 03:56:38 2010
afm               3886             N      N      N  Fri Mar 26 08:45:06 2010
afm               3887             N      N      N  Sat Mar 20 18:22:15 2010
afm               3889             N      N      N  Sun Mar 21 06:15:00 2010
afm               3890             N      N      N  Sat Mar 20 18:22:16 2010
afm               3895             N      N      N  Fri Mar 26 08:45:08 2010
afm               3898             N      N      N  Fri Mar 26 08:45:08 2010
afm               3904             N      Y      N  Mon Apr  5 19:28:56 2010
afm               3915             N      N      N  Sun Mar 21 06:15:01 2010
afm               3918             N      Y      N  Mon Mar 22 03:43:42 2010
afm               3919             N      N      N  Sun Mar 21 06:15:03 2010
afm               3922             N      Y      N  Mon Mar 22 03:56:44 2010
afm               3930             N      N      N  Sun Mar 21 06:15:03 2010
afm               3942             N      Y      N  Wed Apr  7 18:47:39 2010
afm               3943             N      Y      N  Tue Apr  6 00:09:46 2010
afm               3950             N      Y      N  Mon Mar 22 03:43:45 2010
afm               3962             N      Y      N  Mon Mar 22 03:43:47 2010
afm               3967             N      Y      N  Tue Apr  6 21:57:55 2010
afm               4054             N      Y      N  Tue Mar 23 07:30:21 2010
afm               4220             N      N      N  Fri Mar 26 08:45:34 2010
afm               4224             N      N      N  Sat Mar 20 18:22:45 2010
--More--
switch#
```


Send comments to nx5000-docfeedback@cisco.com

This example shows how to display detailed information from the process log:

```
switch# show processes log details
=====
Service: afm
Description: Acl manager Daemon

Started at Fri Dec  4 00:36:05 2009 (209115 us)
Stopped at Fri Dec  4 00:36:19 2009 (274038 us)
Uptime: 14 seconds

Start type: SRV_OPTION_RESTART_STATEFUL (24)
Death reason: SYSMGR_DEATH_REASON_FAILURE_SIGNAL (2)
Last heartbeat 0.00 secs ago
RLIMIT_AS: 272490099
System image name: n5000-uk9.4.2.1.N1.0.173.bin
System image version: 4.2(1)N1(0.173) S0

PID: 2948
Exit code: signal 11 (core dumped)

CWD: /var/sysmgr/work

Virtual Memory:

      CODE      08048000 - 081467A4
      DATA      08147000 - 0816A968
      BRK        08192000 - 085E3000
      STACK      BFFFFFFA90
      TOTAL      99840 KB

Register Set:

      EBX B6FA2178      ECX 00000001      EDX 0836EF98
      ESI 0000000C      EDI 0836F040      EBP BFFFEB48
      EAX BFFFEB70      XDS C010007B      XES 0000007B
      EAX FFFFFFFF (orig) EIP 00000000      XCS 00000073
      EFL 00010296      ESP BFFFEB1C      XSS 0000007B

Stack: 3956 bytes. ESP BFFFEB1C, TOP BFFFFFFA90

0xBFFFEB1C: B6F3B1EA BFFFEB70 B6568860 00000001 ....p...`.V....
0xBFFFEB2C: B6F3B1CE 00000000 B6FA2294 0000024F .....".O...
0xBFFFEB3C: 00000007 0000000C 00000000 BFFFEBD8 .....
0xBFFFEB4C: 08107B82 0836F040 BFFFEB70 BFFFEB68 {...@.6.p...h...
0xBFFFEB5C: BFFFEB6C B6F71C64 00000000 BFFFEB88 l...d.....
0xBFFFEB6C: B6F4F72A 00000000 00000008 B6F75D71 *.....q]...
--More--
switch#
```

This example shows how to display detailed information from the process log for a specific process:

```
switch# show processes log pid 2948
=====
Service: afm
Description: Acl manager Daemon

Started at Fri Dec  4 00:36:05 2009 (209115 us)
Stopped at Fri Dec  4 00:36:19 2009 (274038 us)
Uptime: 14 seconds

Start type: SRV_OPTION_RESTART_STATEFUL (24)
Death reason: SYSMGR_DEATH_REASON_FAILURE_SIGNAL (2)
Last heartbeat 0.00 secs ago
```

Send comments to nx5000-docfeedback@cisco.com

```
RLIMIT_AS: 272490099
System image name: n5000-uk9.4.2.1.N1.0.173.bin
System image version: 4.2(1)N1(0.173) S0

PID: 2948
Exit code: signal 11 (core dumped)

CWD: /var/sysmgr/work

Virtual Memory:

      CODE      08048000 - 081467A4
      DATA      08147000 - 0816A968
      BRK         08192000 - 085E3000
      STACK      BFFFFFFA90
      TOTAL      99840 KB

Register Set:

      EBX B6FA2178      ECX 00000001      EDX 0836EF98
      ESI 0000000C      EDI 0836F040      EBP BFFFFFFB48
      EAX BFFFFFFB70      XDS C010007B      XES 0000007B
      EAX FFFFFFFF (orig) EIP 00000000      XCS 00000073
      EFL 00010296      ESP BFFFFFFB1C      XSS 0000007B

Stack: 3956 bytes. ESP BFFFFFFB1C, TOP BFFFFFFA90

0xBFFFFFFB1C: B6F3B1EA BFFFFFFB70 B6568860 00000001 ....p...`.V....
0xBFFFFFFB2C: B6F3B1CE 00000000 B6FA2294 0000024F .....".O...
0xBFFFFFFB3C: 00000007 0000000C 00000000 BFFFFFFBD8 .....
0xBFFFFFFB4C: 08107B82 0836F040 BFFFFFFB70 BFFFFFFB68 .{..@.6.p...h...
0xBFFFFFFB5C: BFFFFFFB6C B6F71C64 00000000 BFFFFFFB88 l...d.....
0xBFFFFFFB6C: B6F4F72A 00000000 00000008 B6F75D71 *.....q]..
--More--
switch#
```

Related Commands

| Command | Description |
|------------------------------|---|
| show processes | Displays the process information for the switch. |
| show processes cpu | Displays the CPU utilization information for processes. |
| show processes memory | Displays the memory allocation information for processes. |

Send comments to nx5000-docfeedback@cisco.com

show processes memory

To display the memory allocation information for processes, use the **show processes memory** command.

show processes memory [shared [detail]]

| | | |
|---------------------------|---------------|--|
| Syntax Description | shared | (Optional) Displays the shared memory allocation. |
| | detail | (Optional) Displays the shared memory in bytes instead of the default kilobytes. |

| | |
|------------------------|---|
| Command Default | Displays memory allocated to the processes. |
|------------------------|---|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to display information about the memory allocation for processes:

```
switch# show processes memory
```

| PID | MemAlloc | StkSize | RSSMem | LibMem | StackBase/Ptr | Process |
|------|----------|---------|--------|---------|-------------------|----------------|
| ---- | ----- | ----- | ----- | ----- | ----- | ----- |
| 1 | 147456 | 86016 | 495616 | 1126400 | bffffea0/bffff990 | init |
| 2 | 0 | 0 | 0 | 0 | 0/0 | ksoftirqd/0 |
| 3 | 0 | 0 | 0 | 0 | 0/0 | desched/0 |
| 4 | 0 | 0 | 0 | 0 | 0/0 | events/0 |
| 5 | 0 | 0 | 0 | 0 | 0/0 | khelper |
| 10 | 0 | 0 | 0 | 0 | 0/0 | kthread |
| 18 | 0 | 0 | 0 | 0 | 0/0 | kacpid |
| 169 | 0 | 0 | 0 | 0 | 0/0 | kblockd/0 |
| 182 | 0 | 0 | 0 | 0 | 0/0 | khubd |
| 247 | 0 | 0 | 0 | 0 | 0/0 | pdflush |
| 248 | 0 | 0 | 0 | 0 | 0/0 | pdflush |
| 249 | 0 | 0 | 0 | 0 | 0/0 | kswapd0 |
| 250 | 0 | 0 | 0 | 0 | 0/0 | aio/0 |
| 251 | 0 | 0 | 0 | 0 | 0/0 | SerrLogKthread |
| 809 | 0 | 0 | 0 | 0 | 0/0 | kide/0 |
| 812 | 0 | 0 | 0 | 0 | 0/0 | ata/0 |
| 817 | 0 | 0 | 0 | 0 | 0/0 | mtdblockd |
| 845 | 0 | 0 | 0 | 0 | 0/0 | scsi_eh_0 |
| 846 | 0 | 0 | 0 | 0 | 0/0 | usb-storage |
| 1362 | 0 | 0 | 0 | 0 | 0/0 | kjournald |
| 1370 | 0 | 0 | 0 | 0 | 0/0 | kjournald |
| 2127 | 0 | 0 | 0 | 0 | 0/0 | jffs2_gcd_mtd2 |
| 2184 | 0 | 0 | 0 | 0 | 0/0 | kjournald |
| 2644 | 155648 | 86016 | 438272 | 1216512 | bffffdf0/bffffcf0 | portmap |

```
--More--
```

```
switch#
```

Send comments to nx5000-docfeedback@cisco.com

This example shows how to display information about the shared memory allocation for processes:

```
switch# show processes memory shared
Component          Shared Memory      Size      Used  Available  Reference
                   Address      (kbytes)  (kbytes)  (kbytes)      Count
smm                0X60000000          1024         3       1021         21
cli                0X60110000      30720*      13982     16738         6
npacl              0X61F20000       4096*         1       4095         1
u6rib-ufdm         0X62330000        320*        188       132         1
am                 0X62390000        1024*        13       1011         4
urib               0X624A0000      32768*       700     32068        11
urib-redis         0X644B0000       4096*         0       4096        11
icmpv6             0X648C0000        1024         0       1024         1
u6rib              0X649D0000     16384*       665     15719         5
urib-ufdm          0X659E0000       2048*         0       2048         1
ip                 0X65BF0000       2048         68      1980        10
u6rib-notify       0X65E00000       2048*       795     1253         5
ipv6               0X66010000        1024         59       965         3
igmp               0X66120000        1024         0       1024         1
Shared memory totals - Size: 98 MB, Used: 17 MB, Available: 82 MB
switch#
```

Related Commands

| Command | Description |
|---------------------------|---|
| show processes | Displays the process information for the switch. |
| show processes cpu | Displays the CPU utilization information for processes. |
| show processes log | Displays the contents of the process log. |

Send comments to nx5000-docfeedback@cisco.com

show running-config

To display the running configuration, use the **show running-config** command.

show running-config [all]

| Syntax Description | all (Optional) Displays all the default and configured information. | | | | |
|---------------------------|---|---------|--------------|--------------|------------------------------|
| Command Default | Displays only the configured information. | | | | |
| Command Modes | EXEC mode | | | | |
| Command History | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>4.0(0)N1(1a)</td><td>This command was introduced.</td></tr> </table> | Release | Modification | 4.0(0)N1(1a) | This command was introduced. |
| Release | Modification | | | | |
| 4.0(0)N1(1a) | This command was introduced. | | | | |

Examples

This example shows how to display the changes that you have made to the running configuration:

```
switch# show running-config

!Command: show running-config
!Time: Tue Jul 13 06:05:42 2010

version 4.2(1)N2(1)
feature fcoe
feature telnet
feature tacacs+
feature udd
feature interface-vlan
feature lacp
feature vpc
feature lldp
feature fex
snmp-server enable traps entity fru
role name default-role
    description This is a system defined role and applies to all users.
    rule 5 permit command feature environment
    rule 4 permit command feature hardware
    rule 3 permit command feature module
    rule 2 permit command feature snmp
    rule 1 permit command feature system
role name praveena
username admin password 5 $1$VrQsB2KX$4jkUcx3sXWU8lhI1mlwLa/ role network-admin
username oregon password 5 $1$p3VJ0/BY$Kp22A08NeqCQ0asxUKXq91 role network-operator
no password strength-check
ip domain-lookup
ip host switch 192.168.2.215
ip host BEND-1 192.168.2.215
tacacs-server host 192.168.2.54 key 7 "wawy1234"
aaa group server tacacs+ t1
    server 192.168.2.54
```

Send comments to nx5000-docfeedback@cisco.com

```

    use-vrf management
aaa group server tacacs+ tacacs
radius-server host 192.168.2.5 key 7 "KkwyCet" authentication accounting
aaa group server radius r1
    server 192.168.2.5
    use-vrf management
hostname switch
logging event link-status default
errdisable recovery interval 30
no errdisable detect cause link-flap
errdisable recovery cause pause-rate-limit
--More--
switch#

```

This example shows how to display the entire running configuration, including the default values:

```
switch# show running-config all
```

Related Commands

| Command | Description |
|---|---|
| copy running-config startup-config | Copies the running configuration to the startup configuration. |
| show running-config diff | Displays the differences between the running configuration and the startup configuration. |
| show startup-config | Displays the startup configuration. |

Send comments to nx5000-docfeedback@cisco.com

show running-config diff

To display the differences between the running configuration and the startup configuration, use the **show running-config diff** command.

show running-config diff

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines [Table 1-7](#) describes the notations used in the command output.

Table 1-7 *show running-config diff* Notations

| Notation | Description |
|---|---|
| ***** --- line1, line2 --- *** line1, line2 *** | Indicates ranges of lines where differences occur. The range of lines indicated with asterisks (*) is for the startup configuration and the range indicated with dashes (–) is for the startup configuration. |
| + text | Indicates that the line is in the running configuration but is not in the startup configuration. |
| – text | Indicates that the line is not in the running configuration but it is in the startup configuration. |
| ! text | Indicates that the line exists in both configurations but in different orders. |

Examples This example shows how to display the difference between the running configuration and the startup configuration:

```
switch# show running-config diff
*** Startup-config
--- Running-config
*****
*** 1874,1883 ***
--- 1873,1883 ---
    system cores tftp://192.168.2.5/tftpboot/ vrf management
    vsan database
        vsan 700
    cfs eth distribute
    fcdomain fcid database
```

Send comments to nx5000-docfeedback@cisco.com

```
+ vsan 700 wwn 10:00:00:00:00:15:43:e8 fcid 0x350000 dynamic
  vsan 1 wwn 20:44:00:0d:ec:b0:fc:40 fcid 0x780000 dynamic
  vsan 1 wwn 20:43:00:0d:ec:b0:fc:40 fcid 0x780001 dynamic
  vsan 1 wwn 24:01:00:0d:ec:b0:fc:40 fcid 0x780002 dynamic

  interface Vlan1
  *****
  *** 2089,2103 ***
  --- 2089,2113 ---
    priority-flow-control mode on
    speed 1000
    flowcontrol receive on
    service-policy type qos input 1

+ interface port-channel1932
+ shutdown
+ switchport mode trunk
+ switchport trunk allowed vlan 600
+ spanning-tree bpdufilter enable
+ speed 10000
+
  interface vfc1

  interface vfc199
    bind mac-address 00:00:11:11:22:22
+ fcoe fcf-priority 1
  no shutdown
+ vsan database
+ vsan 700 interface vfc199

  interface fc3/1

  interface fc3/2

--More--
switch#
```

Related Commands

| Command | Description |
|---|---|
| copy running-config startup-config | Copies the running configuration to the startup configuration. |
| show running-config | Displays the differences between the running configuration and the startup configuration. |
| show startup-config | Displays the startup configuration. |

Send comments to nx5000-docfeedback@cisco.com

show sprom

To display the contents of the serial PROM (SPROM) on the switch, use the **show sprom** command.

show sprom { **all** | **backplane** | **fex** { *chassis_ID* { **all** | **backplane** | **powersupply** *ps-num* } | **all** } | **module** *module-number* | **powersupply** *ps-num* | **sup** }

| Syntax Description | | |
|------------------------------------|--|--|
| all | | Displays the SPROM contents for all components on the physical device. |
| backplane | | Displays the SPROM contents for the backplane. |
| fex | | Displays information about the attached Fabric Extender units. |
| <i>chassis_ID</i> | | (Optional) Fabric Extender chassis ID. The chassis ID is from 100 to 199. |
| module <i>module-number</i> | | Displays the SPROM contents for an I/O module. The module number range is from 1 to 3. |
| powersupply <i>ps-num</i> | | Displays the SPROM contents for a power supply. The power supply number is 1 or 2. |
| sup | | Displays the SPROM contents for the active supervisor module. |

| Command Default | None |
|-----------------|------|
|-----------------|------|

| Command Modes | EXEC mode |
|---------------|-----------|
|---------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|---|
| | 4.0(0)N1(1a) | This command was introduced. |
| | 4.0(1a)N2(1) | This command was modified to provide Fabric Extender support. |

| Usage Guidelines | The SPROM on the switch contains detailed information about the hardware, including serial, part, and revision numbers. If you need to report a problem with a system component, you can extract serial number information using the show sprom command. |
|------------------|---|
|------------------|---|

| Examples | This example shows how to display SPROM information for all components on the physical device: |
|----------|--|
|----------|--|

```
switch# show sprom all
DISPLAY backplane sprom contents:
Common block:
  Block Signature : 0xabab
  Block Version  : 3
  Block Length   : 160
  Block Checksum : 0x17d7
  EEPROM Size    : 65535
  Block Count    : 4
  FRU Major Type : 0x6001
  FRU Minor Type : 0x0
  OEM String     : Cisco Systems, Inc.
  Product Number : N5K-C5020P-BF
```

■ **show sprom**

Send comments to nx5000-docfeedback@cisco.com

```

Serial Number      : SSI13390FZT
Part Number       : 68-3301-06
Part Revision     : A0
Mfg Deviation     : 0
H/W Version      : 0.0
Mfg Bits         : 0
Engineer Use     : 0
snmpOID          : 9.12.3.1.3.719.0.0
Power Consump    : 0
RMA Code         : 0-0-0-0
CLEI Code        : COMXG00ARC
VID              : V04
Chassis specific block:
Block Signature   : 0x6001
Block Version    : 3
Block Length     : 39
Block Checksum   : 0x3ca
Feature Bits     : 0x0
HW Changes Bits  : 0x0
Stackmib OID     : 0
MAC Addresses    : 00-0d-ec-e7-df-40
Number of MACs   : 64
OEM Enterprise   : 0
OEM MIB Offset   : 0
MAX Connector Power: 0
WWN software-module specific block:
Block Signature   : 0x6005
Block Version    : 1
Block Length     : 0
Block Checksum   : 0x20dd
wwn usage bits:
00 00 00 00 00 00 00 00
--More--
switch#

```

This example shows how to display SPROM information for the backplane:

```

switch# show sprom backplane
DISPLAY backplane sprom contents:
Common block:
Block Signature   : 0xabab
Block Version    : 3
Block Length     : 160
Block Checksum   : 0x17d7
EEPROM Size      : 65535
Block Count      : 4
FRU Major Type   : 0x6001
FRU Minor Type   : 0x0
OEM String       : Cisco Systems, Inc.
Product Number   : N5K-C5020P-BF
Serial Number    : SSI13390FZT
Part Number     : 68-3301-06
Part Revision    : A0
Mfg Deviation    : 0
H/W Version     : 0.0
Mfg Bits        : 0
Engineer Use    : 0
snmpOID        : 9.12.3.1.3.719.0.0
Power Consump   : 0
RMA Code        : 0-0-0-0
CLEI Code       : COMXG00ARC
VID            : V04
Chassis specific block:
Block Signature   : 0x6001

```

Send comments to nx5000-docfeedback@cisco.com

```
Block Version    : 3
--More--
switch#
```

This example shows how to display SPROM information for an attached Fabric Extender:

```
switch# show sprom fex 101 all
```

Related Commands

| Command | Description |
|-------------------------------|---|
| show hardware internal | Displays information about the physical hardware. |
| show inventory | Displays hardware inventory information. |

Send comments to nx5000-docfeedback@cisco.com

show startup-config

To display the startup configuration, use the **show startup-config** command.

show startup-config

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|--|
| Examples | This example shows how to display the startup configuration: |
|-----------------|--|

```
switch# show startup-config

!Command: show startup-config
!Time: Tue Jul 13 06:14:51 2010
!Startup config saved at: Fri Jul 9 23:19:25 2010

version 4.2(1)N2(1)
feature fcoe
feature telnet
feature tacacs+
feature udd
feature interface-vlan
feature lacp
feature vpc
feature lldp
feature fex
snmp-server enable traps entity fru
role name default-role
  description This is a system defined role and applies to all users.
  rule 5 permit command feature environment
  rule 4 permit command feature hardware
  rule 3 permit command feature module
  rule 2 permit command feature snmp
  rule 1 permit command feature system
role name praveena
username admin password 5 $1$VrQsB2KX$4jkUcx3sXWU8lhI1mlwLa/ role network-admin
username oregon password 5 $1$p3VJ0/BY$Kp22A08NeqCQ0asxUKXq91 role network-oper
ator
--More--
switch#
```

Send comments to nx5000-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|---|---|
| | copy running-config startup-config | Copies the running configuration to the startup configuration. |
| | show running-config | Displays the running configuration. |
| | show running-config diff | Displays the differences between the running configuration and the startup configuration. |

Send comments to nx5000-docfeedback@cisco.com

show switchname

To display the hostname for the device, use the **show switchname** command.

show switchname

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | The show hostname command also displays the switch hostname. |
|-------------------------|---|

| | |
|-----------------|--|
| Examples | This example shows how to display the hostname for the switch: |
|-----------------|--|

```
switch# show switchname
```

| | | |
|-------------------------|----------------------------|---|
| Related Commands | Command | Description |
| | hostname | Configures the hostname for the switch. |
| | show hostname | Displays the hostname. |
| | switchname | Configures the hostname for the switch. |

Send comments to nx5000-docfeedback@cisco.com

show system cores

To display the core filename, use the **show system cores** command.

show system cores

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | Use the system cores command to configure the system core filename. |
|-------------------------|--|

| | |
|-----------------|--|
| Examples | This example shows how to display destination information for the system core files: |
|-----------------|--|

```
switch# show system cores
Cores are transferred to tftp://192.168.2.5/tftpboot/
switch#
```

| Related Commands | Command | Description |
|-------------------------|---------------------|--------------------------------------|
| | system cores | Configures the system core filename. |

Send comments to nx5000-docfeedback@cisco.com

show system reset-reason

To display the reset history for the switch, use the **show system reset-reason** command.

show system reset-reason [**fex chassis_ID**]

| Syntax Description | fex chassis_ID | (Optional) Specifies the Fabric Extender chassis ID. The chassis ID is from 100 to 199. |
|--------------------|-----------------------|---|
|--------------------|-----------------------|---|

| Command Default | None |
|-----------------|------|
|-----------------|------|

| Command Modes | EXEC mode |
|---------------|-----------|
|---------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|---|
| | 4.0(0)N1(1a) | This command was introduced. |
| | 4.0(1a)N2(1) | This command was modified to provide Fabric Extender support. |

Examples

This example shows how to display the reset-reason history for the switch:

```
switch# show system reset-reason
----- reset reason for Supervisor-module 1 (from Supervisor in slot 1) ---
1) No time
   Reason: Unknown
   Service:
   Version: 4.2(1)N2(1)

2) No time
   Reason: Unknown
   Service:
   Version: 4.2(1)N2(1)

3) At 543557 usecs after Fri Jul  9 18:20:45 2010
   Reason: Reset due to upgrade
   Service:
   Version: 4.2(1)N1(1)

4) At 572283 usecs after Fri Jul  9 05:12:27 2010
   Reason: Reset due to upgrade
   Service:
   Version: 4.2(1)N2(1)

switch#
```

This example shows how to display the reset-reason history for an attached Fabric Extender:

```
switch# show system reset-reason fex 100
----- reset reason for FEX 100 ---

1) At 0 usecs after Unknown time
   Reset Reason: Unknown (0)
```


Send comments to nx5000-docfeedback@cisco.com

```
Service (Additional Info):  
Image Version: 4.2(1)N2(1)
```

```
2) At 0 usecs after Unknown time
```

```
Reset Reason: Unknown (0)  
Service (Additional Info):  
Image Version: 4.2(1)N2(1)
```

```
3) At 713709 usecs after Fri Jul 9 18:36:32 2010
```

```
Reset Reason: Reset due to upgrade (88)  
Service (Additional Info): Reset due to upgrade  
Image Version: 4.2(1)N1(1)
```

```
4) At 702748 usecs after Fri Jul 9 05:27:06 2010
```

```
Reset Reason: Reset due to upgrade (88)  
Service (Additional Info): Reset due to upgrade  
Image Version: 4.2(1)N2(1)
```

```
switch#
```

Send comments to nx5000-docfeedback@cisco.com

show system resources

To display the system resources, use the **show system resources** command.

show system resources

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|------------------|
| Command Modes | Any command mode |
|----------------------|------------------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.2(1)N2(1) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | This command does not require a license. |
|-------------------------|--|

| | |
|-----------------|--|
| Examples | <p>This example shows how to display the system resources on a switch:</p> <pre>switch(config)# show system resources</pre> |
|-----------------|--|

| | | |
|-------------------------|---------------------------|---|
| Related Commands | Command | Description |
| | show processes cpu | Displays the CPU utilization information for processes on the device. |

Send comments to nx5000-docfeedback@cisco.com

show system uptime

To display the amount of time since the last system restart, use the **show system uptime** command.

show system uptime

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|---|
| Examples | This example shows how to display the amount of time since the last system restart: |
|-----------------|---|

```
switch# show system uptime
System start time:      Mon Jul 12 01:37:08 2010
System uptime:         1 days, 4 hours, 42 minutes, 19 seconds
Kernel uptime:         1 days, 4 hours, 44 minutes, 19 seconds
Active supervisor uptime: 1 days, 4 hours, 42 minutes, 19 seconds
switch#
```

Send comments to nx5000-docfeedback@cisco.com

show tech-support

To display information for Cisco technical support, use the **show tech-support** command.

show tech-support [**brief** | **commands** | *feature*]

| | | |
|---------------------------|-----------------|--|
| Syntax Description | brief | (Optional) Displays information only about the status of the device. |
| | commands | (Optional) Displays the complete list of commands that are executed by the show tech-support command. |
| | <i>feature</i> | (Optional) Specific feature name. Use the command-line interface (CLI) context-sensitive help (for example, show tech-support ?) for the list of features. |

| | |
|------------------------|--|
| Command Default | Displays information for all features. |
|------------------------|--|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

The output from the **show tech-support** command is very long. To better manage this output, you can redirect the output to a file (for example, **show tech-support > filename**) in the local writable storage file system or the remote file system.

You can use one of the following redirection methods:

- **> filename**—Redirects the output to a file.
- **>> filename**—Redirects the output to a file in append mode.

Examples

This example shows how to display technical support information:

```
switch# show tech-support
---- show tech-support ----
`show switchname`
switch
`show system uptime`
System start time:      Mon Jul 12 01:37:08 2010
System uptime:         1 days, 4 hours, 42 minutes, 53 seconds
Kernel uptime:        1 days, 4 hours, 44 minutes, 54 seconds
Active supervisor uptime: 1 days, 4 hours, 42 minutes, 53 seconds
`show interface mgmt0`
mgmt0 is up
  Hardware: GigabitEthernet, address: 000d.ece7.df40 (bia 000d.ece7.df40)
  Internet Address is 192.168.1.215/24
  MTU 1500 bytes, BW 1000000 Kbit, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 1/255
```

Send comments to nx5000-docfeedback@cisco.com

```

Encapsulation ARPA
full-duplex, 1000 Mb/s
1 minute input rate 5408 bits/sec, 4 packets/sec
1 minute output rate 1320 bits/sec, 1 packets/sec
Rx
  465934 input packets 311703 unicast packets 73820 multicast packets
  80411 broadcast packets 250277048 bytes
Tx
  158490 output packets 155374 unicast packets 1725 multicast packets
  1391 broadcast packets 13184030 bytes

'show system resources'
Load average:  1 minute: 2.28   5 minutes: 1.77   15 minutes: 1.30
--More--
switch#

```

This example shows how to redirect the technical support information to a file:

```
switch# show tech-support > bootflash:TechSupport.txt
```

This example shows how to display the brief technical support information for the switch:

```

switch# show tech-support brief
Switch Name           : switch
Switch Type           : 40x10GE/Supervisor
Kickstart Image       : 4.2(1)N2(1) bootflash:/sanity-kickstart
System Image          : 4.2(1)N2(1) bootflash:/sanity-system
IP Address/Mask       : 192.168.1.215/24
No of VSANs           : 2
Configured VSANs      : 1,700

VSAN    1:    name:VSAN0001, state:active, interop mode:default
           domain id:0x78(120), WWN:20:01:00:0d:ec:e7:df:41 [Principal]
           active-zone:<NONE>, default-zone:deny

VSAN   700:   name:VSAN0700, state:active, interop mode:default
           domain id:0x35(53), WWN:22:bc:00:0d:ec:e7:df:41 [Principal]
           active-zone:<NONE>, default-zone:permit

```

| Interface | Vsan | Admin Mode | Admin Trunk Mode | Status | SFP | Oper Mode | Oper Speed (Gbps) | Port Channel |
|-----------|------|------------|------------------|-----------|-----|-----------|-------------------|--------------|
| fc3/1 | 1 | auto | on | sfpAbsent | -- | -- | -- | -- |
| fc3/2 | 1 | auto | on | sfpAbsent | -- | -- | -- | -- |
| fc3/3 | 1 | auto | on | down | sw1 | -- | -- | -- |
| fc3/4 | 1 | auto | on | down | sw1 | -- | -- | -- |
| fc3/5 | 1 | auto | on | sfpAbsent | -- | -- | -- | -- |

```

--More--
switch#

```

This example shows how to display the technical support information for a specific feature:

```

switch# show tech-support aaa
'show running-config aaa all'

!Command: show running-config aaa all
!Time: Tue Jul 13 06:23:49 2010

version 4.2(1)N2(1)
aaa authentication login default local
aaa authorization config-commands default local
aaa authorization commands default local

```

Send comments to nx5000-docfeedback@cisco.com

```

aaa accounting default local
aaa user default-role
no aaa authentication login error-enable
no aaa authentication login mschap enable
no aaa authentication login mschapv2 enable
no aaa authentication login ascii-authentication
no radius-server directed-request
no tacacs-server directed-request

`show system internal aaa event-history msgs`
1) Event:E_MTS_RX, length:60, at 932934 usecs after Tue Jul 13 06:23:49 2010
   [REQ] Opc:MTS_OPC_SDWRAP_DEBUG_DUMP(1530), Id:0X011968A2, Ret:SUCCESS
   Src:0x00000101/7389, Dst:0x00000101/111, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x011968A2, Sync:UNKNOWN, Payloadsize:216
   Payload:
   0x0000:  01 00 2f 74 6d 70 2f 64 62 67 64 75 6d 70 31 39

--More--
switch#

```

This example shows how to display the commands used to generate the technical support information:

```
switch# show tech-support commands
```

Send comments to nx5000-docfeedback@cisco.com

show terminal

To display information about the terminal configuration for a session, use the **show terminal** command.

show terminal

| | |
|---------------------------|--|
| Syntax Description | This command has no arguments or keywords. |
|---------------------------|--|

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|---|
| Examples | This example shows how to display information about the terminal configuration for a session: |
|-----------------|---|

```
switch# show terminal
TTY: /dev/pts/1 Type: "ansi"
Length: 29 lines, Width: 80 columns
Session Timeout: 0 minutes
Event Manager CLI event bypass: no
Redirection mode: ascii
switch#
```

| Related Commands | Command | Description |
|-------------------------|---------------------------------|---|
| | terminal length | Configures the terminal display length for the session. |
| | terminal session-timeout | Configures the terminal inactive session timeout for a session. |
| | terminal type | Configures the terminal type for a session. |
| | terminal width | Configures the terminal display width for a session. |

Send comments to nx5000-docfeedback@cisco.com

show version

To display information about the software version, use the **show version** command.

show version [*fex chassis_ID* | *image filename*]

| | | |
|---------------------------|-----------------------|---|
| Syntax Description | fex chassis_ID | (Optional) Specifies the Fabric Extender chassis ID. The chassis ID is from 100 to 199. |
| | image filename | (Optional) Displays the version information for a system or kickstart image file. |

Command Default Displays software version information for the running kickstart and system images.

Command Modes EXEC mode

| | | |
|------------------------|----------------|---|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| | 4.0(1a)N2(1) | This command was modified to provide Fabric Extender support. |

Examples This example shows how to display the version information for the kickstart and system image running on the device:

```
switch# show version
Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2010, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained herein are owned by
other third parties and are used and distributed under license.
Some parts of this software are covered under the GNU Public
License. A copy of the license is available at
http://www.gnu.org/licenses/gpl.html.

Software
  BIOS:          version 1.3.0
  loader:        version N/A
  kickstart:     version 4.2(1)N2(1)
  system:        version 4.2(1)N2(1)
  power-seq:     version v1.2
  BIOS compile time:      09/08/09
  kickstart image file is: bootflash:/sanity-kickstart
  kickstart compile time: 7/28/2010 11:00:00 [07/07/2010 22:20:39]
  system image file is:   bootflash:/sanity-system
  system compile time:    7/28/2010 11:00:00 [07/07/2010 23:47:55]

Hardware
  cisco Nexus5020 Chassis ("40x10GE/Supervisor")
  Intel(R) Xeon(R) CPU          with 2074288 kB of memory.
  Processor Board ID JAF1344BHNC
```


Send comments to nx5000-docfeedback@cisco.com

```
Device name: NEXUS5K-1
bootflash:    1003520 kB

Kernel uptime is 0 day(s), 9 hour(s), 9 minute(s), 7 second(s)

Last reset
  Reason: Unknown
  System version: 4.2(1)N2(1)
  Service:

plugin
  Core Plugin, Ethernet Plugin, Fc Plugin
switch#
```

This example shows how to display the version information for an attached Fabric Extender:

```
switch# show version fex 100
Software
  Bootloader version:    1.12
  System boot mode:     primary
  System image version:  4.2(1)N2(1) [build 4.2(1)N2(1)]

Hardware
  Module:                Fabric Extender 48x1GE Module
  CPU:                   Motorola, e300c1
  Serial number:         JAF1302ABDP
  Bootflash:             locked

Kernel uptime is 0 day(s), 9 hour(s), 9 minutes(s), 16 second(s)

Last reset at Fri Jul 02 04:27:04 2010
  Reason: Reset Requested by CLI command reload
  Service: Reload requested by supervisor
switch#
```

Send comments to nx5000-docfeedback@cisco.com

sleep

To cause the command-line interface (CLI) to pause before displaying the prompt, use the **sleep** command.

sleep *seconds*

| Syntax Description | <i>seconds</i> Number of seconds. The range is from 0 to 2147483647. | | | | | |
|--------------------|--|--|---------|--------------|-------------------|------------------------------|
| Command Default | None | | | | | |
| Command Modes | EXEC mode | | | | | |
| Command History | <table><tr><th>Release</th><th>Modification</th></tr><tr><td>4.0(0)N1(1a)</td><td>This command was introduced.</td></tr></table> | | Release | Modification | 4.0(0)N1(1a) | This command was introduced. |
| Release | Modification | | | | | |
| 4.0(0)N1(1a) | This command was introduced. | | | | | |
| Usage Guidelines | You can use this command in command scripts to delay the execution of the script. | | | | | |
| Examples | This example shows how to cause the CLI to pause for 5 seconds before displaying the prompt: switch# sleep 5 | | | | | |
| Related Commands | <table><tr><th>Command</th><th>Description</th></tr><tr><td>run-script</td><td>Runs command scripts.</td></tr></table> | | Command | Description | run-script | Runs command scripts. |
| Command | Description | | | | | |
| run-script | Runs command scripts. | | | | | |

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

speed

To configure the transmit and receive speed for the console port, use the **speed** command. To revert to the default, use the **no** form of this command.

speed *speed*

no speed *speed*

| Syntax Description | <i>speed</i> | Speed in bits per second. Valid speeds are 300, 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200. |
|--------------------|--------------|---|
|--------------------|--------------|---|

| Command Default | The default console port speed is 9600 bits per second. |
|-----------------|---|
|-----------------|---|

| Command Modes | Terminal line configuration mode |
|---------------|----------------------------------|
|---------------|----------------------------------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| Usage Guidelines | You can configure the console port only from a session on the console port. |
|------------------|---|
|------------------|---|

| Examples | This example shows how to configure the speed for the console port: |
|----------|---|
|----------|---|

```
switch# configure terminal
switch(config)# line console
switch(config-console)# speed 57600
```

This example shows how to revert to the default speed for the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# no speed 57600
```

| Related Commands | Command | Description |
|------------------|----------------------------|---|
| | line console | Enters the console terminal configuration mode. |
| | show running-config | Displays the running configuration. |

Send comments to nx5000-docfeedback@cisco.com

stopbits

To configure the stop bits for the console port, use the **stopbits** command. To revert to the default, use the **no** form of this command.

stopbits {1 | 2}

no stopbits {1 | 2}

| | | |
|---------------------------|----------|--------------------------|
| Syntax Description | 1 | Specifies one stop bit. |
| | 2 | Specifies two stop bits. |

| | |
|------------------------|------------|
| Command Default | 1 stop bit |
|------------------------|------------|

| | |
|----------------------|----------------------------------|
| Command Modes | Terminal line configuration mode |
|----------------------|----------------------------------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | You can configure the console port only from a session on the console port. |
|-------------------------|---|

| | |
|-----------------|---|
| Examples | This example shows how to configure the number of stop bits for the console port: |
|-----------------|---|

```
switch# configure terminal
switch(config)# line console
switch(config-console)# stopbits 2
```

This example shows how to revert to the default number of stop bits for the console port:

```
switch# configure terminal
switch(config)# line console
switch(config-console)# no stopbits 2
```

| | | |
|-------------------------|----------------------------|---|
| Related Commands | Command | Description |
| | line console | Enters the console terminal configuration mode. |
| | show running-config | Displays the running configuration. |

Send comments to nx5000-docfeedback@cisco.com

switchname

To configure the hostname for the device, use the **switchname** command. To revert to the default, use the **no** form of this command.

switchname *name*

no switchname

Syntax Description

| | |
|-------------|---|
| <i>name</i> | Hostname for the switch. The name is alphanumeric, case sensitive, can contain special characters, and can have a maximum of 32 characters. |
|-------------|---|

Command Default

“switch” is the default hostname.

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

The Cisco NX-OS software uses the hostname in command-line interface (CLI) prompts and in default configuration filenames.

The **switchname** command performs the same function as the **hostname** command.

Examples

This example shows how to configure the hostname for a Cisco Nexus 5000 Series switch:

```
switch# configure terminal
switch(config)# switchname Engineering2
Engineering2(config)#
```

This example shows how to revert to the default hostname:

```
Engineering2# configure terminal
Engineering2(config)# no switchname
switch(config)#
```

Related Commands

| Command | Description |
|------------------------|---------------------------------|
| hostname | Configures the switch hostname. |
| show hostname | Displays the switch hostname. |
| show switchname | Displays the switch hostname. |

Send comments to nx5000-docfeedback@cisco.com

system cores

To configure the destination for the system core, use the **system cores** command. To revert to the default, use the **no** form of this command.

system cores tftp:*tftp_URL* [**vrf management**]

no system cores

| | | |
|--------------------|-----------------------|--|
| Syntax Description | tftp: | Specifies a TFTP server. |
| | <i>tftp_URL</i> | URL for the destination file system and file. Use the following format: <i>[/server[:port]][/path/]filename</i> |
| | vrf management | (Optional) Specifies to use the management virtual routing and forwarding (VRF). |

Command Default None

Command Modes Interface configuration mode

| | | |
|-----------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to configure a core file:

```
switch# configure terminal
switch(config)# system cores tftp://serverA:69/core_file
```

This example shows how to disable system core logging:

```
switch# configure terminal
switch(config)# no system cores
```

| | | |
|------------------|--------------------------|-----------------------------|
| Related Commands | Command | Description |
| | show system cores | Displays the core filename. |

Send comments to nx5000-docfeedback@cisco.com

system startup-config unlock

To unlock the startup configuration file, use the **system startup-config unlock** command.

system startup-config unlock *process-id*

| | | |
|---------------------------|---|------------------------------|
| Syntax Description | <i>process-id</i> Identifier of the process that has locked the startup-configuration file. | |
| Command Default | None | |
| Command Modes | EXEC mode | |
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |
| Usage Guidelines | Use the show system internal sysmgr startup-config locks command to display the locks on the startup configuration file. | |
| Examples | This example shows how to unlock the startup-configuration file: switch# system startup-config unlock 10 | |

Send comments to nx5000-docfeedback@cisco.com

tail

To display the last lines of a file, use the **tail** command.

tail [*filesystem*: [*//server/*]] [*directory*] *filename* [*lines*]

| | | |
|---------------------------|---------------------|---|
| Syntax Description | <i>filesystem</i> : | (Optional) Name of the file system. Valid values are bootflash , modflash , or volatile . |
| | <i>//server/</i> | (Optional) Name of the server. Valid values are <i>///</i> , //module-1/ , //sup-1/ , //sup-active/ , or //sup-local/ . The double slash (<i>//</i>) is required. |
| | <i>directory</i> | (Optional) Name of a directory. The directory name is case sensitive. |
| | <i>filename</i> | Name of the file to display. The filename is case sensitive. |
| | <i>lines</i> | (Optional) Number of lines to display. The range is from 0 to 80. |



Note

There can be no spaces in the *filesystem://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

| | |
|------------------------|-----------------------------|
| Command Default | Displays the last 10 lines. |
|------------------------|-----------------------------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to display the last 10 lines of a file:

```
switch# tail bootflash:startup.cfg
```

This example shows how to display the last 20 lines of a file:

```
switch# tail bootflash:startup.cfg 20
```

| | | |
|-------------------------|----------------|---|
| Related Commands | Command | Description |
| | cd | Changes the current working directory. |
| | copy | Copies files. |
| | dir | Displays the directory contents. |
| | pwd | Displays the name of the current working directory. |

[Send comments to nx5000-docfeedback@cisco.com](mailto:nx5000-docfeedback@cisco.com)

terminal length

To set the number of lines of output to display on the terminal screen for the current session before pausing, use the **terminal length** command. To revert to the default, use the **no** form of this command.

terminal length *lines*

terminal no length

Syntax Description

| | |
|--------------|---|
| <i>lines</i> | Number of lines to display. The range is from 0 to 511. Use 0 to not pause while displaying output. |
|--------------|---|

Command Default

The initial default for the console is 0 (do not pause output). The initial default for virtual terminal sessions is defined by the client software. The default for the **no** form is 24 lines.

Command Modes

EXEC mode

Command History

| Release | Modification |
|--------------|------------------------------|
| 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines

The session pauses after displaying the number of lines set in the terminal length. Press the space bar to display another screen of lines or press the **Enter** key to display another line. To return to the command prompt, press **Ctrl-C**.

The terminal length setting applies only to the current session.

Examples

This example shows how to set the number of lines of command output to display on the terminal before pausing:

```
switch# terminal length 28
```

This example shows how to revert to the default number of lines:

```
switch# terminal no length
```

Related Commands

| Command | Description |
|----------------------|--|
| show terminal | Displays the terminal session configuration. |

Send comments to nx5000-docfeedback@cisco.com

terminal session-timeout

To set the terminal inactivity timeout for the current session, use the **terminal session-timeout** command. To revert to the default, use the **no** form of this command.

terminal session-timeout *minutes*

terminal no session-timeout

| Syntax Description | <i>minutes</i> Number of minutes. The range is from 0 to 525600 minutes (8760 hours). Use 0 to disable the terminal inactivity timeout. | | | | | |
|--------------------|---|--|---------|--------------|---------------|--|
| Command Default | Terminal session timeout is disabled (0 minutes). | | | | | |
| Command Modes | EXEC mode | | | | | |
| Command History | <table><tr><th>Release</th><th>Modification</th></tr><tr><td>4.0(0)N1(1a)</td><td>This command was introduced.</td></tr></table> | | Release | Modification | 4.0(0)N1(1a) | This command was introduced. |
| Release | Modification | | | | | |
| 4.0(0)N1(1a) | This command was introduced. | | | | | |
| Usage Guidelines | The terminal session inactivity timeout setting applies only to the current session. | | | | | |
| Examples | <p>This example shows how to set the terminal inactivity timeout for the session to 10 minutes:</p> <pre>switch# terminal session-timeout 10</pre> <p>This example shows how to revert to the default terminal inactivity timeout for the session:</p> <pre>switch# terminal no session-timeout</pre> | | | | | |
| Related Commands | <table><tr><th>Command</th><th>Description</th></tr><tr><td>show terminal</td><td>Displays the terminal session configuration.</td></tr></table> | | Command | Description | show terminal | Displays the terminal session configuration. |
| Command | Description | | | | | |
| show terminal | Displays the terminal session configuration. | | | | | |

Send comments to nx5000-docfeedback@cisco.com

terminal terminal-type

To set the terminal type for the current session, use the **terminal terminal-type** command. To revert to the default, use the **no** form of this command.

terminal terminal-type *type*

terminal no terminal-type

| | | |
|---------------------------|-------------|---|
| Syntax Description | <i>type</i> | Type of terminal. The type string is case sensitive, must be a valid type (for example, ansi, vt100, or xterm), and has a maximum of 80 characters. |
|---------------------------|-------------|---|

| | |
|------------------------|--|
| Command Default | For a virtual terminal, the terminal type is set during negotiation with the client software. Otherwise, vt100 is the default. |
|------------------------|--|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|------------------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | The terminal type setting applies only to the current session. |
|-------------------------|--|

Examples This example shows how to set the terminal type:

```
switch# terminal terminal-type xterm
```

This example shows how to revert to the default terminal type:

```
switch# terminal no terminal-type
```

| Related Commands | Command | Description |
|-------------------------|----------------------|--|
| | show terminal | Displays the terminal session configuration. |

Send comments to nx5000-docfeedback@cisco.com

terminal width

To set the number of character columns on the terminal screen for the current line for a session, use the **terminal width** command. To revert to the default, use the **no** form of this command.

terminal width *columns*

terminal no width

| Syntax Description | <i>columns</i> Number of columns. The range is from 24 to 511. | | | | | |
|--------------------|--|--|---------|--------------|---------------|--|
| Command Default | For a virtual terminal, the width is set during negotiation with the client software. Otherwise, 80 columns is the default. | | | | | |
| Command Modes | EXEC mode | | | | | |
| Command History | <table><tr><th>Release</th><th>Modification</th></tr><tr><td>4.0(0)N1(1a)</td><td>This command was introduced.</td></tr></table> | | Release | Modification | 4.0(0)N1(1a) | This command was introduced. |
| Release | Modification | | | | | |
| 4.0(0)N1(1a) | This command was introduced. | | | | | |
| Usage Guidelines | The terminal width setting applies only to the current session. | | | | | |
| Examples | <p>This example shows how to set the number of columns to display on the terminal:</p> <pre>switch# terminal width 70</pre> <p>This example shows how to revert to the default number of columns:</p> <pre>switch# terminal no width</pre> | | | | | |
| Related Commands | <table><tr><th>Command</th><th>Description</th></tr><tr><td>show terminal</td><td>Displays the terminal session configuration.</td></tr></table> | | Command | Description | show terminal | Displays the terminal session configuration. |
| Command | Description | | | | | |
| show terminal | Displays the terminal session configuration. | | | | | |

Send comments to nx5000-docfeedback@cisco.com

traceroute

To discover the routes that packets take when traveling to an IP address, use the **traceroute** command.

traceroute {*dest-addr* | *hostname*} [**vrf** {*vrf-name* | **default** | **management**}] [**source** *src-addr*]

| | | |
|---------------------------|-------------------------------|--|
| Syntax Description | <i>dest-addr</i> | IP address of the destination device. The format is <i>A.B.C.D</i> . |
| | <i>hostname</i> | Name of the destination device. The name is case sensitive. |
| | vrf <i>vrf-name</i> | (Optional) Specifies the virtual routing and forwarding (VRF) to use. The name is case sensitive. |
| | default | (Optional) Specifies the default VRF. |
| | management | (Optional) Specifies the management VRF. |
| | source <i>src-addr</i> | (Optional) Specifies a source IP address. The format is <i>A.B.C.D</i> . The default is the IPv4 address for the management interface of the switch. |

Command Default None

Command Modes EXEC mode

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

Examples This example shows how to discover a route to a network device:

```
switch# traceroute 192.168.255.18 vrf management
```

| | | |
|-------------------------|--------------------|--|
| Related Commands | Command | Description |
| | ping | Displays the network connectivity to another network device. |
| | traceroute6 | Discovers the route to a device using IPv6 addressing. |

Send comments to nx5000-docfeedback@cisco.com

traceroute6

To discover the routes that packets take when traveling to an IPv6 address, use the **traceroute6** command.

traceroute6 {*dest-addr* | *hostname*} [**vrf** {*vrf-name* | **default** | **management**}] [**source** *src-addr*]

| Syntax Description | | |
|-------------------------------|--|---|
| <i>dest-addr</i> | | IPv6 address of the destination device. The format is <i>A:B::C:D</i> . |
| <i>hostname</i> | | Name of the destination device. The name is case sensitive. |
| vrf <i>vrf-name</i> | | (Optional) Specifies the virtual routing and forwarding (VRF) instance. The name is case sensitive and can be a maximum of 32 alphanumeric characters. |
| default | | (Optional) Specifies the default VRF. |
| management | | (Optional) Specifies the management VRF. |
| source <i>src-addr</i> | | (Optional) Specifies a source IPv6 address. The format is <i>A:B::C:D</i> . The default is the IPv6 address for the management interface of the switch. |

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(1a)N1(1) | This command was introduced. |

Examples

This example shows how to discover a route to a device:

```
switch# traceroute6 2001:0DB8::200C:417A vrf management
```

| Related Commands | Command | Description |
|------------------|-------------------|--|
| | ping6 | Determines connectivity to another device using IPv6 addressing. |
| | traceroute | Discovers the route to a device using IPv4 addressing. |

Send comments to nx5000-docfeedback@cisco.com

update license

To update an existing license, use the **update license** command.

update license [*filesystem:* [*//server/*]] [*directory*] *src-filename* [*target-filename*]

| | | |
|---------------------------|------------------------|--|
| Syntax Description | <i>filesystem:</i> | (Optional) Name of the file system. Valid values are bootflash or volatile . |
| | <i>//server/</i> | (Optional) Name of the server. Valid values are <i>///</i> , <i>//module-1/</i> , <i>//sup-1/</i> , <i>//sup-active/</i> , or <i>//sup-local/</i> . The double slash (//) is required. |
| | <i>directory</i> | (Optional) Name of a directory. The directory name is case sensitive. |
| | <i>src-filename</i> | Name of the source license file. |
| | <i>target-filename</i> | (Optional) Name of the target license file. |

**Note**

There can be no spaces in the *filesystem://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

| | |
|------------------------|------|
| Command Default | None |
|------------------------|------|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-----------------|---|
| Examples | This example shows how to update a license: switch# update license bootflash:fm.lic fm-update.lic |
|-----------------|---|

| | | |
|-------------------------|----------------|-------------------------------|
| Related Commands | Command | Description |
| | show license | Displays license information. |

Send comments to nx5000-docfeedback@cisco.com

write erase

To erase configurations in persistent memory areas, use the **write erase** command.

write erase [**boot** | **debug**]

| | | |
|---------------------------|--------------|---|
| Syntax Description | boot | (Optional) Erases only the boot configuration. |
| | debug | (Optional) Erases only the debug configuration. |

| | |
|------------------------|--|
| Command Default | Erases all configuration in persistent memory. |
|------------------------|--|

| | |
|----------------------|-----------|
| Command Modes | EXEC mode |
|----------------------|-----------|

| | | |
|------------------------|----------------|------------------------------|
| Command History | Release | Modification |
| | 4.0(0)N1(1a) | This command was introduced. |

| | |
|-------------------------|--|
| Usage Guidelines | You can use this command to erase the startup configuration in the persistent memory when information is corrupted or otherwise unusable. Erasing the startup configuration returns the switch to its initial state. |
|-------------------------|--|

| | |
|-----------------|--|
| Examples | This example shows how to erase the startup configuration: |
|-----------------|--|

```
switch# write erase
```

This example shows how to erase the debug configuration in the persistent memory:

```
switch# write erase debug
```

| | | |
|-------------------------|---|--|
| Related Commands | Command | Description |
| | copy running-config startup-config | Copies the running configuration to the startup configuration. |
| | show running-config | Displays the startup configuration. |