



Running Cisco DCNM Behind a Firewall

This chapter provides information about running Cisco DCNM behind a firewall.

- [Running Cisco DCNM Behind a Firewall, on page 1](#)

Running Cisco DCNM Behind a Firewall

Generally, an Enterprise (external world) and Datacenter is separated by a firewall, i.e., DCNM is configured behind a firewall. The Cisco DCNM Web Client, Cisco DCNM SAN Client, and Cisco Device Manager connectivity will pass-through that firewall. A firewall can be placed between the DCNM Server and DCNM-managed devices also.

Beginning with Cisco DCNM Release 11.0(1), DCNM SAN Client initiates communication with DCNM SAN Server on HTTPS port 443. However, both DCNM SAN Client and Device Manager communicate with the devices directly also. Device Manager can be invoked through DCNM SAN Server UI and it runs within the context of the DCNM SAN Server. The Device Manager communication with devices remains same, as if it was running independently.

DCNM SNMP proxy services on DCNM SAN Server use a configurable TCP port (9198 by default) for SNMP communications between the DCNM SAN Client or Device Manager, and DCNM Server.

Performance Manager uses TCP, by default, for data collections.

The UDP SNMP_TRAP local ports are between 1163-1170, for both Cisco DCNM-SAN and Device Manager. DCNM-SAN Client and Device Manager use the first available UDP port for sending and receiving SNMP responses.

You can select the UDP port that the Device Manager uses for SNMP responses by uncommenting the following statement:

- On a Windows desktop, uncomment the following in the `DeviceManager.bat` file in the `C:\Program Files\Cisco Systems\MDS9000\bin` directory:

```
rem JVMARGS=%JVMARGS% -Dsnmp.localport=[localport]
```

Where [localport] is the value of free local port.



Note On the windows VM, run the `netstat -nab` command, to view the ports that are used by the `javaw.exe` process.

- On a LINUX desktop, uncomment the following in the `DeviceManager.sh` file in the `$HOME/.cisco_mds9000/bin` directory:

```
# JVMARGS=$JVMARGS -Dsnmp.localport=[localport]
```

Where [localport] is the value of free local port.

Any standard port where the Ingress traffic enters from clients cannot be modified unless you disable the local firewall.

The following table lists all ports that are used for communication between DCNM Web Client, DCNM SAN Client, Device Manager, SSH Client, and DCNM Server.

Port Number	Protocol	Service Name	Direction of Communication	Remarks
22	TCP	SSH	SSH to DCNM SAN Server	SSH access to external world is optional.
443	TCP	HTTPS	Client to DCNM SAN Server	Cisco DCNM Web Client, Cisco DCNM SAN Client to the Cisco DCNM Server
1099	TCP	Java RMI	Client to DCNM SAN Server	Cisco DCNM SAN Client to Server
1163 to 1170	UDP	SNMP_TRAP	Device to SAN Client and Device Manager	Cisco DCNM SAN Client and Cisco Device Manager use same range of ports.
2443	TCP	HTTPS	Client to DCNM Server	Required during installation, to reach the server. DCNM closes this port after installation completes.
3528	TCP	JBOSS	Client to DCNM SAN Server	Wildfly JBOSS IIOP
3529	TCP	JBOSS	Client to DCNM SAN Server	Wildfly JBOSS IIOP SSL

Port Number	Protocol	Service Name	Direction of Communication	Remarks
9198	UDP/TCP	SNMP	<p>SAN Client, Device Manager to DCNM SAN Server.</p> <p>Cisco DCNM SAN Client picks a random free local port (UDP) or 9198 (TCP) if SNMP proxy is enabled. The port can be changed with the <code>client -Dsnmp.localport</code> option.</p> <p>Cisco Device Manager picks a random free local port (UDP) or 9198 (TCP) if SNMP proxy is enabled. The port can be changed in <code>server.properties</code> file.</p> <p>DCNM SNMP proxy is used when SAN Client or Device Manager cannot reach managed devices directly and SNMP responses coming to DCNM SAN Server from managed devices can be relayed to SAN Client and Device Manager. DCNM SAN Client and Device Manager must reach to DCNM SAN Server port 9198 (or whatever port is configured) to get the SNMP response.</p>	<p>Cisco DCNM SNMP proxy services use the TCP port (9198 by default) for SNMP communications between the Cisco DCNM SAN Client or Cisco Device Manager and the Cisco DCNM Server.</p>

Port Number	Protocol	Service Name	Direction of Communication	Remarks
61616	TCP	Messaging	DCNM SAN Client to DCNM SAN Server	

The following table lists all the ports that are used for communication between the Cisco DCNM Server and other services which can be hosted on either side of the firewall.

Port Number	Protocol	Service Name	Direction of Communication	Remarks
49	TCP/UDP	TACACS+	Cisco DCNM SAN Server to ACS Server	ACS Server can be on either side of the firewall.
53	TCP/UDP	DNS	Cisco DCNM SAN Server to DNS Server	DNS Server can be on either side of the firewall.
123	UDP	NTP	Cisco DCNM SAN Server to NTP Server	NTP Server can be on either side of the firewall.
1521	TCP	Oracle	DCNM SAN Server to the Oracle database Server	<p>This is necessary if the Oracle server is installed external to the DCNM host machine. Oracle server may be configured to listen on a different port and in that case that port in question must be taken into account.</p> <p>Note You can choose the Oracle server port during DCNM SAN installation and must not be modified later, after installation.</p>

Port Number	Protocol	Service Name	Direction of Communication	Remarks
5432	TCP	Postgres	Cisco DCNM SAN Server to Postgres Server	The default installation of DCNM does not need this port. This is necessary if Postgres is installed externally to the DCNM host machine.

Port Number	Protocol	Service Name	Direction of Communication	Remarks
9198	UDPTCP	SNMP	DCNM SAN Client, Device Manager to DCNM SAN Server	

Port Number	Protocol	Service Name	Direction of Communication	Remarks
				<p>Cisco DCNM SNMP proxy services use the TCP port (9198 by default) on DCNM SAN Server for SNMP communications between the Cisco DCNM SAN Client or Cisco Device Manager and the Cisco DCNM Server.</p> <p>Cisco DCNM SAN Client picks a random free local port (UDP) or 9198 (TCP) to reach SNMP proxy. The port can be changed with the client <code>-Dsnmp.localportoption</code>.</p> <p>Cisco Device Manager picks a random free local port (UDP) or 9198 (TCP) to reach SNMP proxy. The port can be changed in the <code>server.properties</code> file.</p> <p>DCNM SNMP proxy is used when SAN Client or Device Manager cannot reach the managed devices directly and SNMP responses coming to DCNM SAN Server from managed devices can be relayed to SAN Client and Device Manager. DCNM</p>

Port Number	Protocol	Service Name	Direction of Communication	Remarks
				SAN Client and Device Manager must reach to DCNM SAN Server port 9198 (or whatever port is configured) to get the SNMP response.

The following table lists all the ports that are used for communication between Cisco DCNM Server and Managed devices.

Port Number	Protocol	Service Name	Direction of Communication	Remarks
22	TCP	SSH	Both Direction	Server to Device – To manage devices. Device to Server – SCP (POAP)
67	UDP	DHCP	Device to DCNM SAN Server	
69	TCP	TFTP	Device to DCNM SAN Server	Required for POAP
161	TCP/UDP	SNMP	DCNM SAN Server to Device	Cisco DCNM configured via <code>server.properties</code> to use TCP on port 161 instead of UDP port 161.
514	UDP	Syslog	Device to DCNM SAN Server	
2162	UDP	SNMP_TRAP	Device to DCNM SAN Server	

Port Number	Protocol	Service Name	Direction of Communication	Remarks
5989	TCP	SMI-S Agent	Both direction	<p>Server to Device. This is where the Storage device listens.</p> <p>An application to DCNM Server – When DCNM Server is acting as storage proxy.</p> <p>Server to the Storage device port number is depended upon where the storage device is listening on. It could be 5989, 5888, or other ports.</p>
57500	TCP	gRPC	Device to DCNM SAN Server	SAN Telemetry Streaming

