



Peer-Server Configuration Mode Commands

The Peer-Server configuration mode provides the commands to define and manage the peer server configuration part of the SS7 routing on an SGSN.

Command Modes

Exec > Global Configuration > SS7 Routing Domain Configuration > Peer-Server Configuration

configure > **ss7-routing-domain** *rd_id* **variant** *variant_type* > **peer-server id** *server_id*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-ss7-rd-ss7rd_id-ps-id-peer-server_id)#
```



Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [end](#), [page 2](#)
- [exit](#), [page 3](#)
- [mode](#), [page 4](#)
- [name](#), [page 5](#)
- [psp](#), [page 6](#)
- [routing-context](#), [page 8](#)
- [self-point-code](#), [page 10](#)

end

end

Exits the configuration mode and returns to the Exec mode.

Product All

Privilege Security Administrator, Administrator

Syntax Description end

Usage Guidelines Change the mode back to the Exec mode.

exit

Exits the configuration mode and returns to the Global configuration mode.

Product

All

Privilege

Security Administrator, Administrator

Syntax Description

exit

Usage Guidelines

Return to the Global configuration mode.

mode

Configures the operational mode of the peer-server.



Important

In Release 20.0, HNBGW is not supported. This command must not be used for HNBGW in Release 20.0. For more information, contact your Cisco account representative.

Product

SGSN
HNB-GW

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > SS7 Routing Domain Configuration > Peer-Server Configuration
configure > ss7-routing-domain rd_id variant variant_type > peer-server id server_id
Entering the above command sequence results in the following prompt:
[local]host_name(config-ss7-rd-ss7rd_id-ps-id-peer-server_id) #

Syntax Description

mode (loadshare | standby)

loadshare
Sets the peer-server to load share. This is the default.

standby
Sets the peer-server to be in standby mode.

Usage Guidelines

Configure the operational mode of the peer-server.

Examples

Configure the peer-server for standby mode.
mode standby

name

Defines the unique identification - the name - of the peer-server in the SS7 routing domain.



Important

In Release 20.0, HNBBGW is not supported. This command must not be used for HNBBGW in Release 20.0. For more information, contact your Cisco account representative.

Product

SGSN
HNB-GW

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > SS7 Routing Domain Configuration > Peer-Server Configuration

configure > ss7-routing-domain *rd_id* variant *variant_type* > peer-server id *server_id*

Entering the above command sequence results in the following prompt:

```
[local]host_name (config-ss7-rd-ss7rd_id-ps-id-peer-server_id) #
```

Syntax Description

name *name*

no name

no

Removes the peer server's name from this configuration instance.

name

name: Must be a string of 1 to 64 alphanumeric characters to define a unique identification for the peer-server within the specific SS7 routing domain. Double quotes must be used to create a name that includes spaces.

Usage Guidelines

Create peer server names that are easy to remember and uniquely identify the PSP.



Examples

Use this command to create an easily remembered alphanumeric name for the peer-server:

name "Berlin West"

psp

Creates the peer-server-process (PSP) instance and enters the PSP configuration mode. See the PSP Configuration Mode chapter in this guide for information on the configuration commands.

	
Important	In Release 20.0, HNBGW is not supported. This command must not be used for HNBGW in Release 20.0. For more information, contact your Cisco account representative.
	
Important	This command configures a mandatory parameter in the configuration of the peer server.

Product	SGSN HNB-GW
---------	----------------

Privilege	Security Administrator, Administrator
-----------	---------------------------------------

Command Modes	Exec > Global Configuration > SS7 Routing Domain Configuration > Peer-Server Configuration configure > ss7-routing-domain rd_id variant variant_type > peer-server id server_id Entering the above command sequence results in the following prompt: [local]host_name (config-ss7-rd-ss7rd_id-ps-id-peer-server_id) #
---------------	---

Syntax Description	[no] psp instance id no Removes the PSP instance from the peer server configuration. id <i>id</i> Uniquely identifies the specific peer-server-process configuration. The Id must be an integer from 1 to 4 or for SGSN with Release 15.0 or higher, the value range is 1 to12.
--------------------	--

Usage Guidelines	Use this command to define the peer-server-process (PSP) instance ID number for the SGSN configuration.
------------------	---



Examples

Use this command to create instance #3 for the PSP configuration:

psp instance 3

routing-context

Defines the ID of the routing context for the peer-server to use.

	
Important	In Release 20.0, HNBGW is not supported. This command must not be used for HNBGW in Release 20.0. For more information, contact your Cisco account representative.
	
Important	This command configures a mandatory parameter in the configuration of the peer server.

Product SGSN
 HNB-GW

Privilege Security Administrator, Administrator

Command Modes Exec > Global Configuration > SS7 Routing Domain Configuration > Peer-Server Configuration
configure > ss7-routing-domain rd_id variant variant_type > peer-server id server_id
Entering the above command sequence results in the following prompt:
[local]host_name (config-ss7-rd-ss7rd_id-ps-id-peer-server_id) #

Syntax Description **routing-context id**
 no routing-context

 id
id Uniquely identifies a specific routing context for the peer-server-process to use. The Id must be an integer from 1 to 65535.
From release 17.0 onwards, the SGSN supports an integer of 0 to 4294967295 as a valid value for the routing-context ID in M3UA messages.

 no
Removes the routing-context definition from the peer server configuration.

Usage Guidelines Use this command to define routing contexts for the peer server.

Examples

Define routing-context instance 15:
routing-context 15

self-point-code

This command defines the point-code to identify the SGSN as a peer server.



Important

In Release 20.0, HNBGW is not supported. This command must not be used for HNBGW in Release 20.0. For more information, contact your Cisco account representative.

Product

SGSN
HNB-GW

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > SS7 Routing Domain Configuration > Peer-Server Configuration
configure > ss7-routing-domain *rd_id* variant *variant_type* > peer-server id *server_id*
Entering the above command sequence results in the following prompt:
[local]*host_name*(config-ss7-rd-ss7rd_*rd_id*-ps-id-peer-server_*id*) #

Syntax Description

self-point-code *point-code*
no self-point-code

point-code

Point-code is an SS7-type address for an element in the SS7 network. Point-codes must be defined in dotted-decimal format in a string of 1 to 11 digits. Options include:

- 0.0.1 to 7.255.7 for point-code in the ITU range.
- 0.0.1 to 255.255.255 for point-code in the ANSI range.
- 0.0.1 to 15.31.255 for point-code in the TTC Range.
- a string of 1 to 11 digits in dotted-decimal to represent a point-code in a different range.

no

Removes the self-point-code configuration for this linkset in the peer server.

**Important**


Removing the self-point-code will result in the termination of all traffic on this link.

Usage Guidelines

Use this command to define the point-code to identify the SGSN.

Examples

Use the following command to remove the self-point-code definition from the peer-server configuration:
no self-point-code

 **self-point-code**