



Send documentation comments to mdsfeedback-doc@cisco.com.

CHAPTER

9

L Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. See the “Command Modes” section to determine the appropriate mode for each command. For more information, refer to the *Cisco MDS 9000 Family Configuration Guide*.

- [line console](#), page 9-2
- [line vty](#), page 9-4
- [logging console](#), page 9-5
- [logging level](#), page 9-6
- [logging logfile](#), page 9-10
- [logging module](#), page 9-11
- [logging monitor](#), page 9-12
- [logging server](#), page 9-13

line console

Send documentation comments to mdsfeedback-doc@cisco.com.

line console

To configure a terminal line, use the **line console** command.

```
line console [databits number] [exec-timeout minutes] [exit] [flowcontrol none | software] [no]
[parity even | none | odd] [speed speed] [stopbits 1 | 2]
```

Syntax	Description
line console	Configures a primary terminal line.
databits	Set number of databits per character.
<i>number</i>	Enters number of databits.
exec-timeout	Configure exec timeout.
<i>minutes</i>	Enter timeout in minutes 0-525600. 0 to disable.
exit	Exit from this submode.
flowcontrol	Set the flow control.
none	Set no flowcontrol.
software	Set software flowcontrol.
no	Negate a command or set its defaults.
parity	Set terminal parity.
even	Set even parity.
none	Set no parity.
odd	Set odd parity.
speed	Set the transmit and receive speeds.
<i>speed</i>	Set transmit and receive speeds.
stopbits	Set async line stopbits.
1	Set one stop bit.
2	Set two stop bits.

Defaults	Disabled
Command Modes	Configuration mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	The line console command available in config t command mode. line console configuration commands available in config-console submode.

Examples	The following example configures a line console and sets the options for that terminal line.
	<pre>switch## config t switch(config)##</pre>

Send documentation comments to mdsfeedback-doc@cisco.com.

```
switch(config)# line console
switch(config-console)# databits 60
switch(config-console)# exec-timeout 60
switch(config-console)# flowcontrol software
switch(config-console)# parity even
switch(config-console)# stopbits 1
```

Related Commands

Command	Description
line vty	Configure virtual terminal line.

line vty

Send documentation comments to mdsfeedback-doc@cisco.com.

line vty

To configure a virtual terminal line, use the **line vty** command.

```
line vty exec-timeout minutes | exit | no
```

Syntax	Description
line vty	Configures a virtual terminal line.
exec-timeout	Configure exec timeout.
<i>minutes</i>	Enter timeout in minutes 0-525600. 0 to disable.
exit	Exit from this submode.
no	Negate a command or set its defaults.

Defaults None.

Command Modes Configuration mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines The **line vty** command available in **config t** command mode. **line vty** configuration commands available in config-line submode.

Examples The following example configures a virtual terminal line and sets the timeout for that line.

```
switch## config t
switch(config)# line vty
switch(config-line)# exec-timeout 60
```

Related Commands	Command	Description
	line console	Configure primary terminal line.

Send documentation comments to mdsfeedback-doc@cisco.com.

logging console

To set console logging, use the **logging console** command.

logging console range [size bytes]

Syntax	Description
logging console	Sets console logging.
<i>range</i>	0-7 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
<i>size bytes</i>	Configures the size of the log file in bytes. The valid range is 4096- 4194304 bytes.

Defaults	Disabled.
Command Modes	Configuration mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	None.

Examples	The following example reverts console logging to the factory set default severity level of 2 (critical). Logging messages with a severity level of 2 or above will be displayed on the console.
	<pre>switch## config t switch(config)# logging console 2 switch(config-console)#</pre>

logging level

Send documentation comments to mdsfeedback-doc@cisco.com.

logging level

To modify message logging facilities, use the **logging level** command.

```
logging level [ acl severity level ] [ all severity level ] [auth severity level ] [ authpriv severity
level ][ bootvar severity level ][ callhome severity level ][ cron severity level ][daemon
severity level ][ fcc severity level ][ fcdomain severity level ][fcns severity level ][ fcs
severity level ][ flogi severity level ][ fspf severity level ][ ftp severity level ][ ipconf
severity level ][ ipfc severity level ][ kernel severity level ][ local0 severity level ][ local1
severity level ][ local2 severity level ][ local3 severity level ][ local4 severity level ][ local5
severity level ][ local6 severity level ][ local7 severity level ][ mail severity level ][ mcast
severity level ][ module ][ news ][ ntp ][ platform ][ port ][ port-channel ][ qos ][ rdl ]
[ rib severity level ][ rscn severity level ][ scsi-target severity level ][ security severity
level ][ syslog severity level ][ sysmgr severity level ][ tlport severity level ][ user severity
level ][ uucp severity level ][ vni severity level ][ vrrp configuraion severity level engine
severity level ][ vsan severity level ][ vshd severity level ][ wnnm severity level ][ xbar
severity level ][ zone severity level ]

no logging level [ acl severity level ] [ all severity level ] [auth severity level ] [ authpriv
severity level ][ bootvar severity level ][ callhome severity level ][ cron severity level
][daemon severity level ][ fcc severity level ][ fcdomain severity level ][fcns severity
level ][ fcs severity level ][ flogi severity level ][ fspf severity level ][ ftp severity level
][ ipconf severity level ][ ipfc severity level ][ kernel severity level ][ local0 severity level
][ local1 severity level ][ local2 severity level ][ local3 severity level ][ local4 severity
level ][ local5 severity level ][ local6 severity level ][ local7 severity level ][ mail severity
level ][ mcast severity level ][ module ][ news ][ ntp ][ platform ][ port ][ port-channel
][ qos ][ rdl ][ rib severity level ][ rscn severity level ][ scsi-target severity level ][
security severity level ][ syslog severity level ][ sysmgr severity level ][ tlport severity
level ][ user severity level ][ uucp severity level ][ vni severity level ][ vrrp configuraion
severity level engine severity level ][ vsan severity level ][ vshd severity level ][ wnnm
severity level ][ xbar severity level ][ zone severity level ]
```

Syntax	Description
logging level	Sets console logging.
acl	Sets 0-7 syslog filter level for acl manager. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
all	Sets 0-7 severity level for all facilities. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
auth	Sets 0-7 severity level for authorization system. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
authpriv	Sets 0-7 severity level for authorization (private) system. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
bootvar	Sets 0-7 severity level for bootvar. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
callhome	Sets 0-7 severity level for Callhome feature. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
cron	Sets 0-7 severity level 1 for Cron/at facility. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
daemon	Sets 0-7 severity level for system daemons 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug

Send documentation comments to mdsfeedback-doc@cisco.com.

fcc	Sets 0-7 severity level for FCC. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
fcdomain	Sets 0-7 syslog message level for fcdomain. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
fcns	Sets 0-7 syslog filter level for name server 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
fcs	Sets 0-7 syslog filter level for FCS. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
flogi	Sets 0-7 syslog message level for flogi. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
fspf	Sets 0-7 syslog message level for FSPF. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
ftp	Sets 0-7 syslog message level for File Transfer System. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
ipconf	Sets 0-7 syslog message level for IP configuration. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
ipfc	Sets 0-7 syslog message level for IPFC. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
kernel	Sets 0-7 syslog message level for kernel. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
local0	Sets 0-7 syslog message level for local use daemons. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
local2	Sets 0-7 syslog message level for local use daemons. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
local3	Sets 0-7 syslog message level for local use daemons. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
local4	Sets 0-7 syslog message level for local use daemons. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
local5	Sets 0-7 syslog message level for local use daemons. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
local6	Sets 0-7 syslog message level for local use daemons. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
local7	Sets 0-7 syslog message level for local use daemons. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
lpr	Sets 0-7 syslog message level for line printer system. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
mail	Sets 0-7 syslog message level for mail system. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
mcast	Sets 0-7 syslog message level for mcast 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
module	Sets 0-7 syslog message level for module. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
news	Sets 0-7 syslog message level for USENET news 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
ntp	Sets 0-7 syslog message level for NTP. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug

logging level

Send documentation comments to mdsfeedback-doc@cisco.com.

platform	Sets 0-7 syslog message level for platform manager. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
port	Sets 0-7 syslog message level for port. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
port-channel	Sets 0-7 syslog message level for a Port Channel. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
qos	Sets 0-7 syslog message level for QoS manager. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
rdl	Sets 0-7 syslog message level for RDL. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
rib	Sets 0-7 syslog message level for rib. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
rscn	Sets 0-7 syslog message level for RSCN. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
scsi-target	Sets 0-7 syslog message level for SCSI target. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
security	Sets 0-7 syslog message level for security. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
syslog	Sets 0-7 syslog message level for internal syslog messages. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
sysmgr	Sets 0-7 syslog message level for system manager. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
tlport	Sets 0-7 syslog message level for TL Port. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
user	Sets 0-7 syslog message level user process. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
uucp	Sets 0-7 syslog message level for Unix-to-Unix copy system. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
vni	Sets 0-7 syslog message level for virtual network interface. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
vrrp	Sets 0-7 syslog message level for vrrp. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
vrrp configuration	Sets 0-7 syslog message level 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
vrrp engine	Sets 0-7 syslog message level 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
vsan	Sets 0-7 syslog message level for VSAN. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
vshd	Sets 0-7 syslog message level for vshd. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
wwnm	Sets 0-7 syslog message level for WWN manager. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
xbar	Sets 0-7 syslog message level for Xbar. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
zone	Sets 0-7 syslog message level for zone server. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug

Send documentation comments to mdsfeedback-doc@cisco.com.

Defaults	Disabled
Command Modes	Configuration mode
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	None.
Examples	Configures Telnet or SSH logging for the kernel facility at level 4 (warning). As a result, logging messages with a severity level of 4 or above will be displayed. switch## config t switch(config)# logging level kernel 4

logging logfile

Send documentation comments to mdsfeedback-doc@cisco.com.

logging logfile

To set message logging for logfile, use the **logging logfile** command.

logging logfile *file name severity level*

Syntax	logging logfile	Sets message logging for logfile.
	<i>file name</i>	Enters the logfile name.
	<i>severity level</i>	0-7 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
------------------------	---

Usage Guidelines	None.
-------------------------	-------

Examples	The following example configures logging information for errors or events above a severity level of 3 (errors) to be logged in a file named ManagerLogFile. By configuring this limit, the file size is restricted to 3000000 bytes.
-----------------	--

```
switch## config t
switch(config)# logging logfile ManagerLogFile 3 size 3000000
```

Related Commands	Command	Description
	show logging logfile	Displays the message logging for the logfile.

Send documentation comments to mdsfeedback-doc@cisco.com.

logging module

To set message logging for linecards, use the **logging module** command.

logging module *severity level*

Syntax	logging module	Sets message logging for modules.
	<i>severity level</i>	0-7 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug

Defaults None.

Command Modes Configuration mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example sets message logging for modules at level 7.

```
switch## config t
switch(config)##
switch(config)# logging module 7
```

logging monitor

Send documentation comments to mdsfeedback-doc@cisco.com.

logging monitor

To set monitor message logging, use the **logging monitor** command.

logging monitor *severity level*

Syntax	logging monitor	Sets message logging.
	<i>severity level</i>	0-7 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
------------------------	---

Usage Guidelines	None.
-------------------------	-------

Examples	The following example sets terminal line (monitor) message logging at level 2.
	<pre>switch## config t switch(config)# logging monitor 2</pre>

Related Commands	Command	Description
	show logging monitor	Displays the message logging for the logfile.

Send documentation comments to mdsfeedback-doc@cisco.com.

logging server

To set message logging for the remote server, use the **logging server** command.

```
logging server [ hostname | ip address severity_level | facility auth | authpriv | cron | daemon |
ftp | kernel | local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7 | lpr | mail | news
| syslog | user | uucp ]
```

Syntax	Description
logging server	Sets message logging for remote server.
<i>hostname</i>	Enters host name for remote server.
<i>ip address</i>	Enters the IP address for the remote server.
<i>severity_level</i>	Enter severity level of message. 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug
facility	Facility to use when forwarding to server
auth	Use auth facility
authpriv	Use authpriv facility
cron	Use Cron/at facility
daemon	Use daemon facility
ftp	Use file transfer system facility
kernel	Use kernel facility
local0	Use local0 facility
local1	Use local1 facility
local2	Use local2 facility
local3	Use local3 facility
local4	Use local4 facility
local5	Use local5 facility
local6	Use local6 facility
local7	Use local7 facility
lpr	Use lpr facility
mail	Use mail facility
news	Use USENET news facility
syslog	Use syslog facility
user	Use user facility
uucp	Use Unix-to-Unix copy system facility

Defaults	None.
Command Modes	Configuration mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

logging server

Send documentation comments to mdsfeedback-doc@cisco.com.

Usage Guidelines	None.
-------------------------	-------

Examples	Enable message logging to the specified remote server for level 7 messages.
-----------------	---

```
switch## config t  
switch(config)# logging sever sanjose 7
```

Related Commands	Command	Description
	show logging server	Displays the message logging for the remote server.
