



Getting Started

This chapter includes information about Cisco SME installation and the preliminary tasks that you must complete before configuring Cisco SME. It includes the following:

- [Cisco SME Installation, page 2-1](#)
- [Before You Begin, page 2-3](#)
- [Cisco SME Configuration Restrictions, page 2-24](#)



Note To check for additional information about this release, and to determine if this release supports SME, refer to the *Cisco MDS 9000 Family Release Notes* available at the following Cisco Systems website:
http://www.cisco.com/en/US/products/ps5989/prod_release_notes_list.html

Cisco SME Installation

Cisco SME has the following installation requirements:

- Cisco MDS SAN-OS Release 3.3(3) or later must be installed on the Cisco MDS 9222i switch or the Cisco MDS 9000 Family switch with an MSM-18/4 module.

To determine if the release supports SME, refer to the [Cisco MDS 9000 Family Release Notes](#) and the [Cisco Data Center Interoperability Matrix](#).

- Cisco Fabric Manager Server must be installed on a computer that you want to use to provide centralized MDS management services and performance monitoring. The Cisco Key Management Center (Cisco KMC) is on this server.



Note Although you need to install Fabric Manager Server, you do not need a Fabric Manager Server license to use Cisco SME. Additional Fabric Manager Server capabilities are not enabled by default with Cisco SME, so there is no free performance monitoring or other functionality.

- Fabric Manager Web Client can be used to configure and manage Cisco SME using a web browser.

Cisco Fabric Manager is installed using the Fabric Manager Installation CD-ROM included with your switch, or you can download Fabric Manager. For information on installing Fabric Manager, see the *Cisco MDS 9000 Family Fabric Manager Configuration Guide*. For information on installing Cisco MDS SAN-OS Release 3.2(2), see the *Cisco MDS 9000 Family CLI Configuration Guide*.

Send documentation comments to mdsfeedback-doc@cisco.com

You can use one of two configuration management tools to configure Cisco Storage Media Encryption.

- [Cisco MDS 9000 Fabric Manager, page 2-2](#)
- [Command Line Interface, page 2-2.](#)

Cisco MDS 9000 Fabric Manager

The Cisco Fabric Manager is a set of network management tools that supports Secure Simple Network Management Protocol version 3 (SNMPv3). It provides a graphical user interface (GUI) that displays real-time views of your network fabrics, and lets you manage the configuration of Cisco MDS 9000 Family devices and third-party switches. The Cisco Fabric Manager applications are:

- Fabric Manager Web Client—Provides a graphical user interface (GUI) that displays real-time views of your network fabric, and lets you manage the configuration of Cisco MDS 9000 Family devices and third-party switches.



Note

Cisco SME configuration is supported in Fabric Manager Web Client only.

- Fabric Manager Server—Must be started before running the Fabric Manager Client. It can be accessed by up to 16 Fabric Manager Clients at a time.
- Device Manager—Presents two views of a switch.
 - Device View displays a continuously updated physical representation of the switch configuration, and provides access to statistics and configuration information for a single switch.
 - Summary View presents real-time performance statistics of all active interfaces and channels on the switch for Fibre Channel and IP connections.



Note

During the Fabric Manager installation, the `use_ip` flag in the `smeserver.properties` file is set to FALSE by default. If you choose to use IP addresses, the DNS server should not be configured on any switch in the fabric and the `use_ip` flag in the `smeserver.properties` file must be set to TRUE.

The Cisco Fabric Manager applications are an alternative to the CLI for most switch configuration commands.

For more information on configuring the Cisco MDS switch using the Cisco MDS 9000 Family Fabric Manager.

Command Line Interface

With the CLI, you can type commands at the switch prompt, and the commands are executed when you press the **Enter** key. The CLI parser provides command help, command completion, and keyboard sequences that allow you to access previously executed commands from the buffer history.

For more information on configuring the Cisco MDS switch using the CLI, refer to the *Cisco MDS 9000 CLI Configuration Guide*.

Send documentation comments to mdsfeedback-doc@cisco.com

Before You Begin

This section describes the required tasks that must be completed before you configure Cisco SME. It includes the following:

- [Enabling Clustering, page 2-3](#)
- [Enabling Cisco SME, page 2-6](#)
- [Enabling SSH, page 2-9](#)
- [Enabling DNS, page 2-13](#)
- [Creating and Assigning Cisco SME Roles and Cisco SME Users, page 2-14](#)
- [Installing Fabric Manager, Fabric Manager Client, and Enabling HTTPS, page 2-17](#)
- [Adding a Fabric and Changing the Fabric Name, page 2-18](#)
- [Installing Smart Card Drivers, page 2-21](#)
- [Obtaining and Installing Licenses, page 2-21](#)
- [Cisco SME Requirements, page 2-22](#)
- [Cisco SME Configuration Overview, page 2-23](#)

Before configuring Cisco SME, you must explicitly enable clustering, Cisco SME, SSH, and DNS on the MDS switch with an installed MSM-18/4 module or on the MDS 9222i switch. By default, these are disabled. The configuration and verification operations for Cisco SME are only available when these are enabled on a switch.

Enabling Clustering

You can enable clustering on the Cisco MDS 9000 switch with an installed MSM-18/4 module using Fabric Manager and Device Manager 3.2(2).



Note

Be sure to enable clustering first, then enable Cisco SME.

This section includes the following topics:

- [Enabling Clustering Using Fabric Manager, page 2-3](#)
- [Enabling Clustering Using Device Manager, page 2-5](#)

Enabling Clustering Using Fabric Manager

To enable clustering using Fabric Manager, follow these steps:

Before You Begin

Send documentation comments to mdsfeedback-doc@cisco.com

-
- Step 1** In the Physical Attributes pane, select End Devices > SME Clusters.

Figure 2-1 Physical Attributes Pane



- Step 2** From the Control tab in the information pane, locate the switch.


- Step 3** From the dropdown menu in the Command column, select **enable**. The default is noSelection.



Note You can select **enable** on multiple switches and then click **Apply**.

Send documentation comments to mdsfeedback-doc@cisco.com

Figure 2-2 Information Pane



Step 4 Click the **Apply** icon.

Enabling Clustering Using Device Manager


To enable clustering using Device Manager, do the following for a specific switch:

- Step 1** From the Admin menu in the device screen, select **Feature Control..**
- Step 2** Select **cluster**.
- Step 3** From the Action column drop-down menu, select **enable**.

Before You Begin

Send documentation comments to mdsfeedback-doc@cisco.com

Figure 2-3 Device Manager Feature Control Window



Step 4 Click the **Apply** icon.

Enabling Cisco SME

You can enable Cisco SME using Fabric Manager or Device Manager.



Note Be sure to enable clustering first then enable Cisco SME.

This section includes the following topics:

- [Enabling Cisco SME Using Fabric Manager, page 2-7](#)
- [Enabling Cisco SME Using Device Manager, page 2-8](#)

Send documentation comments to mdsfeedback-doc@cisco.com

Enabling Cisco SME Using Fabric Manager

To enable Cisco SME using Fabric Manager, follow these steps:

- Step 1** In the Physical Attributes pane, select **End Devices > SME Clusters**.

Figure 2-4 Physical Attributes Pane



- Step 2** From the Control tab in the information pane, locate the switch.

- Step 3** From the dropdown menu in the Command column, select **enable**. The default is noSelection.


Before You Begin

Send documentation comments to mdsfeedback-doc@cisco.com



Note You can select **enable** on multiple switches and then click **Apply**.

Figure 2-5 Information Pane



Step 4 Click the **Apply** icon.


Enabling Cisco SME Using Device Manager

To enable Cisco SME using Device Manager, do the following for a specific device:

- Step 1** From the Admin menu in the device screen, select **Feature Control...**
- Step 2** Select **sme**.
- Step 3** From the Action column drop-down menu, select **enable**.

Send documentation comments to mdsfeedback-doc@cisco.com

Figure 2-6 Device Manager Feature Control Window



Step 4 Click the **Apply** icon.

Enabling SSH

Before using Cisco SME, you need to generate an SSH server key-pair SSH on the MDS switch with the MSM-18/4 modules installed. By default, the SSH service is disabled.

This section includes the following:

- [Enabling SSH Using Device Manager, page 2-9](#)
- [Enabling SSH Using the CLI, page 2-11](#)
- [Enabling SSH Using Fabric Manager, page 2-12](#)

Enabling SSH Using Device Manager

Before using Cisco SME, you need to generate an SSH server key-pair SSH on the MDS switch with the MSM-18/4 modules installed. By default, the SSH service is disabled.

To enable SSH using Device Manager, follow these steps:

Step 1 From the Security menu in the device screen, select **SSH/Telnet**.

Step 2 Check **SSH** and then click **Create**.

Before You Begin


Send documentation comments to mdsfeedback-doc@cisco.com

Figure 2-7 Device Manager SSH Telnet Window



Step 3 Click **Create** again.

Figure 2-8 Device Manager Create SSH Window



Step 4 Close both the windows. Repeat these steps for each switch.


Figure 2-9 Device Manager Final Window



Step 5 Go to Fabric Manager Web Client and enable SSH on the switches that have Cisco SME configured.

Send documentation comments to mdsfeedback-doc@cisco.com

Figure 2-10 Enabling SSH on Cisco SME configured switches



Enabling SSH Using the CLI

Before using Cisco SME, you need to generate an SSH server key-pair SSH on the MDS switch with the MSM-18/4 modules installed.

Be sure to have an SSH server key-pair with the appropriate version before enabling the SSH service. Generate the SSH server key-pair according to the SSH client version used. The number of bits specified for each key-pair ranges from 768 to 2048.



Note For additional information on enabling SSH, refer to the *Cisco 9000 Family CLI Configuration Guide*.

Generating the SSH Server Key-Pair

The SSH service accepts three types of key-pairs for use by SSH versions 1 and 2.

- The **dsa** option generates the DSA key-pair for the SSH version 2 protocol.
- The **rsa** option generates the RSA key-pair for the SSH version 2 protocol.



Note RSA1 is not supported for Cisco SME; use the **rsa** or **dsa** option.

If you delete all of the SSH keys, you cannot start a new SSH session.

To generate the SSH server key-pair, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# ssh key dsa 1024	Generates the DSA server key-pair.
Step 3	switch(config)# ssh key rsa 1024	Generates the RSA server key-pair.
Step 4	switch(config)# no ssh key rsa 1024	Clears the RSA server key-pair configuration.

Before You Begin

Send documentation comments to mdsfeedback-doc@cisco.com

To enable or disable the SSH service using the CLI, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# ssh server enable	Enables the use of the SSH service.
Step 3	switch(config)# no ssh server enable	Disables (default) the use of the SSH service and resets the switch to its factory defaults.

Enabling SSH Using Fabric Manager

You must first generate the SSH keys using either the Device Manager or the CLI. If you try to enable SSH in the Fabric Manager Web Client before generating the SSH keys, you will get an error message. See [Figure 2-11](#).

Figure 2-11 Error Message in Fabric Manager




After generating the keys, enable SSH in Fabric Manager as follows:

- Step 1** Log in to Fabric Manager.
- Step 2** In the Physical Attributes pane, select **Switch>Security > SSH/Telnet**.

Send documentation comments to mdsfeedback-doc@cisco.com

Figure 2-12 Physical Attributes Pane



Step 3 Select SSH or Telnet for all switches in the fabric.

Figure 2-13 Information Pane

Switch	SSH	Telnet
sw172-22-46-220	<input checked="" type="checkbox"/>	<input type="checkbox"/>
sw172-22-46-223	<input checked="" type="checkbox"/>	<input type="checkbox"/>
sw172-22-46-233	<input checked="" type="checkbox"/>	<input type="checkbox"/>
sw172-22-46-224	<input checked="" type="checkbox"/>	<input type="checkbox"/>
sw172-22-47-133	<input checked="" type="checkbox"/>	<input type="checkbox"/>
sw172-22-46-221	<input checked="" type="checkbox"/>	<input type="checkbox"/>
sw172-22-46-225	<input checked="" type="checkbox"/>	<input type="checkbox"/>
sw172-22-47-132	<input checked="" type="checkbox"/>	<input type="checkbox"/>
sw172-22-46-222	<input checked="" type="checkbox"/>	<input type="checkbox"/>

Step 4 Click the **Apply** icon.

Enabling DNS

DNS offers services to map a host name to an IP address in the network through a DNS server. When you configure DNS on the switch, you can substitute the host name for the IP address with all IP commands, such as ping, telnet, upload, and download.

You must decide to use DNS completely or to use IP addresses fully in your fabric. A combination of these will not work with the Cisco SME feature.

If you chose to use DNS, the following requirements apply:

- All switches should be configured using DNS.

Before You Begin

Send documentation comments to mdsfeedback-doc@cisco.com

- The domain-name (or the domain list), and the IP name server must be configured to reach remote switches.
- The DNS server should be configured on the Fabric Manager server.

If you choose to use IP addresses, the DNS server should not be configured on any switch in the fabric and the use_ip flag in the smeserver.properties must be set to TRUE.

For information on configuring DNS, refer to the Configuring IP Services chapter in the *Cisco MDS 9000 Family CLI Configuration Guide*.

To verify that DNS is enabled everywhere in the cluster, ping between the Fabric Manager server and the MDS switches and also between the MDS switches with DNS names.

sme.useIP for IP Address or Name Selection

If you do not have DNS configured on all switches in the cluster, you can use sme.useIP. For information about sme.useIP, see [Chapter 9, “Cisco SME Troubleshooting”](#).

IP Access Lists for the Management Interface

Cluster communication requires the use of the Management interface. IP ACL configurations must allow UDP and TCP traffic on ports 9333, 9334, 9335, and 9336.

Creating and Assigning Cisco SME Roles and Cisco SME Users

The Cisco SME feature provides two primary roles: Cisco SME Administrator and the Cisco SME Recovery Officer. By default, Cisco SME assigns both the Cisco SME Administrator and the Cisco SME Recovery Officer to the same user. This assignment works well for small scale deployments of Cisco SME.


Note

For Basic and Standard security modes, one user should hold the Cisco SME Administrator and the Cisco SME Recovery Officer roles.

Send documentation comments to mdsfeedback-doc@cisco.com

Table 2-1 shows a description of the Cisco SME roles and the number of users that should be considered for each role.

Table 2-1 Cisco SME Roles and Responsibilities

Cisco SME Role	Master Key Security Mode	Required # of users for this role	What operations is this role responsible for?
Cisco SME Administrator	Basic mode Standard mode	1 user should hold the Cisco SME Administrator and the Cisco SME Recovery officer roles. 1 per VSAN is the minimum for day to day operations; must have access to all VSANs (if there are many VSANs and multiple VSAN administrators are assigned, then Cisco SME administrators, then there may be one Cisco SME Administrator per VSAN for key recovery operations.)	<ul style="list-style-type: none"> • Cisco SME management • Tape management • Export/Import tape volume groups
Cisco SME Recovery Officer	Advanced mode	5 users (1 for each smart card) Each smart card holder must be present during the cluster creation to provide the user login and password information and smart card pin.	<ul style="list-style-type: none"> • Master key recovery • Replace smart card

Configuring the AAA Roles

For information on configuring the AAA roles for the Cisco SME Administrator and the Cisco SME Recovery Officer, refer to the *Cisco MDS 9000 Family CLI Configuration Guide*.

Before You Begin

Send documentation comments to mdsfeedback-doc@cisco.com

Creating and Assigning Cisco SME Roles Using Fabric Manager

For detailed information on creating and assigning roles, refer to the *Cisco MDS 9000 Family Fabric Manager Configuration Guide*.




Note Cisco SME role names must begin with “sme”. For example, valid role names could be “sme-admin”, “sme-recovery”, or “sme-admin-vsan1”.

You need to create a Cisco SME role and then assign users to the Cisco SME role. To create a Cisco SME role, follow these steps:


- Step 1** In the Admin tab, click on **Configure > Local Database**.
- Step 2** Click the **Add...** button.

Figure 2-14 Creating and Assigning Cisco SME Roles



185616

- Step 3** Type in the user name and password.



- Step 4** For the user role, select **sme-admin** or **sme-recovery** from the roles drop-down menu.
- Step 5** Click **Add**.

Send documentation comments to mdsfeedback-doc@cisco.com

Creating and Assigning Cisco SME Roles Using the CLI

For detailed information on creating and assigning roles, refer to the *Cisco MDS 9000 Family CLI Configuration Guide*.

To create a Cisco SME role or to modify the profile for an existing Cisco SME role, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# role name sme-admin switch(config-role)#	Places you in the mode for the specified role (sme-admin). Note: The role submode prompt indicates that you are now in the role submode. This submode is now specific to Cisco SME.
Step 3	switch(config)# no role name sme-admin	Deletes the role called sme-admin.
Step 4	switch(config-role)# rule 1 permit config feature sme	Allows you to add Cisco SME configuration commands to the sme-admin role.
Step 5	switch(config-role)# rule 2 permit show feature sme	Allows you to add Cisco SME show commands to the sme-admin role.
Step 6	switch(config-role)# rule 3 permit debug feature sme	Allows you to add Cisco SME debug commands to the sme-admin role.
Step 7	switch(config-role)# description SME Admins	Assigns a description to the new role. The description is limited to one line and can contain spaces.
Step 8	switch(config)# username usam role sme-admin	Adds the specified user (usam) to the sme-admin role.



Note Only users belonging to the network-admin role can create roles.



Note The two security roles required by Cisco SME can be implicitly created by using the **setup sme** command. For VSAN based access control, you must create the custom roles.

Installing Fabric Manager, Fabric Manager Client, and Enabling HTTPS

To be able to manage Cisco SME, you need to install Fabric Manager Server Enterprise edition. For information on installing Cisco Fabric Manager, refer to the installation chapters of the .



Note To configure Cisco SME, the Fabric Manager user credentials must be the same as the switch user.



Note To configure Cisco SME in a dual fabric environment, all the switches in the cluster should have the same credentials for SME user.

Cisco SME requires the HTTPS protocol on the Cisco MDS 9000 switch with an MSM-18/4 module installed. You must enable HTTPS during the Fabric Manager installation. To enable HTTPS, refer to the installation information in the *Cisco MDS 9000 Family Fabric Manager Configuration Guide*.

Before You Begin

Send documentation comments to mdsfeedback-doc@cisco.com

Adding a Fabric and Changing the Fabric Name

You need to add the fabric that includes the Cisco MDS switch with the MSM-18/4 module installed. Or you also can add a fabric that includes an MDS 9222i switch.




Note Cisco SAN-OS Release 3.2(2) supports one cluster per switch. You will want to consider this during your planning.

To add a fabric using Fabric Manager Web Server, follow these steps:

- Step 1** Log in to Fabric Manager Web Client.
- Step 2** Click the **Admin** tab.
- Step 3** Click **Configure**.
- Step 4** Click **Add**.

Figure 2-15 Fabric Manager Admin Screen



The Add Fabric seed switch screen displays fields to log in to the fabric seed switch.

Send documentation comments to mdsfeedback-doc@cisco.com

- Step 5** Enter the fabric seed switch name or IP address and enter the community.
Step 6 Click **Add**.


Figure 2-16 Fabric Seed Switch Login



Note It takes a few minutes after you click Add connect to the seed switch.

A notification window indicates that monitoring has started and that the fabric will be available after discover is complete.

Figure 2-17 Monitoring Notification



- Step 7** Click **Ok** to return to the main screen.



Note The fabric name is identified as the fabric plus the switch name. You need to manually change the fabric name so that if you reopen the fabric with a different seed switch, the fabric name will remain the same. If you do not manually change the fabric name and you reopen the fabric with a different seed switch, the fabric may be renamed to show the new switch name. Choose a unique name that is easily identifiable.

Before You Begin

Send documentation comments to mdsfeedback-doc@cisco.com

Figure 2-18 New Fabric Added



- Step 8** Select the fabric and click **Edit**.
Step 9 Enter a unique fabric name, user name, and password.
Step 10 Select **Manage Continuously** and click **Modify**.



Note Cisco SME requires that you select **Manage Continuously** to receive continuous updates from the switches.


Figure 2-19 Enter a Unique Fabric Name

Fabric Name:	Cisco_fabric1
User Name:	admin
Password:	*****
Use SNMPv3:	<input checked="" type="checkbox"/>
Auth-Privacy:	MD5
Monitor:	TRUE
Change credentials:	<input checked="" type="checkbox"/>
<input type="button" value="Modify"/> <input type="button" value="Close"/>	

- Step 11** Click **Close** to return to the main screen and view the new fabric name.

Send documentation comments to mdsfeedback-doc@cisco.com

Figure 2-20 Viewing the New Fabric Name



186631

Installing Smart Card Drivers

The smart card reader must be connected to a management workstation that is used to configure Cisco SME. The smart card driver and the smart card drivers library file must be installed in the workstation. These are found on the Fabric Manager Installation CD.

When connecting a new smart card reader after the installation of smart card drivers, you may be required to restart the computer. If the card reader is not recognized on your workstation, you may need to install the latest smart card drivers. You can find the **Download** link on the Fabric Manager Web Client.



Note

The smart card reader is only supported on Windows platforms.

Obtaining and Installing Licenses

To use the Cisco SME feature, you need the appropriate Cisco SME license; however, enabling Cisco SME without a license key starts a counter on the grace period. You then have 120 days to install the appropriate license keys or disable the use of Cisco SME. If at the end of the 120-day grace period the switch does not have a valid license key for Cisco SME, it will be automatically disabled.

To identify if the Cisco SME feature is active, use the **show license usage license-name** command.



Note

You can not use a Cisco SME interface if the Cisco SME licenses are not installed.

Before You Begin

Send documentation comments to mdsfeedback-doc@cisco.com

The following three Cisco SME licenses are available:

Table 2-2 Cisco SME Licenses

Part Number	Description	Applicable Product
M9500SME1MK9	Cisco Storage Media Encryption (SME) package for MSM-18/4 module	MDS 9500 Series with MSM
M9200SME1MK9	Cisco Storage Media Encryption (SME) package for MSM-18/4 module	MDS 9200 Series with MSM
M9200SME1FK9	Cisco Storage Media Encryption (SME) package for fixed slot	MDS 9222i Switch only

To obtain and install Cisco SME licenses, refer to the licensing chapter in the *Cisco MDS 9000 Family CLI Configuration Guide*.

Cisco SME Requirements

This section describes the following requirements:

- [Java Cryptography Extension Requirement, page 2-22](#)
- [Zoning Requirement, page 2-22](#)
- [FC-Redirect Requirements, page 2-22](#)

Java Cryptography Extension Requirement

Cisco SME requires Java Cryptography Extension (JCE) Unlimited Strength Jurisdiction Policy Files 5C0 (for JRE 1.5). You will need to extract and copy the local_policy.jar and the US_export_policy.jar files to the \$JAVA_HOME\jre\lib\security\ directory. You can obtain these files from the Fabric Manager Installation CD.

Zoning Requirement

Zoning requirements include the following:

- Internal virtual N-ports are created by Cisco SME in the default zone. The default zone must be set to deny and these virtual N-ports must not be zoned with any other host or target.

For information on zoning, refer to the *Cisco MDS 9000 Family CLI Configuration Guide*.

FC-Redirect Requirements

FC-Redirect requirements include the following:

- The MDS switch with the MSM-18/4 module installed or the 9222i switch needs to be running SAN-OS Release 3.2(2).
- The target must be connected to an MDS 95XX/9216/9222i switch running SAN-OS 3.2(2).
- 32 targets per MSM-18/4 module can be FC-redirected.

Send documentation comments to mdsfeedback-doc@cisco.com

- Each FC-redirected target can be zoned to 16 hosts or less.
- CFS should be enabled on all required switches for FC-redirect.
- Cisco SME servers and tape devices should not be part of an IVR zone set.

Cisco SME Configuration Overview

Before configuring Cisco SME on your switch, it is important to become familiar with the Cisco SME configuration process. This section provides an overview of the Cisco SME configuration process and includes the following topics:

- [Initial Cisco SME Configuration, page 2-23](#)
- [Saving Cisco SME Cluster Configurations, page 2-23](#)

Initial Cisco SME Configuration

**Note**

For information about what you need to do *before* you initially configure Cisco SME, see the “[Before You Begin](#)” section on page 2-3.

Cisco SME configuration tasks listed below provide an overview of the basic Cisco SME configuration process. Complete the Cisco SME configuration tasks on the switch with an installed MSM-18/4 module or on a Cisco MDS 9222i switch.

Cisco SME basic configuration tasks include the following:

- Create the Cisco SME interface ([Chapter 4, “Cisco SME Interface Configuration”](#))
- Create a cluster for Cisco SME ([Chapter 3, “Cisco SME Cluster Management”](#))
- Add the interfaces to the cluster ([Chapter 3, “Cisco SME Cluster Management”](#))
- Create a tape group (including selecting the backup server and discovering backup libraries) ([Chapter 5, “Cisco SME Tape Configuration”](#))

For details about configuration procedures using the CLI, see [Chapter 7, “Using the Command Line Interface to Configure SME.”](#)

Saving Cisco SME Cluster Configurations

**Caution**

Configuration changes must be saved on all switches in the cluster for correct cluster operation. This must be done after the initial cluster creation and after all subsequent changes are made to the cluster configuration.

You must save configuration changes whenever switches or interfaces are added or deleted from a cluster.

Cisco SME Configuration Restrictions

Send documentation comments to mdsfeedback-doc@cisco.com

Cisco SME Configuration Restrictions

This section includes information on Cisco SME configuration limitations and restrictions. It contains the following:

- [FICON Restriction, page 2-24](#)
- [iSCSI Restriction, page 2-24](#)
- [FC-Redirect Restrictions, page 2-24](#)
- [Cisco SME Configuration Limits, page 2-25](#)

FICON Restriction

Cisco SME is not supported on FICON devices and Cisco SME cluster devices can not be part of a FICON VSAN.

iSCSI Restriction

You can not configure Cisco SME and iSCSI on the same Cisco MDS MSM-18/4 module as SME uses the iSCSI port indices.

FC-Redirect Restrictions

FC-Redirect is not supported on the following switches:

- Cisco MDS 9124 switch
- Cisco MDS 9134 switch
- Cisco MDS 9020 switch and the Cisco MDS 9040 switch

Send documentation comments to mdsfeedback-doc@cisco.com

Cisco SME Configuration Limits

Table lists the Cisco SME configurations and the corresponding limits.

Table 2-3 Cisco SME Configuration Limits

Configuration	Limit
Number of clusters per switch	1
Switches in a cluster	4
Number of switches in the fabric	10
Fabrics in a cluster	2
Modules in a switch	11
Cisco MSM-18/4 modules in a cluster	32
Initiator-Target-LUNs (ITLs)	1024
LUNs behind a target	32
Host and target ports in a cluster	128
Number of hosts per target	128
Tape backup groups per cluster	2
Volume groups in a tape backup group	4
Cisco Key Management Center (number of keys)	32K
Targets per switch that can be FC-Redirected	32

Cisco SME Configuration Restrictions

Send documentation comments to mdsfeedback-doc@cisco.com