

CRS-1 Upgrade Procedure:
3.3.0/3.3.1/3.3.2/3.3.3/3.3.4 to 3.3.5

Obtain Required PIE files:

The following package files are required to perform the upgrade:

PIE File Description	Sample PIE Filename	Package Name
Composite Mini Package (OS-MBI, Base, Admin, Fwdg, Ic Rout)	comp-hfr-mini.pie-3.3.5	disk0:comp-hfr-mini-3.3.5
Multicast Package	hfr-mcast-p.pie-3.3.5	disk0:hfr-mcast-3.3.5
Manageability Package	hfr-mgbl-p.pie-3.3.5	disk0:hfr-mgbl-3.3.5
MPLS Package	hfr-mpls-p.pie-3.3.5	disk0:hfr-mpls-3.3.5
Security Package	hfr-k9sec-p.pie-3.3.5	disk0:hfr-k9sec-3.3.5
Diagnostic Package	hfr-diag-p.pie-3.3.5	disk0:hfr-diag-3.3.5

Note1: The filenames listed here may not necessarily be the filenames of the actual files since the files can be renamed. The actual filenames used will not affect the operation.

Install Mandatory SMUs:

N/A

Check System Stability:

The following commands should be executed to verify basic system stability before the upgrade:

<code>show platform</code>	(verify that all nodes are in "IOS XR RUN" state)
<code>show redundancy</code>	(verify that a Standby RP is available and in "ready" state)
<code>show ipv4 interface brief</code>	
<or>	
<code>show ipv6 interface brief</code>	(verify that all interfaces are "UP")
<code>show install active</code>	(verify that the proper set of packages are active)
<code>cfs check</code>	(in user mode; verify and clear configuration
<code>inconsistency</code>)	

Perform Pre-Upgrade Tasks:

- 1) Check ROMMON version. Upgrade to the latest ROMMON version supported if necessary. Refer to the Release Notes for the latest version supported and for the ROMMON upgrade procedure.

`router(admin)# show diag`

Upgrade:

- 1) Add the required pies to disk:

`router(admin)# install add <source>/<path>/<pie> sync`

Note1: The <source> can be one of disk0:, disk1:, compactflash:, tftp:, ftp: or rcp:.

Note2: The above step must be repeated for each pie file, or all of the pies can be added together in a single 'install add ..' command. To add all pies using a single command, list all of the pies (including their source) within the 'install add ..' command in the following manner:

`router(admin)# install add <source>/comp-hfr-mini.pie-3.3.5
<source>/hfr-mcast-p.pie-3.3.5 <source>/hfr-mgbl-p.pie-3.3.5
<source>/hfr-mpls-p.pie-3.3.5 <source>/hfr-k9sec-p.pie-3.3.5
<source>/hfr-diag-p.pie-3.3.5 sync`

Note3: The use of 'sync' option will prevent the user from executing any other command during the install operation.

Note4: Under idle conditions, this command may take at least 35 minutes to complete, during which the router will be fully functional. This operation will take longer to complete on a Multi-Chassis system.

- 2) Test the activation using the 'test' option. Testing the activation will give you a preview of the activation.

```
router(admin)# install activate disk0:comp-hfr-mini-3.3.5 disk0:hfr-mcast-3.3.5 disk0:hfr-mgbl-3.3.5 disk0:hfr-k9sec-3.3.5 disk0:hfr-mpls-3.3.5 disk0:hfr-diag-3.3.5 sync test
```

Note1: No actual changes will be made when 'test' option is used.

Note2: Any config that is incompatible with the new version being activated will be identified. The 'show configuration removed' command can be used to view what will be removed as result of the software upgrade.

Note3: Such removed config can be reapplied using the 'load config removed <config>.cfg' command from config mode.

- 3) Activate all of the packages added in step 1:

```
router(admin)# install activate disk0:comp-hfr-mini-3.3.5 disk0:hfr-mcast-3.3.5 disk0:hfr-mgbl-3.3.5 disk0:hfr-k9sec-3.3.5 disk0:hfr-mpls-3.3.5 disk0:hfr-diag-3.3.5 sync
```

Note1: The output of 'install add' command executed in step 1 provides the list of names of packages to be used in 'install activate ..' command.

Note2: The use of 'sync' option will prevent the user from executing any other command during the install operation.

Note3: The router will reload at the end of activation to start using the new packages.

Note4: Under idle conditions, this operation may take at least 20 minutes to complete.

- 4) Verify system stability through commands described under **Check System Stability** section. If system issues are detected or if the upgrade needs to be backed out for any reason, please follow the steps described in **Downgrade** section to rollback the software configuration.

- 5) Check to see if there were any failed startup config. If there were any startup config that failed to be applied, then refer to item #1 in the **Caveats** section to see how it should be handled.

```
router# show config failed startup
```

- 6) Commit the newly activated software:

```
router(admin)# install commit
```

Downgrade:

Special Downgrade Instructions:

1. Downgrading to 3.2.x images only:

All 'banner' configurations must be removed prior to downgrading from 3.3.5. The removed 'banner' config can be reapplied once the downgrade is completed. Failure to do so can result in a large config loss.

```
router(config)# no banner <>
router(config)# commit
```

- 1) List the available rollback points:
`router(admin)# show install rollback ?`
- 2) Identify the rollback point by executing the following show command and analyzing the software configuration at the rollback point:
`router(admin)# show install rollback <rollback point>`
Note1: A valid rollback point must be specified. The output will show list of active packages for that rollback point.
- 3) Test the rollback operation using the 'test' option. Testing the rollback operation can give you a preview of the rollback.
`router(admin)# install rollback to <rollback point> sync test`
Note1: The output will detect if any incompatible config and will be removed. In such cases, 'show configuration removed' command can be used to view what will be removed as result of the software downgrade.
Note2: Removed command can be reapplied at a later time using the 'load config removed <config>.cfg' command from config mode..
The following is a sample output:
`Warning: SDR Owner: No incompatible configuration will be removed due to the
Warning: 'test' option
Info: SDR Owner: Detected incompatibility between the activated software
Info: and router running configuration.
Info: SDR Owner: Removing the incompatible configuration from the running
Info: configuration.
Info: SDR Owner: Saving removed configuration in file '20060316131636.cfg'
Info: on node 'RP/0/0/CPU0:'
Info: Use the "show configuration removed 20060316131636.cfg" command to
Info: view the removed config.
Info: NOTE: You must address the incompatibility issues with the
Info: removed configuration above and re-apply it to the running
Info: configuration as required. To address these issues use the
Info: "load configuration removed 20060316131636.cfg" and "commit"
Info: commands.`
Use the command suggested in the above example to display the config that will potentially be removed after the downgrade.
- 4) Perform the rollback operation:
`router(admin)# install rollback to <rollback point> sync`
Note1: Based on the set of packages being activated and deactivated as part of the rollback operation, one or more nodes may be reloaded. Please be patient as this operation could take some time.
Note2: If you previously executed 'install remove' command to permanently remove any packages in the rollback configuration then the rollback operation will not proceed. To resolve this issue, run the following command to re-add the relevant packages:
`router(admin)# install add <device or tftp>/<path>/<pie> sync`
Note3: The use of 'sync' option will prevent the user from executing any other command during the install operation.
- 5) Restore the original configuration that was backed up in **Perform Pre-Upgrade Tasks** section.
- 6) Install commit the newly activated software.

```
router(admin)# install commit
```

- 7) Verify system stability through commands described in **Check System Stability** Section.

Post-Upgrade / Post-Downgrade Procedure:

Once software upgrade or downgrade has been completed, disk space can be recovered (optional) by removing any inactive packages that are no longer needed (if the packages are required at a later time, they can be re-added). Please follow these steps to remove inactive packages:

- 1) Obtain the list of inactive packages and note the names of packages that are not needed:

```
router(admin)# show install inactive brief
```

- 2) Remove the unnecessary inactive packages:

```
router(admin)# install remove disk0:<package_name1>  
disk0:<package_name2> .. disk0:<pkg_nameN> sync
```

Note1: The use of 'sync' option will prevent the user from executing any other command during the install operation.

Caveats:

1. During software upgrade or downgrade, the system could detect incompatible configuration and remove it from the running configuration. The removed config will be saved to a file on the router. Some configuration could also fail due to syntax or semantic error as the router boots the new version of the software.

The operator must browse the removed or failed configuration and then address the changes so that the config can be properly applied on the new version of software:

- Addressing incompatible and removed configuration:
During the test activation of a new software version, incompatible configuration will be identified and removed from the router running configuration. Syslog and console logs will provide the necessary information on the name of the removed configuration file. To address the incompatible configuration, users should browse the removed configuration file, address the syntax and semantics errors and re-apply the config as required and/or applicable after upgrade.
To display the removed configuration, execute the following command from exec mode:

```
router# show configuration removed <removed config filename>
```

- Addressing failed admin and non-admin configuration during reload:
Some configuration may fail to take effect when the router boots with the new software. These configurations will be saved as failed configuration. During activation of the new software version, operator would be notified via syslog and console log where configuration failed to take effect. To address the failed configuration, user should browse both the admin and non-admin failed configuration, address syntax and semantics errors and re-apply it as required.
To display the failed configuration, execute the following command:

```
router# show configuration failed startup  
router(admin) # show configuration failed startup
```

2. In 3.2.x releases, 'disk0:' is the only boot media where the image software and configuration are stored. In R3.3, customers can choose an alternate boot media other than disk0: to store the software and configuration. However, when upgrading from 3.2.x to R3.3 and/or downgrading from R3.3 to 3.2.x, 'disk0:' is always the source of configuration after the router reload operation. If the configuration is not stored on 'disk0:' it is the responsibility of the operator to copy the configuration to 'disk0:'.